Form Number 3354-530 Rev A

Rear Roller Brush Kit

Reelmaster® 5200-D and 5400-D

Model No. 03533

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2006
All Rights Reserved

Register your product at www.Toro.com



Brush Assembly

Ref	Part No.	Qty.	Description
1	104-8240	1	Roller Brush ASM
1:2	105-6792	1	Brush-Roller
1:3	104-1830	2	Bolt-J
1:4	3296-2	2	Nut-Lock
2	95-9619	2	Key-Square
3	104-1842	2	Roller Bearing ASM
3:1	3245-1	1	Screw-Set, HSH
4	104-8202	2	Housing-Bearing, Roller Brush
5	302-5	2	Fitting-Grease
6	104-8233	1	RH Bracket ASM
7	104-8234	1	LH Bracket ASM
8	32128-20	2	Nut-HF
9	322-16	2	Screw-HH
10	3234-14	8	Screw-HHF
11	3245-35	4	Screw-Set
12	3211-6	2	Screw-HH
13	3211-4	2	Screw-HH
14	322-5	1	Screw-HH
15	322-7	1	Screw-HH
16	104-8232	1	Plate-Brush
17	82-4240	1	Spacer-Bearing
18	110-9722	1	Pulley-Driven
19	3296-29	2	Nut-Lock, NI
20	87-8640	4	Washer-Flat

Ref	Part No.	Qty.	Description
21	104-8225	1	Cover-Belt
22	3296-47	2	Nut-Lock, NI
23	110-4121	1	Idler Pulley ASM
23:2	251-259	1	Bearing-Ball
23:3	104-4727	1	Ring-Retaining
24	108-6709	1	Belt-Drive
25	106-7504	1	Pulley-Drive
26	32151-34	1	Ring-Retaining
27	104-8248	1	Drive Shaft ASM
27:2	98-5215	1	Bearing-Ball, Radial
28	3296-39	2	Nut-Lock, NI
29	104-8244	1	Weight-End
30	253-149	1	Seal-Oil
31	110-4054	1	Screw-HH, Special
32	105-6766	1	Pad-Wear
33	3296-44	1	Nut-Lock, NI
34	323-11	1	Screw-HH
35	108-0635	1	Bracket-Arm