



## **Z587L Z Master<sup>®</sup>** **With 60in TURBO FORCE<sup>®</sup> Side Discharge Mower**

**Model No. 74251 - 260000001 and up.**

### **Parts Catalog**

#### **Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### **Understanding Reference Numbers**

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### **Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### **Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

| Description                              | Page     | Description                              | Page     |
|------------------------------------------|----------|------------------------------------------|----------|
| Front Frame Assembly                     | ..... 3  | Fuel Tank Assembly                       | ..... 28 |
| Castor and Wheel Assembly                | ..... 5  | Electrical Components Assembly           | ..... 29 |
| Main Frame Assembly                      | ..... 6  | Cylinder and Crankcase Assembly Kawasaki |          |
| Brake and Wheel Hub Assembly             | ..... 7  | FD750D-BS03                              | ..... 30 |
| Steering Control Assembly                | ..... 8  | Valve and Camshaft Assembly Kawasaki     |          |
| Hydraulic System Assembly                | ..... 9  | FD750D-BS03                              | ..... 32 |
| Seat and Roll-Over-Protection-System     |          | Lubrication Equipment Assembly Kawasaki  |          |
| Assembly                                 | ..... 11 | FD750D-BS03                              | ..... 34 |
| Deluxe Seat Assembly No. 110-0838        | ..... 12 | Cooling Equipment Assembly Kawasaki      |          |
| Roll-Over-Protection-System Assembly No. |          | FD750D-BS03                              | ..... 36 |
| 108-1097                                 | ..... 13 | Electric Equipment Assembly Kawasaki     |          |
| Deck Connection Assembly                 | ..... 14 | FD750D-BS03                              | ..... 38 |
| 60 Inch Deck Assembly                    | ..... 15 | Control Equipment Assembly Kawasaki      |          |
| Spindle Assembly No. 106-3217            | ..... 17 | FD750D-BS03                              | ..... 40 |
| Deck Decal Assembly No. 107-1624         | ..... 18 | Carburetor Assembly Kawasaki FD750D-BS03 | ..... 42 |
| Rubber Deflector Assembly No. 108-2792   | ..... 19 | Piston and Crankshaft Assembly Kawasaki  |          |
| Lever Assembly No. 107-1664              | ..... 20 | FD750D-BS03                              | ..... 44 |
| Drive Idler Assembly                     | ..... 21 | Air Filter and Muffler Assembly Kawasaki |          |
| Z-Stand Assembly                         | ..... 22 | FD750D-BS03                              | ..... 45 |
| Engine and Clutch Assembly               | ..... 23 | Starter Assembly Kawasaki FD750D-BS03    | ..... 46 |
| Air Cleaner Assembly No. 95-5805         | ..... 24 | Fuel Pump and Filter Assembly Kawasaki   |          |
| Cooling System Assembly                  | ..... 25 | FD750D-BS03                              | ..... 48 |
| Hood Assembly                            | ..... 26 | Attachments and Accessories List         | ..... 49 |
| Cooling Mounting Frame Assembly          | ..... 27 |                                          |          |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | INC. .... incorporated                       |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HF. .... hex flange                        | PTH. .... phillips truss head                |
| HH. .... hex head                          | PTO. .... power-take-off                     |
| HHF. .... hex head flange                  | RH. .... right hand                          |
| HHFTF. .... hex head flange thread forming | ROPS. .... roll-over-protection-system       |
| HJ. .... hex jam                           | SFH. .... slotted fillister head             |
| HLH. .... hex lag head                     | SHH. .... slotted hex head                   |
| HOC. .... height-of-cut                    | SHWH. .... slotted hex washer head           |
| HSBH. .... hex socket button head          | SPH. .... slotted pan head                   |
| HSFH. .... hex socket flat head            | SQH. .... square head                        |
| HSH. .... hex socket head                  | SRH. .... slotted round head                 |
| HWH. .... hex washer head                  | STD. .... standard                           |
| HWHTF. .... hex washer head thread forming | TAP. .... self tapping                       |
| HYD. .... hydraulic                        | TTH. .... torx truss head                    |

## Footnotes

- ❶ Not illustrated
- ❷ Obtain from your local Kawasaki dealer


- ❸ Not serviced separately



## Front Frame Assembly


| Ref  | Part No.    | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 106-8998    | 1    | Frame ASM                 |
| 1:2  | 107-1857    | 1    | Decal-Brake, Parking      |
| 1:3  | 1-811010    | 2    | Plug                      |
| 1:4  | 302-19      | 5    | Fitting-Grease            |
| 1:5  | 94-1291     | 2    | Bushing                   |
| 1:6  | 104-7759    | 1    | Decal-Warning             |
| 1:7  | 103-1918    | 1    | Bushing                   |
| 3    | 106-9981    | 1    | Front Floorpan ASM        |
| 3:2  | 106-7451    | 1    | Decal                     |
| 3:3  | 107-2112    | 1    | Decal-Warning             |
| 4    | 103-1918    | 1    | Bushing                   |
| 5    | 103-2083-03 | 1    | Lift Lever ASM            |
| 6    | 1-633295    | 1    | Grip-Lever, Lift          |
| 7    | 103-2064-03 | 1    | Arm-Lift, Deck            |
| 8    | 1-633325    | 1    | Spring-Compression        |
| 9    | 3256-24     | 1    | Washer-Flat               |
| 10   | 3296-39     | 9    | Nut-Lock, NI              |
| 11   | 32151-103   | 5    | Ring-Snap                 |
| 12   | 1-633068    | 2    | Arm-Lift, Deck            |
| 14   | 323-29      | 2    | Screw-HH                  |
| 15   | 110-0833    | 1    | Outer Deck Lift Plate ASM |
| 15:2 | 107-1860    | 1    | Decal-Height, Deck        |
| 16   | 108-7759-01 | 1    | Plate-Lift, Deck          |
| 17   | 1-633082    | 1    | Bushing-Lever, Lift       |

| Ref  | Part No.    | Qty. | Description             |
|------|-------------|------|-------------------------|
| 18   | 1-633080    | 1    | Bushing-Lever, Lift     |
| 19   | 323-13      | 1    | Screw-HH                |
| 20   | 106-9951    | 1    | Hitch Pin ASM           |
| 22   | 323-9       | 2    | Screw-HH                |
| 23   | 98-5975     | 12   | Washer-Belleville       |
| 24   | 3290-357    | 15   | Nut-HHF, Whiz           |
| 25   | 323-6       | 1    | Screw-HH                |
| 26   | 323-7       | 12   | Screw-HH                |
| 27   | 3256-29     | 4    | Washer-Flat             |
| 35   |             | 2    | Front Frame Spring ASM  |
| 35:1 | 1-633096    | 1    | Rod-Lift, Deck          |
| 35:2 | 1-633441    | 2    | Swivel-Deck Mount, Rear |
| 35:3 | 3217-11     | 4    | Nut-Hex                 |
| 35:4 | 3218-6      | 2    | Nut-Jam                 |
| 35:5 | 3256-7      | 2    | Washer-Flat             |
| 35:6 | 1-633064    | 1    | Spring-Support, Deck    |
| 36   | 107-1861    | 1    | Decal-Height, Deck      |
| 38   | 3274-94     | 4    | Screw-HSBH              |
| 40   | 108-7786-01 | 1    | RH Front Deck Lift ASM  |
| 41   | 106-8984-01 | 1    | LH Deck Lift ASM        |
| 42   | 1-523157    | 2    | Washer-Spacer, 14 GA    |
| 43   | 32151-29    | 2    | Ring-Retaining          |
| 44   | 3274-18     | 2    | Screw-HSH               |
| 45   | 3218-2      | 2    | Nut-Jam                 |




## Front Frame Assembly (continued)

| Ref | Part No. | Qty. | Description |
|-----|----------|------|-------------|
| 46  | 1-513658 | 2    | Bumper      |



Castor and Wheel Assembly


| Ref    | Part No.    | Qty. | Description           |  |  |  |  |
|--------|-------------|------|-----------------------|--|--|--|--|
| 1      | 103-4882    | 2    | Cap-Grease            |  |  |  |  |
| 2      | 3296-51     | 2    | Nut-Lock, NI          |  |  |  |  |
| 3      | 1-633508    | 6    | Washer-Bellville      |  |  |  |  |
| 4      | 254-94      | 4    | Bearing-Cone, Tapered |  |  |  |  |
| 5      | 254-72      | 4    | Bearing-Cup, Tapered  |  |  |  |  |
| 7      | 1-543511    | 2    | Seal-Grease           |  |  |  |  |
| 8      | 103-1474-01 | 2    | Fork-Caster           |  |  |  |  |
| 11     | 1-644251    | 2    | Caster Wheel ASM      |  |  |  |  |
| 11:1   | 1-633580    | 2    | Seal-Bearing          |  |  |  |  |
| 11:2   | 1-633581    | 2    | Spacer-Bearing        |  |  |  |  |
| 11:3   | 1-633585    | 2    | Bearing-Cone, Taper   |  |  |  |  |
| 11:4   | 1-633959    | 1    | Spacer-Caster, Front  |  |  |  |  |
| 11:5   |             | 1    | Wheel And Tire ASM    |  |  |  |  |
| 11:5:1 | 1-523009    | 1    | Tire                  |  |  |  |  |
| 11:5:2 | 1-633987    | 1    | Wheel                 |  |  |  |  |
| 11:5:3 | 1-633584    | 2    | Bearing-Cup           |  |  |  |  |
| 21     | 325-39      | 2    | Screw-HH              |  |  |  |  |
| 22     | 3296-23     | 2    | Nut-Lock, NI          |  |  |  |  |



## Main Frame Assembly


| Ref  | Part No.    | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 1-633964-03 | 1    | Stop-Brake, Park       |
| 4    | 322-43      | 6    | Screw-HH               |
| 5    | 323-6       | 2    | Screw-HH               |
| 11   | 108-1095    | 1    | Main Frame ASM         |
| 11:2 | 107-8076    | 1    | Decal-Console, Top     |
| 12   | 1-633970    | 2    | Wheel And Tire ASM     |
| 12:1 | 1-633993    | 1    | Tire                   |
| 12:2 | 1-633992    | 1    | Wheel                  |
| 12:3 | 232-27      | 1    | Stem-Valve             |
| 13   | 107-1858    | 1    | Floorpan               |
| 13:2 | 98-4387     | 1    | Decal-Protection, Ear  |
| 13:3 | 107-1864    | 1    | Decal-Location, Manual |
| 15   | 242-50      | 8    | Nut-Lug                |
| 21   | 3296-39     | 2    | Nut-Lock, NI           |
| 24   | 1-513762    | 1    | Clip-Loom              |
| 25   | 1-303335    | 1    | Tie-Plastic            |
| 27   | 321-4       | 3    | Screw-HH               |
| 28   | 32128-33    | 1    | Nut-HF                 |
| 44   | 3256-70     | 6    | Washer-Flat            |
| 47   | 106-7498    | 1    | Pocket                 |
| 48   | 106-7488-03 | 1    | Hinge-Floorpan, LH     |
| 49   | 106-7489-03 | 1    | Hinge-Floorpan, RH     |
| 50   | 323-20      | 2    | Screw-HH               |
| 51   | 3296-59     | 2    | Nut-Lock, NI           |

| Ref | Part No. | Qty. | Description    |
|-----|----------|------|----------------|
| 52  | 3296-42  | 4    | Nut-Lock, NI   |
| 53  | 3256-63  | 2    | Washer-Flat    |
| 54  | 3258-166 | 2    | Screw-PRH      |
| 55  | 106-9989 | 1    | Decal-Warning  |
| 56  | 106-7492 | 1    | Decal-Danger   |
| 57  | 107-1865 | 2    | R-Clamp        |
| 58  | 104-7050 | 1    | Housing-Manual |
| 59  | 104-7048 | 1    | Cap-Housing    |



## Brake and Wheel Hub Assembly

| Ref  | Part No.    | Qty. | Description            | Ref | Part No. | Qty. | Description          |
|------|-------------|------|------------------------|-----|----------|------|----------------------|
| 1    | 1-513140    | 2    | Bearing-Control        | 19  | 103-2399 | 3    | Pin-Spring, Clevis   |
| 2    | 1-633454    | 2    | Spring-Brake           | 20  | 325-17   | 8    | Screw-HH             |
| 3    | 103-4332    | 1    | Brake Rod And Yoke ASM | 21  | 1481     | 2    | Fitting-Grease       |
| 3:1  | 1-633131    | 2    | Yoke-Linkage, Brake    | 22  | 103-0131 | 8    | Nut-Square           |
| 3:2  | 1-633477    | 1    | Rod-Brake              | 23  | 3219-3   | 4    | Nut-Hex              |
| 3:3  | 3219-3      | 2    | Nut-Hex                | 24  | 3290-357 | 4    | Nut-HHF, Whiz        |
| 4    | 1-634500    | 1    | Brake Lever ASM        | 25  | 3253-7   | 8    | Washer-Lock          |
| 4:2  | 1-633268    | 1    | Grip-Lever, Brake      | 26  | 3256-4   | 4    | Washer-Flat          |
| 5    | 1-632217-03 | 1    | Shaft-Brake            | 27  | 3272-10  | 2    | Pin-Cotter           |
| 6    | 103-0352-03 | 2    | Bracket-Brake          | 28  | 1-806800 | 2    | Pin-Cotter           |
| 7    | 1-523157    | 2    | Washer-Spacer, 14 GA   | 29  | 322-9    | 6    | Screw-HH             |
| 9    | 103-0355    | 2    | Band-Brake             | 30  | 103-0384 | 6    | Spacer               |
| 10   | 1-633380    | 4    | Spacer-Wheel, Short    | 31  | 103-0374 | 2    | Retainer-Band, Brake |
| 11   | 1-633382    | 4    | Spacer-Wheel, Long     | 32  | 1-808285 | 1    | Pin-Clevis           |
| 12   | 1-633102    | 2    | Bearing-Flange, Side   |     |          |      |                      |
| 13   | 103-4333    | 2    | Brake Rod And Yoke ASM |     |          |      |                      |
| 13:1 | 1-633131    | 1    | Yoke-Linkage, Brake    |     |          |      |                      |
| 13:2 | 1-633477    | 1    | Rod-Brake              |     |          |      |                      |
| 13:3 | 3219-3      | 1    | Nut-Hex                |     |          |      |                      |
| 14   | 1-633144    | 2    | Pin-Trunion            |     |          |      |                      |
| 15   | 103-0590    | 2    | Hub And Wheel ASM      |     |          |      |                      |
| 15:1 | 103-0589    | 1    | Wheel Hub ASM          |     |          |      |                      |
| 15:2 | 1-633926    | 4    | Stud-Wheel             |     |          |      |                      |
| 18   | 323-4       | 4    | Screw-HH               |     |          |      |                      |




## Steering Control Assembly

| Ref  | Part No. | Qty. | Description            |
|------|----------|------|------------------------|
| 1    | 1-303105 | 2    | Yoke-Adjustable        |
| 2    | 98-5975  | 4    | Washer-Belleville      |
| 3    | 103-4079 | 2    | Damper-Control, Motion |
| 5    | 1-603735 | 2    | Bushing-Flanged        |
| 6    | 1-603737 | 2    | Bolt-Return, Neutral   |
| 7    | 1-603807 | 2    | Spring-Return, Neutral |
| 8    | 1-403180 | 4    | Screw-HH               |
| ②9   |          | 1    | Tracking Rod ASM       |
| 9:1  | 1-543017 | 1    | Balljoint-RH           |
| 9:2  | 3219-2   | 3    | Nut-Hex                |
| 9:4  | 1-804524 | 1    | Nut                    |
| 9:5  | 1-633152 | 1    | Balljoint-Thread, LH   |
| ②10  |          | 1    | Tracking Rod ASM       |
| 10:1 | 1-543017 | 1    | Balljoint-RH           |
| 10:2 | 3219-2   | 1    | Nut-Hex                |
| 10:3 | 103-3060 | 1    | Knob-Tracking          |
| 10:4 | 1-804524 | 2    | Nut                    |
| 10:5 | 1-323245 | 2    | Spring-Compression     |
| 10:6 | 1-633152 | 1    | Balljoint-Thread, LH   |
| 11   | 108-7238 | 1    | LH Lever ASM           |
| 11:1 | 106-9987 | 1    | Grip-Control, Motion   |
| 12   | 1-632208 | 2    | Arm-Control, Pump      |
| 13   | 103-4781 | 1    | Control-Motion, LH     |
| 14   | 103-4782 | 1    | Control-Motion, RH     |

| Ref  | Part No. | Qty. | Description          |
|------|----------|------|----------------------|
| 16   | 1-633102 | 4    | Bearing-Flange, Side |
| 18   | 103-0407 | 2    | Arm-Shaft, Control   |
| 20   | 322-6    | 4    | Screw-HH             |
| 21   | 323-4    | 8    | Screw-HH             |
| 22   | 323-6    | 4    | Screw-HH             |
| 23   | 323-9    | 6    | Screw-HH             |
| 24   | 1-803022 | 2    | Screw-Set            |
| 25   | 3296-39  | 6    | Nut-Lock, NI         |
| 26   | 3219-2   | 4    | Nut-Hex              |
| 28   | 3220-2   | 2    | Nut-Jam              |
| 29   | 3256-2   | 2    | Washer-Flat          |
| 30   | 3256-3   | 4    | Washer-Flat          |
| 32   | 3272-5   | 2    | Pin-Cotter           |
| 33   | 1-808280 | 2    | Pin-Clevis           |
| 34   | 32128-20 | 4    | Nut-HF               |
| 35   | 3290-357 | 8    | Nut-HHF, Whiz        |
| 37   | 108-7237 | 1    | RH Lever ASM         |
| 37:1 | 106-9987 | 1    | Grip-Control, Motion |
| 38   | 3296-29  | 8    | Nut-Lock, NI         |
| 39   | 3217-16  | 4    | Nut-Hex              |






## Hydraulic System Assembly

| Ref   | Part No. | Qty. | Description          |
|-------|----------|------|----------------------|
| 1     | 103-3736 | 1    | HYD Hose ASM         |
| 2     | 103-1947 | 1    | HYD Reservoir ASM    |
| 2:1   |          | 1    | Reservoir-HYD        |
| 2:1:1 | 103-1948 | 1    | Cap-Reservoir, HYD   |
| 2:1:2 | 103-1949 | 1    | Gasket-Cap           |
| 2:2   | 1-523552 | 1    | Decal-Tank, HYD      |
| 3     | 104-7836 | 1    | Head-Filter          |
| 4     | 103-3733 | 1    | HYD Hose ASM         |
| 6     | 1-633750 | 1    | Filter-HYD           |
| 6     | 1-633752 | 1    | Filter-HYD, Winter   |
| 7     | 103-1799 | 2    | Elbow-90 DEG         |
| 7:1   | 237-42   | 1    | O-Ring               |
| 10    | 1-603991 | 4    | Fitting-Straight     |
| 10:1  | 237-80   | 1    | O-Ring               |
| 10:2  | 1-603992 | 1    | O-Ring               |
| 11    | 103-6988 | 2    | Motor-Wheel          |
| 11:1  | 1-809036 | 1    | Nut-HH               |
| 11:2  | 3257-42  | 1    | Key-Woodruff         |
| 11:99 | 1-000099 | 1    | Seal Kit             |
| 11:99 | 1-000139 | 1    | Bearing Kit          |
| 11:99 | 103-2748 | 1    | Drive Link Kit       |
| 12    | 1-603384 | 1    | Bushing-Pivot, Idler |
| 13    | 103-3330 | 1    | Spring-Extension     |
| 14    | 109-1936 | 1    | Pump Inlet Hose ASM  |

| Ref    | Part No. | Qty. | Description         |
|--------|----------|------|---------------------|
| 14:1   | 103-1826 | 1    | HYD Hose ASM        |
| 14:2   | 103-1827 | 1    | HYD Hose ASM        |
| 14:3   | 103-1828 | 1    | Adapter-Run, Tee    |
| 14:3:1 | 237-42   | 1    | O-Ring              |
| 16     | 103-1716 | 3    | Clamp-Hose          |
| 17     | 103-1988 | 2    | Clamp-Hose          |
| 18     | 103-1801 | 1    | Adapter-Straight    |
| 18:1   | 237-42   | 1    | O-Ring              |
| 19     | 103-1912 | 1    | Adapter-Straight    |
| 19:1   | 237-42   | 1    | O-Ring              |
| 20     | 103-1802 | 2    | Fitting-HYD, 90 DEG |
| 20:1   | 1-603921 | 1    | O-Ring              |
| 21     | 1-603990 | 4    | Fitting-Straight    |
| 21:1   | 1-603920 | 1    | O-Ring              |
| 21:2   | 1-603992 | 1    | O-Ring              |
| 22     | 103-3737 | 1    | HYD Hose ASM        |
| 23     | 103-3735 | 1    | HYD Hose ASM        |
| 25     | 103-1808 | 1    | Hose-HYD            |
| 26     | 103-1807 | 1    | Elbow-45 DEG        |
| 26:1   | 237-42   | 1    | O-Ring              |
| 27     | 103-1806 | 1    | HYD Hose ASM        |
| 28     | 103-6907 | 2    | Sheave              |
| 29     | 1-633567 | 1    | Sheave              |
| 30     | 103-7445 | 1    | Belt-V              |




Hydraulic System Assembly (continued)

| Ref   | Part No. | Qty. | Description          |
|-------|----------|------|----------------------|
| 31    | 1-633167 | 1    | Sheave-Idler         |
| 33    | 1-634277 | 1    | Bearing Arm ASM      |
| 33:1  | 1-513034 | 2    | Sleeve-Bearing       |
| 33:3  | 302-40   | 1    | Fitting-Grease       |
| 34    | 321-6    | 2    | Screw-HH             |
| 35    | 323-8    | 1    | Screw-HH             |
| 36    | 323-9    | 1    | Screw-HH             |
| 37    | 1-800805 | 1    | Screw-HH             |
| 38    | 323-7    | 4    | Screw-HH             |
| 39    | 1-803022 | 2    | Screw-Set            |
| 40    | 30-1710  | 2    | Screw                |
| 41    | 1-803050 | 2    | Screw-Set            |
| 42    | 3256-22  | 2    | Washer-Flat          |
| 43    | 3256-3   | 1    | Washer-Flat          |
| 44    | 3256-4   | 1    | Washer-Flat          |
| 45    | 13-2840  | 1    | Key-Square           |
| 46    | 5-1077   | 2    | Key-Square           |
| 47    | 3290-357 | 8    | Nut-HHF, Whiz        |
| 48    | 32128-33 | 2    | Nut-HF               |
| 49    | 1-805004 | 2    | Washer-Lock          |
| 50    | 321-3    | 2    | Screw-HH             |
| 51    | 103-7262 | 2    | Pump-HYD             |
| ●51:1 | 103-7441 | 1    | Bearing-Shaft, Input |
| ●51:2 | 103-7443 | 1    | Cylinder Block Kit   |


| Ref   | Part No. | Qty. | Description        |
|-------|----------|------|--------------------|
| ●51:3 | 103-8448 | 1    | Thrust Bearing Kit |
| ●51:4 | 105-6184 | 1    | Overhaul Seal Kit  |

11



**Deluxe Seat Assembly No. 110-0838**


| Ref | Part No. | Qty. | Description              |  |  |  |  |
|-----|----------|------|--------------------------|--|--|--|--|
| 1   |          | 1    | Seat ASM                 |  |  |  |  |
| 1:1 | 107-1880 | 1    | Seat Track Kit           |  |  |  |  |
| 1:2 | 107-1885 | 1    | Weight Indicator Kit     |  |  |  |  |
| 1:3 | 107-1881 | 1    | Knob Kit                 |  |  |  |  |
| 1:4 | 107-1883 | 1    | Bottom Cushion Kit       |  |  |  |  |
| 1:5 | 107-1886 | 1    | Switch Kit               |  |  |  |  |
| 1:6 | 107-1887 | 1    | Armrest Kit              |  |  |  |  |
| 1:7 | 107-1884 | 1    | Shock Absorber Kit       |  |  |  |  |
| 1:8 | 107-1882 | 1    | Back Cushion Kit         |  |  |  |  |
| 4   | 110-0883 | 1    | Retractable Seatbelt Kit |  |  |  |  |
| 4:2 | 3212-4   | 2    | Screw-HH                 |  |  |  |  |
| 4:3 | 3296-7   | 2    | Nut-Lock                 |  |  |  |  |



## Roll-Over-Protection-System Assembly No. 108-1097


| Ref  | Part No.    | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| ② 1  |             | 1    | Upper Tube ASM              |
| 1:2  | 107-2101    | 1    | Decal-ROPS                  |
| 1:3  | 107-2102    | 1    | Decal-Warning, Folding ROPS |
| 2    | 3296-73     | 2    | Nut-Lock, NI                |
| 4    | 103-4553    | 2    | ROPS Fold Pin ASM           |
| 5    | 325-13      | 2    | Screw-HH                    |
| 6    | 32128-23    | 2    | Nut-HF                      |
| ② 7  |             | 1    | Tube-Support, RH            |
| ② 12 |             | 1    | Tube-Support, LH            |
| 13   | 109-2365    | 2    | Bumper-Rubber               |
| 16   | 107-3052-03 | 1    | Seat Support Frame ASM      |
| 17   | 107-3058    | 1    | Catch-Latch, Seat           |
| 18   | 322-3       | 2    | Screw-HH                    |
| 19   | 3296-29     | 2    | Nut-Lock, NI                |
| 20   | 3296-39     | 1    | Nut-Lock, NI                |
| 23   | 323-20      | 1    | Screw-HH                    |
| 24   | 107-0076    | 1    | Spring-Torsion              |
| 25   | 107-0075    | 1    | Bushing-Latch, Seat         |
| 26   | 103-4434    | 1    | Grip-Lever                  |
| 28   | 3256-24     | 1    | Washer-Flat                 |
| 29   | 107-3083    | 1    | Latch ASM                   |
| 34   | 110-0883    | 1    | Retractable Seatbelt Kit    |
| 34:2 | 3212-4      | 2    | Screw-HH                    |
| 34:3 | 3296-7      | 2    | Nut-Lock                    |

| Ref    | Part No. | Qty. | Description       |
|--------|----------|------|-------------------|
| ① ② 54 |          | 1    | Bag-Bolt, ROPS    |
| 54:3   | 323-6    | 8    | Screw-HH          |
| 54:4   | 98-5975  | 8    | Washer-Belleville |
| 54:5   | 3290-357 | 8    | Nut-HHF, Whiz     |



Deck Connection Assembly


| Ref | Part No.    | Qty. | Description         |  |  |  |  |
|-----|-------------|------|---------------------|--|--|--|--|
| 1   | 32128-37    | 8    | Nut-HF              |  |  |  |  |
| 3   | 103-9792    | 4    | Deck Chain ASM      |  |  |  |  |
| 4   | 302-19      | 4    | Fitting-Grease      |  |  |  |  |
| 5   | 3217-11     | 2    | Nut-Hex             |  |  |  |  |
| 6   | 3253-8      | 2    | Washer-Lock         |  |  |  |  |
| 7   | 327-11      | 2    | Screw-HH            |  |  |  |  |
| 8   | 1-633029    | 2    | Balljoint-Spherical |  |  |  |  |
| 9   | 3219-6      | 2    | Nut-Hex             |  |  |  |  |
| 10  | 109-1181    | 2    | Strut-Deck          |  |  |  |  |
| 11  | 1-632199-01 | 2    | Pin-Strut           |  |  |  |  |
| 12  | 322-3       | 2    | Screw-HH            |  |  |  |  |
| 13  | 3296-29     | 2    | Nut-Lock, NI        |  |  |  |  |
| 14  |             | 1    | 60 Inch Deck ASM    |  |  |  |  |



## 60 Inch Deck Assembly

| Ref | Part No.    | Qty. | Description         |
|-----|-------------|------|---------------------|
| 1   | 105-8783    | 1    | Belt                |
| 2   | 74-5950     | 2    | Latch-Swell         |
| 3   | 107-8536    | 2    | Cover-Belt          |
| 4   | 106-3220    | 1    | Guide-Belt          |
| 5   | 105-8792-01 | 1    | Plate-Skid          |
| 6   | 32144-70    | 4    | Screw-HH            |
| 7   | 108-4121-01 | 2    | Bracket-Cover       |
| 8   | 108-2177-01 | 1    | Bracket-Cover, Tall |
| 9   | 106-7354-01 | 1    | Plate-Roller, LH    |
| 10  | 106-7355-01 | 1    | Plate-Roller, RH    |
| 11  | 3290-357    | 38   | Nut-HHF, Whiz       |
| 12  | 323-28      | 1    | Screw-HH            |
| 13  | 92-1624     | 33   | Screw               |
| 14  | 105-7734    | 3    | Pulley              |
| 15  | 106-3217    | 3    | Spindle ASM         |
| 16  | 105-7718-03 | 3    | Blade-Hi Flow       |
| 17  | 323-23      | 4    | Screw-HH            |
| 18  | 98-7913     | 4    | Tube-Spacer         |
| 19  | 322-50      | 1    | Screw-HH            |
| 20  | 98-5967     | 1    | Spacer-Wheel        |
| 21  | 1-603299    | 6    | Roller-Scalp, Anti  |
| 22  | 3296-29     | 1    | Nut-Lock, NI        |
| 23  | 107-1624    | 1    | Deck ASM            |
| 24  | 105-7657-01 | 1    | Baffle ASM          |


| Ref | Part No.    | Qty. | Description              |
|-----|-------------|------|--------------------------|
| 25  | 105-7669-01 | 1    | Baffle ASM               |
| 26  | 98-7912     | 4    | Tube-Spanner             |
| 27  | 108-4052    | 1    | Spring-Torsion           |
| 28  | 105-4622    | 1    | Spacer                   |
| 29  | 108-2792    | 1    | Rubber Deflector ASM     |
| 30  | 108-4122-01 | 1    | Bracket-Cover            |
| 31  | 107-1664    | 2    | Lever ASM                |
| 32  | 323-12      | 2    | Screw-HH                 |
| 33  | 106-3214    | 2    | Mount-Pulley             |
| 34  | 3256-24     | 4    | Washer-Flat              |
| 35  | 1-633109    | 3    | Idler-Flat               |
| 36  | 3231-1      | 10   | Screw-CARR               |
| 37  | 99-3058     | 2    | Washer                   |
| 38  | 323-9       | 1    | Screw-HH                 |
| 39  | 1-603496    | 1    | Bushing-Idler            |
| 40  | 105-7787-01 | 1    | Plate-Idler              |
| 41  | 105-7788    | 2    | Spacer                   |
| 42  | 3231-4      | 2    | Screw-CARR               |
| 43  | 3296-39     | 7    | Nut-Lock, NI             |
| 44  | 98-5975     | 1    | Washer-Belleville        |
| 45  | 103-0862    | 3    | Screw-Cap                |
| 46  | 103-0865    | 3    | Washer-Blade Bolt, Heavy |
| 47  | 106-3216-01 | 1    | Baffle-Discharge         |
| 48  | 112843      | 1    | Washer                   |



## 60 Inch Deck Assembly (continued)


| Ref | Part No.    | Qty. | Description |
|-----|-------------|------|-------------|
| 50  | 108-7220-01 | 1    | Guide-Belt  |






Spindle Assembly No. 106-3217

| Ref   | Part No. | Qty. | Description              |  |  |  |  |
|-------|----------|------|--------------------------|--|--|--|--|
| 1     | 10-8040  | 1    | Key-Square               |  |  |  |  |
| 2     | 106-3277 | 1    | Hub-Pulley               |  |  |  |  |
| 3     | 103-0865 | 1    | Washer-Blade Bolt, Heavy |  |  |  |  |
| 4     | 106-3204 | 2    | Shield-Bearing           |  |  |  |  |
| 5     |          | 1    | Spindle Bearing ASM      |  |  |  |  |
| 5:1   | 106-3211 | 1    | Housing-Spindle          |  |  |  |  |
| 5:2   | 106-3207 | 1    | Bearing ASM              |  |  |  |  |
| 5:2:1 | 27-0960  | 1    | Bearing ASM              |  |  |  |  |
| 5:2:2 | 106-3206 | 1    | Spacer-Set, Matched      |  |  |  |  |
| 5:3   | 253-133  | 2    | Seal-Oil                 |  |  |  |  |
| 5:4   | 302-5    | 1    | Fitting-Grease           |  |  |  |  |
| 6     | 106-3218 | 2    | Spacer-Seal              |  |  |  |  |
| 7     | 106-3233 | 1    | Spindle Shaft ASM        |  |  |  |  |
| 8     | 3219-6   | 1    | Nut-Hex                  |  |  |  |  |



**Deck Decal Assembly No. 107-1624**

| Ref | Part No. | Qty. | Description              |  |  |  |  |
|-----|----------|------|--------------------------|--|--|--|--|
| 2   | 54-9220  | 1    | Decal-Danger             |  |  |  |  |
| 3   | 66-1340  | 1    | Decal-Danger             |  |  |  |  |
| 4   | 98-5954  | 3    | Decal-Missing, Cover     |  |  |  |  |
| 5   | 1-403005 | 1    | Decal-Danger             |  |  |  |  |
| 6   | 68-8340  | 1    | Decal-Torque             |  |  |  |  |
| 7   | 105-7797 | 1    | Decal-Routing, Belt      |  |  |  |  |
| 8   | 105-7798 | 1    | Decal-Scalp, Anti        |  |  |  |  |
| 9   | 58-6520  | 3    | Decal-Grease             |  |  |  |  |
| 10  | 110-2067 | 1    | Decal-Setting, Baffle    |  |  |  |  |
| 11  | 107-1613 | 2    | Decal-Grease             |  |  |  |  |
| 12  | 107-1619 | 1    | Decal                    |  |  |  |  |
| 13  | 107-1621 | 1    | Decal-Service, Check     |  |  |  |  |
| 14  | 110-2068 | 1    | Decal-Adjustment, Baffle |  |  |  |  |
| 15  | 107-3137 | 1    | Plate-Turbo              |  |  |  |  |
| 16  | 3274-104 | 2    | Screw-HSBH               |  |  |  |  |
| 17  | 1-303334 | 4    | Washer-Spring            |  |  |  |  |
| 18  | 3296-29  | 2    | Nut-Lock, NI             |  |  |  |  |




## Rubber Deflector Assembly No. 108-2792

| Ref | Part No.    | Qty. | Description        |  |  |  |  |
|-----|-------------|------|--------------------|--|--|--|--|
| 1   | 3231-4      | 4    | Screw-CARR         |  |  |  |  |
| 2   | 106-3246-01 | 1    | Deflector          |  |  |  |  |
| 3   | 106-3248-03 | 1    | Strap-Discharge    |  |  |  |  |
| 4   | 108-5029    | 1    | Deflector-Rubber   |  |  |  |  |
| 5   | 108-4059-01 | 1    | Plate-Hinge, Rear  |  |  |  |  |
| 6   | 106-3253-01 | 1    | Plate-Hinge, Front |  |  |  |  |
| 7   | 3296-39     | 4    | Nut-Lock, NI       |  |  |  |  |

# Lever Assembly No. 107-1664


| Ref | Part No. | Qty. | Description  |
|-----|----------|------|--------------|
| 1   | 106-3239 | 1    | Screw-Lock   |
| 2   | 107-1644 | 1    | Cap-Lock     |
| 3   | 106-3241 | 1    | Lever-Lock   |
| 4   | 3296-29  | 1    | Nut-Lock, NI |



## Drive Idler Assembly


| Ref  | Part No.    | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 98-5975     | 1    | Washer-Belleville     |
| 6    | 103-2627    | 1    | Bushing-Idler         |
| 7    | 1-603384    | 1    | Bushing-Pivot, Idler  |
| 9    | 1-603496    | 1    | Bushing-Idler         |
| 10   | 99-4638     | 1    | Idler                 |
| 11   | 1-603402    | 1    | Spring-Extension      |
| 12   | 1-633166    | 1    | Pulley-Idler          |
| 14   | 103-3147    | 1    | Arm ASM               |
| 14:1 | 1-513034    | 2    | Sleeve-Bearing        |
| 14:2 | 302-40      | 1    | Fitting-Grease        |
| 15   | 323-12      | 2    | Screw-HH              |
| 16   | 323-9       | 1    | Screw-HH              |
| 17   | 323-13      | 1    | Screw-HH              |
| 18   | 1-800805    | 1    | Screw-HH              |
| 19   | 3296-39     | 3    | Nut-Lock, NI          |
| 20   | 3256-24     | 3    | Washer-Flat           |
| 21   | 3290-357    | 6    | Nut-HHF, Whiz         |
| 22   | 1-603401    | 1    | Spacer-Fender         |
| 24   | 3256-4      | 3    | Washer-Flat           |
| 26   | 106-3271    | 1    | Travel Limiter ASM    |
| 26:1 | 106-3228-03 | 1    | Plate-Limiter, Pulley |
| 26:2 | 106-3229    | 1    | Pad-Bumper            |
| 26:3 | 3269-24     | 2    | Rivet                 |
| 27   | 108-7204-03 | 1    | Guide-Belt, LH        |

| Ref | Part No.    | Qty. | Description    |
|-----|-------------|------|----------------|
| 28  | 108-7229-03 | 1    | Guide-Belt, RH |
| 29  | 3231-2      | 2    | Screw-CARR     |



Z-Stand Assembly


| Ref | Part No.    | Qty. | Description           |  |  |  |  |
|-----|-------------|------|-----------------------|--|--|--|--|
| 1   | 323-20      | 1    | Screw-HH              |  |  |  |  |
| 2   | 100-6542-01 | 1    | Bracket-Cradle        |  |  |  |  |
| 3   | 3296-39     | 2    | Nut-Lock, NI          |  |  |  |  |
| 4   | 107-1874    | 1    | Leg ASM               |  |  |  |  |
| 4:2 | 106-7464    | 1    | Decal-Z Stand         |  |  |  |  |
| 5   | 283-55      | 1    | Pin-Clevis            |  |  |  |  |
| 6   | 100-9692-01 | 1    | Pivot Pin ASM         |  |  |  |  |
| 7   | 323-8       | 1    | Screw-HH              |  |  |  |  |
| 8   | 100-9686-01 | 1    | Bracket-Latch         |  |  |  |  |
| 9   | 3-6781      | 2    | Washer-Thrust         |  |  |  |  |
| 10  | 283-71      | 1    | Pin-Lynch             |  |  |  |  |
| 11  | 3290-355    | 1    | Pin-Hair              |  |  |  |  |
| 12  | 100-6547    | 2    | Cushion-Rubber        |  |  |  |  |
| 14  | 105-1647    | 1    | Pin-Hitch, Cotterless |  |  |  |  |
| 15  | 100-9385    | 1    | Lanyard-Nylon         |  |  |  |  |
| 16  | 321-4       | 1    | Screw-HH              |  |  |  |  |
| 17  | 3296-42     | 1    | Nut-Lock, NI          |  |  |  |  |



## Engine and Clutch Assembly

| Ref | Part No.  | Qty. | Description                  |
|-----|-----------|------|------------------------------|
| 2   | 103-2759  | 1    | Muffler                      |
| 4   | 106-7022  | 1    | Tube-Drain, Oil              |
| 5   | 52-4780   | 1    | Rod-Belt                     |
| 6   | 1-603610  | 2    | Washer-Spring                |
| 7   | 1-303334  | 6    | Washer-Spring                |
| 9   | 103-6589  | 1    | Clutch                       |
| 11  |           | 1    | Engine-Kawasaki, Fd750D-Bs03 |
| 12  | 33013-00  | 4    | Nut-Hex                      |
| 13  | 1-805004  | 4    | Washer-Lock                  |
| 14  | 103-0152  | 1    | Keeper-Clutch                |
| 15  | 95-5806   | 1    | Bracket-Mounting             |
| 16  | 3256-3    | 4    | Washer-Flat                  |
| 17  | 95-5805   | 1    | Air Cleaner ASM              |
| 18  | 1-643009  | 1    | Clamp-Hose                   |
| 20  | 1-643084  | 1    | Hose-Inlet, Air              |
| 25  | 48-7570   | 1    | Screw-HH                     |
| 33  | 33115-025 | 5    | Screw-HH                     |
| 37  | 33115-020 | 2    | Screw-HH                     |
| 39  | 322-6     | 3    | Screw-HH                     |
| 42  | 3296-29   | 2    | Nut-Lock, NI                 |
| 44  | 103-1966  | 1    | Adapter                      |
| 46  | 92-6877   | 1    | Valve-Drain, Oil             |
| 47  | 103-0114  | 1    | Spacer-Clutch                |
| 48  | 103-1511  | 1    | Arrestor-Spark               |


| Ref | Part No. | Qty. | Description       |
|-----|----------|------|-------------------|
| 49  | 103-1512 | 1    | Clamp-Muffler     |
| 50  | 3256-24  | 1    | Washer-Flat       |
| 51  | 98-5975  | 1    | Washer-Belleville |
| 52  | 1-643083 | 1    | Hose-Aircleaner   |



## Air Cleaner Assembly No. 95-5805

| Ref | Part No. | Qty. | Description    |
|-----|----------|------|----------------|
| 2   | 108-3811 | 1    | Filter-Air     |
| 3   | 94-3652  | 1    | Cover ASM      |
| 4   | 87-9400  | 1    | Valve-Vacuator |
| 5   | 285-17   | 1    | Plug-Pipe      |






Cooling System Assembly


| Ref | Part No. | Qty. | Description             |
|-----|----------|------|-------------------------|
| 1   | 104-7843 | 1    | Radiator Trim Plate ASM |
| 1:2 | 65-2690  | 2    | Decal-Surface, Hot      |
| 1:3 | 104-2449 | 1    | Decal-Coolant           |
| 2   | 1-643161 | 1    | Cap-Radiator            |
| 3   | 103-1046 | 1    | Radiator-Mount          |
| 4   | 322-1    | 12   | Screw-HH                |
| 5   | 3256-23  | 14   | Washer-Flat             |
| 6   | 100-4301 | 1    | Fan Mounting Plate ASM  |
| 6:2 | 1-643253 | 2    | Decal-Fan, Radiator     |
| 7   | 1-803067 | 4    | Screw                   |
| 8   | 3256-16  | 8    | Washer-Flat             |
| 9   | 1-804254 | 4    | Nut                     |
| 10  | 1-633831 | 1    | Fan                     |
| 11  | 1-633989 | 4    | Clamp-Hose              |
| 12  | 103-0074 | 1    | Hose-Inlet, Radiator    |
| 13  | 103-0075 | 1    | Hose-Outlet, Radiator   |
| 14  | 1-643164 | 1    | Cap-Tank, Overflow      |
| 15  | 1-643163 | 1    | Tank-Overflow           |
| 16  | 1-643131 | 1    | Hose                    |
| 17  | 1-643259 | 1    | Fitting-Elbow           |
| 18  | 1-513645 | 1    | Bushing-Valve, Fuel     |
| 20  | 321-2    | 2    | Screw-HH                |
| 21  | 1-303287 | 3    | Tie-Plastic             |
| 22  | 109-0041 | 1    | Hose, Overflow          |

| Ref | Part No.    | Qty. | Description          |
|-----|-------------|------|----------------------|
| 23  | 1-633851    | 1    | Extension-Crankshaft |
| 24  | 3255-8      | 3    | Washer-Lock          |
| 25  | 33014-00    | 3    | Nut-Hex              |
| 26  | 1-633869    | 1    | Fan-Pump, Cooling    |
| 27  | 3256-22     | 3    | Washer-Flat          |
| 28  | 1-809095    | 3    | Screw-HSH            |
| 29  | 103-0098    | 1    | Shroud-Fan, HYD      |
| 30  | 3296-2      | 6    | Nut-Lock             |
| 31  | 3256-14     | 12   | Washer-Flat          |
| 32  | 3290-500    | 6    | Screw-PPH            |
| 33  | 103-0895-03 | 1    | Shield-LH            |
| 34  | 1-633794-03 | 1    | Shield-RH            |
| 35  | 321-4       | 6    | Screw-HH             |
| 36  | 32128-33    | 6    | Nut-HF               |
| 37  | 103-3270    | 1    | Decal                |



Hood Assembly


| Ref | Part No.    | Qty. | Description            |  |  |  |  |
|-----|-------------|------|------------------------|--|--|--|--|
| 1   | 1-633864-03 | 1    | Screen-Radiator        |  |  |  |  |
| 2   | 1-803072    | 17   | Rivet                  |  |  |  |  |
| 3   | 3256-14     | 12   | Washer-Flat            |  |  |  |  |
| 4   | 322-4       | 4    | Screw-HH               |  |  |  |  |
| 5   | 104-5136    | 1    | Hood                   |  |  |  |  |
| 6   | 3256-23     | 10   | Washer-Flat            |  |  |  |  |
| 7   | 1-303435    | 5    | Washer-Spring          |  |  |  |  |
| 8   | 3296-29     | 4    | Nut-Lock, NI           |  |  |  |  |
| 9   | 1-633885-03 | 2    | Plate-Hinge, Hood      |  |  |  |  |
| 10  | 1-632986-03 | 2    | Shackle-Hinge          |  |  |  |  |
| 11  | 32128-20    | 25   | Nut-HF                 |  |  |  |  |
| 12  | 322-3       | 16   | Screw-HH               |  |  |  |  |
| 13  | 1-808285    | 2    | Pin-Clevis             |  |  |  |  |
| 14  | 3256-24     | 6    | Washer-Flat            |  |  |  |  |
| 15  | 1-806003    | 2    | Pin-Hair               |  |  |  |  |
| 16  | 1-643106-03 | 1    | Angle-Radiator, RH     |  |  |  |  |
| 17  | 1-643108-03 | 1    | Angle-Radiator, Bottom |  |  |  |  |
| 18  | 1-643107-03 | 1    | Angle-Radiator, Top    |  |  |  |  |
| 19  | 1-643105-03 | 1    | Angle-Radiator, LH     |  |  |  |  |
| 20  | 1-643187    | 2    | Seal-Trim              |  |  |  |  |
| 21  | 1-643186    | 2    | Seal-Trim              |  |  |  |  |
| 23  | 1-643188    | 2    | Latch-Rubber           |  |  |  |  |
| 24  | 923786      | 4    | Rivet                  |  |  |  |  |
| 28  | 106-7456    | 1    | Decal                  |  |  |  |  |



## Cooling Mounting Frame Assembly

| Ref    | Part No.    | Qty. | Description         |
|--------|-------------|------|---------------------|
| 1      | 3256-24     | 6    | Washer-Flat         |
| 2      | 1-803075    | 4    | Screw-Head, Truss   |
| 4      | 3296-2      | 4    | Nut-Lock            |
| 5      | 1-633878-03 | 1    | Crossbar            |
| 6      | 322-4       | 4    | Screw-HH            |
| 7      | 32128-20    | 12   | Nut-HF              |
| 8      | 322-3       | 8    | Screw-HH            |
| 9      | 3296-42     | 6    | Nut-Lock, NI        |
| 10     | 32128-33    | 2    | Nut-HF              |
| 11     | 109-2365    | 2    | Bumper-Rubber       |
| 12     | 321-9       | 2    | Screw-HH            |
| 13     | 1-643339    | 1    | Decal-Routing, Belt |
| 14     | 103-0107-03 | 1    | Brace-Radiator, LH  |
| 15     | 1-632985-03 | 1    | Brace-Radiator, RH  |
| 16     | 103-2870-03 | 1    | Deflector-Air       |
| 17     | 3269-3      | 4    | Rivet-Pop           |
| 18     | 49-2040     | 2    | Screw-HWHTF         |
| 19     | 103-0110-03 | 1    | Plenum-Intake, Air  |
| 20     | 1-644276    | 1    | Shield ASM          |
| 20:1   | 1-633462    | 1    | Decal-Important     |
| 20:2   | 1-634308    | 1    | Shield/Lift ASM     |
| 20:2:1 | 103-1308    | 1    | Shield-Engine       |
| 20:2:2 | 1-633300-03 | 1    | Lift-Shield         |
| 20:2:3 | 1-803035    | 3    | Rivet-Pop           |


| Ref  | Part No.    | Qty. | Description             |
|------|-------------|------|-------------------------|
| 20:3 | 103-5881    | 1    | Decal-Devices, Rotating |
| 21   | 321-4       | 4    | Screw-HH                |
| 22   | 103-7452-03 | 1    | Plate-Side, LH          |
| 23   | 3256-2      | 6    | Washer-Flat             |
| 24   | 923786      | 4    | Rivet                   |
| 25   | 322-5       | 9    | Screw-HH                |
| 26   | 1-632873-03 | 1    | Mount-Radiator, Rear    |
| 27   | 1-633886-03 | 1    | Guard-Bumper            |
| 28   | 1-633897-03 | 2    | Rib-Top                 |
| 29   | 1-633898-03 | 2    | Rib-Bottom              |
| 30   | 1-633877-03 | 2    | Bar-Hook, Latch         |
| 31   | 1-643189    | 2    | Keeper-Latch, Rubber    |
| 32   | 3290-357    | 10   | Nut-HHF, Whiz           |
| 33   | 323-6       | 6    | Screw-HH                |
| 34   | 3256-23     | 11   | Washer-Flat             |
| 35   | 323-7       | 4    | Screw-HH                |
| 36   | 103-7623-03 | 2    | Strap-Guard             |
| 37   | 103-7453-03 | 1    | Plate-Side, RH          |



## Fuel Tank Assembly

| Ref    | Part No.    | Qty. | Description               |
|--------|-------------|------|---------------------------|
| 1      | 1-303077    | 17   | Clamp                     |
| 2      | 110-9887    | 1    | Control Panel ASM         |
| 2:1    | 110-3871-03 | 1    | Panel-Control             |
| 2:2    | 110-5722    | 1    | Decal-Panel, Control (Lc) |
| 3      | 109-0302    | 1    | Hose-Fuel                 |
| 4      | 110-4170    | 1    | Hose-Fuel                 |
| 8      | 110-1876    | 1    | Hose-Fuel                 |
| 9      | 1-633023    | 6    | Stud                      |
| 10     | 105-3644    | 1    | LH Fuel Tank Kit ASM      |
| ② 10:1 |             | 1    | LH Fuel Tank ASM          |
| 10:1:2 | 103-2605    | 1    | Fitting-Fuel, Bulkhead    |
| 10:2   | 109-0346    | 1    | Cap-Fuel, Gas             |
| 11     | 105-3643    | 1    | RH Fuel Tank Kit ASM      |
| ② 11:1 |             | 1    | RH Fuel Tank ASM          |
| 11:1:2 | 103-2605    | 1    | Fitting-Fuel, Bulkhead    |
| 11:2   | 109-0346    | 1    | Cap-Fuel, Gas             |
| 12     | 1-603770    | 1    | Valve-Fuel                |
| 13     | 109-0660    | 3    | Hose-Fuel                 |
| 14     | 1-633349    | 6    | Spring-Tank, Fuel         |
| 15     | 321-4       | 2    | Screw-HH                  |
| 16     | 322-3       | 2    | Screw-HH                  |
| 17     | 3296-47     | 6    | Nut-Lock, NI              |
| 18     | 3256-2      | 2    | Washer-Flat               |
| 19     | 1-805005    | 2    | Washer-Lock               |

| Ref | Part No. | Qty. | Description                |
|-----|----------|------|----------------------------|
| 20  | 3256-23  | 8    | Washer-Flat                |
| 23  | 3251-1   | 4    | Screw-PPH                  |
| 24  | 1-303435 | 4    | Washer-Spring              |
| 25  | 321-3    | 2    | Screw-HH                   |
| 26  | 1-805004 | 2    | Washer-Lock                |
| 28  | 1-513762 | 1    | Clip-Loom                  |
| 29  | 32128-33 | 2    | Nut-HF                     |
| 31  | 99-5005  | 1    | Fitting-Tee, Barbed        |
| 32  | 99-5000  | 2    | Valve-Check, Fuel          |
| 33  | 109-0678 | 2    | Hose-Fuel                  |
| 44  | 110-5717 | 1    | Cable-Throttle             |
| 45  | 110-5720 | 1    | Control-Choke, Push / Pull |
| 46  | 1-807513 | 2    | Bolt-CARR                  |
| 47  | 1-603175 | 1    | Knob-Ball                  |
| 48  | 3296-2   | 2    | Nut-Lock                   |
| 49  | 1-303335 | 4    | Tie-Plastic                |




## Electrical Components Assembly

| Ref  | Part No.  | Qty. | Description             |
|------|-----------|------|-------------------------|
| 1    | 106-7496  | 1    | Harness-Wire            |
| 2    | 1-816001  | 1    | Fuse-Blade Type, 20 Amp |
| 3    | 1-816003  | 1    | Fuse-Blade Type, 30 Amp |
| 4    | 1-643275  | 3    | Relay                   |
| 5    | 1-803071  | 2    | Screw                   |
| 6    | 3296-2    | 4    | Nut-Lock                |
| 7    | 1-543393  | 1    | Insulator-Solenoid      |
| 8    | 321-4     | 5    | Screw-HH                |
| 9    | 1-633396  | 3    | Clip-Loom               |
| 10   | 32128-33  | 5    | Nut-HF                  |
| 11   | 33014-00  | 1    | Nut-Hex                 |
| 12   | 3256-23   | 2    | Washer-Flat             |
| 14   | 33114-016 | 1    | Screw-HH                |
| 16   | 1-643145  | 1    | Tab                     |
| 17   | 103-0283  | 1    | Sender-Temperature      |
| 18   | 1-643153  | 1    | Washer-Aluminum         |
| 19   | 1-523279  | 1    | Wire-Battery, Positive  |
| 20   | 1-633307  | 1    | Wire-Ground             |
| 21   | 1-543391  | 1    | Insulator-Battery       |
| 22   | 1-303335  | 10   | Tie-Plastic             |
| 23   | 3256-2    | 2    | Washer-Flat             |
| 24   | 105-1692  | 1    | Battery                 |
| 24:1 | 104-4163  | 1    | Decal-Battery           |
| 24:2 | 104-4164  | 1    | Decal-Battery           |

| Ref | Part No.    | Qty. | Description                  |
|-----|-------------|------|------------------------------|
| 25  | 1-303287    | 2    | Tie-Plastic                  |
| 26  | 107-9277-03 | 1    | Strap-Holddown, Battery      |
| 27  | 1-543792    | 2    | Wingnut                      |
| 28  | 1-633651    | 2    | Bolt-Holddown                |
| 29  | 3290-500    | 8    | Screw-PPH                    |
| 31  | 1-633181    | 3    | Plate-Tapped                 |
| 33  | 1-633111    | 1    | Switch                       |
| 34  | 1-513762    | 1    | Clip-Loom                    |
| 35  | 103-5221    | 1    | Switch-PTO                   |
| 36  | 103-0206    | 1    | Switch-Starting, Key         |
| 37  | 1-513374    | 1    | Meter-Hour                   |
| 38  | 100-6186    | 1    | Module-Delay, Seat           |
| 39  | 1-643115    | 1    | Tie-Plastic                  |
| 41  | 63-8360     | 2    | Key-Ignition                 |
| 43  | 1-643037    | 1    | Gauge-Voltmeter              |
| 44  | 1-643021    | 1    | Gauge-Temperature            |
| 48  | 1-513051    | 2    | Switch-Open, Normally        |
| 49  | 103-1027    | 1    | Decal-Relay                  |
| 50  | 103-1227    | 1    | Harness-Wiring, Seat         |
| 53  | 107-9309    | 1    | Decal-Instructions, Charging |

# Cylinder and Crankcase Assembly

## Kawasaki FD750D-BS03




## Cylinder and Crankcase Assembly

### Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description         |  |  |  |  |
|---------|------------|------|---------------------|--|--|--|--|
| ③11004  | 11004-2142 | 2    | Gasket-Head         |  |  |  |  |
| ③11008  | 11008-2145 | 1    | Head-Cylinder       |  |  |  |  |
| ③11008A | 11008-2146 | 1    | Head-Cylinder       |  |  |  |  |
| ③11022  | 11022-2072 | 1    | Case-Rocker         |  |  |  |  |
| ③11022A | 11022-2073 | 1    | Case-Rocker         |  |  |  |  |
| ③11060  | 11060-2466 | 1    | Gasket-Breather     |  |  |  |  |
| ③11060A | 11060-2470 | 2    | Gasket-Case, Rocker |  |  |  |  |
| ③13271  | 13271-2105 | 2    | Plate               |  |  |  |  |
| ③14091  | 14091-2064 | 1    | Cover-Breather      |  |  |  |  |
| ③16126  | 16126-2225 | 2    | Valve-Breather      |  |  |  |  |
| ③49015  | 49015-6232 | 1    | Cover-Crankcase     |  |  |  |  |
| ③49120  | 49120-6127 | 1    | Crankcase           |  |  |  |  |
| ③59071  | 59071-2079 | 1    | Joint               |  |  |  |  |
| ③92009  | 92009-2308 | 2    | Screw               |  |  |  |  |
| ③92043  | 92043-1037 | 6    | Pin                 |  |  |  |  |
| ③92049  | 92049-2242 | 1    | Seal-Oil            |  |  |  |  |
| ③92049A | 92049-2243 | 1    | Seal-Oil            |  |  |  |  |
| ③92093  | 92093-2086 | 1    | Seal                |  |  |  |  |
| ③92141  | 92141-2118 | 1    | Bearing-Plane       |  |  |  |  |
| ③92141A | 92141-2119 | 1    | Bearing-Plane       |  |  |  |  |
| ③92151  | 92151-2158 | 4    | Bolt                |  |  |  |  |
| ③92151A | 92151-2159 | 8    | Bolt                |  |  |  |  |
| ③92170  | 92170-2002 | 2    | Clamp               |  |  |  |  |
| ③92191  | 92191-2105 | 1    | Tube                |  |  |  |  |
| ③130    | 130G0630   | 8    | Bolt-Flanged        |  |  |  |  |
| ③130A   | 130G0830   | 4    | Bolt-Flanged        |  |  |  |  |
| ③130B   | 130G0845   | 6    | Bolt                |  |  |  |  |
| ③130C   | 130G0860   | 4    | Bolt-Flanged        |  |  |  |  |
| ③172    | 172G0822   | 4    | Bolt-Stud           |  |  |  |  |
| ③670    | 670B2011   | 3    | O-Ring              |  |  |  |  |

# Valve and Camshaft Assembly

## Kawasaki FD750D-BS03






## Valve and Camshaft Assembly

### Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description            |  |  |  |  |
|---------|------------|------|------------------------|--|--|--|--|
| ⑤11051  | 11051-2092 | 2    | Bracket                |  |  |  |  |
| ⑤12004  | 12004-2113 | 2    | Valve-Intake           |  |  |  |  |
| ⑤12005  | 12005-2100 | 2    | Valve-Exhaust          |  |  |  |  |
| ⑤12009  | 12009-2060 | 4    | Retainer-Spring, Valve |  |  |  |  |
| ⑤12011  | 12011-2052 | 8    | Collet                 |  |  |  |  |
| ⑤12016  | 12016-2063 | 4    | Arm-Rocker             |  |  |  |  |
| ⑤12032  | 12032-2060 | 4    | Tappet                 |  |  |  |  |
| ⑤13116  | 13116-2074 | 4    | Rod-Push               |  |  |  |  |
| ⑤16007  | 16007-2052 | 4    | Seat-Spring            |  |  |  |  |
| ⑤49078  | 49078-2060 | 4    | Spring-Valve, Engine   |  |  |  |  |
| ⑤49118  | 49118-2138 | 1    | Camshaft               |  |  |  |  |
| ⑤92049  | 92049-2100 | 4    | Seal-Oil               |  |  |  |  |
| ⑤92145  | 92145-2085 | 1    | Spring                 |  |  |  |  |
| ⑤92151A | 92151-2165 | 4    | Bolt-M6                |  |  |  |  |
| ⑤92152A | 92152-2077 | 4    | Collar                 |  |  |  |  |
| ⑤92200  | 92200-2128 | 4    | Washer                 |  |  |  |  |
| ⑤130    | 130G0814   | 4    | Bolt-Flanged           |  |  |  |  |
| ⑤311    | 311B0600   | 4    | Nut-Hex                |  |  |  |  |

Lubrication Equipment Assembly  
Kawasaki FD750D-BS03




## Lubrication Equipment Assembly

### Kawasaki FD750D-BS03

| Ref     | Part No.      | Qty. | Description        |  |  |  |  |
|---------|---------------|------|--------------------|--|--|--|--|
| ③11009  | 11009-2566    | 2    | Gasket-Plug, Drain |  |  |  |  |
| ③13107  | 13107-2281    | 1    | Shaft-Pump, Oil    |  |  |  |  |
| ③13280  | 13280-2061    | 1    | Holder-Pump, Oil   |  |  |  |  |
| ③14091  | 14091-2065    | 1    | Cover-Pump, Oil    |  |  |  |  |
| ③16115  | 16115-2126    | 1    | Cap-Filler, Oil    |  |  |  |  |
| ③16154  | 16154-1075    | 1    | Rotor-Pump, Outer  |  |  |  |  |
| ③16154A | 16154-1076    | 1    | Rotor-Pump, Inner  |  |  |  |  |
| ③16154B | 16154-1079    | 1    | Rotor-Pump         |  |  |  |  |
| ③32153  | 32153-2076-9H | 1    | Pipe-Gauge, Oil    |  |  |  |  |
| ③49065  | 49065-2071    | 1    | Filter-Oil         |  |  |  |  |
| ③49065A | 49065-2082    | 1    | Filter             |  |  |  |  |
| ③52005  | 52005-2132    | 1    | Gauge-Oil          |  |  |  |  |
| ③59051  | 59051-2354    | 1    | Gear-Spur, 33T     |  |  |  |  |
| ③92042  | 92042-014     | 2    | Pin                |  |  |  |  |
| ③92066  | 92066-2099    | 2    | Plug-Drain         |  |  |  |  |
| ③92144  | 92144-2053    | 1    | Spring             |  |  |  |  |
| ③130    | 130G0616      | 3    | Bolt               |  |  |  |  |
| ③130A   | 130G0625      | 2    | Bolt-Flanged       |  |  |  |  |
| ③600    | 600A1300      | 1    | Ball-Steel         |  |  |  |  |
| ③670    | 670B2010      | 1    | O-Ring (10Mm)      |  |  |  |  |
| ③670B   | 670B3025      | 1    | O-Ring             |  |  |  |  |

# Cooling Equipment Assembly

## Kawasaki FD750D-BS03




## Cooling Equipment Assembly

### Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description       |  |  |  |  |
|---------|------------|------|-------------------|--|--|--|--|
| ③11009  | 11009-3028 | 1    | Gasket            |  |  |  |  |
| ③11060  | 11060-2475 | 1    | Gasket-Thermostat |  |  |  |  |
| ③13107  | 13107-2097 | 1    | Shaft-Impeller    |  |  |  |  |
| ③16142  | 16142-2077 | 1    | Cover-Pump        |  |  |  |  |
| ③16160  | 16160-2127 | 1    | Body-Upper        |  |  |  |  |
| ③16160A | 16160-6002 | 1    | Body-Valve        |  |  |  |  |
| ③39062A | 39062-2083 | 1    | Hose-Cooling      |  |  |  |  |
| ③39062B | 39062-2084 | 1    | Hose-Cooling      |  |  |  |  |
| ③39062C | 39062-2089 | 1    | Hose-Cooling      |  |  |  |  |
| ③49044  | 49044-2063 | 1    | Pump-Water        |  |  |  |  |
| ③49054  | 49054-2058 | 1    | Thermostat        |  |  |  |  |
| ③49063  | 49063-1054 | 1    | Seal-Mechanical   |  |  |  |  |
| ③59051  | 59051-2355 | 1    | Gear-Spur, 25T    |  |  |  |  |
| ③59256  | 59256-2069 | 1    | Impeller          |  |  |  |  |
| ③59336  | 59336-2078 | 1    | Case-Pump         |  |  |  |  |
| ③92043  | 92043-2237 | 1    | Pin               |  |  |  |  |
| ③92049  | 92049-2111 | 1    | Seal-Oil          |  |  |  |  |
| ③92170  | 92170-1284 | 2    | Clamp             |  |  |  |  |
| ③92171  | 92171-2056 | 4    | Clamp             |  |  |  |  |
| ③92200  | 92200-2134 | 1    | Washer            |  |  |  |  |
| ③92200A | 92200-2135 | 1    | Washer            |  |  |  |  |
| ③130    | 130C0812   | 1    | Bolt-Flanged      |  |  |  |  |
| ③130A   | 130G0625   | 3    | Bolt-Flanged      |  |  |  |  |
| ③130B   | 130G0635   | 2    | Bolt-Flanged      |  |  |  |  |
| ③130C   | 130G0830   | 2    | Bolt-Flanged      |  |  |  |  |
| ③130D   | 130G0845   | 1    | Bolt              |  |  |  |  |
| ③130E   | 130G0860   | 2    | Bolt-Flanged      |  |  |  |  |
| ③130F   | 130G0880   | 4    | Bolt-Flanged      |  |  |  |  |
| ③171    | 171G0818   | 3    | Bolt-Stud         |  |  |  |  |
| ③551    | 551A0314   | 1    | Pin-Dowel         |  |  |  |  |
| ③670    | 670B1507   | 1    | O Ring            |  |  |  |  |

# Electric Equipment Assembly

## Kawasaki FD750D-BS03




## Electric Equipment Assembly

### Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description          |  |  |  |  |
|---------|------------|------|----------------------|--|--|--|--|
| ③11009  | 11009-2766 | 1    | Gasket               |  |  |  |  |
| ③11052  | 11052-2058 | 1    | Bracket              |  |  |  |  |
| ③21066  | 21066-2079 | 1    | Regulator-Voltage    |  |  |  |  |
| ③21121  | 21121-2090 | 1    | Coil-Ignition, No. 1 |  |  |  |  |
| ③21121A | 21121-2091 | 1    | Coil-Ignition, No. 2 |  |  |  |  |
| ③21193  | 21193-2177 | 1    | Flywheel ASM         |  |  |  |  |
| ③26004  | 26004-1093 | 1    | Fuse ASM             |  |  |  |  |
| ③26030  | 26030-2320 | 1    | Harness              |  |  |  |  |
| ③27010  | 27010-7001 | 1    | Switch               |  |  |  |  |
| ③59031  | 59031-2127 | 1    | Coil-Charging        |  |  |  |  |
| ③92009  | 92009-2273 | 4    | Screw                |  |  |  |  |
| ③92037  | 92037-2101 | 1    | Clamp                |  |  |  |  |
| ③92066  | 92066-2099 | 1    | Plug-Drain           |  |  |  |  |
| ③92070  | 92070-2110 | 2    | Plug-Spark, Bpr2Es   |  |  |  |  |
| ③92072  | 92072-1195 | 1    | Band                 |  |  |  |  |
| ③92151  | 92151-2097 | 1    | Bolt (12X30)         |  |  |  |  |
| ③92170  | 92170-2060 | 5    | Clamp                |  |  |  |  |
| ③92171  | 92171-2060 | 1    | Clamp                |  |  |  |  |
| ③92200  | 92200-2119 | 1    | Washer               |  |  |  |  |
| ③130    | 130G0520   | 4    | Bolt-Flanged         |  |  |  |  |
| ③130A   | 130G0630   | 2    | Bolt-Flanged         |  |  |  |  |
| ③130B   | 130G0812   | 3    | Bolt                 |  |  |  |  |
| ③130C   | 130G0816   | 2    | Bolt-Flanged         |  |  |  |  |
| ③214    | 214B0510   | 1    | Screw-Pan            |  |  |  |  |
| ③510    | 510A5100   | 1    | Key-Woodruff         |  |  |  |  |

# Control Equipment Assembly

## Kawasaki FD750D-BS03






## Control Equipment Assembly

### Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description       |  |  |  |  |
|---------|------------|------|-------------------|--|--|--|--|
| ③11051  | 11051-2113 | 1    | Bracket           |  |  |  |  |
| ③13168  | 13168-2466 | 1    | Lever-Throttle    |  |  |  |  |
| ③13168A | 13168-2467 | 1    | Lever-Choke       |  |  |  |  |
| ③16169  | 16169-2142 | 1    | Link-Choke        |  |  |  |  |
| ③16171  | 16171-2091 | 1    | Link              |  |  |  |  |
| ③21187  | 21187-2073 | 1    | Arm ASM           |  |  |  |  |
| ③39003  | 39003-2091 | 1    | Arm-Pivot         |  |  |  |  |
| ③39129  | 39129-2099 | 1    | Spring-Governor   |  |  |  |  |
| ③42036  | 42036-2060 | 1    | Sleeve            |  |  |  |  |
| ③49110  | 49110-2094 | 1    | Governor ASM      |  |  |  |  |
| ③49113  | 49113-2170 | 1    | Control Panel ASM |  |  |  |  |
| ③59226  | 59226-2328 | 1    | Panel-Control     |  |  |  |  |
| ③92002  | 92002-1902 | 1    | Bolt              |  |  |  |  |
| ③92002A | 92002-2269 | 1    | Bolt              |  |  |  |  |
| ③92009  | 92009-2381 | 2    | Screw             |  |  |  |  |
| ③92015  | 92015-2051 | 2    | Nut               |  |  |  |  |
| ③92022  | 92022-2372 | 1    | Washer-6X19X1.2   |  |  |  |  |
| ③92027  | 92027-1461 | 1    | Collar            |  |  |  |  |
| ③92037  | 92037-2209 | 2    | Clamp             |  |  |  |  |
| ③92143  | 92143-2135 | 2    | Collar-6X13X2.3   |  |  |  |  |
| ③92143A | 92143-2148 | 1    | Collar            |  |  |  |  |
| ③92144  | 92144-2052 | 1    | Spring            |  |  |  |  |
| ③92145  | 92145-2058 | 1    | Spring            |  |  |  |  |
| ③92145A | 92145-2095 | 1    | Spring            |  |  |  |  |
| ③92150  | 92150-2182 | 2    | Bolt (5X18)       |  |  |  |  |
| ③92200  | 92200-2035 | 1    | Washer            |  |  |  |  |
| ③92200A | 92200-2108 | 2    | Washer            |  |  |  |  |
| ③92200B | 92200-2120 | 1    | Washer            |  |  |  |  |
| ③92200C | 92200-2122 | 1    | Washer            |  |  |  |  |
| ③130    | 130B0630   | 2    | Bolt-Flanged      |  |  |  |  |
| ③130A   | 130G0614   | 2    | Bolt              |  |  |  |  |
| ③311    | 311B0600   | 1    | Nut-Hex           |  |  |  |  |
| ③312    | 312B0500   | 2    | Nut-Hex           |  |  |  |  |
| ③411    | 411b0600   | 1    | Washer-Plain      |  |  |  |  |
| ③482    | 482J7000   | 1    | Circlip-Type E    |  |  |  |  |


# Carburetor Assembly

## Kawasaki FD750D-BS03




## Carburetor Assembly Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description         |  |  |  |  |
|---------|------------|------|---------------------|--|--|--|--|
| ③11060  | 11060-2468 | 1    | Gasket-Intake       |  |  |  |  |
| ③11060A | 11060-2469 | 1    | Gasket-Intake       |  |  |  |  |
| ③11060B | 11060-2471 | 2    | Gasket-Pipe, Intake |  |  |  |  |
| ③11061B | 11061-2075 | 1    | Gasket              |  |  |  |  |
| ③15003  | 15003-2776 | 1    | Carburetor ASM      |  |  |  |  |
| ③16060  | 16060-2194 | 1    | Pipe-Intake         |  |  |  |  |
| ③16073  | 16073-2206 | 1    | Insulator           |  |  |  |  |
| ③16146  | 16146-2227 | 1    | Cover ASM           |  |  |  |  |
| ③16183  | 16183-2006 | 1    | Float ASM           |  |  |  |  |
| ③16184  | 16184-2004 | 1    | Float Chamber ASM   |  |  |  |  |
| ③16185  | 16185-2036 | 1    | Throttle Valve ASM  |  |  |  |  |
| ③16186  | 16186-2036 | 1    | Choke Valve ASM     |  |  |  |  |
| ③23013  | 23013-2059 | 1    | Screw ASM           |  |  |  |  |
| ③23013A | 23013-2060 | 1    | Screw ASM           |  |  |  |  |
| ③59076  | 59076-2065 | 1    | Manifold-Intake     |  |  |  |  |
| ③92037  | 92037-1610 | 1    | Clamp               |  |  |  |  |
| ③92063  | 92063-2400 | 1    | Jet-Main            |  |  |  |  |
| ③92063B | 92063-2401 | 2    | Jet-Main (No. 98.8) |  |  |  |  |
| ③92063C | 92063-2412 | 1    | Jet-Main (No. 93.8) |  |  |  |  |
| ③92064  | 92064-2113 | 2    | Jet-Pilot           |  |  |  |  |
| ③130    | 130G0825   | 8    | Bolt                |  |  |  |  |
| ③130A   | 130T06110  | 4    | Bolt-Flanged        |  |  |  |  |
| ③701    | 701Q061000 | 1    | Tube-Pvc            |  |  |  |  |



## Piston and Crankshaft Assembly Kawasaki FD750D-BS03

| Ref    | Part No.   | Qty. | Description        |  |  |  |  |
|--------|------------|------|--------------------|--|--|--|--|
| ③13001 | 13001-2125 | 2    | Piston-Engine      |  |  |  |  |
| ③13002 | 13002-2069 | 2    | Pin-Piston         |  |  |  |  |
| ③13008 | 13008-6007 | 2    | Ring-Set, Piston   |  |  |  |  |
| ③13251 | 13251-2058 | 2    | Connecting Rod ASM |  |  |  |  |
| ③49119 | 49119-2198 | 1    | Crankshaft ASM     |  |  |  |  |
| ③59051 | 59051-2358 | 1    | Gear-Spur, 33T     |  |  |  |  |
| ③92036 | 92036-008  | 4    | Ring-Snap          |  |  |  |  |
| ③92151 | 92151-2150 | 4    | Bolt               |  |  |  |  |
| ③510   | 510A5100   | 1    | Key-Woodruff       |  |  |  |  |




## Air Filter and Muffler Assembly Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description        |  |  |  |  |
|---------|------------|------|--------------------|--|--|--|--|
| ③11051  | 11051-2088 | 1    | Bracket            |  |  |  |  |
| ③11060  | 11060-2467 | 2    | Gasket-Muffler     |  |  |  |  |
| ③11060A | 11060-2474 | 1    | Gasket-Filter, Air |  |  |  |  |
| ③14073  | 14073-2075 | 1    | Duct-Lower         |  |  |  |  |
| ③14073A | 14073-2076 | 1    | Duct-Upper         |  |  |  |  |
| ③16060  | 16060-2197 | 1    | Pipe-Intake        |  |  |  |  |
| ③92037  | 92037-1654 | 1    | Clamp              |  |  |  |  |
| ③92093  | 92093-2118 | 1    | Seal               |  |  |  |  |
| ③92170  | 92170-2075 | 1    | Clamp              |  |  |  |  |
| ③130    | 130G0620   | 3    | Bolt-Flanged       |  |  |  |  |
| ③317    | 317R0800   | 1    | Nut-Hex            |  |  |  |  |
| ③461    | 461F0800   | 1    | Washer-Spring      |  |  |  |  |



# Starter Assembly

## Kawasaki FD750D-BS03



## Starter Assembly Kawasaki FD750D-BS03

| Ref     | Part No.   | Qty. | Description      |  |  |  |  |
|---------|------------|------|------------------|--|--|--|--|
| ③11012  | 11012-2226 | 1    | Cap              |  |  |  |  |
| ③13081  | 13081-2108 | 1    | Clutch ASM       |  |  |  |  |
| ③13091  | 13091-2068 | 1    | Brush Holder     |  |  |  |  |
| ③13168  | 13168-2131 | 1    | Lever            |  |  |  |  |
| ③14024  | 14024-2205 | 1    | Cover            |  |  |  |  |
| ③16073  | 16073-2098 | 1    | Insulator        |  |  |  |  |
| ③16146  | 16146-2187 | 1    | Cover ASM        |  |  |  |  |
| ③16146A | 16146-2225 | 1    | Cover ASM        |  |  |  |  |
| ③21039  | 21039-2059 | 4    | Brush            |  |  |  |  |
| ③21040  | 21040-2052 | 4    | Spring-Brush     |  |  |  |  |
| ③21080  | 21080-2054 | 1    | Armature         |  |  |  |  |
| ③21163  | 21163-2120 | 1    | Starter-Electric |  |  |  |  |
| ③27010  | 27010-2122 | 1    | Switch           |  |  |  |  |
| ③32085  | 32085-2097 | 1    | Stopper          |  |  |  |  |
| ③92002  | 92002-2277 | 2    | Bolt             |  |  |  |  |
| ③92015  | 92015-2146 | 2    | Nut              |  |  |  |  |
| ③92015A | 92015-2147 | 1    | Nut              |  |  |  |  |
| ③92033  | 92033-2081 | 1    | Ring-Snap        |  |  |  |  |
| ③130    | 130G0835   | 2    | Bolt-Flanged     |  |  |  |  |
| ③317    | 317B0800   | 2    | Nut              |  |  |  |  |
| ③461    | 461F0800   | 2    | Washer-Spring    |  |  |  |  |



## Fuel Pump and Filter Assembly Kawasaki FD750D-BS03

| Ref    | Part No.   | Qty. | Description |
|--------|------------|------|-------------|
| ④49019 | 49019-1055 | 1    | Filter-Fuel |
| ④49040 | 49040-2065 | 1    | Pump-Fuel   |
| ④59071 | 59071-2119 | 1    | Joint       |
| ④92170 | 92170-2042 | 2    | Clamp       |
| ④92190 | 92190-2095 | 1    | Tube        |



## Attachments and Accessories

For 74251 - Z587L Z Master, With 60in TURBO FORCE Side Discharge Mower

| Product Name                        | Model/Part  |
|-------------------------------------|-------------|
| Belt-Seat .....                     | 100-4928    |
| Blade-Mid Flow, 20.5 Inch .....     | 105-7715-03 |
| Blade-Lo Flow, 20.5 Inch .....      | 105-7716-03 |
| Blade-Hi Flow, 20.5 Inch .....      | 105-7718-03 |
| Blade-Recycler, 20.5 Inch .....     | 105-7777-03 |
| Blade-Atomic, 20.5 Inch .....       | 105-8777-03 |
| 60 Inch Recycler Kit .....          | 107-1611    |
| 6 Pack Blade, 20.5in Hi-Flow .....  | 108-1114    |
| 6 Pack-Blade, 20.5in Atomic .....   | 108-1115    |
| 6 Pack Blade, 20.5in Mid-Flow ..... | 108-1123    |
| 6 Pack-Blade, 20.5in Lo Flow .....  | 108-1128    |
| 6 Pack-Blade, 20.5in Recycler ..... | 110-0405    |
| Hitch Kit .....                     | 99-8925     |

## NOTES

## NOTES

