



22in Recycler[®] Lawnmower

Model No. 20012 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Deck, Side Chute and Rear Door Assembly 3	Engine Assembly No. 1 Tecumseh LV195EA-362003D 10
Rear Axle Assembly 4	Engine Assembly No.2 Tecumseh LV195EA-362003D 12
Front Axle and Transmission Assembly 5	Carburetor Assembly No. 640350 Tecumseh LV195EA-362003D 14
Transmission Assembly No. 106-3955 6	Rewind Starter Assembly No. 590739 Tecumseh LV195EA-362003D 15
Engine and Blade Assembly 7	Recoil Starter Assembly No. 590702 (Optional) Tecumseh LV195EA-362003D 16
Bail and Handle Assembly 8		
Rear Bag Assembly 9		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head

Footnotes


- | | |
|--|----------------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain from your local Tecumseh dealer | ❹ Included in Repair Kit 632760B |
| ❺ Included in Gasket Kit 37613A | |



Deck, Side Chute and Rear Door Assembly

Ref	Part No.	Qty.	Description
1	322-3	4	Screw-HH
2	105-1808-03	2	Plate-HOC, Front
3	104-8694-03	1	Baffle-Front
4	3296-29	8	Nut-Lock, NI
5	104-7916	1	Housing
5:1	94-8072	1	Decal-Danger
6	105-1296	1	Decal-Deck
7	32128-32	2	Nut-HHF
8	3229-11	2	Screw-CARR
9	99-5293	1	Spring-Torsion
10	99-5292	1	Bracket-Cover
11	99-5291	1	Rod-Cover
12	105-3028	1	Chute-Discharge, Side
13	106-8376	1	Discharge Door ASM
13:2	107-0795	1	Latch-Door
13:3	107-7456	1	Cap-Door
13:4	107-7461	1	Screw-Plastite
15	32112-6	1	Nut-Push
16	110-1635	1	11 Inch RH HOC Plate ASM
18	105-3032	1	Spring-Door, Rear
19	105-1324	1	Rear Door ASM
19:2	104-7909	1	Decal-Warning
19:3	104-7908	1	Decal-Warning
22	46-6810	1	Screw And Washer ASM


Ref	Part No.	Qty.	Description
23	46-8091	2	Screw-HWH
24	105-1842	1	Plug-Discharge, Rear
25	105-1827	1	Rod-Pivot, Rear Door
27	104-9369	1	Plug-Dome
28	110-1634	1	11 Inch LH HOC Plate ASM
29	105-3006	4	Washer-Stepped
30	105-3047	1	Baffle-Rear



Front Axle and Transmission Assembly

Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder
2	105-1815	2	Wheel Gear ASM
2:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	104-8670	2	Gear-Pinion, 13T
5	105-6840	6	Washer-Thrust
7	108-3794	2	Cover-Wheel
7:1		1	Cover
7:2	614426	1	Washer-Stepped
8	105-1807	2	Arm-Pivot, Front
9	105-1809	2	Arm-Spring
10	105-3042	2	Knob-Lever, HOC
11	32151-36	2	Ring-Retaining
12	104-8698	2	Retainer-Bearing, HOC
13	104-8699	2	Bearing-Ball
14	39-9650	2	Spring-Compression
15	612066	2	Key
16	106-3955	1	Transmission ASM
17	108-9756	1	Gasket-Gearbox
18	46-8091	2	Screw-HWH
19	105-1833-03	1	Bracket-Pivot, Fwd
20	32144-4	2	Screw-HWH
21	92-5791	1	Spacer
22	91-2258	1	V-Belt


Ref	Part No.	Qty.	Description
23	104-8691	2	Pulley-Half, Front
24	3256-24	1	Washer-Flat
25	3296-5	1	Nut-Lock
26	105-1839	1	Cover-Belt, Front
27	36-4780	1	Washer



Transmission Assembly No. 106-3955

Ref	Part No.	Qty.	Description
1	32144-4	4	Screw-HWH
2	3285-19	1	Pin-Groove
3	36-4780	1	Washer
4	92-5790	1	Pinion
5	100-1048	1	Bearing-Ball
6	104-8671	1	Gear-Bevel, 37T
7	106-3957	1	Shaft-Output
8	104-8673	2	Bushing-Shaft, Output
9	104-8674	1	Gearcase-Upper
10	104-8675-03	1	Cover-Gearcase
11	105-6839	1	Gasket-Gearcase

--	--	--	--



Engine and Blade Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
3	108-3766-03	1	Support-Blade				
4	108-9764-03	1	Blade-22 Inch				
5	106-3987	1	Blade Driver ASM				
6	106-3999	1	Spacer-Driver				
7	95-1726	3	Screw-Taptite				
8	32144-85	1	Screw-HWH				
9	105-3031-03	1	Guide-Belt				
② ⑤ 10		1	Engine-Tecumseh, Lv195Ea-362003D				
10:3	105-6815	1	Decal-Recoil				
11	92-1701	1	Stop-Rope				
13	105-6832	1	Decal-Primer				
14	106-8387	1	Muffler Guard ASM				
14:1	106-5517	1	Decal-Surface, Hot				


Engine Assembly No. 1

Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
①1	37465	1	Cylinder ASM	①135	35395	1	Spark Plug-Resistor (Rj19Lm)
①2	26727	2	Pin-Dowel	①150	31672	2	Spring-Valve
①6	33734	1	Element-Breather	①151	31673	2	Cap-Spring, Valve
①7	36557	1	Breather ASM	①151A	40017	1	Seal-Valve, Intake
①12	37944	1	Tube-Breather	①166	37694	1	Shroud-Engine
①12A	36558	1	Breather Cover And Tube ASM	①①169	36783	1	Gasket-Cover, Valve
①12B	36694	1	Elbow-Tube, Breather	①172	36784	1	Cover-Valve
①14	28277	1	Washer	①178	29752	2	Nut And Lock Washer ASM (1/4-28)
①15	30589	1	Governor Rod ASM	①182	6201	2	Screw (1/4-28 X 7/8)
①16	34839A	1	Lever-Governor	①①184	26756	1	Gasket (Carburetor To Intake Pipe)
①17	31335	1	Clamp-Lever, Governor	①185	37466	1	Pipe-Intake
①18	651018	1	Screw (T-15, 8-32 X 19/64)	①186	32653	1	Link-Governor
①19	36281	1	Spring-Extension	①189	650839	2	Screw (1/4-20 X 3/8)
①20	32600	1	Seal-Oil	①191	36559A	1	Bracket-Brake
①30	37692	1	Crankshaft	①195	610973	1	Terminal
①40	40044	1	Piston, Pin And Ring Set (STD.)	①207	34336A	1	Link-Throttle
①40	40045	1	Piston, Pin And Ring Set (.010In Os)	①216	33086	1	Lever-Adjusting, Rpm
①42	40006	1	Ring Set (STD.)	①223	650451	2	Screw (1/4-20 X 1)
①42	40007	1	Ring Set (.010In Os)	①①224	36786	1	Gasket-Pipe, Intake
①43	20381	2	Ring-Retaining, Piston Pin	①238	650932	2	Screw (10-32 X 49/64)
①45	36777	1	Connecting Rod ASM	①①239	34338	1	Gasket-Air Cleaner
①46	32610A	2	Bolt-Rod, Connecting	①241	36919	1	Collar-Air Cleaner
①48	27241	2	Lifter-Valve	①245	36905	1	Filter-Air Cleaner
①50	37460	1	Camshaft ASM (Exhaust Mcr)	①250	37122	1	Cover-Air Cleaner
①52	29914	1	Oil Pump ASM	①260	37696A	1	Housing-Blower
①62	650760	2	Screw (8-32 X 3/8In)	①262	650831	2	Screw (1/4-20 X 1/2)
①65	30200	4	Screw (10-24 X 9/16)	①275	37498	1	Muffler
①①69	37609	1	Gasket-Flange, Mounting	①277	650988	2	Screw (1/4-20 X 2-9/32)
①70	37608A	1	Flange-Mounting	①285	35000A	1	Cup-Starter
①72	37614	1	Plug-Drain, Oil	①287	650926	2	Screw (8-32 X 21/64)
①75	27897	1	Seal-Oil	①290	37962	1	Line-Fuel
①80	30574A	1	Shaft-Governor	①292	26460	2	Clamp-Line, Fuel
①81	30590A	1	Washer	①298	28763	1	Screw (10-32 X 35/64)
①82	30591	1	Governor Gear ASM	①300	37947	1	Fuel Tank ASM
①83	30588A	1	Spool-Governor	①301	37844	1	Fuel Cap ASM
①86	650488	6	Screw (1/4-20 X 1-1/4)	①305	35647A	1	Tube-Fill, Oil
①89	611298	1	Key-Flywheel	①①306	37610	1	O-Ring
①90	611299	1	Flywheel	①307	35499	1	O-Ring
①92	650815	1	Washer-Belleville	①309	650562	1	Screw (10-32 X 1/2)
①93	650816	1	Nut-Flywheel	①309A	650783	1	Screw (10-24 X 3/4)
①100	34443C	1	Ignition-Solid State	①310	35648	1	Dipstick
①101	610118	1	Cover-Spark Plug	①311A	37611	1	Bracket-Holddown
①103	651007	2	Screw (T-15, 10-24 X 15/16)	①313	34080	1	Spacer
①104	37480	1	Bushing-Cam	①347	650898A	1	Screw (10-32 X 27/32)
①110A	37047	1	Wire-Ground				
①①119	37796	1	Gasket-Head, Cylinder				
①120	37714	1	Head-Cylinder				
①125	36780	1	Valve-Exhaust (1/32 Os)				
①125	37288	1	Valve-Exhaust (STD.)				
①126	37289	1	Valve-Intake (STD.)				
①130	6021A	8	Screw (5/16-18 X 1-7/16)				


Engine Assembly No.2

Tecumseh LV195EA-362003D



Engine Assembly No.2 Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description				
3370	35977	1	Decal-Warning				
3370	37695	1	Decal-Primer				
3370	36261	1	Decal-Lubrication				
3380	640350	1	Carburetor ASM (Includes Gasket #26756)				
3390	590739	1	Rewind Starter ASM				
3400	37613A	1	Gasket Set				
3416	37530	1	Spark Arrestor Kit				
130	806173B	1	Replacement Engine				
130	750876	1	Shortblock-Replacement				



Carburetor Assembly No. 640350 Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description
③0	640350	1	Carburetor ASM (Includes Gasket #26756)
③1	631615	1	Throttle Shaft And Lever ASM
③2	631767	1	Spring-Return, Throttle
③44	631184	1	Washer-Seal, Dust
③45	631183	1	Seal-Dust, Throttle
③6	640070	1	Shutter-Throttle
③47	650506	1	Screw-Shutter
③16	631807	1	Fitting-Fuel
③17	651025	1	Screw-Throttle/Idle Speed
③18	630766	1	Spring-Tension
③20	640016	1	Screw-Restrictor, Idle
③20A	640200	1	Cap-Screw, Idle Restrictor
③25	631867	1	Bowl-Float
③427	631024	1	Shaft-Float
③28	632802	1	Float (Plastic)
③429	631028	1	O Ring-Bowl, Float
③430	631021A	1	Inlet Needle, Seat And Clip ASM (Includes 31)
③31	631022	1	Clip-Spring
③35	640351	1	Primer Bulb/Valve Repair Kit
③36	640080	1	Tube-Nozzle, Main
③36A	632766	1	Tube-Carburetor
③437	632547	2	O Ring-Tube, Main Nozzle

Ref	Part No.	Qty.	Description
③40	640030	1	Nut-Bowl, High Speed
③444	27110A	1	Washer-Bowl
③447	630748	1	Welch Plug-Idle Mixture Well
③448	631027	2	Welch Plug-Atmospheric Vent
③60	632760B	1	Repair Kit

NOTES

NOTES

NOTES

