



22in Recycler[®] Lawnmower

Model No. 20012 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Deck, Side Chute and Rear Door Assembly	 3	Engine Assembly No. 1 Tecumseh LV195EA-362003D	 10
Rear Axle Assembly	 4	Engine Assembly No.2 Tecumseh LV195EA-362003D	 12
Front Axle and Transmission Assembly	 5	Carburetor Assembly No. 640350 Tecumseh LV195EA-362003D	 14
Transmission Assembly No. 106-3955	 6	Rewind Starter Assembly No. 590739 Tecumseh LV195EA-362003D	 15
Engine and Blade Assembly	 7	Recoil Starter Assembly No. 590702 (Optional) Tecumseh LV195EA-362003D	 16
Bail and Handle Assembly	 8		
Rear Bag Assembly	 9		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HS. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head

Footnotes


- | | |
|--|----------------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain from your local Tecumseh dealer | ❹ Included in Repair Kit 632760B |
| ❺ Included in Gasket Kit 37613A | |



Deck, Side Chute and Rear Door Assembly


Ref	Part No.	Qty.	Description
1	322-3	4	Screw-HH
2	105-1808-03	2	Plate-HOC, Front
3	104-8694-03	1	Baffle-Front
4	3296-29	8	Nut-Lock, NI
5	104-7916	1	Housing
5:1	94-8072	1	Decal-Danger
6	105-1296	1	Decal-Deck
7	32128-32	2	Nut-HHF
8	3229-11	2	Screw-CARR
9	99-5293	1	Spring-Torsion
10	99-5292	1	Bracket-Cover
11	99-5291	1	Rod-Cover
12	105-3028	1	Chute-Discharge, Side
13	106-8376	1	Discharge Door ASM
13:2	107-0795	1	Latch-Door
13:3	107-7456	1	Cap-Door
13:4	107-7461	1	Screw-Plastite
15	32112-6	1	Nut-Push
16	110-1635	1	11 Inch RH HOC Plate ASM
18	105-3032	1	Spring-Door, Rear
19	105-1324	1	Rear Door ASM
19:2	104-7909	1	Decal-Warning
19:3	104-7908	1	Decal-Warning
22	46-6810	1	Screw And Washer ASM

Ref	Part No.	Qty.	Description
23	46-8091	2	Screw-HWH
24	105-1842	1	Plug-Discharge, Rear
25	105-1827	1	Rod-Pivot, Rear Door
27	104-9369	1	Plug-Dome
28	110-1634	1	11 Inch LH HOC Plate ASM
29	105-3006	4	Washer-Stepped
30	105-3047	1	Baffle-Rear




Rear Axle Assembly

Ref	Part No.	Qty.	Description				
1	105-1843	1	Shield-Trailing				
2	105-1811	1	Brace-Plate, HOC				
3	32153-3	2	Nut-Hex, Side Deform				
4	110-1612	2	Bushing-Mount				
5	105-3042	2	Knob-Lever, HOC				
6	110-1630	2	Arm-11 Inch Spring, Rear				
7	105-1819	2	Arm-Pivot, Rear				
8	110-7466	2	Washer-Wheel Bolt				
9	110-1632	2	11 In Wheel ASM				
10	614650	2	Bolt-Shoulder				
11	322-6	4	Screw-HH				
12	105-3048	2	Washer-Flat				
13	104-9373	3	Plug-Dome				
14	104-9368	1	Plug-Dome				
15	322-3	2	Screw-HH				
16	3229-11	4	Screw-CARR				
17	3296-16	4	Nut-Lock, NI				




Front Axle and Transmission Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder	23	104-8691	2	Pulley-Half, Front
2	105-1815	2	Wheel Gear ASM	24	3256-24	1	Washer-Flat
2:1	27-6250	2	Bushing	25	3296-5	1	Nut-Lock
3	65-2720	4	Klipring-Locking	26	105-1839	1	Cover-Belt, Front
4	104-8670	2	Gear-Pinion, 13T	27	36-4780	1	Washer
5	105-6840	6	Washer-Thrust				
7	108-3794	2	Cover-Wheel				
1 2 7:1		1	Cover				
7:2	614426	1	Washer-Stepped				
8	105-1807	2	Arm-Pivot, Front				
9	105-1809	2	Arm-Spring				
10	105-3042	2	Knob-Lever, HOC				
11	32151-36	2	Ring-Retaining				
12	104-8698	2	Retainer-Bearing, HOC				
13	104-8699	2	Bearing-Ball				
14	39-9650	2	Spring-Compression				
15	612066	2	Key				
16	106-3955	1	Transmission ASM				
17	108-9756	1	Gasket-Gearbox				
18	46-8091	2	Screw-HWH				
19	105-1833-03	1	Bracket-Pivot, Fwd				
20	32144-4	2	Screw-HWH				
21	92-5791	1	Spacer				
22	91-2258	1	V-Belt				




Transmission Assembly No. 106-3955

Ref	Part No.	Qty.	Description				
1	32144-4	4	Screw-HWH				
2	3285-19	1	Pin-Groove				
3	36-4780	1	Washer				
4	92-5790	1	Pinion				
5	100-1048	1	Bearing-Ball				
6	104-8671	1	Gear-Bevel, 37T				
7	106-3957	1	Shaft-Output				
8	104-8673	2	Bushing-Shaft, Output				
9	104-8674	1	Gearcase-Upper				
10	104-8675-03	1	Cover-Gearcase				
11	105-6839	1	Gasket-Gearcase				



Engine and Blade Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
3	108-3766-03	1	Support-Blade				
4	108-9764-03	1	Blade-22 Inch				
5	106-3987	1	Blade Driver ASM				
6	106-3999	1	Spacer-Driver				
7	95-1726	3	Screw-Taptite				
8	32144-85	1	Screw-HWH				
9	105-3031-03	1	Guide-Belt				
2 10			1 Engine-Tecumseh, Lv195Ea-362003D				
10:3	105-6815	1	Decal-Recoil				
11	92-1701	1	Stop-Rope				
13	105-6832	1	Decal-Primer				
14	106-8387	1	Muffler Guard ASM				
14:1	106-5517	1	Decal-Surface, Hot				




Bail and Handle Assembly

Ref	Part No.	Qty.	Description				
1	104-8677	1	Cable-Brake				
2	108-8162	2	Knob-Locking				
3	104-8680-05	1	Handle-Upper				
4	106-8330	1	Guide-Rope				
5	3256-1	2	Washer-Flat				
6	3296-73	2	Nut-Lock, NI				
7	107-0757	1	Stop-Pivot				
8	105-6800-03	1	Bail-Brake				
9	105-1837-03	1	Bail-Control				
10	104-8682	1	Stop-Pivot				
11	95-4453	1	Screw				
12	92-7729	1	Anchor-Cable, Upper				
13	105-1845	1	Cable-Traction				
14	92-2260	2	Screw-Handle				
15	107-0784-05	1	Handle-Lower				
16	106-6805	2	Guide-Cable				
18	614249	1	Strap-Tie				



Engine Assembly No. 1

Tecumseh LV195EA-362003D




Engine Assembly No. 1

Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
③1	37465	1	Cylinder ASM	③135	35395	1	Spark Plug-Resistor (Rj19Lm)
③2	26727	2	Pin-Dowel	③150	31672	2	Spring-Valve
③6	33734	1	Element-Breather	③151	31673	2	Cap-Spring, Valve
③7	36557	1	Breather ASM	③151A	40017	1	Seal-Valve, Intake
③12	37944	1	Tube-Breather	③166	37694	1	Shroud-Engine
③12A	36558	1	Breather Cover And Tube ASM	③③169	36783	1	Gasket-Cover, Valve
③12B	36694	1	Elbow-Tube, Breather	③172	36784	1	Cover-Valve
③14	28277	1	Washer	③178	29752	2	Nut And Lock Washer ASM (1/4-28)
③15	30589	1	Governor Rod ASM	③182	6201	2	Screw (1/4-28 X 7/8)
③16	34839A	1	Lever-Governor	③③184	26756	1	Gasket (Carburetor To Intake Pipe)
③17	31335	1	Clamp-Lever, Governor	③185	37466	1	Pipe-Intake
③18	651018	1	Screw (T-15, 8-32 X 19/64)	③186	32653	1	Link-Governor
③19	36281	1	Spring-Extension	③189	650839	2	Screw (1/4-20 X 3/8)
③20	32600	1	Seal-Oil	③191	36559A	1	Bracket-Brake
③30	37692	1	Crankshaft	③195	610973	1	Terminal
③40	40044	1	Piston, Pin And Ring Set (STD.)	③207	34336A	1	Link-Throttle
③40	40045	1	Piston, Pin And Ring Set (.010In Os)	③216	33086	1	Lever-Adjusting, Rpm
③42	40006	1	Ring Set (STD.)	③223	650451	2	Screw (1/4-20 X 1)
③42	40007	1	Ring Set (.010In Os)	③③224	36786	1	Gasket-Pipe, Intake
③43	20381	2	Ring-Retaining, Piston Pin	③238	650932	2	Screw (10-32 X 49/64)
③45	36777	1	Connecting Rod ASM	③③239	34338	1	Gasket-Air Cleaner
③46	32610A	2	Bolt-Rod, Connecting	③241	36919	1	Collar-Air Cleaner
③48	27241	2	Lifter-Valve	③245	36905	1	Filter-Air Cleaner
③50	37460	1	Camshaft ASM (Exhaust Mcr)	③250	37122	1	Cover-Air Cleaner
③52	29914	1	Oil Pump ASM	③260	37696A	1	Housing-Blower
③62	650760	2	Screw (8-32 X 3/8In)	③262	650831	2	Screw (1/4-20 X 1/2)
③65	30200	4	Screw (10-24 X 9/16)	③275	37498	1	Muffler
③③69	37609	1	Gasket-Flange, Mounting	③277	650988	2	Screw (1/4-20 X 2-9/32)
③70	37608A	1	Flange-Mounting	③285	35000A	1	Cup-Starter
③72	37614	1	Plug-Drain, Oil	③287	650926	2	Screw (8-32 X 21/64)
③75	27897	1	Seal-Oil	③290	37962	1	Line-Fuel
③80	30574A	1	Shaft-Governor	③292	26460	2	Clamp-Line, Fuel
③81	30590A	1	Washer	③298	28763	1	Screw (10-32 X 35/64)
③82	30591	1	Governor Gear ASM	③300	37947	1	Fuel Tank ASM
③83	30588A	1	Spool-Governor	③301	37844	1	Fuel Cap ASM
③86	650488	6	Screw (1/4-20 X 1-1/4)	③305	35647A	1	Tube-Fill, Oil
③89	611298	1	Key-Flywheel	③③306	37610	1	O-Ring
③90	611299	1	Flywheel	③307	35499	1	O-Ring
③92	650815	1	Washer-Belleville	③309	650562	1	Screw (10-32 X 1/2)
③93	650816	1	Nut-Flywheel	③309A	650783	1	Screw (10-24 X 3/4)
③100	34443C	1	Ignition-Solid State	③310	35648	1	Dipstick
③101	610118	1	Cover-Spark Plug	③311A	37611	1	Bracket-Holddown
③103	651007	2	Screw (T-15, 10-24 X 15/16)	③313	34080	1	Spacer
③104	37480	1	Bushing-Cam	③347	650898A	1	Screw (10-32 X 27/32)
③110A	37047	1	Wire-Ground				
③③119	37796	1	Gasket-Head, Cylinder				
③120	37714	1	Head-Cylinder				
③125	36780	1	Valve-Exhaust (1/32 Os)				
③125	37288	1	Valve-Exhaust (STD.)				
③126	37289	1	Valve-Intake (STD.)				
③130	6021A	8	Screw (5/16-18 X 1-7/16)				

Engine Assembly No.2


Tecumseh LV195EA-362003D



Engine Assembly No.2


Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description
③370	35977	1	Decal-Warning
③370	37695	1	Decal-Primer
③370	36261	1	Decal-Lubrication
③380	640350	1	Carburetor ASM (Includes Gasket #26756)
③390	590739	1	Rewind Starter ASM
③400	37613A	1	Gasket Set
③416	37530	1	Spark Arrestor Kit
①③0	806173B	1	Replacement Engine
①③0	750876	1	Shortblock-Replacement







Carburetor Assembly No. 640350 Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
30	640350	1	Carburetor ASM (Includes Gasket #26756)	40	640030	1	Nut-Bowl, High Speed
31	631615	1	Throttle Shaft And Lever ASM	44	27110A	1	Washer-Bowl
32	631767	1	Spring-Return, Throttle	47	630748	1	Welch Plug-Idle Mixture Well
44	631184	1	Washer-Seal, Dust	48	631027	2	Welch Plug-Atmospheric Vent
45	631183	1	Seal-Dust, Throttle	60	632760B	1	Repair Kit
36	640070	1	Shutter-Throttle				
47	650506	1	Screw-Shutter				
36	631807	1	Fitting-Fuel				
37	651025	1	Screw-Throttle/Idle Speed				
38	630766	1	Spring-Tension				
39	640016	1	Screw-Restrictor, Idle				
20A	640200	1	Cap-Screw, Idle Restrictor				
25	631867	1	Bowl-Float				
47	631024	1	Shaft-Float				
28	632802	1	Float (Plastic)				
29	631028	1	O Ring-Bowl, Float				
30	631021A	1	Inlet Needle, Seat And Clip ASM (Includes 31)				
31	631022	1	Clip-Spring				
35	640351	1	Primer Bulb/Valve Repair Kit				
36	640080	1	Tube-Nozzle, Main				
36A	632766	1	Tube-Carburetor				
47	632547	2	O Ring-Tube, Main Nozzle				




This illustration may not depict actual equipment and is for reference purposes only.






Rewind Starter Assembly No. 590739

Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description				
③1	590739	1	Rewind Starter ASM				
③2	590618A	1	Pulley And Rewind Spring ASM				
③3	590772	1	Repair Kit				
③4	590701	1	Handle-Starter				
③5	590535	1	Rope-Starter (98In X 9/64In Diameter)				



This illustration may not depict actual equipment and is for reference purposes only.



Recoil Starter Assembly No. 590702 (Optional)
Tecumseh LV195EA-362003D

Ref	Part No.	Qty.	Description				
③1	590702	1	Starter-Recoil				
③2	590700	1	Pulley And Rewind Spring ASM				
③3	590774	1	Repair Kit				
③4	590701	1	Handle-Starter				
③5	590535	1	Rope-Starter (98In X 9/64In Diameter)				

NOTES

NOTES

NOTES

