Form Number 3354-683 Rev A

Dethatching Reel
Greensmaster® 3000 Series

Model No. 04496 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2005
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page	Description	Page
Height-of-Cut Assembly	 3	Dethatcher Shaft Assembly	 5
Reel Drive Assembly	 4	Roll and Scraper Assembly	 6
		Roller Assembly No. 95-5943	 7

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
INC. . . . . incorporated
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over-protection-system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

Footnotes


❶ Not illustrated

❷ Not serviced separately




Height-of-Cut Assembly

Ref	Part No.	Qty.	Description
2	33025-00	2	Nut-Lock
5	95-1633	2	HOC Adjust ASM
6	3296-5	2	Nut-Lock
7	95-1638	2	Bracket-Rear, HOC Adjust
8	33014-00	2	Nut-Hex
9	99-8168	2	Collar-HOC
10	33114-030	2	Screw-HH
11	33125-025	2	Screw-CARR
12	3256-24	2	Washer-Flat
13	65-8600	2	Knob-Adjustment, Height
14	10-5060	2	Bracket-HOC
15	3296-29	2	Nut-Lock, NI
16	3256-23	2	Washer-Flat
17	10-5010	2	Screw-Adjustment, Roller
18	3253-3	2	Washer-Lock
19	321-4	2	Screw-HH
20	3-7253	2	Bolt-Carriage
21	3255-8	4	Washer-Lock
22	322-5	4	Screw-HH
23	94-2958	2	Stud-Ball
24	3254-6	2	Washer-Lock, Internal
25	99-8189	1	Plate-Gauge,.060
26	99-8188	1	Plate-Gauge,.120
27	99-8187	1	Plate-Gauge,.250




Reel Drive Assembly

Ref	Part No.	Qty.	Description
2	2410-30	1	Cap-Plastic
3	302-5	2	Fitting-Grease
4	95-7148	2	Housing-Bearing
5	93-1394	1	Nut-Spline
6	94-3405	2	Bearing-Ball
6:1	3245-35	1	Screw-Set
6:2	251-77	1	Lockcollar-Bearing
10	48-9590	4	Washer-Lock
11	33115-025	4	Screw-HH
12	95-1642-01	1	Weight-Counter
13	3256-24	2	Washer-Flat
14	93-2569	4	Screw-HHF
15	94-9214	1	Nut-Spline, LH
❷16		1	Dethatcher Shaft ASM




Dethatcher Shaft Assembly

Ref	Part No.	Qty.	Description
1	94-9202	1	Shaft-Dethatcher
2	106-6355	36	Blade-11 Tooth (Carbide)
❶2	106-5422	36	Blade-11 Tooth (Narrow Carbide)
3	82-6600	2	Spacer (0.73")
4	67-5840	2	Nut-Jam
5	17-1580	35	Spacer (0.5")



Roll and Scraper Assembly

Ref	Part No.	Qty.	Description
1	95-5943	1	Roller ASM
2	94-9226	1	Bracket-Scraper
3	33014-00	2	Nut-Hex
4	3256-74	12	Washer-Flat
5	98-2196	1	Rod-Shield
6	33024-00	8	Nut-Lock
7	33115-020	2	Screw-HH
8	3256-24	2	Washer-Flat
9	33114-020	4	Screw-HH
13	94-9220	1	Scraper-Roller, LH
14	94-9219	1	Scraper-Roller, RH
16	98-3551	1	Grass Shield ASM
17	104-2065	5	Screw-HWH
20	36-7260	1	Bar-Off, Cut
23	302-5	2	Fitting-Grease
24	257-11	4	Washer-Thrust
❷26		2	Wheel / Bearing ASM
26:1	94-9211	1	Wheel ASM
26:2	95-7497	2	Bushing-Wheel
27	94-9213	2	Collar-Shaft
28	94-9210	1	Shaft-Wheel, Rear
30	93-6688	1	Decal-Danger, Europe



Roller Assembly No. 95-5943

Ref	Part No.	Qty.	Description
2	302-5	2	Fitting-Grease
3	85-9970	2	Bearing-Ball
4	85-7190	2	Washer-Shield
5	32151-12	2	Ring-Retaining
6	95-5946	1	Shaft-Roller


TORO®