



CE Kit

Dingo® 320-D Compact Utility Loader

Model No. 22365

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Decal Assembly	 3	Auxiliary Valve Control Lever Assembly	 5
Lever Lock Assembly	 4	Parking Brake Assembly	 6


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	INC.	incorporated
ASM.	assembly	LH.	left hand
BBC.	blade brake clutch	NI.	nylon insert
CARR.	carriage	NPTF.	national pipe thread fine
DEG.	degrees	PFH.	phillips flat head
EXT.	external	PPH.	phillips pan head
FH.	flat head	PPHTF.	phillips pan head thread forming
GA.	gauge	PRH.	phillips round head
HF.	hex flange	PTH.	phillips truss head
HH.	hex head	PTO.	power-take-off
HHF.	hex head flange	RH.	right hand
HHFTF.	hex head flange thread forming	ROPS.	roll-over-protection-system
HJ.	hex jam	SFH.	slotted fillister head
HLH.	hex lag head	SHH.	slotted hex head
HOC.	height-of-cut	SHWH.	slotted hex washer head
HSBH.	hex socket button head	SPH.	slotted pan head
HSFH.	hex socket flat head	SQH.	square head
HS.	hex socket head	SRH.	slotted round head
HWH.	hex washer head	STD.	standard
HWHTF.	hex washer head thread forming	TAP.	self tapping
HYD.	hydraulic	TTH.	torx truss head




Ref	Part No.	Qty.	Description				
1	32144-70	1	Screw-HWHTF				
4	100-1701	1	Decal-Danger				
5	100-1702	1	Decal-Caution				
6	100-1703	1	Decal-Limiter, Speed				
8	108-9733	1	Decal-Control Panel, Ce				
9	100-8821	4	Decal-Warning, Pinch				
10	100-8822	2	Decal-No Rider				
11	93-6686	1	Decal-Oil, HYD				
12	106-5976	1	Decal-Warning				




Lever Lock Assembly

Ref	Part No.	Qty.	Description				
1	108-4702	1	Lever Lock ASM				
1:1	108-4703-03	1	Bracket-Lever Lock				
1:2	108-4704-03	1	Arm-Lever Lock				
1:3	5979	2	Bushing-Nyliner				
1:4	88-7860	2	Spacer				
1:5	321-4	2	Screw-HH				
1:6	3296-42	2	Nut-Lock, NI				
1:7	32144-10	2	Screw-HWH				
1:8	108-4705	1	Spacer				
1:9	3274-56	1	Screw-HSH				



Auxiliary Valve Control Lever Assembly

Ref	Part No.	Qty.	Description				
1	3230-33	2	Screw-CARR				
2	3296-42	2	Nut-Lock, NI				
3	98-0067-03	1	Bracket				
4	32104-96	1	Screw-HH				
5	3253-3	1	Washer-Lock				
6	3217-5	1	Nut-Hex				
7	100-2086	1	Grip-Control				
8	33104-020	1	Screw-HHF				
9	3253-4	1	Washer-Lock				
10	100-2088	1	Cap-Mount				
11	100-2087	1	Mount-Lever				
12	100-2089	1	Spring-Torsion				
13	100-2085	2	Spacer				
14	100-1704	1	Decal-Power, Auxiliary				



Parking Brake Assembly

Ref	Part No.	Qty.	Description				
1	105-8414-03	1	Plate ASM				
2	100-1684-03	1	Lever ASM				
3	62-9130	1	Grip-Handle				
4	3272-6	1	Pin-Cotter				
5	100-1679	1	Cable				
6	283-62	1	Pin-Clevis				
7	3230-23	1	Screw-CARR				
8	100-1683	1	Hub-Lever				
9	3296-29	5	Nut-Lock, NI				
10	100-1674-03	2	Bar-Brake				
11	3256-23	1	Washer-Flat				
12	100-1676-03	2	Bracket-Brake				
13	100-1668	2	Screw-Flange				
14	100-1692	1	Decal-Brake				
15	100-1678-03	1	Spring				
16	100-1677-03	2	Bracket-Cable				
17	322-5	4	Screw-HH				
18	100-6274	2	Tube-Guide				
19	3245-20	2	Screw-HSH				
20	100-4697	1	Tube-Convoluted				
21	105-4056	2	Wheel Hub ASM				
21:2	10-6830	5	Stud-Type, Drive				
22	106-8159	2	Nut-Lock				

NOTES

