

Twin and Triple Bagger Mounting Kit 2004 and after Diesel-Powered 2005 and after Gas-Powered 500 Series Z Master®

Model No. 107-9850

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2005 All Rights Reserved

Contents


Description	Page	Description	Page
Bagger Mounting Assembly for Z597 Diesel Frame		Bagger Mounting Assembly for Z500 Gas	
rrame	3	Frame	4
		Bagger Mounting Assembly for Z593 Diesel Frame	5

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

reviations.
INC incorporated
LHleft hand
NI nylon insert
NPTF national pipe thread fine
PFH phillips flat head
PPH phillips pan head
PPHTF phillips pan head thread
forming
PRH phillips round head
PTH phillips truss head
PTO power-take-off
RH right hand
ROPS roll-over-protection-system
SFH slotted fillister head
SHH slotted hex head
SHWHslotted hex washer head
SPH slotted pan head
SQH square head
SRH slotted round head
STD standard
TAPself tapping
TTHtorx truss head

3354-906 Rev A




Bagger Mounting Assembly for Z597 Diesel Frame

Ref	Part No.	Qty.	Description		
1	3290-357	8	Nut-HHF, Whiz		
2	110-0830-03	2	Plate-Bagger Mount		
3	98-5975	8	Washer-Belleville		
4	323-8	8	Screw-HH		
5	103-1155-03	2	Spacer		

Ļ			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
I			
I			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
I			
I			
I			
ı			
1	i e		


3354-906 Rev A 2



Bagger Mounting Assembly for Z500 Gas Frame

Ref	Part No.	Qty. Description	1	
1	3290-357	8 Nut-HHF, Whiz	1	
2	110-0830-03	2 Plate-Bagger Mount		
3	98-5975	8 Washer-Belleville		
4	323-8	8 Screw-HH		
5	103-1155-03	2 Spacer		

3 3354-906 Rev A



Bagger Mounting Assembly for Z593 Diesel Frame

Ref	Part No.	Qty.	Description			
1	3290-357	8	Nut-HHF, Whiz	Ī		
2	110-0830-03	2	Plate-Bagger Mount			
3	98-5975	8	Washer-Belleville			
4	323-8		Screw-HH			
5	103-1155-03	2	Spacer			

NOTES

NOTES

