



## Cab Kit for Workman® 3000/4000 Series Vehicles

Model No. 07225 - 220000001 and up.

Model No. 07249 - 220000001 and up.

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


## Contents

| Description                    | Page    | Description                     | Page    |
|--------------------------------|---------|---------------------------------|---------|
| Front and Rear Window Assembly | ..... 3 | Seat Belt Installation Assembly | ..... 6 |
| Frame Assembly                 | ..... 4 | Radiator Modification Assembly  | ..... 7 |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|             |                                |             |                                  |
|-------------|--------------------------------|-------------|----------------------------------|
| AR. ....    | as required                    | INC. ....   | incorporated                     |
| ASM. ....   | assembly                       | LH. ....    | left hand                        |
| BBC. ....   | blade brake clutch             | NI. ....    | nylon insert                     |
| CARR. ....  | carriage                       | NPTF. ....  | national pipe thread fine        |
| DEG. ....   | degrees                        | PFH. ....   | phillips flat head               |
| EXT. ....   | external                       | PPH. ....   | phillips pan head                |
| FH. ....    | flat head                      | PPHTF. .... | phillips pan head thread forming |
| GA. ....    | gauge                          | PRH. ....   | phillips round head              |
| HF. ....    | hex flange                     | PTH. ....   | phillips truss head              |
| HH. ....    | hex head                       | PTO. ....   | power-take-off                   |
| HHF. ....   | hex head flange                | RH. ....    | right hand                       |
| HHFTF. .... | hex head flange thread forming | ROPS. ....  | roll-over-protection-system      |
| HJ. ....    | hex jam                        | SFH. ....   | slotted fillister head           |
| HLH. ....   | hex lag head                   | SHH. ....   | slotted hex head                 |
| HOC. ....   | height-of-cut                  | SHWH. ....  | slotted hex washer head          |
| HSBH. ....  | hex socket button head         | SPH. ....   | slotted pan head                 |
| HSFH. ....  | hex socket flat head           | SQH. ....   | square head                      |
| HS. ....    | hex socket head                | SRH. ....   | slotted round head               |
| HWH. ....   | hex washer head                | STD. ....   | standard                         |
| HWHTF. .... | hex washer head thread forming | TAP. ....   | self tapping                     |
| HYD. ....   | hydraulic                      | TTH. ....   | torx truss head                  |




Front and Rear Window Assembly

| Ref | Part No.    | Qty. | Description                         |  |  |  |  |
|-----|-------------|------|-------------------------------------|--|--|--|--|
| 1   | 95-7301     | 1    | Glass-Front                         |  |  |  |  |
| 2   | 95-7336     | 2    | Hinge                               |  |  |  |  |
| 3   | 95-7337     | 2    | Opener-Window                       |  |  |  |  |
| 4   | 33114-045   | 2    | Screw-HH                            |  |  |  |  |
| 5   | 3256-23     | 2    | Washer-Flat                         |  |  |  |  |
| 6   | 48-9510     | 2    | Nut                                 |  |  |  |  |
| 7   | 95-7344     | 1    | Switch-Wiper                        |  |  |  |  |
| 8   | 100-9400-06 | 1    | Panel-Cover, Upper (Only On: 07225) |  |  |  |  |
| 8   | 95-7345-01  | 1    | Panel-Cover, Upper (Only On: 07249) |  |  |  |  |
| 9   | 95-7372     | 1    | Harness-Wire                        |  |  |  |  |
| 10  | 95-7338     | 2    | Seal                                |  |  |  |  |
| 11  | 95-7339     | 1    | Motor-Wiper                         |  |  |  |  |
| 12  | 95-7340     | 1    | Arm-Wiper                           |  |  |  |  |
| 13  | 95-7341     | 1    | Blade-Wiper                         |  |  |  |  |
| 14  | 95-7303     | 1    | Glass-Rear                          |  |  |  |  |
| 15  | 95-7342     | 4    | Glass Fixation Kit                  |  |  |  |  |
| 16  | 99-1098     | 1    | Mirror-Rear View (Only On: 07225)   |  |  |  |  |
| 17  | 99-1101     | 1    | Connector-Wiper                     |  |  |  |  |
| 18  | 100-9379    | 1    | Lens-Wiper                          |  |  |  |  |




## Frame Assembly

| Ref | Part No.   | Qty. | Description                        | Ref | Part No.  | Qty. | Description                 |
|-----|------------|------|------------------------------------|-----|-----------|------|-----------------------------|
| 1   | 100-9388   | 1    | RH Side Panel ASM (Only On: 07225) | 12  | 3290-382  | 2    | Rivet-Pop                   |
| 1   | 100-9386   | 1    | RH Side Panel ASM (Only On: 07249) | 13  | 95-7304   | 2    | Nut-Special, Spring Clip    |
| 1:2 | 67-1300    | 1    | Decal                              | 14  | 95-7343   | 2    | Nut-Special, Barrel         |
| 1:3 | 94-5275    | 1    | Decal (G. V. W.)                   | 15  | 95-7324   | 2    | Mirror (Only On: 07249)     |
| 1:4 | 94-5276    | 1    | Decal-Rollover                     | 16  | 95-7325   | 1    | Support-RH (Only On: 07249) |
| 1:5 | 87-5980    | 1    | Decal-ROPS                         | 17  | 95-7326   | 1    | Support-LH (Only On: 07249) |
| 1:6 | 87-5930    | 1    | Decal-Caution, Fuel                | 18  | 95-7327   | 2    | Cover (Only On: 07249)      |
| 2   | 100-9387   | 1    | LH Side Panel ASM (Only On: 07249) | 19  | 95-7328   | 2    | Seal                        |
| 2   | 100-9389   | 1    | LH Side Panel ASM (Only On: 07225) | 20  | 95-7373   | 2    | Seal-Lower, Cab             |
| 2:2 | 67-1300    | 1    | Decal                              | 21  | 33116-035 | 6    | Screw-HH                    |
| 2:3 | 87-5980    | 1    | Decal-ROPS                         | 22  | 33116-090 | 4    | Screw-HH                    |
| 3   | 95-7315-06 | 1    | Roof                               | 23  | 3256-26   | 12   | Washer-Flat                 |
| 4   | 95-7316-03 | 1    | Bar-Front                          | 24  | 48-9540   | 6    | Nut-Lock, Hex NI            |
| 5   | 95-7317-03 | 1    | Bar-Front                          | 25  | 33115-060 | 8    | Screw-HH                    |
| 6   | 100-9391   | 1    | Front Dash ASM                     | 26  | 3256-4    | 28   | Washer-Flat                 |
| 6:2 | 94-5274    | 1    | Decal-Danger                       | 27  | 48-9520   | 14   | Nut                         |
| 7   | 95-7319-03 | 1    | Molding-RH                         | 28  | 33114-020 | 4    | Screw-HH                    |
| 8   | 95-7320-03 | 1    | Molding-LH                         | 29  | 33114-035 | 6    | Screw-HH                    |
| 9   | 95-7321    | 2    | Striker                            | 30  | 33114-045 | 8    | Screw-HH                    |
| 10  | 95-7322    | 2    | Visor-Sun (Only On: 07249)         | 31  | 43-3220   | 2    | Capscrew-HH                 |
| 11  | 95-7323    | 2    | Hook-Coat                          | 32  | 95-7370   | 4    | Washer-Seal                 |
|     |            |      |                                    | 33  | 95-7371   | 4    | Washer-Seal                 |
|     |            |      |                                    | 34  | 3256-23   | 32   | Washer-Flat                 |
|     |            |      |                                    | 35  | 48-9510   | 16   | Nut                         |



## Frame Assembly (continued)


| Ref  | Part No.    | Qty. | Description              |  |  |  |  |
|------|-------------|------|--------------------------|--|--|--|--|
| 36   | 33113-016   | 10   | Screw-HH                 |  |  |  |  |
| 37   | 3256-16     | 20   | Washer-Flat              |  |  |  |  |
| 38   | 49-7810     | 10   | Nut-Lock                 |  |  |  |  |
| 39   | 95-7329     | 4    | Plug                     |  |  |  |  |
| 40   | 95-7330     | 1    | Holder-Cup               |  |  |  |  |
| 41   | 95-7331     | 1    | Seal                     |  |  |  |  |
| 42   | 100-9390    | 1    | Rear Panel ASM           |  |  |  |  |
| 42:2 | 87-7930     | 1    | Decal-Warning            |  |  |  |  |
| 43   | 95-7333-03  | 1    | Bracket                  |  |  |  |  |
| 44   | 95-7334-06  | 1    | Bail-RH (Only On: 07225) |  |  |  |  |
| 44   | 95-7334-01  | 1    | Bail-RH (Only On: 07249) |  |  |  |  |
| 45   | 95-7335-01  | 1    | Bail-LH (Only On: 07249) |  |  |  |  |
| 45   | 95-7335-06  | 1    | Bail-LH (Only On: 07225) |  |  |  |  |
| 53   | 95-7374     | 1    | Seal-Rear, Lower         |  |  |  |  |
| 55   | 105-1703-03 | 1    | Mount-Seat, LH           |  |  |  |  |
| 56   | 105-1704-03 | 1    | Strap-Seat Pad, RH       |  |  |  |  |



NOTE: Passenger seat assembly is shown.

## Seat Belt Installation Assembly

| Ref | Part No.   | Qty. | Description          |  |  |  |  |
|-----|------------|------|----------------------|--|--|--|--|
| 1   | 110-0413   | 2    | Seatbelt-Retractable |  |  |  |  |
| 2   | 3212-4     | 4    | Screw-HH             |  |  |  |  |
| 3   | 3296-38    | 4    | Nut-Lock, NI         |  |  |  |  |
| 4   | 87-7280-03 | 2    | Bracket-Belt, Seat   |  |  |  |  |
| 5   | 322-10     | 4    | Screw-HH             |  |  |  |  |
| 6   | 3256-3     | 8    | Washer-Flat          |  |  |  |  |
| 7   | 3296-29    | 4    | Nut-Lock, NI         |  |  |  |  |
| 8   | 52-2480    | 4    | Spacer-Wheel         |  |  |  |  |



## Radiator Modification Assembly

| Ref | Part No.   | Qty. | Description           |
|-----|------------|------|-----------------------|
| 1   | 94-5280-03 | 1    | Spacer-Tank, Overflow |
| 2   | 94-5273-03 | 1    | Cover-Radiator, Cab   |

