



Right-Hand Groomer Kit Reelmaster® 5500-D, 6500-D and 6700-D

Model No. 03811

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Description	Page	Description	Page
Groomer Assembly	 3	Groomer Shaft Assembly No. 107-2388	 6
Idler Assembly No. 107-4402	 4	HOC Assembly No. 108-0629	 7
HOC Assembly No. 108-0628	 5	Attachments and Accessories List	 8

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HS. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head



Groomer Assembly


Ref	Part No.	Qty.	Description
1	104-8300	2	Nut-Flange, NI
2	108-0615	1	Cover-Drive, Groomer
3	108-0617	1	Belt-Drive
4	3234-14	3	Screw-HHF
5	107-2386	1	Pulley-Drive
6	108-1429	1	Plate-Retaining
7	108-0634	2	Spacer-Plate, Retaining
8	108-6742	1	Groomer Plate ASM
8:2	108-6738	1	Decal-Warning
9	95-9619	1	Key-Square
10	108-6717	1	Drive ASM
10:1	32151-34	1	Ring-Retaining
10:2	104-1833	1	Drive Shaft ASM
10:2:2	98-5215	2	Bearing-Ball, Radial
10:3	108-0647	1	Housing-Groomer
10:4	253-83	1	Seal-Oil
11	93-9783	1	O-Ring
12	32128-25	2	Nut-HF
13	107-4416	2	Spacer-Arm, Idler
14	107-4402	1	Idler ASM
15	107-8837	1	Spring-Torsion
16	32128-21	1	Nut-HF
17	95-0743	1	Pulley-Driven
18	108-1439	2	Washer-Hardened

Ref	Part No.	Qty.	Description
18	108-1449	2	Washer-Hardened
19	107-4420	1	Spacer-Pulley
20	700260	1	Ring-Retaining
21	9114524	2	Bolt-TAP, HH
22	3234-24	2	Screw-HHF
22	33105-030	2	Screw-HHF
23	108-0628	1	HOC ASM
24	107-4424	2	Guard-Seal
25	95-9615	1	Key-Square
26	108-1438	4	Washer-Hardened
26	48-9220	8	Washer
27	107-2388	1	Groomer Shaft ASM
28	323-4	4	Screw-HH
29	107-8844	1	O-Ring
30	108-0629	1	HOC ASM
31	108-0614	1	Cover-Drive, Groomer
32	108-0608	1	Brush Cover ASM
32:2	107-2398	1	Gasket-Cover
33	108-6741	1	Groomer Plate ASM
33:2	108-6738	1	Decal-Warning
34	107-2394	1	Plate-Brush
35	108-6718	1	Tool-Alignment




Idler Assembly No. 107-4402

Ref	Part No.	Qty.	Description
1	107-4435	2	Bushing-Flange
2	107-8835	1	Arm-Idler
3	108-6270	1	Pulley-Idler
4	38-7820	1	Bearing-Ball
5	88-7200	1	Washer-Flat
6	3253-4	1	Washer-Lock
7	322-3	1	Screw-HH
8	32120-42	1	Ring-Retaining




HOC Assembly No. 108-0628

Ref	Part No.	Qty.	Description				
1	3296-48	2	Nut-Lock, NI				
2	108-1439	2	Washer-Hardened				
3	107-8818	1	Bracket-HOC, Front				
4	107-8833	1	Adjustment Bracket ASM				
4:2	107-8822	1	Stud				
4:3	108-1446	1	Stud				
5	108-6728	1	Bearing Housing ASM				
5:1	107-8821	2	Seal-Grease				
5:3	95-0707	1	Bearing-Aligning, Self				
5:4	107-4419	2	Seal-Grease				
6	110-7352	1	Screw-HOC				
7	302-11	1	Fitting-Lube, 45 DEG				



Groomer Shaft Assembly No. 107-2388

Ref	Part No.	Qty.	Description
1	107-2387	1	Shaft-Groomer
2	3296-60	2	Nut-Lock, NI
3	107-8812	41	Blade-Groomer
4	107-4430	42	Spacer-Plastic



HOC Assembly No. 108-0629

Ref	Part No.	Qty.	Description				
1	3296-48	2	Nut-Lock, NI				
2	108-1439	2	Washer-Hardened				
3	107-8816	1	Bracket-HOC, Front				
4	107-8832	1	Adjustment Bracket ASM				
4:2	107-8822	1	Stud				
4:3	108-1446	1	Stud				
5	108-6729	1	Bearing Housing ASM				
5:1	107-4419	2	Seal-Grease				
5:2	95-0707	1	Bearing-Aligning, Self				
5:4	108-0609	1	Seal-Grease				
5:5	107-8847	1	Plug				
5:6	32151-60	1	Ring-Snap				
6	110-7352	1	Screw-HOC				
7	302-11	1	Fitting-Lube, 45 DEG				

Attachments and Accessories

For 03811 - Right-Hand Groomer Kit, Reelmaster 5500-D, 6500-D and 6700-D

Product Name	Model/Part
Grass Basket ASM	107-9518
Wiehle Scraper ASM	108-0605-03
Gauge Bar ASM	108-6715
Grass Basket Kit (with Groomers only)	108-6743

NOTES

NOTES

NOTES

