



## CCR<sup>™</sup> 2450 Snowthrower

Model No. 38413 - 000000001 and up.

Model No. 38419 - 000000001 and up.

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                                    | Page     | Description                                    | Page     |
|------------------------------------------------|----------|------------------------------------------------|----------|
| Housing and Side Plate Assembly                | ..... 3  | Muffler, Carburetor, and Intake Manifold       |          |
| Impeller Drive Assembly                        | ..... 4  | Assemblies Briggs and Stratton 084132-0120- E1 | ..... 11 |
| Chute Assembly                                 | ..... 5  | Flywheel, Blower Housing, and Rewind Starter   |          |
| Impeller Assembly                              | ..... 6  | Assemblies Briggs and Stratton 084132-0120- E1 | ..... 12 |
| Engine and Frame Assembly                      | ..... 7  | Cylinder, Piston, and Connecting Rod           |          |
| Upper Shroud and Control Panel Assembly        | ..... 8  | Assemblies Briggs and Stratton 084133-0196- E1 | ..... 13 |
| Handle Assembly                                | ..... 9  | Muffler, Carburetor, and Intake Manifold       |          |
| Cylinder, Piston, and Connecting Rod           |          | Assemblies Briggs and Stratton 084133-0196- E1 | ..... 14 |
| Assemblies Briggs and Stratton 084132-0120- E1 | ..... 10 | Flywheel, Blower Housing, and Starter          |          |
|                                                |          | Assemblies Briggs and Stratton 084133-0196- E1 | ..... 15 |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | INC. .... incorporated                       |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HF. .... hex flange                        | PTH. .... phillips truss head                |
| HH. .... hex head                          | PTO. .... power-take-off                     |
| HHF. .... hex head flange                  | RH. .... right hand                          |
| HHFTF. .... hex head flange thread forming | ROPS. .... roll-over-protection-system       |
| HJ. .... hex jam                           | SFH. .... slotted fillister head             |
| HLH. .... hex lag head                     | SHH. .... slotted hex head                   |
| HOC. .... height-of-cut                    | SHWH. .... slotted hex washer head           |
| HSBH. .... hex socket button head          | SPH. .... slotted pan head                   |
| HSFH. .... hex socket flat head            | SQH. .... square head                        |
| HSH. .... hex socket head                  | SRH. .... slotted round head                 |
| HWH. .... hex washer head                  | STD. .... standard                           |
| HWHTF. .... hex washer head thread forming | TAP. .... self tapping                       |
| HYD. .... hydraulic                        | TTH. .... torx truss head                    |

## Footnotes


❶ Not serviced separately

❷ Obtain from your local Briggs & Stratton dealer



## Housing and Side Plate Assembly


| Ref | Part No.   | Qty. | Description            | Ref | Part No.   | Qty. | Description    |
|-----|------------|------|------------------------|-----|------------|------|----------------|
| 1   | 3296-42    | 16   | Nut-Lock, NI           | 26  | 55-8840-03 | 1    | Plate-Side, RH |
| 2   | 52-7290-03 | 1    | Retainer-Bearing       | 27  | 32105-15   | 5    | Screw          |
| 3   | 3234-25    | 1    | Screw-HHF              |     |            |      |                |
| 4   | 3256-24    | 1    | Washer-Flat            |     |            |      |                |
| 5   | 52-7270    | 1    | Washer-Rubber          |     |            |      |                |
| 6   | 38-7820    | 2    | Bearing-Ball           |     |            |      |                |
| 7   | 322-43     | 1    | Screw-HH               |     |            |      |                |
| 8   | 38-8211    | 1    | Pin-Rotor              |     |            |      |                |
| 9   | 321-4      | 3    | Screw-HH               |     |            |      |                |
| 10  | 3256-22    | 7    | Washer-Flat            |     |            |      |                |
| 11  | 321-6      | 3    | Screw-HH               |     |            |      |                |
| 12  | 55-9512    | 1    | Cover-Bottom           |     |            |      |                |
| 14  | 55-9430    | 1    | Bracket-Housing        |     |            |      |                |
| 15  | 3296-2     | 3    | Nut-Lock               |     |            |      |                |
| 16  | 38-8620    | 1    | Flange-Bearing         |     |            |      |                |
| 17  | 52-7280    | 2    | Washer-Thrust          |     |            |      |                |
| 18  | 56-2610    | 1    | Bracket-Housing, Lower |     |            |      |                |
| 19  | 32149-2    | 3    | Nut-Keps               |     |            |      |                |
| 20  | 3229-11    | 3    | Screw-CARR             |     |            |      |                |
| 21  | 3256-67    | 2    | Washer-Flat            |     |            |      |                |
| 22  | 32128-10   | 2    | Nut-Lock, HHF          |     |            |      |                |
| 23  | 55-8760    | 1    | Scraper                |     |            |      |                |
| 24  | 55-9220-03 | 1    | Housing-Lower          |     |            |      |                |
| 25  | 52-9110    | 1    | Flange-Bearing         |     |            |      |                |



Impeller Drive Assembly


| Ref | Part No.   | Qty. | Description         |
|-----|------------|------|---------------------|
| 1   | 55-8851-03 | 1    | Plate-Side, LH      |
| 2   | 3274-31    | 1    | Screw-HSBH          |
| 3   | 55-9620    | 2    | Spacer-Plate, Pivot |
| 4   | 3296-42    | 5    | Nut-Lock, NI        |
| 5   | 3296-29    | 3    | Nut-Lock, NI        |
| 6   | 5-4460     | 2    | Washer-Pivot        |
| 7   | 322-3      | 2    | Screw-HH            |
| 8   | 55-9530    | 1    | Sleeve-Guide, Belt  |
| 9   | 321-13     | 1    | Screw-HH            |
| 10  | 3245-41    | 1    | Screw-HSH           |
| 11  | 3241-7     | 1    | Screw-SQH           |
| 12  | 95-2673    | 1    | Pulley-Engine       |
| 13  | 95-6151    | 1    | Belt-Drive          |
| 14  | 55-9280    | 1    | Spring-Extension    |
| 15  | 32152-2    | 1    | Nut-Lock, Cone      |
| 16  | 63-3610    | 1    | Idler Arm ASM       |
| 17  | 25-5640    | 1    | Washer              |
| 18  | 27-0410    | 1    | Screw-Shoulder      |
| 19  | 60-9480    | 1    | Decal               |
| 20  | 323-29     | 1    | Screw-HH            |
| 21  | 55-9290    | 1    | Pulley-Idler        |
| 22  | 36-3860    | 1    | Screw-HWH, TAP      |
| 23  | 12-3270    | 2    | Screw               |
| 24  | 16-9449    | 1    | Cover-Drive         |

| Ref | Part No. | Qty. | Description       |
|-----|----------|------|-------------------|
| 25  | 32105-15 | 2    | Screw             |
| 26  | 32112-11 | 1    | Nut-Push          |
| 27  | 55-9520  | 1    | Roller-Brake      |
| 28  | 55-9570  | 1    | Pivot Plate ASM   |
| 29  | 55-9550  | 1    | Brake-Arm         |
| 30  | 321-30   | 1    | Screw-HH          |
| 31  | 3290-456 | 1    | Washer-Belleville |
| 32  | 95-2672  | 1    | Pulley Rotor ASM  |
| 33  | 321-4    | 2    | Screw-HH          |
| 34  | 32105-8  | 3    | Screw-SHH         |
| 35  | 95-1904  | 1    | Decal-Hot         |




Chute Assembly

| Ref | Part No.   | Qty. | Description              | Ref | Part No. | Qty. | Description  |
|-----|------------|------|--------------------------|-----|----------|------|--------------|
| 1   | 56-2680    | 1    | Chute-Deflector          | 32  | 3256-70  | 3    | Washer-Flat  |
| 2   | 94-2790    | 1    | Chute ASM W/Decal        | 33  | 3296-29  | 3    | Nut-Lock, NI |
| 2:3 | 94-2900    | 1    | Decal - Danger Discharge |     |          |      |              |
| 3   | 3230-22    | 2    | Screw-CARR               |     |          |      |              |
| 4   | 20-4320    | 2    | Washer-Rubber            |     |          |      |              |
| 5   | 55-8950    | 2    | Plate-Friction           |     |          |      |              |
| 7   | 94-9914    | 1    | Handle-Control, Chute    |     |          |      |              |
| 8   | 3296-29    | 2    | Nut-Lock, NI             |     |          |      |              |
| 9   | 321-4      | 4    | Screw-HH                 |     |          |      |              |
| 10  | 80-4600    | 1    | Spring-Extension         |     |          |      |              |
| 11  | 3256-22    | 5    | Washer-Flat              |     |          |      |              |
| 12  | 55-9370    | 1    | Spacer-Blade, Rotor      |     |          |      |              |
| 13  | 80-4610    | 1    | Detent                   |     |          |      |              |
| 14  | 3296-56    | 1    | Nut-Lock, NI             |     |          |      |              |
| 21  | 3296-42    | 5    | Nut-Lock, NI             |     |          |      |              |
| 22  | 55-8921-03 | 1    | Ring-Support, Chute      |     |          |      |              |
| 23  | 55-8700    | 1    | Housing                  |     |          |      |              |
| 24  | 46-8092    | 2    | Screw-Plastite           |     |          |      |              |
| 25  | 71-4980-03 | 1    | Retainer-Chute, LH       |     |          |      |              |
| 27  | 71-4990-03 | 1    | Retainer-Chute, RH       |     |          |      |              |
| 28  | 71-4950    | 1    | Gear Ring, Chute         |     |          |      |              |
| 29  | 3230-23    | 3    | Screw-CARR               |     |          |      |              |
| 30  | 3290-456   | 2    | Washer-Belleville        |     |          |      |              |
| 31  | 3256-68    | 2    | Washer-Flat              |     |          |      |              |




## Impeller Assembly

| Ref | Part No.   | Qty. | Description         |  |  |  |  |
|-----|------------|------|---------------------|--|--|--|--|
| 1   | 99-9313    | 2    | Blade-Rotor         |  |  |  |  |
| 2   | 55-9370    | 4    | Spacer-Blade, Rotor |  |  |  |  |
| 3   | 55-9202-03 | 1    | Rotor               |  |  |  |  |
| 4   | 3296-56    | 12   | Nut-Lock, NI        |  |  |  |  |
| 5   | 66-6600-03 | 2    | Half-Rotor          |  |  |  |  |
| 6   | 84-1971    | 8    | Screw               |  |  |  |  |
| 7   | 321-8      | 1    | Screw-HH            |  |  |  |  |
| 8   | 321-4      | 4    | Screw-HH            |  |  |  |  |



## Engine and Frame Assembly

| Ref | Part No. | Qty. | Description                                                 | Ref | Part No.   | Qty. | Description              |
|-----|----------|------|-------------------------------------------------------------|-----|------------|------|--------------------------|
| 1   | 32152-8  | 1    | Nut-Lock, Cone                                              | 27  | 66-6501    | 1    | Spacer-Wheel             |
| 2   | 3256-23  | 1    | Washer-Flat                                                 | 28  | 95-1892-03 | 1    | Frame                    |
| 3   | 237-89   | 1    | Grommet-Rubber                                              | 29  | 3296-29    | 3    | Nut-Lock, NI             |
| 4   | 94-9920  | 1    | Tank-Gas                                                    | 31  | 66-6500    | 1    | Spacer-Wheel             |
| 5   | 55-9310  | 1    | Seal-Foam                                                   | 32  | 94-9918-03 | 1    | Support-Recoil           |
| 6   | 49-2482  | 1    | Line-Fuel                                                   | 33  | 2412-91    | 1    | Clamp R (Only On: 38419) |
| 7   | 2412-98  | 4    | Clamp                                                       | 34  | 71-5320    | 1    | Washer-Support, Engine   |
| 8   | 56-6360  | 1    | Filter-Fuel                                                 | 35  | 3296-16    | 1    | Nut-Lock, NI             |
| 9   | 94-9932  | 1    | Hose-Fuel                                                   |     |            |      |                          |
| 10  | 32144-27 | 3    | Screw-Plastite (Only On: 38419)                             |     |            |      |                          |
| 11  | 3296-42  | 4    | Nut-Lock, NI                                                |     |            |      |                          |
| 12  | 3256-22  | 2    | Washer-Flat                                                 |     |            |      |                          |
| 13  | 321-4    | 4    | Screw-HH                                                    |     |            |      |                          |
| 14  | 250-4    | 1    | Tie-Cable                                                   |     |            |      |                          |
| 15  |          | 1    | Engine-Briggs And Stratton, 084132-0120-E1 (Only On: 38413) |     |            |      |                          |
| 15  |          | 1    | Engine-Briggs And Stratton, 084133-0196-E1 (Only On: 38419) |     |            |      |                          |
| 20  | 322-3    | 2    | Screw-HH                                                    |     |            |      |                          |
| 21  | 3290-456 | 5    | Washer-Belleville                                           |     |            |      |                          |
| 22  | 322-3    | 4    | Screw-HH                                                    |     |            |      |                          |
| 25  | 32112-14 | 2    | Nut-Push                                                    |     |            |      |                          |
| 26  | 66-6510  | 2    | Wheel                                                       |     |            |      |                          |




## Upper Shroud and Control Panel Assembly

| Ref | Part No.   | Qty. | Description            |
|-----|------------|------|------------------------|
| 1   | 3256-22    | 2    | Washer-Flat            |
| 2   | 3250-32    | 2    | Screw-PPH              |
| 3   | 100-3305   | 1    | Decal - Ccr 2450 Gts   |
| 4   | 55-3573    | 1    | Cap-Fuel ASM           |
| 5   | 98-1372    | 1    | Hose-Primer            |
| 6   | 12-4659    | 1    | Cont Panel/Primer Body |
| 7   | 55-9350    | 1    | Control Nameplate      |
| 8   | 32144-112  | 3    | Screw-HWH              |
| 9   | 55-9410    | 1    | Guide-Rope, Starter    |
| 10  | 612825     | 1    | Handle-Start           |
| 11  | 612824     | 1    | Clip-Starter           |
| 12  | 66-7460    | 1    | Bulb-Primer            |
| 13  | 44-2750    | 1    | Body-Primer            |
| 14  | 63-8360    | 1    | Key-Ignition           |
| 15  | 40-5940    | 1    | Switch                 |
| 16  | 55-8820    | 1    | Fitting                |
| 17  | 55-8810    | 1    | Control-Choke          |
| 18  | 95-7439    | 1    | Linkage-Choke          |
| 19  | 3256-49    | 1    | Washer-Flat            |
| 20  | 32144-111  | 1    | Screw-PPH              |
| 21  | 98-1373    | 1    | Decal                  |
| 22  | 94-9924-03 | 1    | Shield-Heat            |
| 23  | 32105-8    | 3    | Screw-SHH              |
| 24  | 218-532    | 1    | Connector-Body         |

| Ref | Part No.   | Qty. | Description                             |
|-----|------------|------|-----------------------------------------|
| 25  | 55-9660    | 3    | Washer                                  |
| 26  | 3256-14    | 3    | Washer-Flat                             |
| 27  | 3296-12    | 3    | Nut-Lock                                |
| 28  | 61-4790    | 1    | Decal (Only On: 38419)                  |
| 29  | 94-9919    | 1    | Shroud - Lower                          |
| 30  | 3290-474   | 8    | Palnut                                  |
| 31  | 55-9540-03 | 1    | Retainer-Seal, Chute                    |
| 32  | 55-9260    | 1    | Seal-Chute                              |
| 33  | 100-3301   | 1    | Upper Shroud/Decal ASM (Only On: 38419) |
| 33  | 100-3300   | 1    | Upper Shroud/Decal ASM (Only On: 38413) |

9



# Cylinder, Piston, and Connecting Rod Assemblies

## Briggs and Stratton 084132-0120-E1

| Ref  | Part No. | Qty. | Description                      |
|------|----------|------|----------------------------------|
| 1    | 801260   | 1    | Cylinder ASM                     |
| 3    | 801262   | 1    | Seal-Oil                         |
| 5    | 801283   | 1    | Head-Cylinder                    |
| 7    | 801263   | 1    | Gasket-Head, Cylinder            |
| 13   | 801264   | 1    | Screw (Cylinder Head)            |
| 14   | 801265   | 1    | Stud (Cylinder Head)             |
| 16   | 801220   | 1    | Crankshaft                       |
| 20   | 801261   | 1    | Seal-Oil                         |
| 22   | 801266   | 1    | Screw (Crankcase Cover And Sump) |
| 22A  | 801271   | 1    | Screw (Crankcase Cover And Sump) |
| 24   | 801234   | 1    | Key-Flywheel                     |
| 25   | 801279   | 1    | Piston ASM                       |
| 26   | 801280   | 1    | Ring Set                         |
| 27   | 801275   | 1    | Lock-Pin, Piston                 |
| 28   | 801276   | 1    | Pin-Piston                       |
| 29   | 801277   | 1    | Rod-Connecting                   |
| 32   | 801278   | 1    | Screw                            |
| 48   | 801284   | 1    | Short Block                      |
| 337  | 801254   | 1    | Plug-Spark                       |
| 718  | 690959   | 1    | Pin-Locating                     |
| 1051 | 801274   | 1    | Ring-Retaining                   |
| 1036 | 801294   | 1    | Label-Emissions                  |


| Ref  | Part No. | Qty. | Description  |
|------|----------|------|--------------|
| 1401 | 801290   | 1    | Roller-Strip |



## Muffler, Carburetor, and Intake Manifold Assemblies Briggs and Stratton 084132-0120-E1


| Ref  | Part No. | Qty. | Description                                                   |
|------|----------|------|---------------------------------------------------------------|
| ●50  | 801232   | 1    | Manifold-Intake                                               |
| ●51  | 801224   | 1    | Gasket-Intake                                                 |
| ●54  | 801230   | 1    | Screw (Intake Manifold)                                       |
| ●97  | 801306   | 1    | Shaft-Throttle                                                |
| ●106 | 801317   | 1    | Seat-Inlet                                                    |
| ●109 | 801307   | 1    | Shaft-Choke                                                   |
| ●117 | 801310   | 1    | Jet-Main                                                      |
| ●125 | 801233   | 1    | Carburetor                                                    |
| ●133 | 801316   | 1    | Float-Carburetor                                              |
| ●142 | 801313   | 1    | Nozzle-Carburetor                                             |
| ●147 | 801308   | 1    | Jet-Pilot                                                     |
| ●163 | 801227   | 1    | Gasket-Cleaner, Air                                           |
| ●200 | 801289   | 1    | Blade-Governor                                                |
| ●201 | 801225   | 1    | Link-Vane, Air                                                |
| ●209 | 801223   | 1    | Spring-Governor                                               |
| ●300 | 801250   | 1    | Muffler                                                       |
| ●333 | 801268   | 1    | Armature-Magneto                                              |
| ●334 | 801267   | 1    | Screw                                                         |
| ●426 | 801231   | 1    | Screw                                                         |
| ●613 | 801251   | 1    | Screw                                                         |
| ●654 | 801324   | 1    | Nut (Intake Manifold) (Used Before Engine Code Date 05042600) |
| ●711 | 801229   | 1    | Screw                                                         |

| Ref   | Part No. | Qty. | Description           |
|-------|----------|------|-----------------------|
| ●780  | 801228   | 1    | Anchor-Spring         |
| ●789  | 801253   | 1    | Wire ASM              |
| ●883  | 801252   | 1    | Gasket-Exhaust        |
| ●977  | 801312   | 1    | Gasket Set-Carburetor |
| ●996  | 801226   | 1    | Shield-Carburetor     |
| ●1127 | 801318   | 1    | Screw                 |



**Flywheel, Blower Housing, and Rewind Starter Assemblies**  
**Briggs and Stratton 084132-0120-E1**


| Ref  | Part No. | Qty. | Description      |  |  |  |  |
|------|----------|------|------------------|--|--|--|--|
| 23   | 801246   | 1    | Flywheel         |  |  |  |  |
| 65   | 801243   | 1    | Screw            |  |  |  |  |
| 75   | 801237   | 1    | Washer           |  |  |  |  |
| 304  | 801257   | 1    | Housing-Blower   |  |  |  |  |
| 305  | 801239   | 1    | Screw            |  |  |  |  |
| 318  | 801241   | 1    | Screw            |  |  |  |  |
| 332  | 801238   | 1    | Nut              |  |  |  |  |
| 455  | 801235   | 1    | Cup-Flywheel     |  |  |  |  |
| 493  | 801240   | 1    | Bracket-Mounting |  |  |  |  |
| 592  | 801244   | 1    | Nut              |  |  |  |  |
| 608  | 801242   | 1    | Starter-Rewind   |  |  |  |  |
| 1335 | 801269   | 1    | Nut              |  |  |  |  |
| 1397 | 801270   | 1    | Washer           |  |  |  |  |



## Cylinder, Piston, and Connecting Rod Assemblies

### Briggs and Stratton 084133-0196-E1


| Ref  | Part No. | Qty. | Description                      | Ref  | Part No. | Qty. | Description  |
|------|----------|------|----------------------------------|------|----------|------|--------------|
| 1    | 801322   | 1    | Cylinder ASM                     | 1401 | 801290   | 1    | Roller-Strip |
| 3    | 801262   | 1    | Seal-Oil                         |      |          |      |              |
| 5    | 801283   | 1    | Head-Cylinder                    |      |          |      |              |
| 7    | 801263   | 1    | Gasket-Head, Cylinder            |      |          |      |              |
| 13   | 801264   | 1    | Screw (Cylinder Head)            |      |          |      |              |
| 14   | 801265   | 1    | Stud (Cylinder Head)             |      |          |      |              |
| 16   | 801220   | 1    | Crankshaft                       |      |          |      |              |
| 20   | 801261   | 1    | Seal-Oil                         |      |          |      |              |
| 22   | 801266   | 1    | Screw (Crankcase And Cover Sump) |      |          |      |              |
| 22A  | 801271   | 1    | Screw (Crankcase And Cover Sump) |      |          |      |              |
| 24   | 801234   | 1    | Key-Flywheel                     |      |          |      |              |
| 25   | 801279   | 1    | Piston ASM                       |      |          |      |              |
| 26   | 801280   | 1    | Ring Set                         |      |          |      |              |
| 27   | 801275   | 1    | Lock-Pin, Piston                 |      |          |      |              |
| 28   | 801276   | 1    | Pin-Piston                       |      |          |      |              |
| 29   | 801277   | 1    | Rod-Connecting                   |      |          |      |              |
| 32   | 801278   | 1    | Screw                            |      |          |      |              |
| 48   | 801285   | 1    | Short Block                      |      |          |      |              |
| 337  | 801254   | 1    | Plug-Spark                       |      |          |      |              |
| 718  | 690959   | 1    | Pin-Locating                     |      |          |      |              |
| 1036 | 801294   | 1    | Label-Emissions                  |      |          |      |              |
| 1051 | 801274   | 1    | Ring-Retaining                   |      |          |      |              |



## Muffler, Carburetor, and Intake Manifold Assemblies Briggs and Stratton 084133-0196-E1

| Ref  | Part No. | Qty. | Description                                                   |
|------|----------|------|---------------------------------------------------------------|
| ●50  | 801232   | 1    | Manifold-Intake                                               |
| ●51  | 801224   | 1    | Gasket-Intake                                                 |
| ●54  | 801230   | 1    | Screw (Intake Manifold)                                       |
| ●97  | 801306   | 1    | Shaft-Throttle                                                |
| ●106 | 801317   | 1    | Seat-Inlet                                                    |
| ●109 | 801307   | 1    | Shaft-Choke                                                   |
| ●117 | 801310   | 1    | Jet-Main                                                      |
| ●125 | 801233   | 1    | Carburetor                                                    |
| ●133 | 801316   | 1    | Float-Carburetor                                              |
| ●142 | 801313   | 1    | Nozzle-Carburetor                                             |
| ●147 | 801308   | 1    | Jet-Pilot                                                     |
| ●163 | 801227   | 1    | Gasket-Cleaner, Air                                           |
| ●200 | 801289   | 1    | Blade-Governor                                                |
| ●201 | 801225   | 1    | Link-Vane, Air                                                |
| ●209 | 801223   | 1    | Spring-Governor                                               |
| ●300 | 801250   | 1    | Muffler                                                       |
| ●333 | 801268   | 1    | Armature-Magneto                                              |
| ●334 | 801267   | 1    | Screw                                                         |
| ●426 | 801231   | 1    | Screw                                                         |
| ●613 | 801251   | 1    | Screw                                                         |
| ●654 | 801324   | 1    | Nut (Intake Manifold) (Used Before Engine Code Date 05042600) |
| ●711 | 801229   | 1    | Screw (Starter Motor)                                         |

| Ref   | Part No. | Qty. | Description           |
|-------|----------|------|-----------------------|
| ●780  | 801228   | 1    | Anchor-Spring         |
| ●789  | 801253   | 1    | Wire ASM              |
| ●883  | 801252   | 1    | Gasket-Exhaust        |
| ●977  | 801312   | 1    | Gasket Set-Carburetor |
| ●996  | 801226   | 1    | Shield-Carburetor     |
| ●1127 | 801318   | 1    | Screw                 |



**Flywheel, Blower Housing, and Starter Assemblies**  
**Briggs and Stratton 084133-0196-E1**

| Ref  | Part No. | Qty. | Description            |  |  |  |  |
|------|----------|------|------------------------|--|--|--|--|
| 23   | 801246   | 1    | Flywheel               |  |  |  |  |
| 65   | 801243   | 1    | Screw                  |  |  |  |  |
| 75   | 801237   | 1    | Washer                 |  |  |  |  |
| 304  | 801236   | 1    | Housing-Blower         |  |  |  |  |
| 305  | 801239   | 1    | Screw (Blower Housing) |  |  |  |  |
| 309  | 801247   | 1    | Motor-Starter          |  |  |  |  |
| 318  | 801241   | 1    | Screw                  |  |  |  |  |
| 332  | 801238   | 1    | Nut                    |  |  |  |  |
| 455  | 801235   | 1    | Cup-Flywheel           |  |  |  |  |
| 493  | 801240   | 1    | Bracket-Mounting       |  |  |  |  |
| 510  | 801293   | 1    | Drive-Starter          |  |  |  |  |
| 592  | 801244   | 1    | Nut                    |  |  |  |  |
| 608  | 801242   | 1    | Starter-Rewind         |  |  |  |  |
| 697  | 801248   | 1    | Screw                  |  |  |  |  |
| 813  | 801249   | 1    | Clamp                  |  |  |  |  |
| 1335 | 801269   | 1    | Nut                    |  |  |  |  |
| 1397 | 801270   | 1    | Washer                 |  |  |  |  |

