



## Roll-Over Protection System Multi-Pro® 5000 Series Turf Sprayer

Model No. 41566

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



## Roll-Over Protection System Assembly

| Ref | Part No.   | Qty. | Description              |
|-----|------------|------|--------------------------|
| 1   | 95-2250    | 1    | Rear ROPS Bar ASM        |
| 1:1 | 32148-6    | 14   | Insert-Nut               |
| 1:2 | 93-9850    | 1    | Decal-Roll Over          |
| 1:3 | 92-3788    | 4    | Insert                   |
| 1:4 | 106-4969   | 1    | Decal-Warning, ROPS Ce   |
| 2   | 327-4      | 8    | Screw-HH                 |
| 3   | 3253-8     | 8    | Washer-Lock              |
| 4   | 3217-11    | 8    | Nut-Hex                  |
| 5   | 3296-48    | 4    | Nut-Lock, NI             |
| 6   | 3256-5     | 4    | Washer-Flat              |
| 7   | 110-9720   | 2    | Seat Belt ASM            |
| 8   | 324-5      | 6    | Screw-HH                 |
| 9   | 3232-2     | 2    | Bolt-CARR                |
| 10  | 32128-37   | 4    | Nut-HF                   |
| 11  | 95-2263-03 | 1    | Support-Belt, Outside RH |
| 12  | 3230-1     | 6    | Bolt-CARR                |
| 13  | 32128-44   | 6    | Nut                      |
| 14  | 95-2261-03 | 1    | Support-Belt, Inner RH   |
| 15  | 95-2259-03 | 1    | Support-RH               |
| 16  | 95-2264-03 | 2    | Strap-Support, Belt      |
| 17  | 3230-2     | 2    | Bolt-CARR                |
| 18  | 95-2260-03 | 1    | Support-Belt, Inner LH   |
| 19  | 95-2256-03 | 1    | Support-LH               |
| 20  | 95-2262-03 | 1    | Support-Belt, Outside LH |

| Ref | Part No.    | Qty. | Description |
|-----|-------------|------|-------------|
| 21  | 107-8729-03 | 1    | Support-RH  |
| 22  | 107-8730-03 | 1    | Support-LH  |