



Mid-Size ProLine T-Bar, Gear Drive 15 HP with 52in Side Discharge Mower

Model No. 30319 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine Installation Assembly	 3	Oil Pan / Lubrication Assembly Kohler CV15T-41629	 19
Fuel Tank Assembly	 4	Head / Valve / Breather Assembly Kohler CV15T-41629	 20
Lower Control Assembly	 5	Ignition / Electrical Assembly Kohler CV15T-41629	 21
Transmission Drive Assembly	 6	Blower Housing and Baffle Assembly Kohler CV15T-41629	 22
Wheel Drive and Brake Assembly	 7	Starting System Assembly Kohler CV15T-41629	 23
Upper Handle Assembly	 8	Fuel System Assembly Kohler CV15T-41629	 24
Control Panel Assembly	 9	Engine Control Assembly Kohler CV15T-41629	 25
Carrier Frame Assembly	 10	Air Intake / Filtration Assembly Kohler CV15T-41629	 26
Spindle, Pulley and Belt Assembly	 11	Exhaust Assembly Kohler CV15T-41629	 27
Spindle Assembly No. 106-0787	 12	Attachments and Accessories List	 28
Spindle Assembly No. 106-0785	 13		
Deck Assembly	 14		
Deflector Assembly No. 107-4194	 15		
Drive Belt and Tensioner Assembly	 16		
Crankshaft Assembly Kohler CV15T-41629	 17		
Crankcase Assembly Kohler CV15T-41629	 18		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain from your local Kohler dealer



Engine Installation Assembly


Ref	Part No.	Qty.	Description
1	92-6877	1	Valve-Drain, Oil
2	1-603610	2	Washer-Spring
3	106-0699	1	Decal-Warning, Hot Surfaces
4	106-0699	1	Engine-Kohler, Cv15T-41629
5	32144-19	1	Screw-SHWH
6	2412-87	1	Clamp-Cable
7	2412-98	2	Clamp
8	110-4894	1	Hose-Fuel
9	104-8136	1	Harness-Wire
10	33104-025	1	Screw-HHF
11	3255-8	1	Washer-Lock
12	32128-20	2	Nut-HF
13	237-124	1	Grommet
14	104-6373	1	Tube-Retainer
15	1-613235	4	Washer
16	1-633630	2	Grommet-Brake
17	1-633545	2	Spacer
18	1-633543-03	1	Strap-Clutch, Brake
19	322-11	1	Screw-HH
20	3256-23	5	Washer-Flat
21	33114-025	4	Screw-HH
23	322-7	1	Screw-HH
24	3212-9	1	Screw-HH
25	107-4136	1	Washer

Ref	Part No.	Qty.	Description
26	105-2635	1	Clutch / Brake
27	107-4112	1	Pulley-Drive
28	608006	1	Key-Square
29	94-5847-01	1	Cover-Pulley
30	56-6360	1	Filter-Fuel
31	2412-134	1	R-Clamp
32	12-3270	1	Screw
99	103-1964	1	Hose-Drain, Oil




Fuel Tank Assembly

Ref	Part No.	Qty.	Description				
1	88-3980	1	Gas Cap ASM				
1:3	88-4010	1	Gasket-Cap, Gas				
2	106-0730	1	Fuel Tank ASM				
2:2	103-2605	1	Fitting-Fuel, Bulkhead				
3	104-8121	2	Stud-Threaded				
6	3256-23	4	Washer-Flat				
7	1-633349	2	Spring-Tank, Fuel				
8	3296-47	2	Nut-Lock, NI				
9	106-0546-01	1	Gear Frame ASM				
10	2412-98	4	Clamp				
11	110-4894	1	Hose-Fuel				
12	1-603770	1	Valve-Fuel				
14	109-0678	1	Hose-Fuel				
15	322-4	2	Screw-HH				
16	3253-4	2	Washer-Lock				
17	95-2814	1	Decal-Shut Off, Fuel				
18	98-0776	1	Decal-Caution				



Transmission Drive Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	47-1970	1	Grip	25	27-6230	1	Bolt-Wheel
2	98-3274-03	1	Lever-Shift	26	323-9	1	Screw-HH
3	3296-6	2	Nut-Lock	27	16-7509	1	Lever-Idler
4	98-5975	1	Washer-Belleville	27:1	256-155	2	Bushing-Flange
5	1-323379	1	Washer	28	62-4540	1	Pulley
6	1-323500	1	Transmission	29	3296-39	1	Nut-Lock, NI
7	302-5	2	Fitting-Grease	30	322-2	4	Screw-HH
8	1-323680	2	Coupler	31	3253-4	4	Washer-Lock
9	51-4220	2	Guard-Coupler	32	3296-42	4	Nut-Lock, NI
10	1-323254	2	Flange-Output	33	1-323389-03	2	Bracket-Plate, Shift
11	321-4	4	Screw-HH	34	9264964	4	Screw-HWH, Thread Cut
12	3257-5	3	Key-Woodruff	35	32128-20	2	Nut-HF
13	3245-9	2	Screw-Set	36	1-323387-03	1	Plate-Shift
14	32151-62	2	Ring-Retaining	37	3230-1	2	Bolt-CARR
15	105-2698	2	Pulley-Transmission	38	98-3256	1	Decal-Speed, Ground
16	104-1102	2	Shaft-Output				
17	1-323252	2	Bearing-Shaft				
18	95-1529	1	Rod-Shield				
19	95-1526	1	Shield-Trailing				
20	105-5646	1	Pulley-Driven				
21	3245-1	1	Screw-Set, HSH				
22	32120-64	1	Ring-Snap, External				
23	105-5668	1	V-Belt				
24	68-2190	1	Spring				



Wheel Drive and Brake Assembly


Ref	Part No.	Qty.	Description
1	32151-72	4	Ring-Retaining
2	32151-56	2	Ring-Retaining, External
3	106-8792	2	Plate-Link, Brake
4	106-8779-01	2	Brake Arm ASM
6	3290-307	2	Pin-Hair
7	51-4580	2	Rod-Brake
8	32151-40	2	Ring-Retaining
9	106-8773	2	Brake Link ASM
10	51-4290	2	V-Belt
12	3296-29	8	Nut-Lock, NI
13	254-94	4	Bearing-Cone, Tapered
14	1-523157	2	Washer-Spacer, 14 GA
15	1-809082	2	Nut-SHH
16	106-0892	2	Wheel And Tire ASM
16:1	104-6322	1	Tire
16:2	106-0893	1	Wheel
16:3	232-27	1	Stem-Valve
17	242-50	8	Nut-Lug
18	241-119	2	Cap-Dust
19	1-413333	2	Hub/Wheel ASM
19:2	254-72	2	Bearing-Cup, Tapered
19:3	302-19	1	Fitting-Grease
19:4	1-633926	4	Stud-Wheel
20	106-5544	2	Pulley-Wheel

Ref	Part No.	Qty.	Description
22	1-323262	2	Band-Brake
23	322-5	8	Screw-HH
24	1-543511	2	Seal-Grease
25	104-1197	2	Spacer-Wheel
26	104-1196-01	1	Axle ASM
27	1-806800	2	Pin-Cotter
28	32128-21	6	Nut-HF
29	3234-11	6	Screw-HHF




Upper Handle Assembly

Ref	Part No.	Qty.	Description				
1	105-4677	2	Rod-Control				
2	3272-4	2	Pin-Cotter				
3	237-141	2	Grommet-Rubber				
4	82-2290	1	Decal				
5	82-7680-03	1	Bail ASM				
6	82-7690-03	1	Bar-Control				
7	82-2280	1	Decal				
8	106-5477-03	1	Control Pivot ASM				
9	3272-11	2	Pin-Cotter				
10	105-3158-03	1	Upper Handle ASM				
11	283-55	2	Pin-Clevis				
12	3290-378	1	Tie-Cable				
13	32128-21	4	Nut-HF				
14	3234-11	4	Screw-HHF				
15	98-4387	1	Decal-Protection, Ear				
16	32105-1	1	Screw-SHH				
17	51-4850-03	1	Lever-Brake, Parking				
18	52-2010	1	Decal-Lever, Parking				
19	3296-2	1	Nut-Lock				
20	218-595	1	Connector-Body				
21	82-2190	1	Switch-Bail				




Control Panel Assembly

Ref	Part No.	Qty.	Description				
1	105-0884	1	Decal-Danger				
2	63-8360	1	Key-Ignition				
3	107-4102	1	Cable-Throttle				
4	32104-76	4	Screw				
5	32105-14	4	Screw-SHH				
6	3296-42	1	Nut-Lock, NI				
7	104-8141	1	Module-Delay				
8	93-1187-03	1	Panel-Bottom				
9	321-2	1	Screw-HH				
12	3296-2	4	Nut-Lock				
13	29-5560	1	Switch-On / Off				
13:1	218-461	1	Nut-HH				
13:2	3254-5	1	Washer-Tooth				
14	2412-120	2	R-Clamp				
15	104-7050	1	Housing-Manual				
16	104-8140	1	Switch-PTO				
17	104-8177-03	1	Panel-Control				
18	106-5499	1	Decal-Control Panel				
19	104-7048	1	Cap-Housing				



Carrier Frame Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-0708	1	Carrier Frame ASM	19:3	83-4740	1	Bearing
1:2	32148-9	3	Insert-Nut	19:4	62-5580	2	Bearing-Outside
1:3	94-1291	4	Bushing	19:5	100-6452	1	Tire-Tubeless
1:4	302-5	2	Fitting-Grease	20	100-6453	2	Bushing-Spanner
2	106-3360-01	1	Cover-Frame, Carrier	21	325-19	2	Screw-HH
3	106-0719	1	Decal	22	283-71	2	Pin-Lynch
4	240-3	1	Grommet-Rubber	23	3-6781	8	Washer-Thrust
5	106-0565	3	Washer-Rubber	24	106-5505	1	Decal-Service, Gear (Tbar)
6	106-0887	3	Knob	24	106-5503	1	Decal-Service, Hydro (Tbar)
7	12-3270	2	Screw	24	106-5511	1	Decal-Service, Gear (Pistol Grip)
8	106-3361-01	1	Shield-Heat	24	106-5513	1	Decal-Service, Hydro (Pistol Grip)
9	3290-199	2	Nut-Speed				
10	104-1105	4	Spacer-Support, Deck				
11	1-513336	2	Bushing-Deck				
12	321-5	2	Screw-HH				
13	3256-22	2	Washer-Flat				
14	32120-33	2	Ring-Retaining				
15	1-323539	4	Spacer-Drive, Blade				
16	106-0635	2	Decal-HOC				
17	105-3159-01	2	Castor Fork ASM				
18	32153-5	2	Nut-Lock, Side				
19	100-6451	2	Caster Wheel ASM				
19:1	232-27	1	Stem-Valve				
19:2	302-11	1	Fitting-Lube, 45 DEG				



Spindle, Pulley and Belt Assembly


Ref	Part No.	Qty.	Description
1	106-0619	1	Deck ASM
1:2	32148-10	2	Insert-Threaded
1:3	66-1340	1	Decal-Danger
1:4	106-0705	1	Decal
1:5	93-1122	1	Decal-Danger
1:6	67-5360	3	Decal-Danger
1:7	104-8186	1	Decal-Routing, Belt
1:8	68-8340	1	Decal-Torque
1:9	43-8480	1	Decal-Danger
1:10	106-5532	1	Decal-Anti Scalp
2	104-6397	1	V-Belt
3	3256-24	5	Washer-Flat
4	323-8	1	Screw-HH
5	105-0850	1	Guide-Belt
6	98-5980	1	Guide-Belt
7	104-6396	1	Guide-Belt
8	32128-21	20	Nut-HF
9	52-4780	1	Rod-Belt
10	3231-22	18	Screw-CARR
11	104-6374	1	Plate-Spring
12	104-6375	1	Idler Arm ASM
13	3296-5	1	Nut-Lock
14	7-0081	1	Washer-Flat
15	65-5940	1	Pulley-Idler

Ref	Part No.	Qty.	Description
16	104-6379	1	Bushing-Pulley
17	51-3650	1	Spring-Extension
18	3211-8	1	Screw-HH
19	51-3640	1	Sleeve
20	106-0787	2	Spindle Housing ASM
21	27-0990-03	3	Blade-18 Inch
22	44-2200	3	Screw-Blade
23	3256-6	3	Washer-Flat
24	92-9820	3	Stiffener-Blade
25	323-6	1	Screw-HH
26	323-11	1	Screw-HH
27	106-0785	1	Spindle Housing ASM
28	32128-25	1	Nut-HF
29	3256-3	1	Washer-Flat




Spindle Assembly No. 106-0787

Ref	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex
2	7-4150	1	Washer
3	104-1118	1	Pulley And Hub ASM
4	106-0873	1	Shield-Bearing
5	104-6325	2	Bearing
6	106-0819	1	Housing-Spindle
7	106-0795	1	Spacer-Bearing
8	106-0782	1	Shaft-Spindle



Spindle Assembly No. 106-0785


Ref	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex
2	7-4150	1	Washer
3	104-1117	1	Pulley And Hub ASM
4	106-0873	1	Shield-Bearing
5	104-6325	2	Bearing
6	106-0819	1	Housing-Spindle
7	106-0795	1	Spacer-Bearing
8	106-0781	1	Shaft-Spindle



Deck Assembly


Ref	Part No.	Qty.	Description
1	107-4194	1	Deflector ASM
2	105-4622	1	Spacer
3	104-8554	1	Spring-Torsion
4	3296-29	3	Nut-Lock, NI
5	3296-39	10	Nut-Lock, NI
6	3256-24	6	Washer-Flat
7	1-603299	6	Roller-Scalp, Anti
8	99-2842	3	Spacer
9	106-3363-01	1	Cover-Belt, RH
10	106-3362-01	1	Cover-Belt, LH
11	106-0565	2	Washer-Rubber
12	106-0887	2	Knob
13	106-0684	2	Front Pin ASM
14	3220-3	2	Nut-Hex, Jam
15	1-613204	2	Balljoint
16	104-1156	2	Spacer
17	323-8	2	Screw-HH
18	106-3365	2	Rear Pin ASM
19	3290-256	6	Pin-Hair
20	323-10	2	Screw-HH
21	32128-20	6	Nut-HF
22	322-1	6	Screw-HH
23	3230-30	1	Screw-CARR
24	106-0563	1	Spacer-Wheel

Ref	Part No.	Qty.	Description
25	106-0545	1	Bushing-Roller
26	3256-23	3	Washer-Flat
27	98-5967	1	Spacer-Wheel
28	322-50	2	Screw-HH




Deflector Assembly No. 107-4194

Ref	Part No.	Qty.	Description
1	3231-4	4	Screw-CARR
2	106-3246-01	1	Deflector
3	106-3248-03	1	Strap-Discharge
4	108-5029	1	Deflector-Rubber
5	107-4197-01	1	Bracket-Hinge, Rear
6	107-4196-01	1	Bracket-Hinge, Front
7	3296-39	4	Nut-Lock, NI




Drive Belt and Tensioner Assembly

Ref	Part No.	Qty.	Description				
1	322-7	2	Screw-HH				
2	3256-23	2	Washer-Flat				
3	105-3173-01	1	Weight-Rear				
4	3296-29	2	Nut-Lock, NI				
5	3296-39	1	Nut-Lock, NI				
6	52-2860	3	Washer				
7	104-6377	1	Tube-Idler				
8	106-0734	1	Idler Arm ASM				
8:1	1-513034	2	Sleeve-Bearing				
8:2	302-5	1	Fitting-Grease				
9	323-42	1	Screw-HH				
10	323-6	1	Screw-HH				
11	98-5975	1	Washer-Belleville				
12	3256-24	1	Washer-Flat				
13	1-413099	1	Pulley-Idler				
14	105-8443	1	Spring-Extension				
15	106-0632	1	V-Belt				



Crankshaft Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❸1	12 014 30-S	1	Crankshaft (Includes 2)
❸2	12 139 01-S	1	Plug-Cup



Crankcase Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❶1	12 032 03-S	1	Seal-Oil
❶2		1	Crankcase (Use: Short Block 12 522 18)
❶3	12 445 02-S	1	Strap-Lifting
❶4	M-839025-S	1	Screw-HF (M8X1.25X25)
❶5	24 380 13-S	4	Pin-Locating
❶6	12 067 05-S	1	Rod-Connecting (STD)
❶	12 067 06-S	1	Rod-Connecting (.25)
❶7	12 755 49-S	1	Camshaft Kit (Includes 8,9)
❶8	12 089 31-S	1	Spring-Actuating
❶9	12 422 08-S	1	Shim-Camshaft (Blue)
❶	12 422 09-S	1	Shim-Camshaft (Red)
❶	12 422 10-S	1	Shim-Camshaft (Yellow)
❶	12 422 11-S	1	Shim-Camshaft (Green)
❶	12 422 12-S	1	Shim-Camshaft (Gray)
❶	12 422 13-S	1	Shim-Camshaft (Black)
❶	12 422 07-S	1	Shim-Camshaft (White)
❶10	12 144 27-S	1	Shaft-Balance
❶11	12 874 07-S	1	Piston W/Ring Set (STD) (Includes 12-13)
❶	12 874 11-S	1	Piston W/Ring Set (.08)
❶	12 874 08-S	1	Piston W/Ring Set (.25)
❶	12 874 09-S	1	Piston W/Ring Set (.50)
❶12	12 018 02-S	2	Retainer-Pin, Piston

Ref	Part No.	Qty.	Description
❶13	12 108 07-S	1	Ring Set (STD. And .08)
❶	12 108 08-S	1	Ring Set (.25)
❶	12 108 09-S	1	Ring Set (.50)
❶14	12 380 01-S	1	Pin-Regulating, Governor
❶15	12 043 05-S	1	Gear-Governor
❶16	M-631005-S	1	Washer-Plain (6 Mm)
❶17	12 144 02-S	1	Shaft-Gear, Governor
❶18	52 139 09-S	1	Plug-Cup
❶19	12 755 64-S	1	Governor Cross Shaft Kit (Includes 23)
❶20	X-25-102-S	1	Washer-Plain
❶21	12 032 01-S	1	Seal-Cross Shaft, Governor
❶22	M-631015-S	1	Washer-Plain
❶23	12 154 05-S	1	Clip-Pin, Hitch



Oil Pan / Lubrication Assembly
Kohler CV15T-41629


Ref	Part No.	Qty.	Description				
❶1	12 038 01-S	1	Dipstick ASM (Includes 2-3)				
❷2	25 755 13-S	1	Oil Fill Cap ASM (Includes 3)				
❸3	25 153 02-S	1	O-Ring				
❹4	12 153 02-S	1	O-Ring (Upper Oil Fill Tube)				
❺5	12 123 04-S	1	Oil Fill Tube ASM				
❻6	M-545020-S	1	Screw-HHFTF (M5X0.8X20)				
❼7	12 153 01-S	1	O-Ring-Lower Oil Fill Tube				
❽8	25 162 07-S	1	Screen-Pickup, Oil				
❾9	12 096 03-S	1	Cover-Screen, Oil Pickup				
❿10	M-545016-S	1	Screw-HHFTF (M5X0.8X16)				
⓫11	12 050 01-S	1	Filter-Oil				
⓬12	12 199 50-S	1	Oil Pan ASM (Includes 13, 17-19)				
⓭13	25 462 09-S	1	Valve-Relief, Oil Pressure				
⓮14	25 139 57-S	2	Plug-Square Head Solid (3/8)				
⓯15	25 139 52-S	1	Plug-Pipe (1/8In)				
⓰16	25 139 62-S	1	Plug, Pipe 3/8In Hex Ctsk				
⓱17	M-545016-S	3	Screw-HHFTF (M5X0.8X16)				
⓲18	12 096 34-S	1	Cover-Pump, Oil				
⓳19	12 153 06-S	1	O-Ring (Oil Pump Cover)				
⓴20	12 393 01-S	1	Oil Pump ASM				
⓵21	12 032 03-S	1	Seal-Oil				
⓶22	24 086 16-S	10	Screw-HF (M8X1.25X45)				
⓷23	24 086 17-S	1	Screw-HF (M8X1.25X45)				



Head / Valve / Breather Assembly Kohler CV15T-41629


Ref	Part No.	Qty.	Description
❶	25 351 01-S	2	Lifter-Valve
❷	12 411 04-S	2	Rod-Push
❸	12 041 10-S	1	Gasket-Head, Cylinder
❹	12 017 01-S	1	Valve-Intake (STD)
❺	12 016 01-S	1	Valve-Exhaust (STD)
❻	25 139 60-S	1	Plug-Hex, Countersunk (1/8)
❼	12 318 19-S	1	Head-Cylinder
❽	12 146 22-S	2	Plate-Guide
❾	25 072 12-S	2	Stud-Rocker
❿	25 186 01-S	2	Arm-Rocker
⓫	12 599 03-S	2	Pivot-Arm, Rocker
⓬	25 100 29-S	2	Nut-Hex
⓭	25 086 112-S	2	Screw-Set
⓮	66 032 05-S	2	Seal-Stem, Valve
⓯	12 089 34-S	2	Spring-Valve
⓰	12 173 01-S	2	Cap-Spring, Valve
⓱	12 755 03-S	2	Retainer Kit
⓲	12 468 05-S	1	Washer-Flat (1/2)
⓳	12 112 13-S	1	Spacer-Head Bolt (Exhaust Port)
⓴	20 086 02-S	5	Screw-Flange, Hex (M10X1.5X37)
⓵	25 237 14-S	1	Clamp-Hose
⓶	12 326 18-S	1	Hose-Breather
⓷	M-645016-S	3	Screw-HHFTF (M6X1.0X16)
⓸	12 096 47-S	1	Cover-Valve

Ref	Part No.	Qty.	Description
❷❸	M-545010-S	1	Screw-HHFTF (M5X0.8X10)
❷❹	66 018 04-S	1	Retainer-Reed, Breather
❷❺	12 402 02-S	1	Reed-Breather
❶❶	12 017 02-S	1	Valve-Intake (.25)
❶❷	12 016 02-S	1	Valve-Exhaust (.25)
❶❸	12 041 01-S	1	Gasket-Carburetor
❶❹	12 041 02-S	1	Gasket-Base, Air Cleaner
❶❺	12 041 03-S	1	Gasket-Manifold, Exhaust




Ignition / Electrical Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶1	12 086 14-S	1	Screw-Hex Flange (M10X1.5X45)				
❷2	12 468 03-S	1	Washer-Flat (3/8)				
❸3	24 162 03-S	1	Screen-Grass				
❹4	25 086 47-S	4	Bolt-Shoulder (M6X1.0X16)				
❺5	12 157 03-S	1	Fan				
❻6	X-42-15-S	1	Key				
❼7	12 025 56-S	1	Flywheel				
❽8	12 403 01-S	1	Rectifier-Regulator				
❾9	M-639016-S	2	Screw-HF (M6X1.0X16)				
❿10	236602-S	1	Connector (3 Contact)				
⓫11	41 155 03-S	1	Connector				
⓬12	M-548025-S	2	Screw-HHFTF (M5X0.8X25)				
⓭13	237878-S	1	Stator Kit (Includes 25 452 01-S)				
⓮14	12 132 02-S	1	Spark Plug				
⓯15	X-728-1-S	2	Clip				
⓰16	M-545010-S	2	Screw-HHFTF (M5X0.8X10)				
⓱17	12 584 05-S	1	Module-Ignition				
⓲18	M-545020-S	2	Screw-HHFTF (M5X0.8X20)				
⓳❶	X-22-11-S	1	Washer-Lock, Internal Tooth (1/4)				
⓴❶	12 518 01-S	1	Lead				
⓵❶	25 518 05-S	1	Lead				
⓶❶	24 518 12-S	1	Lead-Black				
⓷❶	25 452 01-S	1	Terminal				




Blower Housing and Baffle Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❶	M-545010-S	9	Screw-HHFTF (M5X0.8X10)				
❷	12 146 07-S	1	Plate-Housing, Blower				
❸	M-550010-S	6	Screw-HF (M5X0.8X10)				
❹	12 096 29-S	1	Cover-Starter				
❺	12 027 68-S	1	Housing-Blower				
❻	12 063 10-S	1	Baffle-Side, Intake				
❼	12 313 03-S	1	Grommet-Spark Plug				
❽	12 063 08-S	1	Baffle-Head, Cylinder				
❾	12 063 19-S	1	Baffle (Cylinder)				
❿	12 113 124-S	1	Decal-15Hp				
⓫	25 113 39-S	1	Decal-Clear Laminat				




Starting System Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	M-550010-S	5	Screw-HF (M5X0.8X10)				
❸2	12 165 01-S	1	Retractable Starter ASM (Includes 3-9)				
❸3	12 081 01-S	1	Housing-Starter				
❸4	25 166 01-S	1	Handle-Start, Recoil				
❸5	12 160 01-S	1	Rope-Starter				
❸6	12 089 06-S	1	Spring And Keeper				
❸7	12 093 01-S	1	Pulley				
❸8	12 757 06-S	1	Dog Repair Kit				
❸9	41 086 09-S	1	Screw-Pozi Driv				
❸10	15 109 01-S	1	Cup-Drive				
❶❸	12 113 07-S	1	Decal-Starting				



Fuel System Assembly
Kohler CV15T-41629


Ref	Part No.	Qty.	Description				
❶1	M-641060-S	2	Nut-Hex Flange (M6X1.0)				
❶2	M-629116-S	2	Stud (M6X1.0X116)				
❶3	12 853 140-S	1	Carburetor Kit (Includes 4-5)				
❶4	12 041 02-S	1	Gasket-Base, Air Cleaner				
❶5	12 041 01-S	2	Gasket-Carburetor				
❶6	12 265 04-S	1	Deflector-Heat				
❶7	47 154 01-S	1	Clip-Cable				
❶❸	12 757 02-S	1	Float Kit				
❶❸	12 757 03-S	1	Carburetor Repair Kit				
❶❸	12 757 08-S	1	Choke Repair Kit				
❶❸	12 757 36-S	1	Throttle Shaft Bearing Kit				
❶❸	12 757 37-S	1	Bowl Replacement Kit				
❶❸	12 755 92-S	1	High Altitude Kit				



Engine Control Assembly

Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	M-664020-S	2	Screw-Socket, 6 Lobed (Thread Forming, M6X1.0X20)				
❸2	M-545016-S	1	Screw-HHFTF (M5X0.8X16)				
❸3	12 237 01-S	1	Clamp-Cable				
❸4	12 536 01-S	1	Speed Control ASM (Includes 5-7)				
❸5	12 086 39-S	1	Screw-Pan Head (W/Loctite)				
❸6	12 089 11-S	1	Spring-Control, Speed				
❸7	12 089 23-S	1	Spring-Return, Choke				
❸8	12 089 19-S	1	Spring-Governor				
❸9	12 755 83-S	1	Governor Lever Kit (Includes 10-12)				
❸10	12 100 07-S	1	Nut-Flange, Hex (1/4-20)				
❸11	52 211 04-S	1	Bolt-Square Neck, Round Head (1/4-20X1)				
❸12	12 090 28-S	1	Lever-Governor				
❸13	25 158 08-S	1	Bushing-Retaining, Linkage				
❸14	12 079 01-S	1	Linkage-Throttle				
❸15	25 158 11-S	1	Bushing-Throttle, Linkage				
❸16	12 079 07-S	1	Linkage-Choke				



Air Intake / Filtration Assembly
Kohler CV15T-41629

Ref	Part No.	Qty.	Description				
❸1	12 743 04-S	1	Air Cleaner Kit (Includes 2-11)				
❸2	20 341 01-S	1	Knob-Cover				
❸3	12 096 44-S	1	Cover-Cleaner, Air				
❸4	12 083 12-S	1	Element-Precleaner				
❸5	12 083 10-S	1	Element-Cleaner, Air (Includes 6-7)				
❸6	12 100 01-S	1	Nut-Wing				
❸7	12 032 11-S	1	Seal				
❸8	12 072 04-S	1	Stud				
❸9	12 086 01-S	2	Screw				
❸10	12 094 14-S	1	Base-Cleaner, Air				
❸11	12 041 02-S	1	Gasket-Base, Air Cleaner				
❶❸	12 113 04-S	1	Decal-Cleaner, Air				

Attachments and Accessories

For 30319 - Mid-Size ProLine T-Bar Gear, 15 HP with 52in Side Discharge Mower

Product Name	Model/Part
Blade-Atomic	104-1301
Electric Starter Kit	104-8580
Striping Kit	106-3370
Weight Kit	106-5491
Soft Bag (3 Bushel)	30104
Steel Grass Catcher	30107
Tru Trak Sulky	30110
Extra High Lift Blade	56-2390
Blade-Recycler	92-7961
52 Inch Recycler Kit	99-4586
52 Inch Mulching Kit	99-8530

NOTES

NOTES

NOTES

