



Commercial Walk-Behind Mower Fixed Deck, Pistol Grip, Gear-Drive with 40 inch TURBO FORCE® Cutting Unit

Model No. 30686 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel Tank Assembly	 3	Lubrication Equipment Assembly Kawasaki Model FH430V-AS25	 19
Transmission Drive Assembly	 4	Cooling Equipment Assembly Kawasaki Model FH430V-AS25	 20
Drive Wheel and Brake Assembly	 6	Electric Equipment Assembly Kawasaki Model FH430V-AS25	 21
Handle and Control Assembly	 7	Control Equipment Assembly Kawasaki Model FH430V-AS25	 22
Control Panel Decal Assembly No. 110-6906	 9	Carburetor Assembly Kawasaki Model FH430V-AS25	 23
Deck Assembly	 10	Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25	 24
Deck Decal Assembly No. 110-4908	 11	Fuel Tank and Fuel Valve Assembly Kawasaki Model FH430V-AS25	 25
Deflector Assembly No.110-0790	 12	Starter Assembly Kawasaki Model FH430V-AS25	 26
Sheave, Spindle and Blade Assembly	 13	Label Assembly Kawasaki Model FH430V-AS25	 27
Idler Assembly	 14	Attachments and Accessories List	 28
Caster Assembly	 15		
Cylinder and Crankcase Assembly Kawasaki Model FH430V-AS25	 16		
Piston and Crankshaft Assembly Kawasaki Model FH430V-AS25	 17		
Valve and Camshaft Assembly Kawasaki Model FH430V-AS25	 18		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head

Footnotes

❶ Not serviced separately


❷ Obtain from your local Kawasaki dealer



Engine and Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	1-633023	2	Stud
2	3256-23	4	Washer-Flat
3	1-633349	2	Spring-Tank, Fuel
4	3296-47	2	Nut-Lock, NI
5	1-303077	4	Clamp
① 26		1	Engine-Kawasaki, FH430V-As25
7	106-0699	1	Decal-Warning, Hot Surfaces
8	32128-21	1	Nut-HF
9	323-14	1	Screw-HH
10	322-7	4	Screw-HH
11	1-303334	4	Washer-Spring
12	103-1966	1	Adapter
13	92-6877	1	Valve-Drain, Oil
14	32128-20	4	Nut-HF
15	109-0293	1	Hose-Fuel
16	1-603770	1	Valve-Fuel
17	109-0306	1	Hose-Fuel
18	322-3	2	Screw-HH
19	1-805005	2	Washer-Lock
20	106-0730	1	Fuel Tank ASM
20:2	103-2605	1	Fitting-Fuel, Bulkhead
21	88-3980	1	Gas Cap ASM
21:3	88-4010	1	Gasket-Cap, Gas
22	33113-016	1	Screw-HH


Ref	Part No.	Qty.	Description
23	1-805004	1	Washer-Lock
24	100-6467	1	Muffler
25	103-5465	1	Clamp-Muffler
26	5-0652	2	Spacer
27	3296-39	1	Nut-Lock, NI
28	1-413510	1	Clip-Loom
29	33114-016	1	Screw-HH
30	323-8	8	Screw-HH
31	98-5975	8	Washer-Belleville
32	3290-357	8	Nut-HHF, Whiz
99	103-1964	1	Hose-Drain, Oil



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	103-9897-01	1	Deck-Engine
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	2	Screw-Set
5	103-6511	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key-Machine
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513051	1	Switch-Open, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission
25	302-19	2	Fitting-Grease

Ref	Part No.	Qty.	Description
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	105-4104	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-HWH, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	3	Pin-Hair
41	1-303186	1	Bellcrank
42	3290-357	1	Nut-HHF, Whiz
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission
50	110-0504	1	Pulley Assembly



Transmission Drive Assembly (continued)


Ref	Part No.	Qty.	Description				
56	1-603610	2	Washer-Spring				
57	3212-6	1	Screw-HH				
58	1-633453	1	Spacer-Clutch				
59	1-373034	2	Washer				
62	32128-33	2	Nut-HF				
64	103-1797-01	1	Bracket-Cable, Choke				
65	103-1796	1	Cable-Choke				
66	1-303282	1	Switch-Start, Neutral				
67	1-323303	1	Linkage-Arm				
68	110-0749	1	Belt-V				
69	1-808280	1	Pin-Clevis				
70	1-303105	1	Yoke-Adjustable				
71	3219-2	1	Nut-Hex				
73	321-4	1	Screw-HH				
74	1-323430	1	Module-Interlock				
75	1-323229	1	Clip-Loom				
76	3256-22	1	Washer-Flat				
77	3296-42	1	Nut-Lock, NI				
78	1-303335	3	Tie-Plastic				



Drive Wheel and Brake Assembly

Ref	Part No.	Qty.	Description
2	99-8664	2	Screw-HH
3	32151-47	6	Ring-Retaining
4	1-806003	2	Pin-Hair
5	1-323245	2	Spring-Compression
6	103-1864	2	Swivel-Lever, Drive
7	322-6	2	Screw-HH
9	3256-23	4	Washer-Flat
10	1-323548	2	Linkage-Brake
11	1-322125	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	10	Nut-HHF, Whiz
14	323-39	4	Screw-HH
18	1-323277	2	Idler-Wheel, Drive
19	302-19	2	Fitting-Grease
21	1-323307	2	Pin-Clevis
22	103-1611-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	2	Nut-Push
25	1-323262	2	Band-Brake
26	1-322117-03	1	Axle
27	1-523157	6	Washer-Spacer, 14 GA
27	1-543436	8	Washer-Spacer, 16GA
28	1-323261	2	Drum-Brake
29	1-323253	4	Sheave-Wheel, Drive


Ref	Part No.	Qty.	Description
34	1-808519	2	Ring-Snap
35	1-323260	8	Spacer-Sheave, Wheel
36	322-6	8	Screw-HH
38	1-323631	2	V-Belt
39	3296-29	4	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville
44	323-6	4	Screw-HH
46	1-805005	8	Washer-Lock
47		2	Wheel And Tire ASM
47:1	1-323720	1	Tire-Turfmaster
47:2	1-323328	1	Wheel And Hub ASM
47:2:1	1-323329	2	Bearing-Flanged
50	32128-20	4	Nut-HF
52	3296-39	4	Nut-Lock, NI
53	1-323287-01	2	Shield-Wheel, Drive
55	1-603402	2	Spring-Extension
56	1-323283	4	Spacer-Shield
57	103-1615-03	1	Arm-Idler, LH
58	103-1616-03	1	Arm-Idler, RH



Handle and Control Assembly

Ref	Part No.	Qty.	Description
1	1-808286	2	Pin-Clevis
2	1-323359	2	Linkage-Wheel, Drive
4	1-303365	2	Bushing-Nylon
5	106-2717-03	1	Rod-Control, Operator Presence
6	106-5486	1	RH Opc Lever ASM
7	104-9838	2	Grip-Foam
8	321-18	2	Screw-HH
9	1-303435	6	Washer-Spring
10	1-323549	2	Spacer
11	3296-42	2	Nut-Lock, NI
12	3290-500	2	Screw-PPH
13	1-513051	1	Switch-Open, Normally
14	1-806003	3	Pin-Hair
15	1-633181	1	Plate-Tapped
16	110-6906	1	Gear Handle ASM
17	1-303363	1	Spring-Extension
18	1-633696	1	Throttle Cable ASM
19	2412-120	2	R-Clamp
20	1-303287	2	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-4	2	Washer-Flat
24	3296-39	1	Nut-Lock, NI
26	1-323298	1	Linkage-Blade, Upper
27	1-322157	1	Lever ASM

Ref	Part No.	Qty.	Description
27:1	1-303020	1	Grip-Lever
28	3234-11	4	Screw-HHF
29	32104-76	2	Screw
30	32128-21	4	Nut-HF
31	104-7050	1	Housing-Manual
32	3296-2	2	Nut-Lock
34	1-513592	1	Knob-Ball
36	1-803001	2	Nut
38	1-807513	2	Bolt-CARR
39	106-5485	1	LH Opc Lever ASM
48	1-324280	1	RH Thumb Latch ASM
48:1	1-303019	1	Grip-Latch
49	1-324279	1	LH Thumb Latch ASM
49:1	1-303019	1	Grip-Latch
50	1-806340	2	Pin-Roll
51	1-808250	2	Pin-Lever, Drive
52	103-1610	1	Harness-Wiring
53	1-303088	1	Clip-Cable
54	1-302006	2	Drive Lever ASM
54:1	1-303021	1	Grip-Lever, Drive
55	29-5560	1	Switch-On / Off
55:1	218-461	1	Nut-HH
55:2	3254-5	1	Washer-Tooth
56	63-8360	1	Key-Ignition




Handle and Control Assembly (continued)

Ref	Part No.	Qty.	Description
57	1-803322	2	Screw-Set
58	323-10	1	Screw-HH
61	104-7048	1	Cap-Housing

Control Panel Decal Assembly No. 110-6906


Ref	Part No.	Qty.	Description				
2	105-4111	2	Decal-Lock, Neutral				
3	106-2737	1	Decal-Warning				
4	106-2733	1	Decal-Throttle				
5	110-6917	1	Decal-Control Panel				
6	95-5537	1	Decal-Engage, Deck				



Deck Assembly


Ref	Part No.	Qty.	Description
1	110-4908	1	Deck ASM
2	110-0795-01	1	Baffle, Adjust
3	108-7273-01	1	Baffle-Discharge
4	108-7282-01	1	Plate-Skid
5	110-0790	1	Deflector ASM
6	110-2034-01	1	Cover-Deck
7	92-1624	5	Screw
8	3290-357	12	Nut-HHF, Whiz
9	322-50	1	Screw-HH
10	105-4622	1	Spacer
11	104-8554	1	Spring-Torsion
12	107-1664	1	Lever ASM
12:1	106-3239	1	Screw-Lock
12:2	107-1644	1	Cap-Lock
12:3	106-3241	1	Lever-Lock
12:4	3296-29	1	Nut-Lock, NI
13	3296-29	1	Nut-Lock, NI
14	106-4161	5	Knob-Handle
15	1-323417	5	Washer
16	1-303536	3	Stud-Shield, Belt (Long)
17	1-303537	2	Stud-Shield, Belt (Short)
18	3231-1	4	Screw-CARR
19	32128-20	5	Nut-HF
20	110-6919	1	Decal

Ref	Part No.	Qty.	Description
21	110-6910-01	1	Baffle ASM
22	323-4	3	Screw-HH




Deck Decal Assembly No. 110-4908

Ref	Part No.	Qty.	Description
2	99-3943	1	Decal-Routing, Belt
3	43-8480	1	Decal-Danger
4	98-5130	1	Decal-Torque, Bolt
5	104-8569	1	Decal-Warning
6	98-5954	2	Decal-Cover, Missing
7	110-2067	1	Decal-Setting, Baffle
8	66-1340	1	Decal-Danger
9	110-2068	1	Decal-Adjustment, Baffle



Deflector Assembly No.110-0790


Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	110-0792-01	1	Deflector				
3	110-0793-03	1	Strap-Discharge				
4	110-0791	1	Deflector-Rubber				
5	107-4164-01	1	Bracket-Mounting, Deflector				
6	3296-39	4	Nut-Lock, NI				



Sheave, Spindle and Blade Assembly


Ref	Part No.	Qty.	Description
1	108-6697	3	Spindle Housing ASM
1:1	110-2118	2	Bearing
1:2	110-2116	1	Spacer-Bearing
1:3	108-6694	1	Housing-Spindle
1:4	32120-8	1	Ring-Snap
2	92-1624	18	Screw
3	3290-357	18	Nut-HHF, Whiz
4	110-4888	3	Washer-Spacer
5	103-2535	3	Spacer-Guard, Bottom
6	1-807267	3	Key
7	1-323529	3	Tube-Spindle, Short
8	1-323539	12	Spacer-Drive, Blade
9	108-4081-03	3	Blade-Rotary, 14 Inch High Sail
10	1-513208	3	Washer-Spring
11	1-800861	3	Screw-Cap, HH
12	103-1330	3	Guard-Bearing, Top
13	1-403183	3	Sheave
14	1-323339	3	Washer-Retainer, Sheave
15	3219-6	3	Nut-Hex
16	1-803310	3	Screw-Set
17	1-403184	2	Bushing-Idler
18	1-403186	1	Idler-Pulley, Flat
19	1-613098	1	Pulley-Idler
20	5-0652	2	Spacer

Ref	Part No.	Qty.	Description
21	98-5975	3	Washer-Belleville
22	1-403188	1	Spacer
23	323-15	1	Screw-HH
24	323-14	2	Screw-HH
25	322-2	1	Screw-HH
26	32128-20	1	Nut-HF
27	3296-39		Nut-Lock, NI




Idler Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-324372	1	Pad / Spring ASM	24	110-2051	1	Rod-Brake
2	321-4	2	Screw-HH	25	1-323748	1	Ring-Push On
3	3296-42	2	Nut-Lock, NI	26	1-323747	1	Spring-Compression
4	322-10	1	Screw-HH	27	1-323746	1	Spacer-Flanged
5	1-403179	1	Tube-Pivot	28	3296-56	1	Nut-Lock, NI
6	32120-35	1	E-Ring	29	1-323071	1	Spring-Extension
7	3256-23	1	Washer-Flat	30	1-303334	1	Washer-Spring
8	1-322235	1	Arm-Assist	31	302-19	2	Fitting-Grease
9	3256-3	1	Washer-Flat				
10	3296-29	1	Nut-Lock, NI				
11	1-303238	1	Eyebolt-Thread, RH				
12	32128-20	3	Nut-HF				
13	1-303236	1	Body-Turnbuckle				
14	1-303348	1	Eyebolt-Thread, LH				
15	702809	1	Screw-Cap				
16	98-5975	1	Washer-Belleville				
17	1-603843	1	Pulley-Idler				
18	1-303434	1	Bushing-Engagement				
19	103-3600	1	Idler Arm ASM				
19:2	1-323729	2	Sleeve-Bearing				
20	32151-103	1	Ring-Snap				
21	322-6	1	Screw-HH				
22	1-303352	1	Washer-Spindle				
23	1-806003	3	Pin-Hair				




Caster Assembly

Ref	Part No.	Qty.	Description				
1	1-513648	2	Wheel And Tire ASM				
❶ 1:1		1	Rim				
1:2	1-513808	1	Tire				
1:3	1-513809	1	Bearing				
1:4	1-513810	2	Bushing				
2	1-513547	2	Spacer				
3	325-20	2	Screw-HH				
4	1-322145-01	2	Fork				
5	3217-9	2	Nut-Hex				
6	3253-7	2	Washer-Lock				
7	1-303314	8	Spacer-Caster				
8	110-2130	2	Support ASM				
8:2	1-303514	2	Bearing-Flanged				
8:3	302-52	1	Fitting-Grease				
9	1-513338	2	Washer-Flat				
10	1-809020	2	Pin				
11	323-4	8	Screw-HH				
12	3290-357	8	Nut-HHF, Whiz				




Cylinder and Crankcase Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
②11004	11004-7008	1	Gasket-Head	②172	172G0818	1	Bolt-Stud
②11008	11008-7011	1	Head-Comp-Cylinder, No.2				
②11008A	11008-7017	1	Head-Comp-Cylinder, No.1				
②11008B	11008-7021	1	Head-Cylinder, No. 2				
②11008C	11008-7022	1	Head-Cylinder, No. 1				
②11022	11022-7003	1	Case-Rocker				
②11060	11060-7001	1	Gasket-Case, Rocker				
②11061	11061-7007	1	Gasket-Cover, Crankcase				
②11061A	11061-7008	1	Gasket-Breather				
②14091	14091-7007	1	Cover				
②49015	49015-7032	1	Cover-Crankcase				
②49120	49120-7015	1	Crankcase				
②59071	59071-2079	1	Joint				
②92043	92043-7001	1	Pin				
②92049	92049-7001	1	Seal-Oil, Rvc2 (6X11X10.2)				
②92049A	92049-7005	1	Seal-Oil, So (8X14X5 Hs)				
②92049B	92049-7015	1	Seal-Oil, Sd (35X62X8 L Hs)				
②92049C	92049-7016	1	Seal-Oil, Sd (35X48X8 R Hs)				
②92049D	92049-7019	1	Seal-Oil, So (8X14X5 Hs)				
②92139	92139-7002	1	Bushing				
②130	130B0612	1	Bolt-Flanged				
②130A	130B0640	1	Bolt-Flanged				
②130B	130T0850	1	Bolt-Flanged				
②130C	130T0875	1	Bolt-Flanged				




Piston and Crankshaft Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
②13001	13001-7009	1	Piston-Engine				
②13002	13002-7001	1	Pin-Piston				
②13008	13008-7001	1	Ring Set-Piston				
②13025	13025-7003	1	Ring Set-Piston (L,0.50)				
②13029	13029-7005	1	Piston-Engine (L,0.50)				
②13031	13031-7033	1	Crankshaft				
②13251	13251-7007	1	Connecting Rod ASM				
②13251A	13251-7008	1	Connecting Rod ASM (U/S=0.50)				
②92033	92033-7005	1	Ring-Snap				
②130	130G0630	1	Bolt-Flanged				



Valve and Camshaft Assembly
Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description				
②12004	12004-7003	1	Valve-Intake				
②12005	12005-7003	1	Valve-Exhaust				
②12009	12009-7001	1	Retainer-Spring, Valve				
②12011	12011-2056	1	Collet				
②12016	12016-7001	1	Arm-Rocker				
②12032	12032-7001	1	Tappet				
②13070	13070-7001	1	Guide				
②13070A	13070-7004	1	Guide				
②13116	13116-2057	1	Rod-Push				
②13271	13271-7007	1	Plate				
②13271A	13271-7021	1	Plate-Governor				
②42036	42036-7009	1	Sleeve				
②49078	49078-7001	1	Spring-Valve, Engine				
②49118	49118-7009	1	Camshaft				
②92009	92009-2341	1	Screw				
②92015	92015-2253	1	Nut				
②92033	92033-7001	1	Ring-Snap				
②92140	92140-7002	1	Ball				
②92145	92145-7001	1	Spring				
②92153	92153-7019	1	Bolt				
②92200	92200-7001	1	Washer				



Lubrication Equipment Assembly


Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
②13107	13107-7009	1	Shaft				
②13271	13271-7017	1	Plate				
②14075	14075-7009	1	Cap ASM				
②16154	16154-2053	1	Rotor-Pump (In)				
②16154A	16154-2054	1	Rotor-Pump (Out)				
②49065	49065-2078	1	Filter-Oil				
②49065A	49065-7004	1	Filter-Oil				
②59051	59051-7011	1	Gear-Spur				
②59231	59231-7003	1	Filler				
②92043	92043-7003	1	Pin				
②92066	92066-7003	1	Plug				
②92140	92140-7003	1	Ball				
②92145	92145-7002	1	Spring				
②130	130B0612	1	Bolt-Flanged				
②670	670D2016	1	O-Ring (16Mm)				




Cooling Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
②13270	13270-7007	1	Plate				
②14037	14037-7021-9H	1	Screen				
②14091	14091-7009	1	Cover				
②49089	49089-7044	1	Shroud-Engine				
②49089A	49089-7045	1	Shroud-Engine				
②59041	59041-7010	1	Fan				
②59066	59066-7023	1	Housing-Fan				
②92004	92004-7007	1	Stud				
②92153	92153-7007	1	Bolt				
②92153A	92153-7008	1	Bolt				
②130	130B0612	1	Bolt-Flanged				
②130A	130B0616	1	Bolt-Flanged				
②130B	130B0816	1	Bolt-Flanged				
②311	311F0600	1	Nut-Hex				




Electric Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
21171	21171-7013	1	Ignition Coil ASM				
21171A	21171-7014	1	Ignition Coil ASM				
21194	21194-7013	1	Flywheel-Comp				
26030	26030-7001	1	Harness				
92004	92004-7008	1	Stud				
92009	92009-2308	1	Screw				
92066	92066-7002	1	Plug				
92066A	92066-7005	1	Plug				
92070	92070-7003	1	Plug-Spark (Rcj8Y, Solid)				
92151	92151-2097	1	Bolt (12X30)				
92200	92200-7002	1	Washer				
130	130B0620	1	Bolt-Flanged				
311	311F0600	1	Nut-Hex				
510	510A5100	1	Key-Woodruff				



Control Equipment Assembly Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description				
②13107	13107-7010	1	Shaft				
②13271	13271-7018	1	Plate				
②16169	16169-7012	1	Link-Choke				
②16171	16171-7007	1	Link				
②39129	39129-7003	1	Spring-Governor				
②49103	49103-7004	1	Arm-Governor				
②49113	49113-7024	1	Panel-Control				
②92009	92009-7007	1	Screw (4X35)				
②92145	92145-7003	1	Spring				
②92145A	92145-7005	1	Spring				
②92150	92150-2182	1	Bolt (5X18)				
②92153	92153-7005	1	Bolt (6X35)				
②92170	92170-7001	1	Clamp				
②130	130B0612	1	Bolt-Flanged				
②214	214B0408	1	Screw-Pan				
②311	311B0600	1	Nut-Hex				
②411	411b0600	1	Washer-Plain				



Carburetor Assembly Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description
②11061	11061-7004	1	Gasket-Insulator
②11061A	11061-7009	1	Gasket-Chamber
②11061B	11061-7010	1	Gasket-Screw
②11061C	11061-7018	1	Gasket-Cleaner, Air
②13107	13107-7018	1	Shaft
②15003	15003-7061	1	Carburetor ASM
②16014	16014-7002	1	Screw-Pilot
②16020	16020-7003	1	Chamber-Float
②16025	16025-7006	1	Valve-Throttle
②16030	16030-7003	1	Valve-Float
②16031	16031-7002	1	Float
②16041	16041-7016	1	Shaft-Choke, Carburetor
②16041A	16041-7018	1	Shaft-Throttle, Carburetor
②16186	16186-7002	1	Choke Valve ASM
②39076	39076-7001	1	Limiter
②49121	49121-7001	1	Nozzle-Main
②59076	59076-7005	1	Manifold-Intake
②92009	92009-2083	1	Screw
②92009A	92009-2349	1	Screw
②92055	92055-2174	1	O-Ring
②92055A	92055-7007	1	O-Ring (Id=31)
②92063	92063-7026	1	Jet-Main, No. 88
②92063A	92063-7028	1	Jet-Main, No. 85
②92063B	92063-7029	1	Jet-Main, No. 82

Ref	Part No.	Qty.	Description
②92081	92081-2234	1	Spring
②92093	92093-2100	1	Seal
②92093A	92093-7003	1	Seal
②92145	92145-7015	1	Spring
②92153	92153-7009	1	Bolt
②92172	92172-7002	1	Screw
②92200	92200-7014	1	Washer



Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
②11011	11011-7035	1	Case-Filter, Air	②220	220B0614	1	Screw-Pan (Cross)
②11013	11013-7025	1	Element-Filter, Air	②233	233B0416	1	Screw
②11013A	11013-7031	1	Element-Filter, Air	②311	311B0400	1	Nut-Hex
②11051	11051-7005-9H	1	Bracket	②317	317R0800	1	Nut-Hex
②11053	11053-7022	1	Bracket	②461	461F0800	1	Washer-Spring
②11060	11060-7021	1	Gasket-Muffler	②670	670B2010	1	O-Ring (10Mm)
②13271	13271-7022	1	Plate				
②16060	16060-7016	1	Pipe-Intake				
②18088	18088-7001	1	Pipe-Exhaust				
②32154	32154-7006	1	Pipe				
②49070	49070-7015	1	Muffler				
②92015	92015-1193	1	Nut				
②92026	92026-7001	1	Spacer (6.2X7.9X5)				
②92055	92055-7015	1	Ring-O				
②92072	92072-7008	1	Band				
②92170	92170-7002	1	Clamp				
②92192	92192-7010	1	Tube				
②92200	92200-2070	1	Washer				
②92210	92210-7004	1	Nut				
②92210A	92210-7019	1	Nut				
②130	130B0610	1	Bolt-Flanged				
②130A	130B0612	1	Bolt-Flanged				
②130B	130B0816	1	Bolt-Flanged				



Fuel Tank and Fuel Valve Assembly


Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
223062	23062-7004-9H	1	Bracket				
249019	49019-7001	1	Filter-Fuel				
249040	49040-7001	1	Pump-Fuel				
292170	92170-2088	1	Clamp				
292191	92191-7002	1	Tube				
292191A	92191-7003	1	Tube (6.35X12.7X160)				
292191B	92191-7004	1	Tube				
2130	130B0620	1	Bolt-Flanged				



Starter Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
13165	13165-7001	1	Pawl-Starter, Recoil				
13271	13271-7003-9H	1	Plate				
14020	14020-7001	1	Retainer				
32099	32099-7002	1	Case-Recoil, Starter				
46075	46075-7001	1	Grip-Recoil, Starter				
49080	49080-7001	1	Pulley-Starting				
49088	49088-7013	1	Starter-Recoil				
59101	59101-7001	1	Reel-Recoil				
59106	59106-7001	1	Rope				
92145	92145-7006	1	Spring				
92145A	92145-7007	1	Spring				
92145B	92145-7008	1	Spring				
92151	92151-7008	1	Bolt				
92200	92200-7004	1	Washer				
92200A	92200-7005	1	Washer				
92210	92210-0003	1	Nut				
130	130B0608	1	Bolt-Flanged				



Label Assembly

Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
②56033	56033-7001	1	Label-Manual
②56070	56070-7001	1	Label-Warning
②56080	56080-2077	1	Label-Brand
②56080A	56080-7024	1	Label-Brand

Attachments and Accessories

For 30686 - Commercial Walk-Behind Mower, Fixed Deck Pistol Grip Gear with 40in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Rotary, 14 Inch Recycling	108-4089-03
Blade-Rotary Mid Flow	108-4110-03
Blade-Rotary, 14 Inch Low Flow	108-4111-03
Blade-Rotary, 14 Inch Atomic	108-4112-03
40 Inch Bagger Enhancement Kit	110-2025
40 Inch Recycler Kit	110-2070
Weight Kit	110-2085
Plate Kit	110-6902
Soft Bag (3 Bushel)	30104
Sulky	30109

NOTES

NOTES

NOTES

