


TORO®MODEL NO. 30114-0000001 Thru
1000001 & UP**PARTS
CATALOG****114 PROLINE WALK POWER MOWER**

C-0500


FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	55-3570	Cap - Fuel Tank	1
2	2412-103	Clamp - Fuel line	1
3	47-2982	Hose - Fuel	1
4	32103-25	Nut - Wing	2
5	3256-23	Washer - Flat	10
6	68-9690	Fitting - Rod	2
7	3290-307	Pin - Cotter	4
8	74-0220	Idler - Bracket L.H.	1
*	74-0230	Idler - Bracket R.H.	1
9	283-6	Pin - Clevis	4
10	74-0521	Fitting - Rod	2
11	67-6380	Bracket - Support L.H.	1
*	67-6370	Bracket - Support R.H.	1
12	323-16	Screw - Hex. Hd. Cap	2
13	323-6	Screw - Hex. Hd. Cap	6
14	3296-23	Nut - Lock	2
15	51-4480	Idler - Wheel	2

Ref. No.	Part No.	Description	No. Used
16	51-4490	Spacer - Idler Wheel	2
17	51-4380	Spring - Torsion L.H.	1
*	51-4370	Spring - Torsion R.H.	1
18	51-4450	Screw - Leveler	2
19	74-0040	Spacer - Pivot Idler	4
20	3296-39	Nut - Lock	8
21	237-124	Grommet	1
22	323-9	Screw - Hex. Hd. Cap	
23	51-4810	Pulley - Idler	1
24	74-0280	Frame	1
25	32128-21	Nut - Hex. Flange	1
26	322-4	Screw - Hex. Hd. Cap	4
27	3253-4	Washer - Lock	4
28	66-7400	Plate - Control	1
29	52-2140	Decal - Ground Speed	1
30	74-0490	Decal - Fuel Shut Off	1
31	74-0360	Frame - Rear	1

*Not Illustrated


TPS



C-0500

FRAME ASSEMBLY (Continued)


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
32	74-0510	Valve - Fuel	1	36	3256-24	Washer - Flat	1
33	237-7	"O"Ring	1	37	3255-7	Washer - Flat	1
34	72-4550	Tank - Fuel	1	38	52-2890	Bushing	2
35	12-3270	Screw - Cap	1				



T-008C

CLUTCH ASSEMBLY NO. 54-3200

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	44-8350	Field Ass'y (Incl. Ref. # 2 & 3)	1	6	44-8330	Spacer - Pulley Bearing	1
2	251-292	Bearing - Field	1	7	44-8340	Collar - Bearing	1
3	44-8310	Ring - Retaining	2	8	251-291	Bearing - Pulley	1
4	44-8360	Field Coil, Rotor & Bearing Assembly (Incl. Ref. # 1)	1	9	3296-5	Nut - Lock	3
5	55-7410	Armature & Pulley Assembly (Incl. Ref. # 3, 6, 7, & 8)	1	10	44-8320	Spring	3




C-0502

AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	322-2	Screw - Hex. Hd. Cap	4
2	3253-4	Washer - Lock	12
3	74-0610	Transmission	1
4	72-2190	Mount - Shift Lever	1
5	7-5461	Spacer	1
7	329-10	Screw - Hex. Hd. Cap	1
8	47-1970	Grip - Engagement	1
9	74-0320	Lever - Shift	1
10	3296-42	Nut - Lock	4
11	32120-64	Ring - Retaining	3
12	51-4270	Bearing - Shaft Extension	2
13	321-4	Screw - Hex. Hd. Cap	4
14	51-4240	Shaft - Extension R.H.	1
*	51-4250	Shaft - Extension L.H.	1
15	3257-5	Key - Woodruff	3
16	3245-3	Screw - Set Socket Hd.	2
17	74-0480	Pulley - Drive	2
18	51-4290	Belt - Drive	2
19	51-4580	Rod - Brake	2
20	51-4610	Brake Arm L.H.	1
*	51-4600	Brake Arm R.H.	1
21	32151-40	Ring - Retaining	2
22	51-4650	Link - Brake	2


Ref. No.	Part No.	Description	No. Used
23	231-111	Tire	2
24	242-80	Rim	2
25	232-27	Valve Stem	2
26	32151-91	Ring - Retaining	2
27	251-321	Bearing	2
28	302-11	Fitting - Grease	2
29	10-8110	Washer - Flat	A/R
30	51-4160	Pulley - Wheel	4
31	51-4170	Spacer - Pulley	8
32	51-4180	Drum - Brake	2
33	51-4700	Brake Band Assembly	2
34	322-7	Screw - Hex. Hd. Cap	8
35	51-4660	Plate - Link Brake	2
36	32151-72	Ring - Retaining	4
37	51-4230	Washer - Wheel	2
38	3241-5	Screw - Set	1
39	26-9670	Belt - Traction	1
40	51-4190	Pulley - Driven	1
41	32151-56	Ring - Retaining	2
42	3290-307	Pin - Cotter	2
43	51-4220	Guard - Coupler	2
44	302-5	Fitting - Grease	2
45	51-4260	Coupler	2

*Not Illustrated



PEERLESS TRANSMISSION MODEL NO. 700-039


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	770090	Case - Transmission	1	28	786081	Chain - Roller (No. 41 Chain 24 Links)	1
2	772099	Cover - Transmission	1	29	780072	Washer - Thrust	5
3	776289A	Shaft - Output & Brake	1	30	780086	Bearing - Needle	1
4	786072	Spacer	1	31	7800142	Bearing - Needle	1
5	778123A	Gear - Spur (25 Teeth)	1	32	792035	Ring - Retaining	1
6	778250	Gear - Spur (27 Teeth)	1	33	780139	Washer - Thrust	1
7	778124A	Gear - Spur (30 Teeth)	1	34	788040	Ring - Retaining	1
8	778125	Gear - Spur (35 Teeth)	1	35	784267	Rod & Fork Ass'y - Shift	1
9	784266	Collar - Shift	1	36	792073	Screw - Flanged Hd. Thr'd Forming	6
10	786083	Sprocket (18 Teeth)	1	37	792089A	Key	4
11	786082	Sprocket (9 Teeth)	1	40	792077	Ball - Steel	1
12	776134	Shaft - Counter	1	41	792078	Screw - Set	1
13	778154	Gear - Bevel (42Teeth)	1	42	792079	Spring	1
13A	778136	Gear - Spur (15 Teeth)	1	43	780108	Washer - Thrust	4
14	778126A	Gear - Spur (20 Teeth)	1	44	792001	"O"Ring	2
15	778249	Gear - Spur (23 Teeth)	1	45	792074	Plug - Threaded	1
16	778127A	Gear - Spur (25 Teeth)	1	46	788069	Seal - Square Cut	1
17	786071	Spacer	1	48	780092	Bearing - Ball	2
18	776135	Shaft - Input	1	49	780065	Washer - Thrust	2
19	778153	Pinion - Bevel Input	1				
27	780105A	Bushing - Flanged	2				



C-0503

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	67-6440	Handle - Upper	1	19	74-0630	Control - Throttle	1
2	74-0720	Tube - Manual	1	20	37-2610	Switch - Clutch	1
3	74-0790	Panel - Control	1	21	74-0470	Rod - Pivot	1
4	74-0800	Decal - Proline	1	22	32151-80	Ring - Push On	2
5	54-3071	Rod - Control	2	23	32105-14	Screw - Hex. Hd. Machine	4
6	51-4850	Lever - Brake, Parking	1	24	74-0380	Control - Pivot	1
7	52-2010	Decal - Parking Brake	1	25	3254-5	Washer - Lock	1
8	237-141	Grommet - Rubber	2	26	52-2120	Decal - Reverse Handle	1
9	3256-24	Washer - Plain	2	27	29-5560	Switch - Off/On	1
10	3296-2	Nut - Lock	5			(Incl. Ref. #16, 18, & 25)	1
11	3290-54	Rivet - Pop	4	28	57-5810	Panel - Bottom	1
12	54-2740	Decal - Control Bar	1	29	3290-378	Cable Tie	2
13	3290-307	Pin - Cotter	2	30	3234-11	Screw - Hex. Hd. Cap	4
14	32105-1	Screw - Hex. Hd. Machine	1	31	32128-21	Nut - Hex. Flange	4
15	51-4730	Bar - Control	1	32	74-0680	Wire Harness	1
16	63-8360	Key	2	33	2412-120	"R" Clamp	2
17	218-500	Nut	1	34	32104-76	Screw - Self Tapping	4
18	218-461	Nut	1				




T-0518

SULKY KIT MODEL NO.30122 (Optional)

Ref. No.	Part No.	Description	No. Used
1	76-1410	Seat Assembly	1
2	62-7400	Decal - Toro	1
3	19-4050	Knob	4
4	76-4670	Bracket - Seat Adjustment	2
5	76-4740	Frame Assembly	1
6	3230-2	Bolt Carriage	4
7	3255-8	Washer - Lock	4
8	322-3	Screw - Hex.Hd. Cap	6
9	55-3720	Tire	2
10	3256-39	Washer - Flat	2

Ref. No.	Part No.	Description	No. Used
11	3272-12	Pin - Cotter	2
12	55-3740	Bearing - Wheel	4
13	55-3730	Valve Stem/Cap	2
14	55-3750	Wheel	2
15	55-9900	Decal - Sulky	1
16	55-9840	Bracket - Footrest	1
17	3296-29	Nut - Lock	6
18	68-4190	Bracket - Hitch	1
19	60-9350	"U"Bolt	2
20	3290-456	Washer - Belleville	4

**Group 2
CRANKCASE**




ENGINE KOHLER MODEL NO. CV14T-1412

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
		Crankcase		10	12 847 01	Piston W/Ring Set (Std.)	1
		Group 2		*	12 847 02	Piston W/Ring Set (.25)	1
1	12 032 03	Seal - Crankshaft	1	*	12 847 03	Piston W/Ring Set (.50)	1
2	12 030 01	Bearing - Crankshaft		11	12 018 02	Retainer - Piston Pin	2
		Flywheel End (Std.)	1	12	12 108 01	Ring Set (Std.)	1
*	12 030 02	Bearing - Crankshaft (.25)	1	*	12 108 02	Ring Set (.25)	1
*	12 030 03	Bearing - Crankshaft (.50)	1	*	12 108 03	Ring Set (.50)	1
3	12 445 02	Strap - Lifting	1	13	12 067 01	Connecting Rod (Std.)	1
4	SM-0839025	Screw - Lifting Strap	1	*	12 067 02	Connecting Rod (.25)	1
5	12 380 03	Dowel - Locating	4	14	12 380 01	Pin - Governor Regulating	1
6	12 010 01	Camshaft Assembly	1	15	12 043 05	Gear - Governor Assembly	1
7	12 089 18	Spring - Actuating	1	16	SM-0631005	Washer - Governor Gear	1
8	12 422 08	Shim - Camshaft	1	17	12 144 02	Shaft - Governor Gear	1
*	12 422 02	Shim - Camshaft	A/R	18	52 139 09	Plug - Cap	1
*	12 422 10	Shim - Camshaft	A/R	19	12 144 01	Shaft - Governor Cross	1
*	12 422 11	Shim - Camshaft	A/R	20	SM-0631015	Washer - Governor Shaft	1
*	12 422 12	Shim - Camshaft	A/R	*	X25-102	Washer	1
*	12 422 06	Shim - Camshaft	A/R	21	12 032 01	Seal - Cross Shaft	1
*	12 422 07	Shim - Camshaft	A/R	22	12 380 04	Pin - Governor Hitch	1
9	12 422 04	Shaft - Balance	1				


*Not Illustrated

ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Group 1 CRANKSHAFT



Group 3 OIL PAN/LUBRICATION




ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Ref. No.	Part No.	Description	No. Used
		Crankshaft Group 1	
1	12 014 02	Crankshaft Assembly	1
2	12 139 0	Plug	1
		Oil Pan / Lubrication Group 3	
1	12 038 01	Dipstick Assembly	1
2	12 153 03	"O"Ring - Dipstick	1
3	12 153 02	"O"Ring - Upper Tube	1
4	12 123 04	Tube - Oil Fill	1
5	SM-0545020	Screw - Oil Fill Tube	1
6	12 153 01	"O"Ring - Lower Tube	2
7	12 162 02	Screen - Oil Pick Up	1
8	12 096 03	Cover - Oil Screen	1
9	SM-0545016	Screw	1
10	SM-1039025	Screw	1
11	12 126 02	Bracket - Oil Pump Relief Valve	1


Ref. No.	Part No.	Description	No. Used
12	12 089 03	Spring - Oil Pump Relief Valve	1
13	12 462 01	Piston - Oil Pump Relief Valve	1
14	12 208 01	Body - Oil Pump Relief Valve	1
15	52 050 02	Filter - Oil	1
16	12 136 01	Adapter - Oil Filter	1
17	X-75-1	Plug - 1/8 N.P.T.F.	2
18	X-75-10	Plug - 3 /8 N.P.T.F.	2
19	12 393 01	Pump -Oil Assembly	1
20	12 032 04	"O"Ring - Pump Cover	1
21	12 096 02	Cover - Oil Pump	1
22	SM-0545016	Screw	3
23	12 032 03	Seal - Oil (P.T.O.End)	1
24	SM-0839045	Screw - Oil Pan	11
25	12 199 09	Pan - Oil	1

ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Group 4 CYLINDER HEAD/VALVE/BREATHER



Group 5 IGNITION/ELECTRICAL



ENGINE KOHLER MODEL NO. CV14T-1412(Continued)


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
		Cylinder Head / Valve / Breather - Group 4				Ignition / Electrical Group 5	
1	12 755 02	Kit Cylinder Head	1	1	SM-1040045	Screw - Flywheel	1
2	12 351 01	Lifter - Valve	2	2	12 468 03	Washer - Flywheel	1
3	12 441 01	Rod - Push	2	3	12 162 03	Screen - Grass	1
4	12 041 04	Gasket - Cylinder Head	1	4	SM-0639016	Screw - Fan	4
5	12 017 01	Valve - Intake (Std.)	1	5	12 112 01	Spacer - Fan	4
	12 017 02	Valve - Intake (.25)	1	6	12 157 01	Fan	1
6	12 016 01	Valve - Exhaust (Std)	1	7	X-42-15	Key	1
	12 016 02	Valve - Exhaust (.25)	1	8	12 403 08	Rectifier - Unregulator	1
7	12 112 04	Spacer - Head Bolt	1	9	SM-639016	Screw - Regulator	2
8	SM-1040080	Screw - Cylinder Head	5	10	236602	Connector - Regulator	1
10	12 032 02	Seal - Valve Stem	1	12	12 025 04	Flywheel Assembly	1
11+	52 018 01	Retainer - Spring	2	13	SM-0548025	Screw - Stator	4
12*	12 089 01	Spring - Valve	1	14	SM-0545010	Screw - Stator Harness	1
	1208915	Spring - Valve, Exhasut	1	15	12 154 02	Clip - Stator Harness	1
13	12 173 01	Cap - Valve Spring	2	16	41 085 07	Stator - 15 Amp.	1
14	12 755 03	Kit - Retainer	2	17	12 132 02	Spark Plug	1
15	X-426-9	Clamp - Hose	2	18	X-728-1	Clip - Kill Lead	1
16	12 326 03	Hose - Breather	1	19	SM-0545010	Screw - Lead Clip	1
17	SM-0645020	Screw - Valve Cover	3	20	12 584 02	Module - Ignition	1
18	12 096 07	Cover -Valve W/Nipple	1	21	SM-0545020	Screw - Ignition Module	2
19	SM-0545010	Screw - Breather Reed	1			NOT ILLUSTRATED	
20	12 018 01	Retainer - Breather Reed	1				
21	12 402 01	Reed - Breather	1	25	518 05	Lead - Black, Rectifier to Connector(5"-14 Gauge	1
22	SM-0642025	Screw - Rocker Bridge	2		12 518 01	Lead - White, Ground to Kill	1
23	12 189 01	Arm - Rocker	2		41 155 03	Connector	1
24	12 126 05	Bridge - Rocker Arm	1				
25	12 144 03	Shaft - Rocker Arm					

*Qty. 2 Used Before serial No. 1933503554 after that Use (Qty.1) 12 089 01 And (Qty.1) 12 089 1


+Used only Before serial No. 1933503554.

ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Group 6 BLOWER HOUSING & BAFFLES



Group 7 STARTING SYSTEM




ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Ref. No.	Part No.	Description	No. Used
		Blower Housing & Baffle Group 6	
1	SM-0545010	Screw	14
2	12 146 07	Plate - Blower Housing	1
3	12 063 01	Baffle - Cylinder Barrel	1
4	12 096 05	Cover - Starter	1
5	12 027 03	Cover - Housing	1
6	12 063 05	Baffle - Carburetor	1
7	12 313 03	Grommet	1
8	12 063 03	Baffle - Cylinder Head	1
		NOT ILLUSTRATED	
	12 133 14	Decal - H.P.	1

Ref. No.	Part No.	Description	No. Used
		Starting System Group 7	
1	SM-0545010	Screw	5
2	12 165 01	Starter (incl.Ref.#3-9)	1
3	12 081 01	Housing - Starter	1
4	234452	Handle - Recoil	1
5	12 160 01	Rope - Starter	1
6	12 089 06	Spring & Keeper	1
7	12 089 01	Pulley	1
8	12 757 06	Kit - Dog Replacement	1
9	41 086 09	Screw - Pozidrive	1
10	15 109 01	Cup - Driver	1


ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Group 8 FUEL SYSTEM




Group 9


ENGINE CONTROLS



Group 11 EXHAUST



Group 10
AIR INTAKE/FILTRATION



ENGINE KOHLER MODEL NO. CV14 T-1412(Continued)

Ref. No.	Part No.	Description	No. Used
Fuel System Group 8			
1	12 853 01	Kit - Carburetor	1
2	12 313 01	Grommet	1
3	12 041 01	Gasket - Air Cleaner	1
4	12 265 01	Deflector - Heat	1
5	12 313 05	Grommet	1
6	12 041 01	Gasket - Carburetor	1
7	12 041 02	Gasket - Air Cleaner	1
8	M-0629122	Stud - Carburetor	2
9	48 154 01	Clip - Cable	1
10	SM-0641060	Nut - Carburetor	2
11	12 368 01	Needle - Idle	1
12	12 089 09	Spring - Idle	1
13	12 086 04	Screw - Idle	1
14	12 089 09	Spring -Idle	1
15	12 146 03	Plate - Throttle	1
16	25 086 27	Screw - Throttle Plate	2
17	12 144 09	Shaft Assembly-Throttle	1
18	12 144 08	Shaft - Choke	1
19	12 089 10	Spring - Choke Return	1
20	12 146 02	Plate - Choke	1
21	12 337 01	Jet - Main	1
22	12 757 02	Kit - Float	1
23	12 041 05	Gasket - Bowl	1
24	12 104 01	Bowl - Fuel	1
25	12 041 06	Gasket - Bowl	1
26	12 086 05	Screw - Bowl	1
*	12 757 01	Kit - Carburetor Repair	1
*	12 755 09	Kit - Kit High Altitude Jet	1
Engine Control Group 9			
1	12 079 03	Linkage - Choke	1
2	12 237 01	Clamp - Cable	1
3	SM-0645020	Screw - Hex. Hd.	2
4	SM-0545016	Screw - Cable Clamp	1
5	12 536 01	Control - Speed (incl Ref.#6-8)	1

Ref. No.	Part No.	Description	No. Used
6	SM-0443045	Screw	1
7	12 089 11	Spring	1
8	12 089 04	Spring - Choke	1
9	12 089 20	Spring - Governor	1
10	SM-0641060	Nut - Governor	1
11	SM-0642025	Screw - Governor	1
12	12 090 05	Lever - Governor	1
13	25 158 09	Bushing - Black Retainer	1
14	12 079 01	Linkage - Throttle	1
15	25 158 08	Bushing - Natural,Linkage	1
Air Intake / Filtration Group 10			
1	12 341 01	Knob - Air Cleaner Cover	1
2	12 096 06	Cover - Air Cleaner	1
3	12 100 01	Nut - Wing	1
4	X-25-63	Washer - Flat	1
5	12 083 08	Precleaner - Element	1
6	12 083 05	Element - Air Cleaner	1
7	12 072 03	Stud - Mounting Plate	1
8	12 086 01	Screw - Mounting Plate	1
9	12 041 02	Gasket - Air Cleaner	1
10	12 094 01	Base - Air Cleaner	1
11	12 113 04	Decal - Air Cleaner	1
Exhaust Group 11			
1	12 068 03	Muffler	1
2	M-0829036	Stud - Exhaust Manifold	2
3	12 042 03	Gasket - Exhaust	1
4	M-0645016	Screw - Muffler	2
5	12 468 01	Washer - Flat	1
6	SM-0841080	Nut - Muffler	2
7	12 126 08	Bracket - Muffler	1
8	SM-0645020	Screw - Valve Cover	1
9	SM-0645025	Screw - Lifting Strap	1
10	12 445 01	Strap - Lifting	1
*	12 522 01	Short Block	1
*	12 755 01	Gasket Set	1

PRODUCT CHANGES

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Lawnmower has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the rear of the housing. In any correspondence concerning the lawnmower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the lawnmower.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any

reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]