



Commercial Walk-Behind Mower Fixed Deck, Pistol Grip, Gear Drive with 36in TURBO FORCE® Cutting Unit

Model No. 30684 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel Tank Assembly	 3	Lubrication Equipment Assembly Kawasaki Model FH430V-AS25	 19
Transmission Drive Assembly	 4	Cooling Equipment Assembly Kawasaki Model FH430V-AS25	 20
Wheel Drive and Brake Assembly	 6	Electric Equipment Assembly Kawasaki Model FH430V-AS25	 21
Handle and Control Assembly	 7	Control Equipment Assembly Kawasaki Model FH430V-AS25	 22
Control Panel Decal Assembly No. 110-6906	 9	Carburetor Assembly Kawasaki Model FH430V-AS25	 23
Deck Assembly	 10	Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25	 24
Deck Decal Assembly No. 110-4907	 11	Fuel Tank and Fuel Valve Assembly Kawasaki Model FH430V-AS25	 25
Deflector Assembly No. 110-0790	 12	Starter Assembly Kawasaki Model FH430V-AS25	 26
Sheave, Spindle and Blade Assembly	 13	Label Assembly Kawasaki Model FH430V-AS25	 27
Idler Assembly	 14	Attachments and Accessories List	 28
Caster Assembly	 15		
Cylinder and Crankcase Assembly Kawasaki Model FH430V-AS25	 16		
Piston and Crankshaft Assembly Kawasaki Model FH430V-AS25	 17		
Valve and Camshaft Assembly Kawasaki Model FH430V-AS25	 18		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	INC. incorporated
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHE. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over-protection-system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread forming	TAP. self tapping
HYD. hydraulic	TTH. torx truss head

Footnotes


- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain from your local Kawasaki dealer



Engine and Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	1-633023	2	Stud
2	3256-23	4	Washer-Flat
3	1-633349	2	Spring-Tank, Fuel
4	3296-47	2	Nut-Lock, NI
5	1-303077	4	Clamp
6		1	Engine-Kawasaki, FH430V-As25
7	106-0699	1	Decal-Warning, Hot Surfaces
8	32128-21	1	Nut-HF
9	323-14	1	Screw-HH
10	322-7	4	Screw-HH
11	1-303334	4	Washer-Spring
12	103-1966	1	Adapter
13	92-6877	1	Valve-Drain, Oil
14	32128-20	4	Nut-HF
15	109-0293	1	Hose-Fuel
16	1-603770	1	Valve-Fuel
17	109-0306	1	Hose-Fuel
18	322-3	2	Screw-HH
19	1-805005	2	Washer-Lock
20	106-0730	1	Fuel Tank ASM
20:2	103-2605	1	Fitting-Fuel, Bulkhead
21	88-3980	1	Gas Cap ASM
21:3	88-4010	1	Gasket-Cap, Gas
22	33113-016	1	Screw-HH


Ref	Part No.	Qty.	Description
23	1-805004	1	Washer-Lock
24	100-6467	1	Muffler
25	103-5465	1	Clamp-Muffler
26	5-0652	2	Spacer
27	3296-39	1	Nut-Lock, NI
28	1-413510	1	Clip-Loom
29	33114-016	1	Screw-HH
30	323-8	8	Screw-HH
31	98-5975	8	Washer-Belleville
32	3290-357	8	Nut-HHF, Whiz
99	103-1964	1	Hose-Drain, Oil



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	103-9897-01	1	Deck-Engine
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	2	Screw-Set
5	103-6511	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key-Machine
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513051	1	Switch-Open, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission
25	302-19	2	Fitting-Grease

Ref	Part No.	Qty.	Description
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	105-4104	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-HWH, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	1	Pin-Hair
41	1-303186	1	Bellcrank
42	3290-357	1	Nut-HHF, Whiz
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission
50	110-4891	1	Pulley ASM



Transmission Drive Assembly (continued)


Ref	Part No.	Qty.	Description				
56	1-603610	2	Washer-Spring				
57	3212-6	1	Screw-HH				
58	1-633453	1	Spacer-Clutch				
59	1-373034	2	Washer				
62	32128-33	2	Nut-HF				
64	103-1797-01	1	Bracket-Cable, Choke				
65	103-1796	1	Cable-Choke				
66	1-303282	1	Switch-Start, Neutral				
67	1-323303	1	Linkage-Arm				
68	110-4886	1	Belt-V				
69	1-808280	1	Pin-Clevis				
70	1-303105	1	Yoke-Adjustable				
71	3219-2	1	Nut-Hex				
73	321-4	1	Screw-HH				
74	1-323430	1	Module-Interlock				
75	1-323229	1	Clip-Loom				
76	3256-22	1	Washer-Flat				
77	3296-42	1	Nut-Lock, NI				
78	1-303335	1	Tie-Plastic				



Wheel Drive and Brake Assembly

Ref	Part No.	Qty.	Description
2	99-8664	2	Screw-HH
3	32151-47	6	Ring-Retaining
4	1-806003	2	Pin-Hair
5	1-323245	2	Spring-Compression
6	103-1864	2	Swivel-Lever, Drive
7	322-6	2	Screw-HH
9	3256-23	4	Washer-Flat
10	1-323548	2	Linkage-Brake
11	1-322125	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	10	Nut-HHF, Whiz
14	323-39	4	Screw-HH
18	1-323277	2	Idler-Wheel, Drive
19	302-19	2	Fitting-Grease
21	1-323307	2	Pin-Clevis
22	103-1611-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	2	Nut-Push
25	1-323262	2	Band-Brake
26	1-322117-03	1	Axle
27	1-523157	6	Washer-Spacer, 14 GA
27	1-543436	8	Washer-Spacer, 16GA
28	1-323261	2	Drum-Brake
29	1-323253	4	Sheave-Wheel, Drive


Ref	Part No.	Qty.	Description
34	1-808519	2	Ring-Snap
35	1-323260	8	Spacer-Sheave, Wheel
36	322-6	8	Screw-HH
38	1-323631	2	V-Belt
39	3296-29	4	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville
44	323-6	4	Screw-HH
46	1-805005	8	Washer-Lock
47		2	Wheel And Tire ASM
47:1	1-323720	1	Tire-Turfmaster
47:2	1-323328	1	Wheel And Hub ASM
47:2:1	1-323329	2	Bearing-Flanged
50	32128-20	4	Nut-HF
52	3296-39	4	Nut-Lock, NI
53	1-323287-01	2	Shield-Wheel, Drive
55	1-603402	2	Spring-Extension
56	1-323283	4	Spacer-Shield
57	103-1615-03	1	Arm-Idler, LH
58	103-1616-03	1	Arm-Idler, RH



Handle and Control Assembly

Ref	Part No.	Qty.	Description
1	1-808286	2	Pin-Clevis
2	1-323359	2	Linkage-Wheel, Drive
4	1-303365	2	Bushing-Nylon
5	106-2717-03	1	Rod-Control, Operator Presence
6	106-5486	1	RH Opc Lever ASM
7	104-9838	2	Grip-Foam
8	321-18	2	Screw-HH
9	1-303435	6	Washer-Spring
10	1-323549	2	Spacer
11	3296-42	2	Nut-Lock, NI
12	3290-500	2	Screw-PPH
13	1-513051	1	Switch-Open, Normally
14	1-806003	3	Pin-Hair
15	1-633181	1	Plate-Tapped
16	110-6906	1	Gear Handle ASM
17	1-303363	1	Spring-Extension
18	1-633696	1	Throttle Cable ASM
19	2412-120	2	R-Clamp
20	1-303287	2	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-4	2	Washer-Flat
24	3296-39	1	Nut-Lock, NI
26	1-323298	1	Linkage-Blade, Upper
27	1-322157	1	Lever ASM

Ref	Part No.	Qty.	Description
27:1	1-303020	1	Grip-Lever
28	3234-11	4	Screw-HHF
29	32104-76	2	Screw
30	32128-21	4	Nut-HF
31	104-7050	1	Housing-Manual
32	3296-2	2	Nut-Lock
34	1-513592	1	Knob-Ball
36	1-803001	2	Nut
38	1-807513	2	Bolt-CARR
39	106-5485	1	LH Opc Lever ASM
48	1-324280	1	RH Thumb Latch ASM
48:1	1-303019	1	Grip-Latch
49	1-324279	1	LH Thumb Latch ASM
49:1	1-303019	1	Grip-Latch
50	1-806340	2	Pin-Roll
51	1-808250	2	Pin-Lever, Drive
52	103-1610	1	Harness-Wiring
53	1-303088	1	Clip-Cable
54	1-302006	2	Drive Lever ASM
54:1	1-303021	1	Grip-Lever, Drive
55	29-5560	1	Switch-On / Off
55:1	218-461	1	Nut-HH
55:2	3254-5	1	Washer-Tooth
56	63-8360	1	Key-Ignition




Handle and Control Assembly (continued)

Ref	Part No.	Qty.	Description
57	1-803322	2	Screw-Set
58	323-10	1	Screw-HH
61	104-7048	1	Cap-Housing


Control Panel Decal Assembly No. 110-6906

Ref	Part No.	Qty.	Description
2	105-4111	2	Decal-Lock, Neutral
3	106-2737	1	Decal-Warning
4	106-2733	1	Decal-Throttle
5	110-6917	1	Decal-Control Panel
6	95-5537	1	Decal-Engage, Deck




Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	110-4907	1	Deck ASM	21	323-4	3	Screw-HH
2	110-2031-01	1	Adjustable Baffle				
3	110-0754-01	1	Baffle-Discharge				
4	110-2037-01	1	Plate-Skid				
5	110-0790	1	Deflector ASM				
6	110-2036-01	1	Cover-Deck				
7	92-1624	3	Screw				
8	3290-357	10	Nut-HHF, Whiz				
9	322-50	1	Screw-HH				
10	105-4622	1	Spacer				
11	104-8554	1	Spring-Torsion				
12	107-1664	1	Lever ASM				
12:1	106-3239	1	Screw-Lock				
12:2	107-1644	1	Cap-Lock				
12:3	106-3241	1	Lever-Lock				
12:4	3296-29	1	Nut-Lock, NI				
13	3296-29	1	Nut-Lock, NI				
14	106-4161	4	Knob-Handle				
15	1-323417	4	Washer				
16	1-303536	2	Stud-Shield, Belt (Long)				
17	1-303537	2	Stud-Shield, Belt (Short)				
18	3231-1	4	Screw-CARR				
19	32128-20	4	Nut-HF				
20	110-6918	1	Decal				




Deck Decal Assembly No. 110-4907

Ref	Part No.	Qty.	Description
2	98-3296	1	Decal-Routing, Belt
3	43-8480	1	Decal-Danger
4	98-5130	1	Decal-Torque, Bolt
5	104-8569	1	Decal-Warning
6	98-5954	2	Decal-Cover, Missing
7	110-2067	1	Decal-Setting, Baffle
8	66-1340	1	Decal-Danger
9	110-2068	1	Decal-Adjustment, Baffle




Deflector Assembly No. 110-0790

Ref	Part No.	Qty.	Description
1	3231-4	4	Screw-CARR
2	110-0792-01	1	Deflector
3	110-0793-03	1	Strap-Discharge
4	110-0791	1	Deflector-Rubber
5	107-4164-01	1	Bracket-Mounting, Deflector
6	3296-39	4	Nut-Lock, NI




Sheave, Spindle and Blade Assembly

Ref	Part No.	Qty.	Description				
1	108-6697	2	Spindle Housing ASM				
1:1	110-2118	2	Bearing				
1:2	110-2116	1	Spacer-Bearing				
1:3	108-6694	1	Housing-Spindle				
1:4	32120-8	1	Ring-Snap				
2	92-1624	12	Screw				
3	3290-357	12	Nut-HHF, Whiz				
4	110-4888	2	Washer-Spacer				
5	103-2535	2	Spacer-Guard, Bottom				
6	1-807267	2	Key				
7	1-323529	2	Tube-Spindle, Short				
8	1-323539	8	Spacer-Drive, Blade				
9	105-7781	2	Blade-Hi Flow, 18 Inch				
10	1-513208	2	Washer-Spring				
11	1-800861	2	Screw-Cap, HH				
12	103-1330	2	Guard-Bearing, Top				
13	1-403183	2	Sheave				
14	1-323339	2	Washer-Retainer, Sheave				
15	3219-6	2	Nut-Hex				
16	1-803310	2	Screw-Set				




Idler Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-324372	1	Pad / Spring ASM	24	1-323715	1	Rod-Brake
2	321-4	2	Screw-HH	25	1-323748	1	Ring-Push On
3	3296-42	2	Nut-Lock, NI	26	1-323747	1	Spring-Compression
4	322-10	1	Screw-HH	27	1-323746	1	Spacer-Flanged
5	1-403179	1	Tube-Pivot	28	3296-56	1	Nut-Lock, NI
6	32120-35	1	E-Ring	29	1-323071	1	Spring-Extension
7	3256-23	1	Washer-Flat	30	1-303334	1	Washer-Spring
8	1-322235	1	Arm-Assist	31	302-19	2	Fitting-Grease
9	3256-3	1	Washer-Flat				
10	3296-29	1	Nut-Lock, NI				
11	1-303238	1	Eyebolt-Thread, RH				
12	32128-20	3	Nut-HF				
13	1-303236	1	Body-Turnbuckle				
14	1-303348	1	Eyebolt-Thread, LH				
15	702809	1	Screw-Cap				
16	98-5975	1	Washer-Belleville				
17	1-603843	1	Pulley-Idler				
18	1-303434	1	Bushing-Engagement				
19	103-3600	1	Idler Arm ASM				
19:2	1-323729	2	Sleeve-Bearing				
20	32151-103	1	Ring-Snap				
21	322-6	1	Screw-HH				
22	1-303352	1	Washer-Spindle				
23	1-806003	1	Pin-Hair				



Caster Assembly


Ref	Part No.	Qty.	Description				
1	1-513648	2	Wheel And Tire ASM				
2		1	Rim				
1:2	1-513808	1	Tire				
1:3	1-513809	1	Bearing				
1:4	1-513810	2	Bushing				
2	1-513547	2	Spacer				
3	325-20	2	Screw-HH				
4	1-322145-01	2	Fork				
5	3217-9	2	Nut-Hex				
6	3253-7	2	Washer-Lock				
7	1-303314	8	Spacer-Caster				
8	110-2130	2	Support ASM				
8:2	1-303514	2	Bearing-Flanged				
8:3	302-52	1	Fitting-Grease				
9	1-513338	2	Washer-Flat				
10	1-809020	2	Pin				
11	323-4	8	Screw-HH				
12	3290-357	8	Nut-HHF, Whiz				



Cylinder and Crankcase Assembly


Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
11004	11004-7008	1	Gasket-Head	172	172G0818	1	Bolt-Stud
11008	11008-7011	1	Head-Comp-Cylinder, No.2				
11008A	11008-7017	1	Head-Comp-Cylinder, No.1				
11008B	11008-7021	1	Head-Cylinder, No. 2				
11008C	11008-7022	1	Head-Cylinder, No. 1				
11022	11022-7003	1	Case-Rocker				
11060	11060-7001	1	Gasket-Case, Rocker				
11061	11061-7007	1	Gasket-Cover, Crankcase				
11061A	11061-7008	1	Gasket-Breather				
14091	14091-7007	1	Cover				
49015	49015-7032	1	Cover-Crankcase				
49120	49120-7015	1	Crankcase				
59071	59071-2079	1	Joint				
92043	92043-7001	1	Pin				
92049	92049-7001	1	Seal-Oil, Rvc2 (6X11X10.2)				
92049A	92049-7005	1	Seal-Oil, So (8X14X5 Hs)				
92049B	92049-7015	1	Seal-Oil, Sd (35X62X8 L Hs)				
92049C	92049-7016	1	Seal-Oil, Sd (35X48X8 R Hs)				
92049D	92049-7019	1	Seal-Oil, So (8X14X5 Hs)				
92139	92139-7002	1	Bushing				
130	130B0612	1	Bolt-Flanged				
130A	130B0640	1	Bolt-Flanged				
130B	130T0850	1	Bolt-Flanged				
130C	130T0875	1	Bolt-Flanged				




Piston and Crankshaft Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
13001	13001-7009	1	Piston-Engine				
13002	13002-7001	1	Pin-Piston				
13008	13008-7001	1	Ring Set-Piston				
13025	13025-7003	1	Ring Set-Piston (L,0.50)				
13029	13029-7005	1	Piston-Engine (L,0.50)				
13031	13031-7033	1	Crankshaft				
13251	13251-7007	1	Connecting Rod ASM				
13251A	13251-7008	1	Connecting Rod ASM (U/S=0.50)				
92033	92033-7005	1	Ring-Snap				
130	130G0630	1	Bolt-Flanged				



Valve and Camshaft Assembly
Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description				
❶12004	12004-7003	1	Valve-Intake				
❶12005	12005-7003	1	Valve-Exhaust				
❶12009	12009-7001	1	Retainer-Spring, Valve				
❶12011	12011-2056	1	Collet				
❶12016	12016-7001	1	Arm-Rocker				
❶12032	12032-7001	1	Tappet				
❶13070	13070-7001	1	Guide				
❶13070A	13070-7004	1	Guide				
❶13116	13116-2057	1	Rod-Push				
❶13271	13271-7007	1	Plate				
❶13271A	13271-7021	1	Plate-Governor				
❶42036	42036-7009	1	Sleeve				
❶49078	49078-7001	1	Spring-Valve, Engine				
❶49118	49118-7009	1	Camshaft				
❶92009	92009-2341	1	Screw				
❶92015	92015-2253	1	Nut				
❶92033	92033-7001	1	Ring-Snap				
❶92140	92140-7002	1	Ball				
❶92145	92145-7001	1	Spring				
❶92153	92153-7019	1	Bolt				
❶92200	92200-7001	1	Washer				



Lubrication Equipment Assembly


Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
13107	13107-7009	1	Shaft				
13271	13271-7017	1	Plate				
14075	14075-7009	1	Cap ASM				
16154	16154-2053	1	Rotor-Pump (In)				
16154A	16154-2054	1	Rotor-Pump (Out)				
49065	49065-2078	1	Filter-Oil				
49065A	49065-7004	1	Filter-Oil				
59051	59051-7011	1	Gear-Spur				
59231	59231-7003	1	Filler				
92043	92043-7003	1	Pin				
92066	92066-7003	1	Plug				
92140	92140-7003	1	Ball				
92145	92145-7002	1	Spring				
130	130B0612	1	Bolt-Flanged				
670	670D2016	1	O-Ring (16Mm)				




Cooling Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
❶13270	13270-7007	1	Plate				
❶14037	14037-7021-9H	1	Screen				
❶14091	14091-7009	1	Cover				
❶49089	49089-7044	1	Shroud-Engine				
❶49089A	49089-7045	1	Shroud-Engine				
❶59041	59041-7010	1	Fan				
❶59066	59066-7023	1	Housing-Fan				
❶92004	92004-7007	1	Stud				
❶92153	92153-7007	1	Bolt				
❶92153A	92153-7008	1	Bolt				
❶130	130B0612	1	Bolt-Flanged				
❶130A	130B0616	1	Bolt-Flanged				
❶130B	130B0816	1	Bolt-Flanged				
❶311	311F0600	1	Nut-Hex				




Electric Equipment Assembly
Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
❶21171	21171-7013	1	Ignition Coil ASM				
❶21171A	21171-7014	1	Ignition Coil ASM				
❶21194	21194-7013	1	Flywheel-Comp				
❶26030	26030-7001	1	Harness				
❶92004	92004-7008	1	Stud				
❶92009	92009-2308	1	Screw				
❶92066	92066-7002	1	Plug				
❶92066A	92066-7005	1	Plug				
❶92070	92070-7003	1	Plug-Spark (Rcj8Y, Solid)				
❶92151	92151-2097	1	Bolt (12X30)				
❶92200	92200-7002	1	Washer				
❶130	130B0620	1	Bolt-Flanged				
❶311	311F0600	1	Nut-Hex				
❶510	510A5100	1	Key-Woodruff				



Control Equipment Assembly Kawasaki Model FH430V-AS25


Ref	Part No.	Qty.	Description				
⑨13107	13107-7010	1	Shaft				
⑨13271	13271-7018	1	Plate				
⑨16169	16169-7012	1	Link-Choke				
⑨16171	16171-7007	1	Link				
⑨39129	39129-7003	1	Spring-Governor				
⑨49103	49103-7004	1	Arm-Governor				
⑨49113	49113-7024	1	Panel-Control				
⑨92009	92009-7007	1	Screw (4X35)				
⑨92145	92145-7003	1	Spring				
⑨92145A	92145-7005	1	Spring				
⑨92150	92150-2182	1	Bolt (5X18)				
⑨92153	92153-7005	1	Bolt (6X35)				
⑨92170	92170-7001	1	Clamp				
⑨130	130B0612	1	Bolt-Flanged				
⑨214	214B0408	1	Screw-Pan				
⑨311	311B0600	1	Nut-Hex				
⑨411	411b0600	1	Washer-Plain				



Carburetor Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
①11061	11061-7004	1	Gasket-Insulator
①11061A	11061-7009	1	Gasket-Chamber
①11061B	11061-7010	1	Gasket-Screw
①11061C	11061-7018	1	Gasket-Cleaner, Air
①13107	13107-7018	1	Shaft
①15003	15003-7061	1	Carburetor ASM
①16014	16014-7002	1	Screw-Pilot
①16020	16020-7003	1	Chamber-Float
①16025	16025-7006	1	Valve-Throttle
①16030	16030-7003	1	Valve-Float
①16031	16031-7002	1	Float
①16041	16041-7016	1	Shaft-Choke, Carburetor
①16041A	16041-7018	1	Shaft-Throttle, Carburetor
①16186	16186-7002	1	Choke Valve ASM
①39076	39076-7001	1	Limiter
①49121	49121-7001	1	Nozzle-Main
①59076	59076-7005	1	Manifold-Intake
①92009	92009-2083	1	Screw
①92009A	92009-2349	1	Screw
①92055	92055-2174	1	O-Ring
①92055A	92055-7007	1	O-Ring (Id=31)
①92063	92063-7026	1	Jet-Main, No. 88
①92063A	92063-7028	1	Jet-Main, No. 85
①92063B	92063-7029	1	Jet-Main, No. 82


Ref	Part No.	Qty.	Description
①92081	92081-2234	1	Spring
①92093	92093-2100	1	Seal
①92093A	92093-7003	1	Seal
①92145	92145-7015	1	Spring
①92153	92153-7009	1	Bolt
①92172	92172-7002	1	Screw
①92200	92200-7014	1	Washer



Air Filter and Muffler Assembly Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
③11011	11011-7035	1	Case-Filter, Air
③11013	11013-7025	1	Element-Filter, Air
③11013A	11013-7031	1	Element-Filter, Air
③11051	11051-7005-9H	1	Bracket
③11053	11053-7022	1	Bracket
③11060	11060-7021	1	Gasket-Muffler
③13271	13271-7022	1	Plate
③16060	16060-7016	1	Pipe-Intake
③18088	18088-7001	1	Pipe-Exhaust
③32154	32154-7006	1	Pipe
③49070	49070-7015	1	Muffler
③92015	92015-1193	1	Nut
③92026	92026-7001	1	Spacer (6.2X7.9X5)
③92055	92055-7015	1	Ring-O
③92072	92072-7008	1	Band
③92170	92170-7002	1	Clamp
③92192	92192-7010	1	Tube
③92200	92200-2070	1	Washer
③92210	92210-7004	1	Nut
③92210A	92210-7019	1	Nut
③130	130B0610	1	Bolt-Flanged
③130A	130B0612	1	Bolt-Flanged
③130B	130B0816	1	Bolt-Flanged


Ref	Part No.	Qty.	Description
③220	220B0614	1	Screw-Pan (Cross)
③233	233B0416	1	Screw
③311	311B0400	1	Nut-Hex
③317	317R0800	1	Nut-Hex
③461	461F0800	1	Washer-Spring
③670	670B2010	1	O-Ring (10Mm)



Fuel Tank and Fuel Valve Assembly


Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description				
③23062	23062-7004-9H	1	Bracket				
③49019	49019-7001	1	Filter-Fuel				
③49040	49040-7001	1	Pump-Fuel				
③92170	92170-2088	1	Clamp				
③92191	92191-7002	1	Tube				
③92191A	92191-7003	1	Tube (6.35X12.7X160)				
③92191B	92191-7004	1	Tube				
③130	130B0620	1	Bolt-Flanged				



Starter Assembly **Kawasaki Model FH430V-AS25**

Ref	Part No.	Qty.	Description				
❸13165	13165-7001	1	Pawl-Starter, Recoil				
❸13271	13271-7003-9H	1	Plate				
❸14020	14020-7001	1	Retainer				
❸32099	32099-7002	1	Case-Recoil, Starter				
❸46075	46075-7001	1	Grip-Recoil, Starter				
❸49080	49080-7001	1	Pulley-Starting				
❸49088	49088-7013	1	Starter-Recoil				
❸59101	59101-7001	1	Reel-Recoil				
❸59106	59106-7001	1	Rope				
❸92145	92145-7006	1	Spring				
❸92145A	92145-7007	1	Spring				
❸92145B	92145-7008	1	Spring				
❸92151	92151-7008	1	Bolt				
❸92200	92200-7004	1	Washer				
❸92200A	92200-7005	1	Washer				
❸92210	92210-0003	1	Nut				
❸130	130B0608	1	Bolt-Flanged				



Label Assembly

Kawasaki Model FH430V-AS25

Ref	Part No.	Qty.	Description
③56033	56033-7001	1	Label-Manual
③56070	56070-7001	1	Label-Warning
③56080	56080-2077	1	Label-Brand
③56080A	56080-7024	1	Label-Brand

Attachments and Accessories

For 30684 - Commercial Walk-Behind Mower, Fixed Deck Pistol Grip Gear with 36in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Recycler, 18 Inch	105-7779-03
Blade-Med Flow, 18 Inch	105-7794-03
Blade-Low Flow, 18 Inch	105-7795-03
Blade-Atomic, 18 Inch	105-7796-03
36 Inch Bagger Enhancement Kit	110-2026
36 Inch Recycler Kit	110-2080
Weight Kit	110-2085
Soft Bag (3 Bushel)	30104
Sulky	30109

NOTES

NOTES

NOTES

