



Z557 Z Master[®]

With 152cm TURBO FORCE[®] Side Discharge Mower

Model No. 74246TE - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front Frame Assembly	 3	Fuel System Assembly	 25
Castor and Wheel Assembly	 5	Electrical Assembly	 26
Main Frame Assembly	 6	Crankshaft Assembly Kohler CH740 0075	 27
Brake and Wheel Hub Assembly	 7	Crankcase Assembly Kohler CH740 0075	 28
Steering Control Assembly	 8	Oil Pan / Lubrication Assembly Kohler CH740 0075	 29
Hydraulic System Assembly	 9	Head / Valve / Breather Assembly Kohler CH740 0075	 30
Seat and Roll-Over Protection System Assembly	 11	Ignition / Electrical Assembly Kohler CH740 0075	 31
Seat Assembly No. 110-0362-19	 12	Blower Housing and Baffle Assembly Kohler CH740 0075	 32
Roll-Over Protection System Assembly No. 108-1097	 13	Starting System Assembly Kohler CH740 0075	 33
Deck Connection Assembly	 14	Fuel System Assembly Kohler CH740 0075	 34
Deck Assembly	 15	Engine Control Assembly Kohler CH740 0075	 35
Spindle Assembly No. 106-3217	 17	Air Intake / Filtration Assembly Kohler CH740 0075	 36
Deck Assembly No. 107-3974	 18	Exhaust Assembly Kohler CH740 0075	 37
Rubber Deflector Assembly No. 108-2792	 19	Decals Kohler CH740 0075	 38
Lever Assembly No. 107-1664	 20	Attachments and Accessories List	 39
Drive Idler Assembly	 21		
Z-Stand Assembly	 22		
Engine and Clutch Assembly	 23		
Muffler and Guard Assembly	 24		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- | | |
|----------------------|--|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Optional Equipment | ❹ Obtain from your local Kohler dealer |



Front Frame Assembly


Ref	Part No.	Qty.	Description
1	107-3980	1	Frame ASM
1:2	107-3968	1	Decal-Brake, Parking
1:3	1-811010	2	Plug
1:4	302-19	5	Fitting-Grease
1:5	94-1291	2	Bushing
1:6	107-3969	1	Decal-Warning
1:7	103-1918	1	Bushing
3	107-3976	1	Footrest
3:2	106-7451	1	Decal
3:3	107-1866	1	Decal-Danger, Slope
4	103-1918	1	Bushing
5	103-2083-03	1	Lift Lever ASM
6	1-633295	1	Grip-Lever, Lift
7	103-2064-03	1	Arm-Lift, Deck
8	1-633325	1	Spring-Compression
9	3256-24	1	Washer-Flat
10	3296-39	9	Nut-Lock, NI
11	32151-103	5	Ring-Snap
12	1-633068	2	Arm-Lift, Deck
14	323-29	2	Screw-HH
15	110-0835	1	Plate-Deck Lift, Outer (Ce)
15:2	107-3961	1	Decal-Deck Height, Large
15:4	105-4674	1	Decal-Noise
16	110-0836	1	Plate-Deck Lift, Inner (Ce)

Ref	Part No.	Qty.	Description
16:2	107-3962	1	Decal-Deck Height, Small
17	1-633082	1	Bushing-Lever, Lift
18	1-633080	1	Bushing-Lever, Lift
19	323-13	1	Screw-HH
20	106-9951	1	Hitch Pin ASM
22	323-9	2	Screw-HH
23	98-5975	12	Washer-Belleville
24	3290-357	15	Nut-HHF, Whiz
25	323-6	1	Screw-HH
26	323-7	12	Screw-HH
27	3256-29	4	Washer-Flat
35		2	Front Frame Spring ASM
35:1	1-633096	1	Rod-Lift, Deck
35:2	1-633441	2	Swivel-Deck Mount, Rear
35:3	3217-11	4	Nut-Hex
35:4	3218-6	2	Nut-Jam
35:5	3256-7	2	Washer-Flat
35:6	1-633064	1	Spring-Support, Deck
38	3274-94	4	Screw-HSBH
40	108-7786-01	1	RH Front Deck Lift ASM
41	106-8984-01	1	LH Deck Lift ASM
42	1-523157	2	Washer-Spacer, 14 GA
43	32151-29	2	Ring-Retaining
44	3274-18	2	Screw-HSH




Front Frame Assembly (continued)

Ref	Part No.	Qty.	Description
45	3218-2	2	Nut-Jam
46	1-513658	2	Bumper



Castor and Wheel Assembly


Ref	Part No.	Qty.	Description				
1	103-4882	2	Cap-Grease				
2	3296-51	2	Nut-Lock, NI				
3	1-633508	6	Washer-Bellville				
4	254-94	4	Bearing-Cone, Tapered				
5	254-72	4	Bearing-Cup, Tapered				
7	1-543511	2	Seal-Grease				
8	103-1474-01	2	Fork-Caster				
11	1-644251	2	Caster Wheel ASM				
11:1	1-633580	2	Seal-Bearing				
11:2	1-633581	2	Spacer-Bearing				
11:3	1-633585	2	Bearing-Cone, Taper				
11:4	1-633959	1	Spacer-Caster, Front				
11:5		1	Wheel And Tire ASM				
11:5:1	1-523009	1	Tire				
11:5:2	1-633987	1	Wheel				
11:5:3	1-633584	2	Bearing-Cup				
21	325-39	2	Screw-HH				
22	3296-23	2	Nut-Lock, NI				



Main Frame Assembly

Ref	Part No.	Qty.	Description
1	1-633964-03	1	Stop-Brake, Park
4	322-43	7	Screw-HH
5	323-6	2	Screw-HH
11	108-1096	1	Main Frame ASM
11:2	107-8077	1	Decal-Console, Top
12	1-633970	2	Wheel And Tire ASM
12:1	1-633993	1	Tire
12:2	1-633992	1	Wheel
12:3	232-27	1	Stem-Valve
13	107-3981	1	Floorpan
13:2	98-4387	1	Decal-Protection, Ear
13:3	107-3982	1	Decal-Location, Manual
15	242-50	8	Nut-Lug
21	3296-39	2	Nut-Lock, NI
24	1-513762	1	Clip-Loom
25	1-303335	1	Tie-Plastic
27	321-4	3	Screw-HH
28	32128-33	1	Nut-HF
44	3256-70	6	Washer-Flat
47	106-7498	1	Pocket
48	106-7488-03	1	Hinge-Floorpan, LH
49	106-7489-03	1	Hinge-Floorpan, RH
50	323-20	2	Screw-HH
51	3296-59	2	Nut-Lock, NI


Ref	Part No.	Qty.	Description
52	3296-42	4	Nut-Lock, NI
53	3256-63	2	Washer-Flat
54	3258-166	2	Screw-PRH
55	107-3964	1	Decal-Warning, Right
56	107-3963	1	Decal-Danger, Left
57	107-1865	2	R-Clamp
58	104-7050	1	Housing-Manual
59	104-7048	1	Cap-Housing
61	32128-25	1	Nut-HF
62	1-653036	1	Washer



Brake and Wheel Hub Assembly

Ref	Part No.	Qty.	Description
1	1-513140	2	Bearing-Control
2	1-633454	2	Spring-Brake
3	103-4332	1	Brake Rod And Yoke ASM
3:1	1-633131	2	Yoke-Linkage, Brake
3:2	1-633477	1	Rod-Brake
3:3	3219-3	2	Nut-Hex
4	1-634500	1	Brake Lever ASM
4:2	1-633268	1	Grip-Lever, Brake
5	1-632217-03	1	Shaft-Brake
6	103-0352-03	2	Bracket-Brake
7	1-523157	2	Washer-Spacer, 14 GA
9	103-0355	2	Band-Brake
10	1-633380	4	Spacer-Wheel, Short
11	1-633382	4	Spacer-Wheel, Long
12	1-633102	2	Bearing-Flange, Side
13	103-4333	2	Brake Rod And Yoke ASM
13:1	1-633131	1	Yoke-Linkage, Brake
13:2	1-633477	1	Rod-Brake
13:3	3219-3	1	Nut-Hex
14	1-633144	2	Pin-Trunion
15	103-0590	2	Hub And Wheel ASM
15:1	103-0589	1	Wheel Hub ASM
15:2	1-633926	4	Stud-Wheel
18	323-4	4	Screw-HH


Ref	Part No.	Qty.	Description
19	103-2399	3	Pin-Spring, Clevis
20	325-17	8	Screw-HH
21	1481	2	Fitting-Grease
22	103-0131	8	Nut-Square
23	3219-3	4	Nut-Hex
24	3290-357	4	Nut-HHF, Whiz
25	3253-7	8	Washer-Lock
26	3256-4	4	Washer-Flat
27	3272-10	2	Pin-Cotter
28	1-806800	2	Pin-Cotter
29	322-9	6	Screw-HH
30	103-0384	6	Spacer
31	103-0374	2	Retainer-Band, Brake
32	1-808285	1	Pin-Clevis



Steering Control Assembly

Ref	Part No.	Qty.	Description
1	1-303105	2	Yoke-Adjustable
2	98-5975	4	Washer-Belleville
3	103-4079	2	Damper-Control, Motion
5	1-603735	2	Bushing-Flanged
6	1-603737	2	Bolt-Return, Neutral
7	1-603807	2	Spring-Return, Neutral
8	1-403180	4	Screw-HH
9	103-4331	1	Tracking Rod ASM
9:1	1-543017	1	Balljoint-RH
9:2	3219-2	3	Nut-Hex
9:4	1-804524	1	Nut
9:5	1-633152	1	Balljoint-Thread, LH
10	103-4330	1	Tracking Rod ASM
10:1	1-543017	1	Balljoint-RH
10:2	3219-2	1	Nut-Hex
10:3	103-3060	1	Knob-Tracking
10:4	1-804524	2	Nut
10:5	1-323245	2	Spring-Compression
10:6	1-633152	1	Balljoint-Thread, LH
11	108-7238	1	LH Lever ASM
11:1	106-9987	1	Grip-Control, Motion
12	1-632208	2	Arm-Control, Pump
13	103-4781	1	Control-Motion, LH
14	103-4782	1	Control-Motion, RH


Ref	Part No.	Qty.	Description
16	1-633102	4	Bearing-Flange, Side
18	103-0407	2	Arm-Shaft, Control
20	322-6	4	Screw-HH
21	323-4	8	Screw-HH
22	323-6	4	Screw-HH
23	323-9	6	Screw-HH
24	1-803022	2	Screw-Set
25	3296-39	6	Nut-Lock, NI
26	3219-2	4	Nut-Hex
28	3220-2	2	Nut-Jam
29	3256-2	2	Washer-Flat
30	3256-3	4	Washer-Flat
32	3272-5	2	Pin-Cotter
33	1-808280	2	Pin-Clevis
34	32128-20	4	Nut-HF
35	3290-357	8	Nut-HHF, Whiz
37	108-7237	1	RH Lever ASM
37:1	106-9987	1	Grip-Control, Motion
38	3296-29	8	Nut-Lock, NI
39	3217-6	4	Nut-Hex



Hydraulic System Assembly

Ref	Part No.	Qty.	Description
1	103-3736	1	HYD Hose ASM
2	107-8433	1	HYD Reservoir ASM
2:1		1	Reservoir-HYD
2:1:1	103-1948	1	Cap-Reservoir, HYD
2:1:2	103-1949	1	Gasket-Cap
2:2	107-2131	1	Decal-Surface, Hot
3	104-7836	1	Head-Filter
4	103-3733	1	HYD Hose ASM
6	1-633752	1	Filter-HYD, Winter
6	1-633750	1	Filter-Oil, HYD
7	103-1799	2	Elbow-90 DEG
7:1	237-42	1	O-Ring
10	1-603991	4	Fitting-Straight
10:1	237-80	1	O-Ring
10:2	1-603992	1	O-Ring
11	103-6988	2	Motor-Wheel
11:1	1-809036	1	Nut-HH
11:2	3257-42	1	Key-Woodruff
11:99	103-6994	1	Seal Kit
11:99	103-2748	1	Drive Link Kit
12	1-603384	1	Bushing-Pivot, Idler
13	103-3330	1	Spring-Extension
14	109-1936	1	Pump Inlet Hose ASM
14:1	103-1826	1	HYD Hose ASM


Ref	Part No.	Qty.	Description
14:2	103-1827	1	HYD Hose ASM
14:3	103-1828	1	Adapter-Run, Tee
14:3:1	237-42	1	O-Ring
16	103-1716	3	Clamp-Hose
17	103-1988	2	Clamp-Hose
18	103-1801	1	Adapter-Straight
18:1	237-42	1	O-Ring
19	103-1912	1	Adapter-Straight
19:1	237-42	1	O-Ring
20	103-1802	2	Fitting-HYD, 90 DEG
20:1	1-603921	1	O-Ring
21	1-603990	4	Fitting-Straight
21:1	1-603920	1	O-Ring
21:2	1-603992	1	O-Ring
22	103-3737	1	HYD Hose ASM
23	103-3735	1	HYD Hose ASM
25	103-1808	1	Hose-HYD
26	103-1807	1	Elbow-45 DEG
26:1	237-42	1	O-Ring
27	103-1806	1	HYD Hose ASM
28	103-6907	2	Sheave
29	1-633567	1	Sheave
30	103-7445	1	Belt-V
31	1-633167	1	Sheave-Idler



Hydraulic System Assembly (continued)


Ref	Part No.	Qty.	Description
33	1-634277	1	Bearing Arm ASM
33:1	1-513034	2	Sleeve-Bearing
33:3	302-40	1	Fitting-Grease
34	321-6	2	Screw-HH
35	323-8	1	Screw-HH
36	323-9	1	Screw-HH
37	1-800805	1	Screw-HH
38	323-7	4	Screw-HH
39	1-803022	2	Screw-Set
40	30-1710	2	Screw
41	1-803050	2	Screw-Set
42	3256-22	2	Washer-Flat
43	3256-3	1	Washer-Flat
44	3256-4	1	Washer-Flat
45	13-2840	1	Key-Square
46	5-1077	2	Key-Square
47	3290-357	8	Nut-HHF, Whiz
48	32128-33	2	Nut-HF
49	1-805004	2	Washer-Lock
50	321-3	2	Screw-HH
51	103-7262	2	Pump-HYD
●51:1	103-7441	1	Bearing-Shaft, Input
●51:2	103-7443	1	Cylinder Block Kit
●51:3	103-8448	1	Thrust Bearing Kit

Ref	Part No.	Qty.	Description
●51:4	105-6184	1	Overhaul Seal Kit
●51:5	106-2053	1	Shock Valve Kit



Seat Assembly No. 110-0362-19


Ref	Part No.	Qty.	Description				
1	110-5719	1	Armrest Kit				
1:1	110-4163	2	Cushion-Arm Rest				
1:2	3256-22	4	Washer-Flat				
1:3	322-10	2	Screw-HH				
1:4	105-3623	2	Channel-Armrest				
1:5	32153-3	2	Nut-Hex, Side Deform				
1:6	105-3621	1	Bracket-Armrest, RH				
1:7	105-3622	1	Bracket-Armrest, LH				
1:8	321-30	8	Screw-HH				
1:9	3296-42	4	Nut-Lock, NI				
1:10	325-2	2	Screw-HH				
1:11	3296-23	2	Nut-Lock, NI				
3	110-4162	1	Cushion-Seat, Bottom				
4	110-0447	1	Cusion-Seat, Back				
7	1-633859	1	Frame-Seat				
8	1-643255	1	Track-Seat				
11	110-0883	1	Retractable Seatbelt Kit				
11:2	3212-4	2	Screw-HH				
11:3	3296-7	2	Nut-Lock				
12	1-543401	4	Spacer-Track				
13	321-30	5	Screw-HH				
14	32128-20	4	Nut-HF				
15	3256-22	5	Washer-Flat				



Roll-Over Protection System Assembly No. 108-1097


Ref	Part No.	Qty.	Description
① 1		1	Upper Tube ASM
1:2	107-2101	1	Decal-ROPS
1:3	107-2102	1	Decal-Warning, Folding ROPS
2	3296-73	2	Nut-Lock, NI
4	103-4553	2	ROPS Fold Pin ASM
5	325-13	2	Screw-HH
6	32128-23	2	Nut-HF
② 7		1	Tube-Support, RH
② 12		1	Tube-Support, LH
13	109-2365	2	Bumper-Rubber (W/Stud)
16	107-3052-03	1	Seat Support Frame ASM
17	107-3058	1	Catch-Latch, Seat
18	322-3	2	Screw-HH
19	3296-29	2	Nut-Lock, NI
20	3296-39	1	Nut-Lock, NI
23	323-20	1	Screw-HH
24	107-0076	1	Spring-Torsion
25	107-0075	1	Bushing-Latch, Seat
26	103-4434	1	Grip-Lever
28	3256-24	1	Washer-Flat
29	107-3083	1	Latch ASM
34	110-0883	1	Retractable Seatbelt Kit
34:2	3212-4	2	Screw-HH
34:3	3296-7	2	Nut-Lock

Ref	Part No.	Qty.	Description
① ② 54		1	Bag-Bolt, ROPS
54:3	323-6	8	Screw-HH
54:4	98-5975	8	Washer-Belleville
54:5	3290-357	8	Nut-HHF, Whiz




Deck Connection Assembly

Ref	Part No.	Qty.	Description				
1	32128-37	8	Nut-HF				
3	103-9792	4	Deck Chain ASM				
4	302-19	4	Fitting-Grease				
5	3217-11	2	Nut-Hex				
6	3253-8	2	Washer-Lock				
7	327-11	2	Screw-HH				
8	1-633029	2	Balljoint-Spherical				
9	3219-6	2	Nut-Hex				
10	109-1181	2	Strut-Deck				
11	1-632199-01	2	Pin-Strut				
12	322-3	2	Screw-HH				
13	3296-29	2	Nut-Lock, NI				
14		1	Deck ASM				




Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	105-8783	1	Belt	26	98-7912	4	Tube-Spanner
2	74-5950	2	Latch-Swell	27	108-4052	1	Spring-Torsion
3	107-8536	2	Cover-Belt	28	105-4622	1	Spacer
4	106-3220	1	Guide-Belt	29	108-2792	1	Rubber Deflector ASM
5	105-8792-01	1	Plate-Skid	30	108-4122-01	1	Bracket-Cover
6	32144-70	6	Screw-HWHTF	31	107-1664	2	Lever ASM
7	108-4121-01	2	Bracket-Cover	32	323-12	2	Screw-HH
8	108-2177-01	1	Bracket-Cover, Tall	33	106-3214	2	Mount-Pulley
9	106-7354-01	1	Plate-Roller, LH	34	3256-24	4	Washer-Flat
10	106-7355-01	1	Plate-Roller, RH	35	1-633109	3	Idler-Flat
11	3290-357	42	Nut-HHF, Whiz	36	3231-1	10	Screw-CARR
13	92-1624	33	Screw	37	99-3058	2	Washer
14	105-7734	3	Pulley	38	323-9	1	Screw-HH
15	106-3217	3	Spindle ASM	39	1-603496	1	Bushings-Idler
16	105-7718-03	3	Blade-Hi Flow	40	105-7787-01	1	Plate-Idler
17	323-23	4	Screw-HH	41	105-7788	2	Spacer
18	98-7913	4	Tube-Spacer	42	3231-4	2	Screw-CARR
19	322-50	2	Screw-HH	43	3296-39	2	Nut-Lock, NI
20	98-5967	1	Spacer-Wheel	44	98-5975	1	Washer-Belleville
21	1-603299	6	Roller-Scalp, Anti	45	103-0862	3	Screw-Cap
22	3296-29	2	Nut-Lock, NI	46	103-0865	3	Washer-Blade Bolt, Heavy
23	107-3974	1	Deck ASM	47	106-3216-01	1	Baffle-Discharge
24	105-7657-01	1	Baffle ASM	48	112843	1	Washer
25	105-7669-01	1	Baffle ASM	50	108-7220-01	1	Guide-Belt




Deck Assembly (continued)

Ref	Part No.	Qty.	Description
①999	105-7715-03	3	Blade-Mid Flow, 20.5 Inch
①999	105-7716-03	3	Blade-Lo Flow, 20.5 Inch
①999	105-7777-03	3	Blade-Recycler, 20.5 Inch
①999	105-8777-03	3	Blade-Atomic, 20.5 Inch




Spindle Assembly No. 106-3217

Ref	Part No.	Qty.	Description				
1	10-8040	1	Key-Square				
2	106-3277	1	Hub-Pulley				
3	103-0865	1	Washer-Blade Bolt, Heavy				
4	106-3204	2	Shield-Bearing				
5		1	Spindle Bearing ASM				
5:1	106-3211	1	Housing-Spindle				
5:2	106-3207	1	Bearing ASM				
5:2:1	27-0960	1	Bearing ASM				
5:2:2	106-3206	1	Spacer-Set, Matched				
5:3	253-133	2	Seal-Oil				
5:4	302-5	1	Fitting-Grease				
6	106-3218	2	Spacer-Seal				
7	106-3233	1	Spindle Shaft ASM				
8	3219-6	1	Nut-Hex				



Deck Assembly No. 107-3974

Ref	Part No.	Qty.	Description				
2	110-2068	1	Decal-Adjustment, Baffle				
3	93-7824	1	Decal-Danger				
4	98-1977	3	Decal-Warning				
5	93-7010	2	Decal-Danger				
6	93-7818	1	Decal-Torque, Blade Bolt				
7	107-3996	1	Decal-Routing, Belt				
8	99-8939	1	Decal-Anti Scalp				
9	58-6520	5	Decal-Grease				
10	110-2067	1	Decal-Setting, Baffle				
12	107-1619	1	Decal				
13	107-3984	1	Decal-Service, Check				
15	107-3137	1	Plate-Turbo				
16	3274-104	2	Screw-HSBH				
17	1-303334	4	Washer-Spring				
18	3296-29	2	Nut-Lock, NI				




Rubber Deflector Assembly No. 108-2792

Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	106-3246-01	1	Deflector				
3	106-3248-03	1	Strap-Discharge				
4	108-5029	1	Deflector-Rubber				
5	108-4059-01	1	Plate-Hinge, Rear				
6	106-3253-01	1	Plate-Hinge, Front				
7	3296-39	4	Nut-Lock, NI				

Lever Assembly No. 107-1664


Ref	Part No.	Qty.	Description
1	106-3239	1	Screw-Lock
2	107-1644	1	Cap-Lock
3	106-3241	1	Lever-Lock
4	3296-29	1	Nut-Lock, NI



Drive Idler Assembly


Ref	Part No.	Qty.	Description
1	98-5975	1	Washer-Belleville
6	103-2627	1	Bushing-Idler
7	1-603384	1	Bushing-Pivot, Idler
9	1-603496	1	Bushing-Idler
10	99-4638	1	Idler
11	1-603402	1	Spring-Extension
12	1-633166	1	Pulley-Idler
14	103-3147	1	Arm ASM
14:1	1-513034	2	Sleeve-Bearing
14:2	302-40	1	Fitting-Grease
15	323-12	2	Screw-HH
16	323-9	1	Screw-HH
17	323-13	1	Screw-HH
18	1-800805	1	Screw-HH
19	3296-39	3	Nut-Lock, NI
20	3256-24	3	Washer-Flat
21	3290-357	6	Nut-HHF, Whiz
22	1-603401	1	Spacer-Fender
24	3256-4	3	Washer-Flat
26	106-3271	1	Travel Limiter ASM
26:1	106-3228-03	1	Plate-Limiter, Pulley
26:2	106-3229	1	Pad-Bumper
26:3	3269-24	2	Rivet
27	108-7204-03	1	Guide-Belt, LH

Ref	Part No.	Qty.	Description
28	108-7229-03	1	Guide-Belt, RH
29	3231-2	2	Screw-CARR




Z-Stand Assembly

Ref	Part No.	Qty.	Description				
1	323-20	1	Screw-HH				
2	100-6542-01	1	Bracket-Cradle				
3	3296-39	2	Nut-Lock, NI				
4	107-1874	1	Leg ASM				
4:2	106-7464	1	Decal-Z Stand				
5	283-55	1	Pin-Clevis				
6	100-9692-01	1	Pivot Pin ASM				
7	323-8	1	Screw-HH				
8	100-9686-01	1	Bracket-Latch				
9	3-6781	2	Washer-Thrust				
10	283-71	1	Pin-Lynch				
11	3290-355	1	Pin-Hair				
12	100-6547	2	Cushion-Rubber				
14	105-1647	1	Pin-Hitch, Cotterless				
15	100-9385	1	Lanyard-Nylon				
16	321-4	1	Screw-HH				
17	3296-42	1	Nut-Lock, NI				




Engine and Clutch Assembly

Ref	Part No.	Qty.	Description				
2	323-9	4	Screw-HH				
3	98-5975	4	Washer-Belleville				
5	52-4780	1	Rod-Belt				
6	1-603610	2	Washer-Spring				
7	1-633615-03	1	Guard-Clutch				
9	103-6579	1	Clutch				
10	1-633179	1	Spacer-Clutch				
12	106-7022	1	Tube-Drain, Oil				
20	103-7454-03	2	Strap-Guard				
24	323-6	6	Screw-HH				
25	3212-10	1	Screw-HH				
32	3290-357	8	Nut-HHF, Whiz				
42		1	Engine-Kohler, Ch740-0075				
46	3256-24	1	Washer-Flat				
47	323-6	1	Screw-HH				
48	98-5975	1	Washer-Belleville				



Muffler and Guard Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	103-3535	1	Cable Heat Shield Kit	37	1-323236	2	Spacer
1:2	321-4	1	Screw-HH	43	1-644316	1	RH Shield ASM
1:3	32128-33	1	Nut-HF	43:1	1-523285	1	Clip-Baffle, Rear
3	109-2365	2	Bumper-Rubber (W/Stud)	43:2	1-633301	1	Shield-Engine
11	107-3977	1	Shield ASM	43:3	1-633794-03	1	Shield-RH
11:2	1-634308	1	Shield/Lift ASM	43:4	1-643315	1	Baffle-Cooler, Engine
11:2:1	103-1308	1	Shield-Engine	43:5	1-803035	5	Rivet-Pop
11:2:2	1-633300-03	1	Lift-Shield	43:6	3256-63	5	Washer-Flat
11:2:3	1-803035	3	Rivet-Pop	44	1-643339	1	Decal-Routing, Belt
11:3	107-3978	1	Decal-Devices, Rotating	45	103-7482	1	Muffler
14	1-634796	1	LH Shield ASM	46	3253-6	2	Washer-Lock
14:1	1-523285	1	Clip-Baffle, Rear	47	324-2	2	Screw-HH
14:2	1-633301	1	Shield-Engine	48	9266934	2	Screw
14:3	1-633795-03	1	Baffle-Engine Shield, LH	51	107-2137-03	1	Shield-Muffler, LH
14:4	1-803035	3	Rivet-Pop	52	110-4151-03	1	Shield-Muffler, RH (Ce)
14:5	3256-63	3	Washer-Flat	53	107-2140-03	2	Shield Strap
17	1-643313-03	1	Guard-Muffler	54	1-803035	2	Rivet-Pop
22	321-4	12	Screw-HH	55	3256-63	2	Washer-Flat
27	3296-42	4	Nut-Lock, NI				
29	3256-2	4	Washer-Flat				
33	32128-33	11	Nut-HF				
34	1-633396	1	Clip-Loom				
35	1-809076	2	Screw				
36	1-323235	2	Washer-Spring				



Fuel System Assembly

Ref	Part No.	Qty.	Description
1	107-9285	1	Fuel Line ASM
1:1	1-303077	12	Clamp
1:2	109-0678	2	Hose-Fuel
1:3	99-5000	2	Valve-Check, Fuel
1:4	109-0305	1	Hose-Fuel
1:5	99-5005	1	Fitting-Tee, Barbed
1:7	109-0302	1	Hose-Fuel
1:8	110-5702	1	Hose-Fuel
1:9	1-603770	1	Valve-Fuel
1:10	109-0660	1	Hose-Fuel
2	112-1783	1	Control Panel ASM W/Decal
2:2	110-5721	1	Decal-Panel, Control
4	1-303335	4	Tie-Plastic
9	1-633023	6	Stud
10	105-3644	1	LH Fuel Tank Kit ASM
②10:1		1	LH Fuel Tank ASM
10:1:2	103-2605	1	Fitting-Fuel, Bulkhead
10:2	109-0346	1	Cap-Fuel, Gas
11	105-3643	1	RH Fuel Tank Kit ASM
②11:1		1	RH Fuel Tank ASM
11:1:2	103-2605	1	Fitting-Fuel, Bulkhead
11:2	109-0346	1	Cap-Fuel, Gas
14	1-633349	6	Spring-Tank, Fuel
16	322-3	2	Screw-HH


Ref	Part No.	Qty.	Description
17	3296-47	6	Nut-Lock, NI
19	1-805005	2	Washer-Lock
20	3256-23	8	Washer-Flat
23	3251-1	4	Screw-PPH
24	1-303435	4	Washer-Spring
26	110-5720	1	Control-Choke, Push / Pull
27	1-807513	2	Bolt-CARR
28	1-603175	1	Knob-Ball
29	110-5717	1	Cable-Throttle
30	3296-2	2	Nut-Lock



Electrical Assembly


Ref	Part No.	Qty.	Description
1	107-9277-03	1	Strap-Holddown, Battery
2	105-1692	1	Battery
2:1	104-4163	1	Decal-Battery
2:2	104-4164	1	Decal-Battery
3	1-543792	2	Wingnut
4	1-633307	1	Wire-Ground
5	1-543391	1	Insulator-Battery
6	1-800282	1	Screw-HH
7	3256-2	2	Washer-Flat
8	3296-29	1	Nut-Lock, NI
9	1-523415	1	Spring-Switch, Seat
10	1-522424-03	1	Mount-Spring, Seat
11	321-4	6	Screw-HH
12	32128-33	6	Nut-HF
13	63-8360	2	Key-Ignition
14	1-513152	1	Switch-Closed, Normally
15	1-513180	1	Plate-Switch, Seat
16	3290-500	12	Screw-PPH
17	1-633181	4	Plate-Tapped
18	1-816001	2	Fuse-Blade Type, 20 Amp
19	1-633111	1	Switch
20	1-513051	2	Switch-Open, Normally
21	1-303287	5	Tie-Plastic
22	100-6186	1	Module-Delay, Seat

Ref	Part No.	Qty.	Description
23	103-0206	1	Switch-Starting, Key
24	1-513374	1	Meter-Hour
25	103-5221	1	Switch-PTO
26	1-633396	3	Clip-Loom
27	106-7497	1	Harness-Wire
28	1-303335	2	Tie-Plastic
29	1-523281	1	Wire-Starter
30	1-543393	1	Insulator-Solenoid
31	1-633651	2	Bolt-Holddown
33	3296-2	4	Nut-Lock
34	1-643275	2	Relay
37	3256-22	1	Washer-Flat
51	3217-6	1	Nut-Hex



Crankshaft Assembly Kohler CH740 0075


Ref	Part No.	Qty.	Description
④1	24 014 06-S	1	Crankshaft



Crankcase Assembly
Kohler CH740 0075

Ref	Part No.	Qty.	Description
2 41		1	Crankcase (Use: Miniblock 24 782 36)
42	24 032 01-S	1	Seal-Oil
43	25 139 57-S	2	Plug-Square Head Solid (3/8)
44	25 755 14-S	1	Valve-Drain, Oil
45	25 173 14-S	1	Cap-Valve, Oil Drain
46	24 380 16-S	6	Pin-Locating
47	24 067 20-S	2	Rod-Connecting (STD)
47	24 067 14-S	2	Rod-Connecting (.25)
48	24 874 08-S	2	Piston W/Ring Set (STD)
48	24 874 16-S	2	Piston W/Ring Set (.08)
48	24 874 20-S	2	Piston W/Ring Set (.25)
48	24 874 21-S	2	Piston W/Ring Set (.50)
49	24 018 01-S	4	Retainer-Piston, Pin
410	24 108 05-S	2	Ring Set (.25)
410	24 108 06-S	2	Ring Set (.25)
410	24 108 07-S	2	Ring Set (.50)
411	12 422 10-S	1	Shim-Camshaft (Yellow)
411	12 422 09-S	1	Shim-Camshaft (Red)
411	12 422 13-S	1	Shim-Camshaft (Black)
411	12 422 07-S	1	Shim-Camshaft (White)
411	12 422 08-S	1	Shim-Camshaft (Blue)
411	12 422 11-S	1	Shim-Camshaft (Green)
411	12 422 12-S	1	Shim-Camshaft (Gray)


Ref	Part No.	Qty.	Description
412	24 012 18-S	1	Camshaft
413	24 018 09-S	1	Ring-Retainer
414	M-931010-S	1	Washer-Flat (8 Mm)
415	28 032 09-S	1	Seal-Shaft, Cross Governor
416	24 468 15-S	1	Washer-Flat (1/4)
417	24 144 38-S	1	Shaft-Cross, Governor
418	52 139 09-S	1	Plug-Cup



Oil Pan / Lubrication Assembly Kohler CH740 0075

Ref	Part No.	Qty.	Description
④1	24 009 83-S	1	Closure Plate ASM
④2	24 755 121-S	1	Dipstick Tube ASM
④3	24 038 10-S	1	Dipstick
④4	24 043 12-S	1	Governor Gear Kit (W/Pin)
④5	12 380 01-S	1	Pin-Regulating, Governor
④6	24 448 02-S	1	Tab-Locking
④7	12 144 02-S	1	Shaft-Gear, Governor
④8	52 032 08-S	1	Seal-Oil (PTO End)
④9	25 139 60-S	1	Plug-Hex, Countersunk (1/8)
④10	24 153 08-S	1	O-Ring
④11	24 393 51-S	1	Oil Pump ASM
④12	24 153 01-S	1	O-Ring
④13	24 381 04-S	1	Pick Up-Oil
④14	M-631005-S	2	Washer-Plain (6 Mm)
④15	M-645025-S	2	Screw-HF (M6X1.0X25)
④16	25 086 49-S	2	Screw-Tapping (1/4-1X3/4)
④17	54 755 21-S	1	Oil Cooler Kit
④18	24 136 05-S	1	Nipple-Filter, Oil
④19	24 153 21-S	1	O-Ring
④20	12 050 01-S	1	Filter-Oil
④21	24 100 01-S	2	Nut-Plastic
④22	25 155 02-S	1	Connector
④23	24 099 03-S	1	Switch-Pressure
④24	24 086 16-S	9	Screw-HF (M8X1.25X45)


Ref	Part No.	Qty.	Description
④25	24 086 17-S	1	Screw-HF (M8X1.25X45)



Head / Valve / Breather Assembly Kohler CH740 0075

Ref	Part No.	Qty.	Description
❶1	24 755 141-S	1	Plain Valve Cover ASM
❶2	M-651030-S	4	Screw-Hex Flange (M6X1.0X30)
❶3	24 153 28-S	1	O-Ring
❶4	24 445 01-S	1	Strap-Lifting
❶5	12 755 03-S	4	Retainer Kit
❶6	12 173 01-S	2	Cap-Spring, Valve
❶7	24 089 02-S	2	Spring-Valve
❶8	235011-S	2	Retainer-Spring
❶9	66 032 05-S	1	Seal-Stem, Valve
❶10	24 318 65-S	1	Head ASM
❶11	24 017 01-S	1	Valve-Intake (Standard)
❶11	24 017 02-S	1	Valve-Intake (.25)
❶12	24 016 01-S	2	Valve-Exhaust (Standard)
❶12	24 016 02-S	1	Valve-Exhaust (.25)
❶13	24 755 66-S	1	Valve Train Kit
❶14	25 351 04-S	4	Lifter-Valve
❶15	24 411 05-S	2	Rod-Push
❶16	24 841 03-S	2	Cylinder Head Gasket Kit (Includes head Mounting Hardware And 24 041 49-S, 24 153 27-S)
❶17	24 318 66-S	1	Head ASM
❶18	25 186 01-S	2	Arm-Rocker
❶19	24 599 02-S	2	Arm-Rocker, Pivot
❶20	24 072 09-S	8	Stud-Head, Cylinder


Ref	Part No.	Qty.	Description
❶21	24 468 16-S	8	Washer
❶22	24 100 10-S	8	Nut-HF (M8X1.25)
❶23	M-640034-S	2	Screw-HF (M6X1.0X34)
❶24	24 755 140-S	1	Valve Cover Kit
❶25	25 755 13-S	1	Oil Fill Cap ASM
❶26	25 153 02-S	1	O-Ring
❶27	12 445 05-S	1	Strap-Lifting
❶28	24 402 03-S	1	Reed-Breather
❶29	66 018 04-S	1	Retainer-Reed, Breather
❶30	M-545010-S	1	Screw-HHFTF (M5X0.8X10)
❶31	24 050 01-S	1	Filter-Breather
❶32	24 033 01-S	1	Breather Kit
❶33	24 041 51-S	1	Gasket-Breather
❶34	24 096 86-S	1	Cover-Breather
❶35	M-645020-S	4	Screw-Flange, Hex (M6X1.0X20)
❶36	25 237 08-S	1	Clamp-Hose
❶37	24 326 77-S	1	Hose-Breather
❶38	25 237 14-S	1	Clamp-Hose
❶❶	24 755 147-S	1	Cylinder Head Hardware Kit



Ignition / Electrical Assembly Kohler CH740 0075

Ref	Part No.	Qty.	Description
❶1	54 755 09-S	1	Stator Kit
❶2	24 126 137-S	1	Bracket-Strap, Ground
❶3	M-548025-S	2	Screw-HHFTF (M5X0.8X25)
❶4	24 584 31-S	1	Module-Advance, Spark
❶5	M-545020-S	1	Screw-HHFTF (M5X0.8X20)
❶6	12 132 02-S	2	Spark Plug
❶7	24 025 15-S	1	Flywheel
❶8	X-42-15-S	1	Key
❶9	12 468 03-S	1	Washer-Flat (3/8)
❶10	12 086 14-S	4	Screw-Hex Flange (M10X1.5X45)
❶11	24 100 02-S	4	Nut-Plastic
❶12	24 584 36-S	4	Module-Ignition
❶13	24 086 41-S	1	Screw
❶14	24 755 08-S	1	Front Drive Shaft Kit
❶15	M-839025-S	4	Screw-HF (M8X1.25X25)
❶16	24 157 11-S	4	Fan
❶17	24 468 11-S	1	Washer-Spring
❶18	24 112 14-S	1	Spacer
❶19	24 141 06-S	2	Ring-Support
❶20	24 162 22-S	1	Screen-Grass
❶21	25 086 43-S	1	Screw-Set
❶22	M-603100-S	2	Screw-HH (M6X1.0X100)
❶23	X-25-53-S	4	Washer-Plain (1/4)
❶24	24 086 18-S	4	Screw-Head, Phillips


Ref	Part No.	Qty.	Description
❶25	X-25-92-S	1	Washer-Plain
❶26	41 403 09-S	1	Rectifier-Regulator
❶27	236602-S	1	Connector (3 Contact)
❶28	47 154 01-S	1	Clip-Cable
❶29	X-25-63-S	1	Washer-Plain (1/4In)
❶30	48 154 02-S	1	Clip-Cable
❶❶	25 468 07-S	1	Washer
❶❶	24 176 98-S	1	Harness-Wiring
❶❶	25 454 03-S	2	Tie-Wire



Blower Housing and Baffle Assembly

Kohler CH740 0075


Ref	Part No.	Qty.	Description				
41	24 027 201-S	1	Housing-Blower				
42	24 100 02-S	2	Nut-Plastic				
43	25 086 43-S	1	Screw-Set				
44	24 100 01-S	3	Nut-Plastic				
45	25 755 21-S	2	Access Panel Kit				
46	25 154 02-S	4	Clip				
47	M-645016-S	10	Screw-HHFTF (M6X1.0X16)				
48	M-561016-S	1	Screw				
49	M-545016-S	2	Screw-HHFTF (M5X0.8X16)				
410	M-545020-S	4	Screw-HHFTF (M5X0.8X20)				
411	24 146 53-S	1	Plate-Backing				
412	24 063 39-S	1	Baffle-Barrel, Cylinder (No. 2 Side)				
413	24 063 70-S	1	Baffle-Valley (No. 2 Side)				
414	M-545010-S	2	Screw-HHFTF (M5X0.8X10)				
415	24 063 59-S	1	Baffle-Valley (No. 1 Side)				
416	24 063 58-S	1	Baffle-Barrel, Cylinder (No. 1 Side)				
1 4	25 154 11-S	1	Clip-Repair (Speed Nut)				
1 4	41 037 10-S	1	Nameplate-Service				



Starting System Assembly


Kohler CH740 0075

Ref	Part No.	Qty.	Description
④1	M-841080-S	1	Nut-Hex Flange (M8X1.25)
④2	25 098 09-S	1	Starter ASM
④3	M-839080-S	2	Screw-Hex Flange (M8X1.25X70)
④4	25 435 06-S	1	Solenoid Kit
④5	25 086 113-S	3	Screw-Torx Head, External
④6	25 755 33-S	1	Pinion Drive Kit
④7	25 141 05-S	1	Ring
④8	25 221 01-S	1	Brush Kit



Fuel System Assembly
Kohler CH740 0075


Ref	Part No.	Qty.	Description				
❹1	25 111 36-S	1	Line (Fuel Pump To Filter)				
❹2	25 237 14-S	6	Clamp-Hose				
❹3	24 853 93-S	1	Carburetor Kit				
❹4	24 041 17-S	1	Gasket-Carburetor				
❹5	24 041 06-S	1	Gasket-Base, Air Cleaner				
❹6	M-651030-S	2	Screw-Hex Flange (M6X1.0X30)				
❹7	24 050 10-S	1	Filter-Fuel				
❹8	25 111 34-S	1	Line-Fuel (24 Inch, Cut to needed Length)				
❹9	24 100 01-S	2	Nut-Plastic				
❹10	24 393 16-S	1	Pump-Pulse, Fuel				
❹11	24 086 12-S	2	Screw-Hex Cap (M6X1.7X18)				
❹12	24 353 02-S	1	Line-Fuel				
❹13	47 154 01-S	1	Clip-Cable				
❹14	M-650012-S	1	Screw-HF (M6X1.0X12)				
❶❹	24 755 137-S	1	High Altitude Kit (10,000 Feet)				
❶❹	24 755 138-S	1	High Altitude Kit				
❶❹	24 757 01-S	1	Solenoid Kit				
❶❹	24 757 02-S	1	Float Repair Kit				
❶❹	24 757 03-S	1	Carburetor Repair Kit				
❶❹	24 757 07-S	1	Choke Repair Kit				
❶❹	24 757 08-S	1	Repair Kit				
❶❹	24 757 09-S	1	Repair Kit				



Engine Control Assembly Kohler CH740 0075


Ref	Part No.	Qty.	Description
④1	M-547050-S	1	Nut-Hex, Lock (M5X0.8)
④2	24 089 03-S	1	Spring-Return, Choke
④3	M-545016-S	1	Screw-HHFTF (M5X0.8X16)
④4	M-645016-S	1	Screw-HHFTF (M6X1.0X16)
④5	24 126 56-S	1	Bracket-Control
④6	X-20-1-S	1	Washer-Lock (1/4)
④7	M-541050-S	1	Nut-HF (M5X0.8)
④8	24 468 01-S	1	Washer-Flat (5.5 Mm)
④9	24 090 07-S	1	Lever-Actuator, Throttle
④10	12 237 01-S	1	Clamp-Cable
④11	24 090 03-S	1	Lever-Control, Throttle
④12	M-446030-S	1	Nut-Hex (M4X0.7)
④13	M-401030-S	1	Screw (M4X0.7X30)
④14	24 079 21-S	1	Linkage-Choke
④15	24 090 05-S	1	Lever-Choke
④16	41 468 03-S	1	Washer-Spring (1/4)
④17	M-545020-S	1	Screw-HHFTF (M5X0.8X20)
④18	24 089 51-S	1	Spring-Limiter, Throttle
④19	24 089 46-S	1	Spring-Governor
④20	24 211 03-S	1	Bolt-Square Neck, Round Head
④21	24 090 33-S	1	Lever-Governor
④22	M-641060-S	1	Nut-Hex Flange (M6X1.0)
④23	25 158 11-S	1	Bushing-Throttle, Linkage
④24	24 089 01-S	1	Spring-Linkage

Ref	Part No.	Qty.	Description
④25	25 158 08-S	1	Bushing-Retaining, Linkage
④26	24 079 01-S	1	Linkage-Throttle




Air Intake / Filtration Assembly
Kohler CH740 0075

Ref	Part No.	Qty.	Description				
❶1	25 324 02-S	1	Hood-Cleaner, Air				
❷2	25 139 20-S	1	Plug-Pipe				
❸3	25 048 07-S	1	Air Cleaner ASM				
❹4	25 081 01-S	1	Housing-Air Cleaner, Heavy Duty				
❺5	25 096 06-S	1	Cover ASM				
❻6	25 154 05-S	1	Clip				
❼7	24 462 07-S	1	Valve-Ejector, Dust				
❽8	25 083 01-S	1	Element-Air, Primary				
❾9	25 083 04-S	1	Element-Air, Safety				
❿10	25 237 21-S	2	Clamp-Hose				
⓫11	24 326 71-S	1	Hose-Cleaner, Air				
⓫12	M-651025-S	1	Screw-HF (M6X1.0X25)				
⓫13	24 029 61-S	1	Adapter-Cleaner, Air				
⓫14	24 041 06-S	1	Gasket-Base, Air Cleaner				
⓫15	24 164 14-S	1	Manifold-Intake				
⓫16	25 086 84-S	1	Screw-HF (M6X1.0X55)				
⓫17	24 041 01-S	1	Gasket-Manifold, Intake				
⓫18	24 314 25-S	1	Shield-Debris				
⓫19	24 086 06-S	1	Screw-Head, Phillips (11/16X3/4)				
⓫20	25 126 02-S	1	Air Cleaner Bracket ASM				
⓫21	M-639016-S	1	Screw-HF (M6X1.0X16)				
⓫22	X-25-73-S	2	Washer-Plain				
⓫23	M-647060-S	2	Nut				
⓫24	24 126 142-S	1	Bracket-Cleaner, Air				



Exhaust Assembly Kohler CH740 0075

Ref	Part No.	Qty.	Description				
41	25 072 04-S	4	Stud (M8X1.25X33)				
42	24 041 49-S	2	Gasket-Manifold, Exhaust				
43	M-841080-S	4	Nut-Hex Flange (M8X1.25)				



Artwork is representative
Actual labels may differ depending on model and specification number

Decals

Kohler CH740 0075

Ref	Part No.	Qty.	Description				
41	25 113 39-S	1	Decal-Clear Laminate				
42	24 113 132-S	1	Decal-27Hp				
43	24 113 25-S	1	Decal-Cooler, Oil				
44	25 113 27-S	1	Decal-Cleaner, Air				
1 4	24 522 307	1	Short Block				
1 4	24 755 113-S	1	Gasket Set				

Attachments and Accessories

For 74246TE - Z557 Z Master, With 152cm TURBO FORCE Side Discharge Mower

Product Name	Model/Part
1.25 Inch Spark Arrester Kit	105-1672
Blade-Mid Flow, 20.5 Inch	105-7715-03
Blade-Lo Flow, 20.5 Inch	105-7716-03
Blade-Hi Flow, 20.5 Inch	105-7718-03
Blade-Recycler, 20.5 Inch	105-7777-03
60 Inch Recycler Kit	107-1611
Striping Kit	107-1630
Turbo Baffle Kit	107-1634
Deluxe Suspension Seat	107-1891
Suspension Kit for Standard Seat	107-1892
6 Pack Blade, 20.5 Inch Hi-Flow	108-1114
6 Pack Blade, 20.5 Inch Mid-Flow	108-1123
6 Pack-Blade, 20.5 Inch Lo Flow	108-1128
6 Pack-Blade, 20.5 Inch Recycler	110-0405
DFS Vac Collection System	78506
Filter Minder Gauge	99-4664
Hitch Kit	99-8925

