

PARTS CATALOG

This exploded view diagram illustrates the assembly of a bicycle seat. The components are numbered as follows:

- 1**: The bicycle seat cushion.
- 2**: The seat post clamp.
- 3**: The seat post clamp bolt.
- 4**: The seat post clamp plate.
- 5**: The seat post clamp plate.
- 6**: The seat post clamp plate.
- 7**: The seat post clamp plate.
- 8**: The seat post clamp plate.
- 9**: The seat post clamp plate.
- 10**: The seat post clamp plate.
- 11**: The seat post clamp plate.
- 12**: The seat post clamp plate.
- 13**: The seat post clamp plate.
- 14**: The seat post clamp plate.
- 15**: The seat post clamp plate.
- 16**: The seat post clamp plate.
- 17**: The seat post clamp plate.
- 18**: The seat post clamp plate.
- 19**: The seat post clamp plate.
- 20**: The seat post clamp plate.

SULKY KIT MODEL NO. 30122

Ref. No.	Part No.	Description	No. Used
11	3272-12	Pin - Cotter	2
12	55-3740	Bearing - Wheel	4
13	55-3730	Valve Stem/Cap	2
14	55-3750	Wheel	2
15	55-9900	Decal - Sulky	1
16	55-9840	Bracket - Footrest	1
17	3296-29	Nut - Lock	6
18	68-4190	Bracket - Hitch	1
19	60-9350	Bolt-U	2
20	3290-456	Washer - Bellville	4