


PART NO. 77-4350

PARTS
CATALOG

450D CRUISE CONTROL KIT

(FOR MODEL NO. 03700-60001 TO 99999)




T-1155-90

TRACTION PEDAL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	76-3280	Pedal - Traction	1
2	49-6470	Pad - Forward	1
3	49-6430	Pad - Reverse	1
4	3211-6	Screw - Cap, Hex. Hd.	1
5	3256-3	Washer - Flat	2
6	76-3370	Bushing	1
7	3296-25	Nut - Lock	1
8	76-3350	Spacer	1
9	76-3340	Link	1
10	76-3330	Spacer	1
11	76-3430	Rod	1
12	3296-6	Nut - Lock	1
13	60-2110	Pin - Roll	4
14	3290-483	Washer - Flat	2
15	325-9	Screw - Cap, Hex. Hd.	1

Ref. No.	Part No.	Description	No. Used
16	47-7030	Bushing - Rubber	1
17	3217-9	Nut - Hex	1
18	60-0760	Clevis	1
19	58-4310	Ring	2
20	58-5100	Washer	2
21	60-5700	Spring	2
22	58-9010	Block	1
23	325-8	Screw - Cap, Hex. Hd.	1
24	3256-26	Washer - Flat	1
25	3219-5	Nut - Hex.	1
26	2411-44	End - Rod, Ball Joint	1
27	76-3310	Boot - Switch	1
28	76-3480	Switch	1
29	60-6740	Washer	1
30	48-6790	Bushing - Flange	2




T-1156-90

ELECTRICAL COMPONENTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3217-5	Nut - Hex	3
2	3255-7	Washer - Lock, Int. Tooth	1
3	76-3320	Bracket	1
4	3256-26	Washer - Flat	1
5	3253-7	Washer - Lock	1
6	325-4	Screw - Cap, Hex. Hd.	1
7	3253-3	Washer - Lock	2
8	2412-74	Clamp - R	1
9	37-2690	Capacitor	1
10	321-6	Screw - Cap, Hex. Hd.	1
11	63-7590	Relay	2
12	3256-58	Washer - Flat	1

Ref. No.	Part No.	Description	No. Used
13	3256-1	Washer - Flat	2
14	321-4	Screw - Cap, Hex. Hd.	1
*	76-3400	Switch (Instrument panel)	1
*	77-4380	Wire - Jumper (Between switch)	1
*	77-4390	Wire - Switch (To power)	1
*	77-4400	Wire - Ground (Indicator light)	1
*	44-2210	Light - Indicator (Instrument panel)	1
*	77-4370	Wiring Harness (Main)	1

*Not Illustrated



T-1157-90

MAGNET HARDWARE INSTALLATION

Ref. No.	Part No.	Description	No. Used
1	48-7640	Screw - Cap, Hex. Hd.	2
2	3253-3	Washer - Lock	2
3	3256-16	Washer - Flat	2
4	76-3380	Collar	1
5	76-3270	Arm Assembly	1
6	3213-1	Screw - Cap, Hex. Hd.	2
7	3253-7	Washer - Lock	2
8	76-3360	Bracket	1
9	76-3490	Plate	1

Ref. No.	Part No.	Description	No. Used
10	48-8030	Washer - Flat	1
11	3290-482	Washer - Belleville	2
12	57-6370	Screw - Cap, Hex. Hd.	1
13	76-3390	Pivot	2
14	76-3420	Spring - Compression	2
15	76-3410	Magnet	2
16	48-7730	Screw - Cap, Hex. Hd.	1
17	3253-4	Washer - Lock	1

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any

reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO Importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.