



Commercial Side-Discharge Lawnmower

Model No. 22242 - 250000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Housing Assembly	 3	Air Cleaner Assembly Briggs and Stratton	
Handle Assembly	 4	12W802-1701-B1	 10
Engine, Blade and Fuel Tank Assembly	 5	Governor Assembly Briggs and Stratton	
Cylinder Assembly Briggs and Stratton		12W802-1701-B1	 11
12W802-1701-B1	 6	Muffler and Fuel Tank Assembly Briggs and	
Crankshaft Assembly Briggs and Stratton		Stratton 12W802-1701-B1	 12
12W802-1701-B1	 7	Blower Housing Assembly Briggs and Stratton	
Crankcase Assembly Briggs and Stratton		12W802-1701-B1	 13
12W802-1701-B1	 8	Starter Assembly Briggs and Stratton 12W802-	
Carburetor Assembly Briggs and Stratton		1701-B1	 14
12W802-1701-B1	 9	358 Engine Gasket Set Assembly Briggs and	
		Stratton 12W802-1701-B1	 15
		121 Carburetor Overhaul Kit and 977	
		Carburetor Gasket Set Briggs and Stratton	 16
		12W802-1701-B1	

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread
GA. gauge	forming
HD. heavy-duty	PRH. phillips round head
HF. hex flange	PTH. phillips truss head
HH. hex head	PTO. power-take-off
HHF. hex head flange	RH. right hand
HHFTF. hex head flange thread forming	ROPS. roll-over protection system
HJ. hex jam	SFH. slotted fillister head
HLH. hex lag head	SHH. slotted hex head
HOC. height-of-cut	SHWH. slotted hex washer head
HSBH. hex socket button head	SPH. slotted pan head
HSFH. hex socket flat head	SQH. square head
HSH. hex socket head	SRH. slotted round head
HWH. hex washer head	STD. standard
HWHTF. hex washer head thread	TAP. self tapping
forming	TTH. torx truss head

Footnotes

- | | | | |
|---|--|---|---|
| ❶ | Not serviced separately | ❷ | Obtain from your local Briggs & Stratton dealer |
| ❸ | Included in Carburetor Overhaul Kit (Ref. No. 121) | ❹ | Included in Engine Gasket Set (Ref. No. 358) |
| ❺ | Included in Carburetor Gasket Set (Ref. No. 977) | | |




Ref	Part No.	Qty.	Description				
1	603567	4	Bolt				
2	683464	2	Wheel/Tire ASM				
3	610646	4	Bolt				
4	153444	4	Spring Arm ASM				
5	608834	4	Washer				
7	93-7368	1	Shield-Trailing				
8	321-3	2	Screw-HH				
9	93-7693	2	Clamp-Shield				
10	98-8332	1	Knob				
11	95-7052	1	Plate-Opening, Chute				
12	43-8480	1	Decal-Danger				
13	614677	2	Screw-Sems				
14	94-1610	3	Nut-Clip				
15	108-9332	1	Housing ASM				
16	3296-56	2	Nut-Lock, NI				
17	93-7250	1	Decal-Warning				
18	608175	1	Bar-Toe				
19	46-6811	2	Screw-HWH				
20	3296-39	4	Nut-Lock, NI				
21	608833-03	4	Bracket-Height, Wheel				
22	684159	2	Wheel And Tire ASM				
23	108-9368-02	1	Spacer-Engine				
24	92-1648	3	Screw-Mount, Engine				




Handle Assembly

Ref	Part No.	Qty.	Description				
1	3230-29	2	Screw-CARR				
2	92-2920-05	1	Handle-Section, Lower				
3	614249	2	Strap-Tie				
4	322-9	2	Screw-HH				
5	3296-29	4	Nut-Lock, NI				
6	609739	2	Washer-Curved				
7	100-2897-05	1	Handle-Upper				
8	100-1174	1	Bail Control Lever ASM				
9	107-0757	1	Stop-Pivot				
10	106-8330	1	Guide-Rope				
11	100-5989	1	Brake Cable ASM				
12	3296-73	1	Nut-Lock, NI				
13	684057-03	1	RH Bracket And Pin ASM				
14	3296-29	4	Nut-Lock, NI				
15	3256-23	2	Washer-Flat				
16	607188	4	Screw				
17	684058-03	1	LH Bracket And Pin ASM				



Engine, Blade and Fuel Tank Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	92-8626	1	Spacer-Blade				
3	100-2899	1	Plate And Collar ASM				
5	92-1648	3	Screw-Mount, Engine				
10	98-4497	1	Tank-Fuel				
11	609830	2	Spring				
12	92-1701	1	Stop-Rope				
13	108-9334	1	Decal-Recoil				
1 2 15		1	Engine-Briggs And Stratton, 12W802-1701-B1				
16	108-9381	1	Gas Cap ASM				
19	108-7470	1	Guard-Muffler				
20	612543	1	Blade				
22	98-4458-03	1	Tank Bracket ASM				
23	3296-29	5	Nut-Lock, NI				
24	104-7577-03	1	Shield-Muffler				
25	32144-1	3	Screw-Taptite				
26	3296-39	2	Nut-Lock, NI				
27	108-9392	1	Line-Fuel				




Cylinder Assembly

Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description
1	697324	1	Cylinder ASM
2	399269	1	Bushing/Seal Kit
3	299819	1	Seal-Oil
4	691160	1	Head-Cylinder
5	692249	1	Gasket-Head, Cylinder
6	695250	1	Breather ASM
7	696125	1	Gasket-Breather
8	691125	1	Screw
9	691781	1	Tube-Breather
10	690912	1	Screw
11	497465	1	Manifold-Intake
12	272199	1	Gasket-Intake
13	691650	1	Screw
14	690450	1	Shield-Cylinder
15	690345	1	Screw
16	697451	1	Plug-Spark
17	89838	1	Wrench-Plug, Spark
18	690272	1	Washer
19	697734	1	Cover-Passage, Breather
20	691879	1	Gasket-Passage, Breather
21	690340	1	Retainer-Shaft, Governor
22	698801	1	Crank-Governor
23	66538	1	Boot-Plug, Spark
24	690345	1	Screw


Ref	Part No.	Qty.	Description
25	690959	1	Pin-Locating
26	691155	1	Seat-Valve (Intake)
27	690380	1	Seat-Valve (Exhaust)
28	262001	1	Bushing-Guide (Exhaust)
29	63709	1	Bushing-Guide (Intake)
30	494256	1	Label Kit
31	275177	1	Manual-Owner's



Crankshaft Assembly

Briggs and Stratton 12W802-1701-B1


Ref	Part No.	Qty.	Description				
216	694079	1	Crankshaft				
224	222698	1	Key				
225	791096	1	Piston ASM				
225	691325	1	Spline-Starter				
226	791098	1	Ring Set				
226	691324	1	Cover-Cleaner, Air				
227	691866	1	Lock-Pin, Piston				
228	499423	1	Pin-Piston (Standard)				
228	298908	1	Pin-Piston (.005 Undersize)				
229	499424	1	Rod-Connecting (Standard)				
232	691664	1	Screw				
232A	695759	1	Screw				
233	262651	1	Valve-Exhaust				
234	262652	1	Valve-Intake				
235	691270	1	Spring-Valve				
236	691270	1	Spring-Valve				
240	692194	1	Retainer-Valve				
245	690548	1	Tappet-Valve				
2741	790345	1	Gear-Timing				
2868	697338	1	Seal-Valve				



Crankcase Assembly


Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
24	493279	1	Sump-Engine				
2412	692232	1	Gasket-Crankcase (.015 Thick, Standard)				
215	691680	1	Plug-Drain, Oil				
2420	399781	1	Seal-Oil				
222	691092	1	Screw (Engine Sump)				
243	691997	1	Slinger-Governor/Oil				
246	691449	1	Camshaft				
248	694810	1	Short Block				
2287	690940	1	Screw				
2523	499621	1	Dipstick				
24524	692296	1	Seal-O Ring				
2525	495265	1	Tube-Dipstick				
24842	691031	1	Seal-O Ring				
2847	692047	1	Dipstick/Tube ASM				



Carburetor Assembly
Briggs and Stratton 12W802-1701-B1


Ref	Part No.	Qty.	Description				
295	691636	1	Screw				
297	493267	1	Shaft And Lever				
2104	691242	1	Pin-Hinge, Float				
2117	497466	1	Main Jet (High Altitude)				
2125	498254	1	Carburetor				
2127	694468	1	Plug-Welch				
2130	691203	1	Valve-Throttle				
2133	398187	1	Float-Carburetor				
2134	398188	1	Needle/Seat Kit				
2137	693981	1	Gasket-Bowl, Float				
5							
2163	272653	1	Gasket-Air Cleaner				
5							
2276	271716	1	Washer-Sealing				
5							
2365	692524	1	Screw				
2617	270344	1	Seal-O Ring				
5							
2633	691321	1	Seal-Shaft, Choke/Throttle				
5							
2975	493640	1	Bowl-Float				



Governor Assembly


Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
2188	690877	1	Screw (Control Bracket)				
2202	691829	1	Link-Governor, Mechanical				
2209	691292	1	Spring-Governor				
2222	698163	1	Bracket-Control				
2227	690783	1	Lever-Control, Governor				
2333	802574	1	Armature-Magneto				
2334	691061	1	Screw				
2356	692390	1	Wire-Stop				
2505	691251	1	Nut				
2562	691119	1	Screw				
2621	692310	1	Switch-Stop				
2668	493823	1	Spacer				
2745	691648	1	Screw (Brake)				
2851	493880	1	Terminal-Spark Plug				
2922	691831	1	Spring-Brake				
2923	691994	1	Brake ASM				
2925	690595	1	Cover-Linkage				




Muffler and Fuel Tank Assembly Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
281	691740	1	Lock-Screw, Muffler				
2187	691050	1	Line-Fuel (Cut To Required Length)				
2240	298090	1	Filter				
2300	692038	1	Muffler				
2601	95162	1	Clamp-Hose				
2613	691340	1	Screw				




Blower Housing Assembly
Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
23	692315	1	Flywheel				
37	694086	1	Guard-Flywheel				
73	691222	1	Screen-Rotating				
78	691108	1	Screw (Flywheel Guard)				
304	493293	1	Housing-Blower				
305	691108	1	Screw				
324	695161	1	Cup/Screen ASM				
332	690662	1	Nut				
363	19069	1	Puller-Flywheel				
1036	790412	1	Label-Emission				





Starter Assembly
Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
●55	691421	1	Housing-Starter, Rewind				
●58	697316	1	Rope-Starter (Cut To Required Length)				
●60	281434	1	Grip-Rope, Starter				
●65	690837	1	Screw				
●456	692299	1	Plate-Friction, Pawl				
●459	281505	1	Ratchet-Pawl				
●592	690800	1	Nut				
●597	691696	1	Screw				
●608	497680	1	Starter-Rewind				
●689	691855	1	Spring-Friction				
●930	791454	1	Guard-Rewind				
●1210	498144	1	Pulley/Spring ASM (Pulley)				
●1211	498144	1	Pulley/Spring ASM (Spring)				



358 Engine Gasket Set Assembly
Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
23	299819	1	Seal-Oil (Magneto Side)				
27	692249	1	Gasket-Head, Cylinder				
212	692232	1	Gasket-Crankcase (.015 Thick, STD)				
220	399781	1	Seal-Oil (PTO Side)				
251	272199	1	Gasket-Intake				
2163	272653	1	Gasket-Air Cleaner				
5							
2358	497316	1	Engine Gasket Set				
2524	692296	1	Seal-O Ring (Dipstick Tube)				
2585	691879	1	Gasket-Passage, Breather				
2617	270344	1	Seal-O Ring (Intake Manifold)				
5							
2668	493823	1	Spacer				
2842	691031	1	Seal-O Ring (Dipstick)				



121 Carburetor Overhaul Kit and 977 Carburetor Gasket Set
Briggs and Stratton 12W802-1701-B1

Ref	Part No.	Qty.	Description				
2104	691242	1	Pin-Hinge, Float				
2121	498260	1	Carburetor Overhaul Kit				
2127	694468	1	Plug-Welch				
2134	398188	1	Needle/Seat Kit				
2137	693981	1	Gasket-Bowl, Float				
2163	272653	1	Gasket-Air Cleaner				
2276	271716	1	Washer-Sealing				
21617	270344	1	Seal-O Ring (Intake Manifold)				
2633	691321	1	Seal-Shaft, Choke/Throttle				
2977	498261	1	Carburetor Gasket Set				

NOTES

NOTES

NOTES

