


TORO®

MODEL NO. 51637-0000001 & UP


**PARTS
CATALOG****TC 2010 GAS TRIMMER**

C-0255-90

TRIMMER HEAD ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	43-4990	Spool & Line Assembly	1	14	3290-321	Screw - Hex. Washer Hd.	2
2	33-8940	Saddle - Spool Cap	1	15	3296-42	Nut - Lock	1
3	42-6050	Driver	1	16	3290-360	Screw - Hex. Washer Hd.	4
4	33-6230	Core - Spool	1	17	42-6030	Washer	1
5	3256-42	Washer	1	18	49-2410	Bearing - Ball	2
6	29-7130	Spring - Compression	1	19	32151-65	Ring - Rretaining	2
7	42-5950	Drum & Eyelet Assembly	1	20	42-5770	Spring - Grip	1
8	321-9	Screw - Hex. Hd. Cap	1	21	32121-95	Pin - Coil	1
9	42-5931	Housing - Bearing (Incl. Ref. #10,17-21)	1	*	43-5000	Line - Cutting .08 Dia. 38' (Optional)	1
10		Shaft - Power	1	*	46-2710	Line - Cutting .08 Dia. 400' (1Lb. Optional)	1
11	3296-2	Nut - Lock	6	*	42-5901	Head Assembly (Incl. Ref. #1-7)	1
12	52-5730	Shield	1				
13	42-5920	Bracket & Knife Blade	1				

*Not Illustrated




C-0591-90

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	46-9810	Shaft - Flex Drive	1
2	57-5460	Liner - Flex Shaft	1
3	76-4480	Decal - Toro	1
4	42-5890	Knob - Loop Handle	1
5	42-5551	Handle	1
6	3296-12	Nut - Lock	2
7	57-5480	Housing - R.H.	1
8	53-7360	Tube - Curved	1
9	218-557	Cap - Switch	1
10	42-6000	Switch	1
11	53-7110	Grip	1
12	54-7630	Bushing - Pilot	1
13	57-5470	Spacer	1
19	76-4370	Cable -Throttle	1
20	55-8411	Cover - Cable	1

Ref. No.	Part No.	Description	No. Used
21	2412-48	Clip	2
22	53-7280	Trough	1
23	32105-12	Screw - Hex. Washer Hd.	1
24	57-5420	Screw - Shoulder	1
25	57-5490	Housing - L. H.	1
26	53-7273	Lever - Throttle	1
27	53-7370	Wire Assembly	2
28	46-9480	Decal - Warning	1
29	3-7253	Bolt - Carriage	1
30	44-6640	Insert - Pole End	1
31	46-9890	Retainer - Tube	2
*	76-4350	Engine - 21cc.	1
*	57-5510	Casing Assembly (Incl. Ref.#2 & 13)	1

*Not Illustrated




C-0582-90

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	56-8770	Nut - Lock	1
2	54-4790	Bolt/Washer	3
3	54-4470	Ring - Retaining	1
4	77-2170	Spacer	1
5	77-2160	Housing - Clutch	1
6	3247-10	Screw - Set	1
7	77-2150	Screw/Washer	1
9	60-7640	Clutch - Drum	1
10	54-5290	Bolt Clutch	2
11	54-6230	Spring	1
12	54-6220	Flyweight	2
*	77-1830	Clutch (Incl. Ref. #11 & 12)	1
13	77-1840	Washer	2
14	60-7780	Fan	1
15	54-6890	Screw	1
16	77-1190	Guard - Spark Plug	1
17	77-1200	Cover - Top	1
18	77-1860	Screw/Washer	3
19	77-1790	Nut - Flanged	2
20	77-1780	Muffler	1

Ref. No.	Part No.	Description	No. Used
21	77-1770	Gasket - Muffler	1
22	77-1210	Stud	2
23	77-1850	Starter - Recoil	1
24	77-2080	Fuel Tank Assembly	1
25	77-1460	Gasket - Insulator	1
26	60-7930	Screw/Washer	2
27	77-1450	Insulator	1
28	77-1430	Gasket - Carburetor	1
29	77-1420	Carburetor Assembly	1
30	77-1760	Case - Air Cleaner	1
31	77-1750	Bracket	1
32	54-4870	Screw/Washer	2
33	60-7680	Screw/Washer	1
34	77-1710	Cover - Air Cleaner	1
35	77-1720	Nut	1
36	77-1730	Element - Air Cleaner	1
37	54-4670	Nut - Conical	1
38	77-9930	Decal - Fuel	1
39	65-2690	Decal - Hot	1

*Not Illustrated






C-0583-90

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	77-1160	Case - Drive	1
2	54-4380	Seal - Oil	2
3	77-1170	Gasket - Baffle	1
4	54-4330	Screw - Pan Hd.	3
5	60-7590	Pin - Dowel	2
6	77-1340	Boot - plug	1
7	77-1350	Plug - Spark	1
8	77-1220	Cylinder	1
9	60-7720	Bolt - Cylinder	2
10	60-7730	Gasket - Cylinder	1
11	54-5920	Clip - Piston Pin	2
12	60-7760	Pin - Piston	1
13	60-7740	Ring - Top	2
14	77-1280	Piston (Incl. Ref.#11 & 12)	1

Ref. No.	Part No.	Description	No. Used
15	54-5930	Bearing - Needle	1
16	60-7600	Case - Starter	1
17	77-1360	Flywheel (Incl. Ref.#19 & 20)	1
18	54-4670	Nut - Conical	1
19	77-1370	Spring - Return	1
20	77-1380	Ratchet	2
21	77-1400	Coil - Ignition	1
22	77-2180	Tube	1
23	77-2190	Lead - wire	1
24	54-4790	Bolt/Washer	2
25	60-7840	Grommet	1
26	54-4360	Bearing - Main	2
27	77-1330	Crank Shaft Assembly	1

*Not Illustrated






C-0585-90

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	77-1690	Screw	4
2	77-1680	Cover - Primer	1
3	77-1670	Pump Assembly - Primer	1
4	77-1660	Body - Primer	1
5	77-1650	Diaphragm	1
6	77-1640	Gasket - Diaphragm	1
7	77-1630	Body - Pump	1
8	77-1620	Screen	2
9	77-1610	Gasket - Pump	1
10	77-1600	Plate	1
11	77-1590	Diaphragm	1
12	77-1580	Gasket - Diaphragm	1
13	77-1570	Jet - Main #43	1
14	77-1550	Gasket - Rubber	1
15	77-1560	O-Ring, Main Jet	1
16		Body - Carburetor- (Ref.)	1
17	77-1530	Plug	1
18	77-1490	Bracket	1
19	77-1480	Nut - Lock	1

Ref. No.	Part No.	Description	No. Used
20	77-1470	Screw - Adjustment	1
21	77-1500	Screw	1
22	77-1510	Holder - Wire	1
23	77-1540	Valve - Throttle	1
24	77-1520	Clip	1
*	77-1420	Carburetor (Incl. Ref. #1 - 24)	1
*	77-2110	Kit - Carburetor	1
25	60-8220	Screw	1
26	65-4470	Washer	1
27	60-8230	Reel	1
28	54-5420	Spring	1
29	54-5440	Knob - Starter	1
30	54-6370	Rope - Starter	1
31	77-1930	Guide	1
32	77-1940	Case - Starter	1
33	76-0790	Decal - Toro	1
*	77-1850	Starter Assembly - Recoil (Incl. Ref. #25-32)	1

*Not Illustrated




C-0585-90

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
34	77-1990	Cap - Fuel	1
35	77-2000	Valve - Breather	1
36	77-2010	Gasket	1
37	77-2020	Cap - Valve	1
*	77-1980	Cap Assembly (Incl. Ref. #34-37)	1
38	60-8280	Pad	4
39	77-1900	Tank Assembly - Fuel (Incl. Ref. #34-47)	1

Ref. No.	Part No.	Description	No. Used
40	77-2070	Weight - Filter	1
41	77-2060	Seal - Dust	1
42	77-2050	Filter - Seal	1
43	77-2040	Washer - Seal	1
44	77-1970	Collar	1
45	77-2030	Grommet - Fuel Tank	1
46	54-6390	Hose - Fuel	1
47	77-1960	Tube - Fuel Return	1
*	77-2100	Filter Assembly - Fuel	1

*Not Illustrated




C-0268-90

SHOULDER HARNESS (Optional)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	46-2951	Nut	1	5	46-2691	Clamp	1
2		Ring	1	*		Clamp & Ring Kit (Incl. Ref.#1,2 & 4,5)	1
3		Standard Harness	1				
4		Screw	1				

*Not Illustrated




C-0269-90

DELUXE SHOULDER / BELT HARNESS (Optional)

Ref. No.	Part No.	Description	No. Used
1	46-2961	Deluxe Harness	1
2		Ring	1
3		Screw	1
4		Clamp	1

Ref. No.	Part No.	Description	No. Used
5	46-2691	Nut	1
*		Clamp & Ring Kit (Incl. Ref. #2-5)	1

*Not Illustrated



C-0270-90

FLEX BLADE KIT NO. 44-9870 (Optional)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	44-2410 ✓	Adapter - Blade	1	4	44-2420 ✓	Nut - Adapter	1
2	46-2790	Blade - Flex	1	*	46-2951 ✓	Shoulder Harness	1
3	51-1340 ✓	Washer	1	*	46-2691 ✓	Clamp & Ring Kit	1
					41-4440	Blade adapter	1
					46-2691	Clamp & Ring Kit (1)	1
					44-4430	Blade/washer	1

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Lawnmower has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the rear of the housing. In any correspondence concerning the lawnmower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the lawnmower.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any

reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

MAINTENANCE RECORD

[illegible]

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.