



Z500 Z Master[®]

With 52in TURBO FORCE[®] Side Discharge Mower

Model No. 74261 - 270000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front Frame Assembly	 3	Muffler and Guard Assembly	 24
Castor and Wheel Assembly	 4	Fuel Tank Assembly	 25
Castor Wheel Assembly No. 110-5746	 5	Electrical Assembly	 26
Main Frame Assembly	 6	Crankshaft Assembly Kohler CH750-0010	 27
Brake and Wheel Hub Assembly	 7	Crankcase Assembly Kohler CH750-0010	 28
Steering Control Assembly	 8	Oil Pan and Lubrication Assembly Kohler CH750-0010	 29
LH Motion Control Assembly No. 109-3906	 9	Head, Valve and Breather Assembly Kohler CH750-0010	 30
RH Motion Control Assembly No. 109-3707	 10	Ignition and Electrical Assembly Kohler CH750-0010	 31
Hydraulic System Assembly	 11	Blower Housing and Baffle Assembly Kohler CH750-0010	 32
Seat and Roll-Over Protection System Assembly	 13	Starting System Assembly Kohler CH750-0010	 33
Seat Assembly No. 110-0446	 14	Fuel System Assembly Kohler CH750-0010	 34
Roll-Over Protection System Assembly No. 108-1097	 15	Engine Control Assembly Kohler CH750-0010	 35
Deck Connection Assembly	 16	Air Intake and Filtration Assembly Kohler CH750-0010	 36
Deck Assembly	 17	Exhaust Assembly Kohler CH750-0010	 38
Spindle Assembly No. 108-7713	 18	Decal Assembly Kohler CH750-0010	 39
Deck Decal Assembly No. 107-1623	 19	Attachments and Accessories List	 40
Rubber Deflector Assembly No. 108-2792	 20		
Lever Assembly No. 107-1664	 21		
Drive Idler Assembly	 22		
Engine and Clutch Assembly	 23		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain from your local Kohler dealer



Front Frame Assembly


Ref	Part No.	Qty.	Description
1	106-8978	1	Frame ASM
1:2	107-1857	1	Decal-Brake, Parking
1:3	1-811010	2	Plug
1:4	302-19	5	Fitting-Grease
1:5	103-1918	1	Bushing
3	106-9981	1	Front Floorpan ASM
3:2	106-7451	1	Decal
3:3	107-2112	1	Decal-Warning
4	103-1918	1	Bushing
5	103-2083-03	1	Lift Lever ASM
6	1-633295	1	Grip-Lever, Lift
7	103-2064-03	1	Arm-Lift, Deck
8	1-633325	1	Spring-Compression
9	3256-24	1	Washer-Flat
10	3296-39	9	Nut-Lock, NI
11	32151-103	5	Ring-Snap
12	1-633068	2	Arm-Lift, Deck
14	323-29	2	Screw-HH
15	110-0833	1	Outer Deck Lift Plate ASM
15:2	107-1860	1	Decal-Height, Deck
16	110-0834	1	Inner Deck Lift Plate ASM
16:2	107-1861	1	Decal-Height, Deck
17	1-633082	1	Bushing-Lever, Lift
18	1-633080	1	Bushing-Lever, Lift

Ref	Part No.	Qty.	Description
19	323-13	1	Screw-HH
20	106-9951	1	Hitch Pin ASM
22	323-9	2	Screw-HH
23	98-5975	12	Washer-Belleville
24	3290-357	15	Nut-HHF, Whiz
25	323-6	1	Screw-HH
26	323-7	12	Screw-HH
27	3256-29	4	Washer-Flat
35		2	Front Frame Spring ASM
35:1	1-633096	1	Rod-Lift, Deck
35:2	1-633441	2	Swivel-Deck Mount, Rear
35:3	3217-11	4	Nut-Hex
35:4	3218-6	2	Nut-Jam
35:5	3256-7	2	Washer-Flat
35:6	1-633064	1	Spring-Support, Deck
38	3274-94	4	Screw-HSBH
40	108-7786-01	1	RH Front Deck Lift ASM
41	106-8984-01	1	LH Deck Lift ASM
42	1-523157	2	Washer-Spacer, 14 GA
43	32151-29	2	Ring-Retaining
44	3274-18	2	Screw-HSH
45	3218-2	2	Nut-Jam
46	1-513658	2	Bumper




Castor and Wheel Assembly

Ref	Part No.	Qty.	Description				
1	103-4882	2	Cap-Grease				
2	3296-51	2	Nut-Lock, NI				
3	1-633508	6	Washer-Bellville				
4	254-94	4	Bearing-Cone, Tapered				
5	254-72	4	Bearing-Cup, Tapered				
7	1-543511	2	Seal-Grease				
8	1-642111-01	2	Caster				
11	110-5746	2	Castor Wheel ASM				



Castor Wheel Assembly No. 110-5746


Ref	Part No.	Qty.	Description				
1	1-633580	2	Seal-Bearing				
2	1-633581	2	Spacer-Bearing				
3	1-633585	2	Bearing-Cone, Taper				
4	1-633959	1	Spacer-Caster, Front				
5		1	Wheel And Tire ASM (Semi-Pneumatic)				
5:3	1-633584	1	Bearing-Cup				
6	325-24	1	Screw-HH				
7	3296-45	1	Nut-Lock, NI				



Main Frame Assembly

Ref	Part No.	Qty.	Description
1	1-633964-03	1	Stop-Brake, Park
4	322-43	6	Screw-HH
5	323-6	2	Screw-HH
11	112-9000	1	Main Frame ASM (W/Decals)
11:1	107-8076	1	Decal-Console, Top
12	1-653010	2	Wheel And Tire ASM
12:1	1-653160	1	Tire
12:2	1-653158	1	Wheel
12:3	232-27	1	Stem-Valve
13	107-1858	1	Floorpan
13:2	98-4387	1	Decal-Protection, Ear
13:3	107-1864	1	Decal-Location, Manual
15	242-50	8	Nut-Lug
21	3296-39	2	Nut-Lock, NI
24	1-513762	1	Clip-Loom
25	1-303335	1	Tie-Plastic
27	321-4	3	Screw-HH
28	32128-33	1	Nut-HF
44	3256-70	6	Washer-Flat
47	106-7498	1	Pocket
48	106-7488-03	1	Hinge-Floorpan, LH
49	106-7489-03	1	Hinge-Floorpan, RH
50	323-20	2	Screw-HH
51	3296-59	2	Nut-Lock, NI


Ref	Part No.	Qty.	Description
52	3296-42	4	Nut-Lock, NI
53	3256-63	2	Washer-Flat
54	3258-166	2	Screw-PRH
55	106-9989	1	Decal-Warning
56	106-7492	1	Decal-Danger
57	107-1865	2	R-Clamp
58	104-7050	1	Housing-Manual
59	104-7048	1	Cap-Housing



Brake and Wheel Hub Assembly

Ref	Part No.	Qty.	Description
1	1-513140	2	Bearing-Control
2	1-633454	2	Spring-Brake
3	103-4332	1	Brake Rod And Yoke ASM
3:1	1-633131	2	Yoke-Linkage, Brake
3:2	1-633477	1	Rod-Brake
3:3	3219-3	2	Nut-Hex
4	1-634500	1	Brake Lever ASM
4:2	1-633268	1	Grip-Lever, Brake
5	1-632217-03	1	Shaft-Brake
6	103-0352-03	2	Bracket-Brake
7	1-523157	2	Washer-Spacer, 14 GA
9	103-0355	2	Band-Brake
10	1-633380	4	Spacer-Wheel, Short
11	1-633382	4	Spacer-Wheel, Long
12	1-633102	2	Bearing-Flange, Side
13	103-4333	2	Brake Rod And Yoke ASM
13:1	1-633131	1	Yoke-Linkage, Brake
13:2	1-633477	1	Rod-Brake
13:3	3219-3	1	Nut-Hex
14	1-633144	2	Pin-Trunion
15	103-0590	2	Hub And Wheel ASM
15:1	103-0589	1	Wheel Hub ASM
15:2	1-633926	4	Stud-Wheel
18	323-4	4	Screw-HH


Ref	Part No.	Qty.	Description
19	103-2399	3	Pin-Spring, Clevis
20	325-17	8	Screw-HH
21	1481	2	Fitting-Grease
22	103-0131	8	Nut-Square
23	3219-3	4	Nut-Hex
24	3290-357	4	Nut-HHF, Whiz
25	3253-7	8	Washer-Lock
26	3256-4	4	Washer-Flat
27	3272-10	2	Pin-Cotter
28	1-806800	2	Pin-Cotter
29	322-9	6	Screw-HH
30	103-0384	6	Spacer
31	103-0374	2	Retainer-Band, Brake
32	1-808285	1	Pin-Clevis



Steering Control Assembly


Ref	Part No.	Qty.	Description
2	98-5975	4	Washer-Belleville
3	109-2339	2	Damper-Control, Motion
8	1-403180	4	Screw-HH
9	103-4331	1	Tracking Rod ASM
9:1	1-543017	1	Balljoint-RH
9:2	3219-2	3	Nut-Hex
9:4	1-804524	1	Nut
9:5	1-633152	1	Balljoint-Thread, LH
10	103-4330	1	Tracking Rod ASM
10:1	1-543017	1	Balljoint-RH
10:2	3219-2	1	Nut-Hex
10:3	103-3060	1	Knob-Tracking
10:4	1-804524	2	Nut
10:5	1-323245	2	Spring-Compression
10:6	1-633152	1	Balljoint-Thread, LH
11	108-7238	1	LH Lever ASM
11:1	106-9987	1	Grip-Control, Motion
12	1-632208	2	Arm-Control, Pump
16	1-633102	4	Bearing-Flange, Side
20	322-6	4	Screw-HH
21	323-4	8	Screw-HH
22	323-6	4	Screw-HH
24	1-803022	2	Screw-Set
30	3256-3	4	Washer-Flat

Ref	Part No.	Qty.	Description
34	32128-20	6	Nut-HF
35	3290-357	8	Nut-HHF, Whiz
37	108-7237	1	RH Lever ASM
37:1	106-9987	1	Grip-Control, Motion
38	3296-29	8	Nut-Lock, NI
39	3217-6	4	Nut-Hex
40	109-3906	1	LH Motion Control ASM
41	109-3907	1	RH Motion Control ASM




LH Motion Control Assembly No. 109-3906

Ref	Part No.	Qty.	Description				
1	1-808280	1	Pin-Clevis				
2	103-0407	1	Arm-Shaft, Control				
3	109-3902	1	Wld,Motion Control LH				
4	109-3903	1	Neutral Return ASM				
4:1	1-303105	1	Yoke-Adjustable				
4:2	1-603737	1	Bolt-Return, Neutral				
4:3	1-603807	1	Spring-Return, Neutral				
4:4	109-3769	1	Bushing, Nylon Flanged				
4:5	3219-2	3	Nut-Hex				
4:6	3230-23	1	Screw-CARR				
4:7	3256-2	1	Washer-Flat				
4:8	109-3908	1	Tab,Adjustment				
5	323-9	3	Screw-HH				
6	3272-5	1	Pin-Cotter				
7	3296-39	3	Nut-Lock, NI				



RH Motion Control Assembly No. 109-3707


Ref	Part No.	Qty.	Description				
1	1-808280	1	Pin-Clevis				
2	103-0407	1	Arm-Shaft, Control				
3	109-3901	1	Control-Motion, RH				
4	109-3903	1	Neutral Return ASM				
4:1	1-303105	1	Yoke-Adjustable				
4:2	1-603737	1	Bolt-Return, Neutral				
4:3	1-603807	1	Spring-Return, Neutral				
4:4	109-3769	1	Bushing, Nylon Flanged				
4:5	3219-2	3	Nut-Hex				
4:6	3230-23	1	Screw-CARR				
4:7	3256-2	1	Washer-Flat				
4:8	109-3908	1	Tab,Adjustment				
5	323-9	3	Screw-HH				
6	3272-5	1	Pin-Cotter				
7	3296-39	3	Nut-Lock, NI				



Hydraulic System Assembly

Ref	Part No.	Qty.	Description
1	103-3736	1	HYD Hose ASM
2	103-1947	1	HYD Reservoir ASM
2:1		1	Reservoir-HYD
2:1:1	103-1948	1	Cap-Reservoir, HYD
2:1:2	103-1949	1	Gasket-Cap
2:2	1-523552	1	Decal-Tank, HYD
3	104-7836	1	Head-Filter
4	103-3733	1	HYD Hose ASM
6	1-633750	1	Filter-Oil, HYD
6	1-633752	1	Filter-HYD, Winter
7	103-1799	2	Elbow-90 DEG
7:1	237-42	1	O-Ring
10	1-603991	4	Fitting-Straight
10:1	237-80	1	O-Ring
10:2	1-603992	1	O-Ring
11	103-6988	2	Motor-Wheel
11:1	1-809036	1	Nut-HH
11:2	3257-42	1	Key-Woodruff
11:99	103-2748	1	Drive Link Kit
11:99	103-6994	1	Seal Kit
12	1-603384	1	Bushing-Pivot, Idler
13	103-3330	1	Spring-Extension
14	109-1936	1	Pump Inlet Hose ASM
14:1	103-1826	1	HYD Hose ASM

Ref	Part No.	Qty.	Description
14:2	103-1827	1	HYD Hose ASM
14:3	103-1828	1	Adapter-Run, Tee
14:3:1	237-42	1	O-Ring
16	103-1716	3	Clamp-Hose
17	103-1988	2	Clamp-Hose
18	103-1801	1	Adapter-Straight
18:1	237-42	1	O-Ring
19	103-1912	1	Adapter-Straight
19:1	237-42	1	O-Ring
20	103-1802	2	Fitting-HYD, 90 DEG
20:1	1-603921	1	O-Ring
21	1-603990	4	Fitting-Straight
21:1	1-603920	1	O-Ring
21:2	1-603992	1	O-Ring
22	103-3737	1	HYD Hose ASM
23	103-3735	1	HYD Hose ASM
25	103-1808	1	Hose-HYD
26	103-1807	1	Elbow-45 DEG
26:1	237-42	1	O-Ring
27	103-1806	1	HYD Hose ASM
28	103-6907	2	Sheave
29	1-633567	1	Sheave
30	103-7445	1	Belt-V
31	1-633167	1	Sheave-Idler




Hydraulic System Assembly (continued)

Ref	Part No.	Qty.	Description
33	1-634277	1	Bearing Arm ASM
33:1	1-513034	2	Sleeve-Bearing
33:3	302-40	1	Fitting-Grease
34	321-6	2	Screw-HH
35	323-8	1	Screw-HH
36	323-9	1	Screw-HH
37	1-800805	1	Screw-HH
38	323-7	4	Screw-HH
39	1-803022	2	Screw-Set
40	30-1710	2	Screw
41	1-803050	2	Screw-Set
42	3256-22	2	Washer-Flat
43	3256-3	1	Washer-Flat
44	3256-4	1	Washer-Flat
45	13-2840	1	Key-Square
46	5-1077	2	Key-Square
47	3290-357	8	Nut-HHF, Whiz
48	32128-33	2	Nut-HF
49	1-805004	2	Washer-Lock
50	321-3	2	Screw-HH
51	103-7262	2	Pump-HYD
●51:1	103-7441	1	Bearing-Shaft, Input
●51:2	103-7443	1	Cylinder Block Kit
●51:3	103-8448	1	Thrust Bearing Kit


Ref	Part No.	Qty.	Description
●51:4	105-6184	1	Overhaul Seal Kit
●51:6	106-2053	1	Shock Valve Kit

13



Seat Assembly No. 110-0446


Ref	Part No.	Qty.	Description				
1	110-5719	1	Armrest Kit				
1:1	110-4163	2	Cushion-Rest, Arm				
1:2	3256-22	4	Washer-Flat				
1:3	322-10	2	Screw-HH				
1:4	105-3623	2	Channel-Armrest				
1:5	32153-3	2	Nut-Hex, Side Deform				
1:6	105-3621	1	Bracket-Armrest, RH				
1:7	105-3622	1	Bracket-Armrest, LH				
1:8	321-30	8	Screw-HH				
1:9	3296-42	4	Nut-Lock, NI				
1:10	325-2	2	Screw-HH				
1:11	3296-23	2	Nut-Lock, NI				
3	110-4162	1	Cushion-Seat, Bottom				
4	110-0447	1	Cusion-Seat, Back				
7	1-633859	1	Frame-Seat				
8	1-643255	1	Track-Seat				
11	110-0883	1	Retractable Seatbelt Kit				
11:2	3212-4	2	Screw-HH				
11:3	3296-7	2	Nut-Lock				
12	1-543401	4	Spacer-Track				
13	321-30	5	Screw-HH				
14	32128-20	4	Nut-HF				
15	3256-22	5	Washer-Flat				



Roll-Over Protection System Assembly No. 108-1097


Ref	Part No.	Qty.	Description
②1		1	Upper Tube ASM
1:2	107-2101	1	Decal-ROPS
1:3	107-2102	1	Decal-Warning, Folding ROPS
2	3296-73	2	Nut-Lock, NI
4	103-4553	2	ROPS Fold Pin ASM
5	325-13	2	Screw-HH
6	32128-23	2	Nut-HF
②7		1	Tube-Support, RH
②12		1	Tube-Support, LH
13	109-2365	2	Bumper-Rubber (W/Stud)
16	107-3052-03	1	Seat Support Frame ASM
17	107-3058	1	Catch-Latch, Seat
18	322-3	2	Screw-HH
19	3296-29	2	Nut-Lock, NI
20	3296-39	1	Nut-Lock, NI
23	323-20	1	Screw-HH
24	107-0076	1	Spring-Torsion
25	107-0075	1	Bushing-Latch, Seat
26	103-4434	1	Grip-Lever
28	3256-24	1	Washer-Flat
29	107-3083	1	Latch ASM
34	110-0883	1	Retractable Seatbelt Kit
34:2	3212-4	2	Screw-HH
34:3	3296-7	2	Nut-Lock

Ref	Part No.	Qty.	Description
①②54		1	Bag-Bolt, ROPS
54:3	323-6	8	Screw-HH
54:4	98-5975	8	Washer-Belleville
54:5	3290-357	8	Nut-HHF, Whiz




Deck Connection Assembly

Ref	Part No.	Qty.	Description				
1	32128-37	8	Nut-HF				
3	103-9792	4	Deck Chain ASM				
3:1	1-633447	1	Chain-Lift, Deck				
3:2	103-1898	2	Screw-HH				
3:3	32128-37	2	Nut-HF				
5	3217-11	2	Nut-Hex				
6	3253-8	2	Washer-Lock				
7	327-11	2	Screw-HH				
8	1-633029	2	Balljoint-Spherical				
9	3219-6	2	Nut-Hex				
10	109-1181	2	Strut-Deck				
10:2		1	Tube And Zerk ASM				
10:2:2	109-1380	2	Fitting-Grease				
11	1-632199-01	2	Pin-Strut				
12	322-3	2	Screw-HH				
13	3296-29	2	Nut-Lock, NI				
14		1	Deck ASM				




Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	105-7790	1	Belt	28	105-4622	1	Spacer
3	107-8536	2	Cover-Belt	29	108-2792	1	Rubber Deflector ASM
4	106-3220	1	Guide-Belt	30	106-6777	2	Handle-Latch, Swell
5	106-7358-01	1	Plate-Skid	31	107-1664	1	Lever ASM
6	32144-70	4	Screw-HWHTF	32	323-12	2	Screw-HH
7	108-4121-01	2	Bracket-Cover	33	106-3214	2	Mount-Pulley
8	108-2177-01	1	Bracket-Cover, Tall	34	3256-24	4	Washer-Flat
11	3290-357	38	Nut-HHF, Whiz	35	1-633109	3	Idler-Flat
12	323-28	1	Screw-HH	36	106-6778	2	Bushing-Latch, Swell
13	92-1624	33	Screw	37	3231-1	10	Screw-CARR
14	105-7735	3	Pulley	38	99-3058	2	Washer
15	108-7713	3	Spindle ASM	39	323-9	1	Screw-HH
16	105-7781-03	3	Blade-Hi Flow	40	1-603496	1	Bushing-Idler
17	323-23	3	Screw-HH	41	105-7787-01	1	Plate-Idler
18	98-7913	3	Tube-Spacer	42	105-7788	2	Spacer
19	322-50	1	Screw-HH	43	3231-4	2	Screw-CARR
20	98-5967	1	Spacer-Wheel	44	3296-39	6	Nut-Lock, NI
21	1-603299	5	Roller-Scalp, Anti	45	108-2178-01	1	Bracket-Cover, Short
22	3296-29	1	Nut-Lock, NI	46	103-0862	3	Screw-Cap
23	107-1623	1	Deck ASM	47	103-0865	3	Washer-Blade Bolt, Heavy
24	105-7754-01	1	Baffle ASM	48	106-3216-01	1	Baffle-Discharge
25	105-7755-01	1	Baffle ASM	49	1-804254	2	Nut
26	98-7912	3	Tube-Spanner	50	108-7220-01	1	Guide-Belt
27	108-4052	1	Spring-Torsion	59	112843	1	Washer




Spindle Assembly No. 108-7713

Ref	Part No.	Qty.	Description				
1	10-8040	1	Key-Square				
2	106-3277	1	Hub-Pulley				
3	103-0865	1	Washer-Blade Bolt, Heavy				
4	106-3204	2	Shield-Bearing				
5		1	Spindle Bearing ASM				
5:1	106-3211	1	Housing-Spindle				
5:2	108-7711	1	Bearing ASM				
5:2:1	108-7710	1	Bearing ASM				
5:2:2	106-3206	1	Spacer-Set, Matched				
5:3	253-133	2	Seal-Oil				
5:4	302-5	1	Fitting-Grease				
6	106-3218	2	Spacer-Seal				
7	106-3233	1	Spindle Shaft ASM				
8	3219-6	1	Nut-Hex				



Deck Decal Assembly No. 107-1623

Ref	Part No.	Qty.	Description				
2	54-9220	1	Decal-Danger				
3	66-1340	1	Decal-Danger				
4	98-5954	3	Decal-Cover, Missing				
5	1-403005	1	Decal-Danger				
6	68-8340	1	Decal-Torque				
7	105-7797	1	Decal-Routing, Belt				
8	105-7798	1	Decal-Scalp, Anti				
9	58-6520	3	Decal-Grease				
10	110-2067	1	Decal-Setting, Baffle				
11	107-1613	2	Decal-Grease				
12	107-1618	1	Decal				
13	107-1621	1	Decal-Service, Check				
14	110-2068	1	Decal-Adjustment, Baffle				




Rubber Deflector Assembly No. 108-2792

Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	106-3246-01	1	Deflector				
3	106-3248-03	1	Strap-Discharge				
4	108-5029	1	Deflector-Rubber				
5	108-4059-01	1	Plate-Hinge, Rear				
6	106-3253-01	1	Plate-Hinge, Front				
7	3296-39	4	Nut-Lock, NI				

Lever Assembly No. 107-1664


Ref	Part No.	Qty.	Description
1	106-3239	1	Screw-Lock
2	107-1644	1	Cap-Lock
3	106-3241	1	Lever-Lock
4	3296-29	1	Nut-Lock, NI



Drive Idler Assembly


Ref	Part No.	Qty.	Description
1	98-5975	1	Washer-Belleville
6	103-2627	1	Bushing-Idler
7	1-603384	1	Bushing-Pivot, Idler
9	1-603496	1	Bushing-Idler
10	99-4638	1	Idler
11	1-603402	1	Spring-Extension
12	1-633166	1	Pulley-Idler
14	103-3147	1	Arm ASM
14:1	1-513034	2	Sleeve-Bearing
14:2	302-40	1	Fitting-Grease
15	323-12	2	Screw-HH
16	323-9	1	Screw-HH
17	323-13	1	Screw-HH
18	1-800805	1	Screw-HH
19	3296-39	3	Nut-Lock, NI
20	3256-24	3	Washer-Flat
21	3290-357	6	Nut-HHF, Whiz
22	1-603401	1	Spacer-Fender
24	3256-4	3	Washer-Flat
26	106-3271	1	Travel Limiter ASM
26:1	106-3228-03	1	Plate-Limiter, Pulley
26:2	106-3229	1	Pad-Bumper
26:3	3269-24	2	Rivet
27	108-7204-03	1	Guide-Belt, LH

Ref	Part No.	Qty.	Description
28	108-7229-03	1	Guide-Belt, RH
29	3231-2	2	Screw-CARR




Engine and Clutch Assembly

Ref	Part No.	Qty.	Description				
2	323-9	4	Screw-HH				
3	98-5975	4	Washer-Belleville				
4	106-7022	1	Tube-Drain, Oil				
5	52-4780	1	Rod-Belt				
6	1-603610	2	Washer-Spring				
7	1-633615-03	1	Guard-Clutch				
9	103-6579	1	Clutch				
10	1-633179	1	Spacer-Clutch				
19	103-3270	1	Decal				
20	103-7454-03	2	Strap-Guard				
24	323-6	6	Screw-HH				
25	3212-10	1	Screw-HH				
32	3290-357	8	Nut-HHF, Whiz				
42		1	Engine-Kohler, Ch750-0010				
46	3256-24	1	Washer-Flat				
47	323-6	1	Screw-HH				
48	98-5975	1	Washer-Belleville				



Muffler and Guard Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	103-3535	1	Cable Heat Shield Kit	36	1-323235	2	Washer-Spring
1:2	321-4	1	Screw-HH	37	1-323236	2	Spacer
1:3	32128-33	1	Nut-HF	43	1-644316	1	RH Shield ASM
3	109-2365	2	Bumper-Rubber (W/Stud)	43:1	1-523285	1	Clip-Baffle, Rear
11	1-644276	1	Shield ASM	43:2	1-633301	1	Shield-Engine
11:1	1-633462	1	Decal-Important	43:3	1-633794-03	1	Shield-RH
11:2	1-634308	1	Shield/Lift ASM	43:4	1-643315	1	Baffle-Cooler, Engine
11:2:1	103-1308	1	Shield-Engine	43:5	1-803035	5	Rivet-Pop
11:2:2	1-633300-03	1	Lift-Shield	43:6	3256-63	5	Washer-Flat
11:2:3	1-803035	3	Rivet-Pop	44	1-643339	1	Decal-Routing, Belt
11:3	103-5881	1	Decal-Devices, Rotating	45	103-7482	1	Muffler
14	1-634796	1	LH Shield ASM	46	3253-6	2	Washer-Lock
14:1	1-523285	1	Clip-Baffle, Rear	47	324-2	2	Screw-HH
14:2	1-633301	1	Shield-Engine	48	9266934	2	Screw
14:3	1-633795-03	1	Baffle-Engine Shield, LH				
14:4	1-803035	3	Rivet-Pop				
14:5	3256-63	3	Washer-Flat				
17	1-643313-03	1	Guard-Muffler				
22	321-4	10	Screw-HH				
27	3296-42	4	Nut-Lock, NI				
29	3256-2	4	Washer-Flat				
33	32128-33	8	Nut-HF				
34	1-633396	1	Clip-Loom				
35	1-809108	2	Screw-HWH				



Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	107-9285	1	Fuel Line ASM
1:1	1-303077	12	Clamp
1:2	109-0678	2	Hose-Fuel
1:3	99-5000	2	Valve-Check, Fuel
1:4	109-0305	1	Hose-Fuel
1:5	99-5005	1	Fitting-Tee, Barbed
1:7	109-0302	1	Hose-Fuel
1:8	110-5702	1	Hose-Fuel
1:9	1-603770	1	Valve-Fuel
1:10	109-0660	1	Hose-Fuel
2	110-5732	1	Control Panel ASM
2:2	110-5731	1	Decal-Panel, Control
4	1-303335	4	Tie-Plastic
9	1-633023	6	Stud
10	105-3644	1	LH Fuel Tank Kit ASM
②10:1		1	LH Fuel Tank ASM
10:1:2	103-2605	1	Fitting-Fuel, Bulkhead
10:2	109-0346	1	Cap-Fuel, Gas
11	105-3643	1	RH Fuel Tank Kit ASM
②11:1		1	RH Fuel Tank ASM
11:1:2	103-2605	1	Fitting-Fuel, Bulkhead
11:2	109-0346	1	Cap-Fuel, Gas
14	1-633349	6	Spring-Tank, Fuel
16	322-3	2	Screw-HH


Ref	Part No.	Qty.	Description
17	3296-47	6	Nut-Lock, NI
19	1-805005	2	Washer-Lock
20	3256-23	8	Washer-Flat
23	3251-1	4	Screw-PPH
24	1-303435	4	Washer-Spring
26	110-5720	1	Control-Choke, Push / Pull
27	1-807513	2	Bolt-CARR
28	1-603175	1	Knob-Ball
29	110-5727	1	Cable-Throttle Control ASM
29:1	112-2334	1	Lever Throttle Cable
30	3296-2	2	Nut-Lock



Electrical Assembly


Ref	Part No.	Qty.	Description
1	107-9277-03	1	Strap-Holddown, Battery
2	105-1692	1	Battery
2:1	104-4163	1	Decal-Battery
2:2	104-4164	1	Decal-Battery
3	1-543792	2	Wingnut
4	1-633307	1	Wire-Ground
5	1-543391	1	Insulator-Battery
6	1-800282	1	Screw-HH
7	3256-2	2	Washer-Flat
8	3296-29	1	Nut-Lock, NI
9	1-523415	1	Spring-Switch, Seat
10	1-522424-03	1	Mount-Spring, Seat
11	321-4	6	Screw-HH
12	32128-33	6	Nut-HF
13	63-8360	2	Key-Ignition
14	1-513152	1	Switch-Closed, Normally
15	1-513180	1	Plate-Switch, Seat
16	3290-500	12	Screw-PPH
17	1-633181	4	Plate-Tapped
18	1-816001	2	Fuse-Blade Type, 20 Amp
19	1-633111	1	Switch
20	1-513051	2	Switch-Open, Normally
21	1-303287	5	Tie-Plastic
22	100-6186	1	Module-Delay, Seat

Ref	Part No.	Qty.	Description
23	103-0206	1	Switch-Starting, Key
23:1	3254-5	1	Washer-Tooth
23:2	218-461	1	Nut-HH
24	1-513374	1	Meter-Hour
25	103-5221	1	Switch-PTO
26	1-633396	3	Clip-Loom
27	106-7497	1	Harness-Wire
28	1-303335	2	Tie-Plastic
29	1-523281	1	Wire-Starter
30	1-543393	1	Insulator-Solenoid
31	1-633651	2	Bolt-Holddown
33	3296-2	4	Nut-Lock
34	1-643275	2	Relay
37	3256-22	1	Washer-Flat
51	3217-6	1	Nut-Hex
53	107-9309	1	Decal-Instructions, Charging



Crankshaft Assembly Kohler CH750-0010


Ref	Part No.	Qty.	Description
❸1	24 014 134-S	1	Crankshaft (Includes 2)
❸2	52 139 09-S	1	Plug-Cup



Crankcase Assembly
Kohler CH750-0010

Ref	Part No.	Qty.	Description
1		1	Crankcase
2	52 139 02-S	1	Plug-Pipe
3	24 032 01-S	1	Seal-Oil
4	25 755 14-S	1	Valve-Drain, Oil (Includes 5)
5	25 173 14-S	1	Cap-Valve, Oil Drain
6	24 380 16-S	6	Pin-Locating
7	24 067 13-S	2	Rod-Connecting (Standard)
8	24 067 14-S	2	Rod-Connecting (.25)
9	66 874 01-S	2	Piston W/Ring Set (STD) (Includes 9,10)
10	66 874 02-S	2	Piston W/Ring Set (.08)
11	66 874 03-S	2	Piston W/Ring Set (.25)
12	66 874 04-S	2	Piston W/Ring Set (.50)
13	24 018 01-S	4	Retainer-Piston, Pin
14	24 108 05-S	2	Ring Set (.25)
15	24 108 06-S	2	Ring Set (.25)
16	24 108 07-S	2	Ring Set (.50)
17	12 422 09-S	1	Shim-Camshaft (Red)
18	12 422 13-S	1	Shim-Camshaft (Black)
19	12 422 07-S	1	Shim-Camshaft (White)
20	12 422 08-S	1	Shim-Camshaft (Blue)
21	12 422 10-S	1	Shim-Camshaft (Yellow)
22	12 422 11-S	1	Shim-Camshaft (Green)
23	12 422 12-S	1	Shim-Camshaft (Gray)


Ref	Part No.	Qty.	Description
12	24 012 18-S	1	Camshaft
13	24 018 09-S	1	Ring-Retainer
14	M-931010-S	1	Washer-Flat (8 Mm)
15	28 032 09-S	1	Seal-Shaft, Cross Governor
16	24 468 15-S	1	Washer-Flat (1/4)
17	24 144 38-S	1	Shaft-Cross, Governor
18	52 139 09-S	1	Plug-Cup



Oil Pan and Lubrication Assembly Kohler CH750-0010

Ref	Part No.	Qty.	Description
❶1	24 009 163-S	1	Closure Plate ASM (Includes 2-14)
❶2	24 755 121-S	1	Dipstick Tube ASM (Includes 3)
❶3	24 038 10-S	1	Dipstick
❶4	24 043 12-S	1	Governor Gear Kit (Includes 5)
❶5	12 380 01-S	1	Pin-Regulating, Governor
❶6	24 448 02-S	1	Tab-Locking
❶7	12 144 02-S	1	Shaft-Gear, Governor
❶8	52 032 08-S	1	Seal-Oil (PTO End)
❶9	24 153 08-S	1	O-Ring
❶10	24 393 51-S	1	Oil Pump ASM (Includes 11,12)
❶11	24 381 04-S	1	Pick Up-Oil
❶12	24 153 01-S	1	O-Ring
❶13	M-631005-S	2	Washer-Plain (6 Mm)
❶14	M-645025-S	2	Screw-HF (M6X1.0X25)
❶15	25 086 49-S	2	Screw-Tapping (1/4-1X3/4)
❶16	12 050 01-S	1	Filter-Oil
❶17	54 755 21-S	1	Oil Cooler Kit (Includes 18-20)
❶18	24 594 32-S	1	Cooler-Oil (Phenolic)
❶19	24 153 21-S	1	O-Ring
❶20	28 136 01-S	1	Nipple-Filter, Oil
❶21	24 100 01-S	2	Nut-Plastic
❶22	25 155 02-S	1	Connector
❶23	24 099 03-S	1	Switch-Pressure


Ref	Part No.	Qty.	Description
❶24	24 086 16-S	9	Screw-HF (M8X1.25X45)
❶25	24 086 17-S	1	Screw-HF (M8X1.25X45)



Head, Valve and Breather Assembly Kohler CH750-0010

Ref	Part No.	Qty.	Description
❶1	24 755 141-S	1	Plain Valve Cover Kit (Includes 2, 3)
❷2	M-651030-S	4	Screw-Hex Flange (M6X1.0X30)
❸3	24 153 28-S	1	O-Ring
❹4	24 445 01-S	1	Strap-Lifting
❺5	12 755 03-S	4	Retainer Kit
❻6	12 173 01-S	2	Cap-Spring, Valve
❼7	24 089 02-S	2	Spring-Valve
❽8	235011-S	2	Retainer-Spring
❾9	66 032 05-S	1	Seal-Stem, Valve
❿10	24 318 99-S	1	Head ASM (No. 1 Cylinder)
❿11	24 017 01-S	1	Valve-Intake (Standard)
❿11	24 017 02-S	1	Valve-Intake (.25)
❿12	24 016 01-S	1	Valve-Exhaust (Standard)
❿12	24 016 02-S	1	Valve-Exhaust (.25)
❿13	24 755 66-S	1	Valve Train Kit (Includes 15, 18, 19)
❿14	25 351 04-S	4	Lifter-Valve
❿15	24 411 05-S	2	Rod-Push
❿16	24 841 03-S	2	Cylinder Head Gasket Kit (Includes 21, 22)
❿17	24 318 100-S	1	Head ASM (No. 2 Cylinder)
❿18	25 186 01-S	2	Arm-Rocker
❿19	24 599 01-S	2	Pivot-Arm, Rocker
❿20	24 072 09-S	8	Stud-Head, Cylinder


Ref	Part No.	Qty.	Description
❿21	24 468 16-S	8	Washer
❿22	24 100 10-S	8	Nut-HF (M8X1.25)
❿23	M-640034-S	2	Screw-HF (M6X1.0X34)
❿24	24 755 140-S	1	Oil Fill Valve Cover Kit (Includes 2, 3)
❿25	25 755 13-S	1	Oil Fill Cap ASM (Includes 26)
❿26	24 153 02-S	1	O-Ring
❿27	12 445 05-S	1	Strap-Lifting
❿28	24 402 03-S	1	Reed-Breather
❿29	66 018 04-S	1	Retainer-Reed, Breather
❿30	M-545010-S	1	Screw-HHFTF (M5X0.8X10)
❿31	24 050 01-S	1	Filter-Breather
❿32	24 033 01-S	1	Breather Kit (Includes 33-35)
❿33	24 041 51-S	1	Gasket-Breather
❿34	24 096 86-S	1	Cover-Breather
❿35	25 139 60-S	1	Plug-Hex, Countersunk (1/8)
❿36	M-645020-S	4	Screw-Flange, Hex (M6X1.0X20)
❿37	25 237 14-S	1	Clamp-Hose
❿38	24 326 80-S	1	Hose-Breather
❿39	25 237 08-S	1	Clamp-Hose
❶❸	24 755 147-S	1	Cylinder Head Hardware Kit (Includes 5-9, 11, 12, 14, 18, 19, 23)



Ignition and Electrical Assembly Kohler CH750-0010


Ref	Part No.	Qty.	Description
❶1	54 755 09-S	1	Stator Kit (Includes 2)
❶2	24 126 139-S	1	Bracket-Wire, Stator
❶3	M-548025-S	2	Screw-HHFTF (M5X0.8X25)
❶4	24 584 36-S	2	Module-Ignition
❶5	M-545020-S	4	Screw-HHFTF (M5X0.8X20)
❶6	24 025 15-S	1	Flywheel
❶7	X-42-15-S	1	Key
❶8	12 468 03-S	1	Washer-Flat (3/8)
❶9	12 086 14-S	1	Screw-Hex Flange (M10X1.5X45)
❶10	24 157 11-S	1	Fan
❶11	24 100 02-S	2	Nut-Plastic
❶12	24 584 38-S	1	Module-Advance, Speed
❶13	24 086 41-S	2	Screw
❶14	25 086 47-S	4	Bolt-Shoulder (M6X1.0X16)
❶15	24 755 08-S	1	Front Drive Shaft Kit (Includes 16)
❶16	M-839025-S	4	Screw-HF (M8X1.25X25)
❶17	X-25-53-S	4	Washer-Plain (1/4)
❶18	24 112 14-S	4	Spacer
❶19	24 141 06-S	1	Ring-Support
❶20	24 162 22-S	1	Screen-Grass
❶21	24 468 11-S	4	Washer-Spring
❶22	M-603100-S	4	Screw-HH (M6X1.0X100)
❶23	25 086 43-S	1	Screw-Set
❶24	41 403 09-S	1	Rectifier-Regulator

Ref	Part No.	Qty.	Description
❶25	X-25-92-S	2	Washer-Plain
❶26	24 086 18-S	2	Screw-Head, Phillips
❶27	236602-S	1	Connector (3 Contact)
❶28	12 154 01-S	1	Clamp-Line, Fuel
❶29	X-25-63-S	1	Washer-Plain (1/4In)
❶30	47 154 01-S	1	Clip-Cable
❶31	25 132 12-S	2	Spark Plug
❶❶	24 176 98-S	1	Harness-Wiring
❶❶	25 454 03-S	2	Tie-Wire
❶❶	24 126 137-S	1	Bracket-Strap, Ground
❶❶	25 468 07-S	1	Washer



Blower Housing and Baffle Assembly
Kohler CH750-0010


Ref	Part No.	Qty.	Description				
❶1	24 027 208-S	1	Housing-Blower (Includes 2-4, 6)				
❷2	24 100 02-S	2	Nut-Plastic				
❸3	25 086 43-S	1	Screw-Set				
❹4	24 100 01-S	1	Nut-Plastic				
❺5	25 755 20-S	1	Access Cover Kit (Includes 6, 7, 8 (Qty.4))				
❻6	24 096 63-S	2	Panel-Access				
❼7	25 154 02-S	4	Clip				
❽8	M-645016-S	10	Screw-HHFTF (M6X1.0X16)				
❾9	M-551016-S	1	Screw-Heavy Hex Flange (M5X0.8X16)				
❿10	M-545016-S	2	Screw-HHFTF (M5X0.8X16)				
❶❶11	24 146 19-S	1	Plate-Backing (No. 2 Side)				
❶❷12	M-545020-S	4	Screw-HHFTF (M5X0.8X20)				
❶❸13	24 063 39-S	1	Baffle-Barrel, Cylinder (No. 2 Side)				
❶❹14	24 063 70-S	1	Baffle-Valley (No. 2 Side)				
❶❺15	M-545010-S	2	Screw-HHFTF (M5X0.8X10)				
❶❻16	24 063 59-S	1	Baffle-Valley (No. 1 Side)				
❶❼7	24 063 58-S	1	Baffle-Barrel, Cylinder (No. 1 Side)				
❶❶❶18	24 146 20-S	1	Plate-Backing (No. 1 Side)				



Starting System Assembly


Kohler CH750-0010

Ref	Part No.	Qty.	Description				
❸1	M-841080-S	1	Nut-Hex Flange (M8X1.25)				
❸2	M-839080-S	2	Screw-Hex Flange (M8X1.25X70)				
❸3	25 098 09-S	1	Starter ASM (Includes 4-8)				
❸4	25 086 113-S	3	Screw-Torx Head, External				
❸5	25 435 06-S	1	Solenoid Kit (Includes 4)				
❸6	25 755 33-S	1	Pinion Drive Kit (Includes 7)				
❸7	25 141 05-S	1	Ring				
❸8	25 221 01-S	1	Brush Kit				



Fuel System Assembly
Kohler CH750-0010

Ref	Part No.	Qty.	Description				
❶1	24 853 104-S	1	Carburetor Kit (Includes 2, 3)				
❶2	24 041 60-S	1	Gasket-Manifold/Carburetor				
❶3	24 041 58-S	1	Gasket-Carburetor/Elbow				
❶4	M-641060-S	4	Nut-Hex Flange (M6X1.0)				
❶5	25 237 14-S	6	Clamp-Hose				
❶6	25 111 34-S	1	Line-Fuel (24 Inch, Cut to needed Length)				
❶7	24 353 02-S	1	Line-Fuel				
❶8	25 111 36-S	1	Line (Fuel Pump To Filter)				
❶9	M-650012-S	1	Screw-HF (M6X1.0X12)				
❶10	24 050 10-S	1	Filter-Fuel				
❶11	47 154 01-S	1	Clip-Cable				
❶12	24 393 16-S	1	Pump-Pulse, Fuel				
❶13	24 086 12-S	2	Screw-Hex Cap (M6X1.7X18)				
❶14	24 100 01-S	2	Nut-Plastic				
❶15	24 431 02-S	1	Sleeve-Insulating				
❶❸	24 757 48-S	1	Service Choke Repair Kit				
❶❸	24 757 49-S	1	Float Kit				
❶❸	24 757 50-S	1	Solenoid Valve Kit				
❶❸	24 757 51-S	1	Overhaul Kit				




Engine Control Assembly Kohler CH750-0010

Ref	Part No.	Qty.	Description
❶1	24 211 03-S	1	Bolt-Square Neck, Round Head
❶2	24 090 33-S	1	Lever-Governor
❶3	M-641060-S	1	Nut-Hex Flange (M6X1.0)
❶4	24 089 01-S	1	Spring-Linkage
❶5	25 158 08-S	1	Bushing-Retaining, Linkage
❶6	24 079 26-S	1	Linkage-Throttle
❶7	25 158 11-S	1	Bushing-Throttle, Linkage
❶8	M-545016-S	3	Screw-HHFTF (M5X0.8X16)
❶9	24 089 03-S	1	Spring-Return, Choke
❶10	M-547050-S	1	Nut-Hex, Lock (M5X0.8)
❶11	24 126 56-S	1	Bracket-Control
❶12	M-645016-S	4	Screw-HHFTF (M6X1.0X16)
❶13	12 237 01-S	2	Clamp-Cable
❶14	24 112 27-S	1	Spacer-Control ASM
❶15	24 090 47-S	1	Lever-Throttle Actuator
❶16	X-20-1-S	1	Washer-Lock (1/4)
❶17	M-541050-S	1	Nut-HF (M5X0.8)
❶18	24 468 20-S	1	Washer-Flat
❶19	24 090 03-S	1	Lever-Control, Throttle
❶20	M-446030-S	1	Nut-Hex (M4X0.7)
❶21	M-401030-S	1	Screw (M4X0.7X30)
❶22	24 468 01-S	1	Washer-Flat (5.5 Mm)
❶23	24 079 27-S	1	Linkage-Choke
❶24	24 090 05-S	1	Lever-Choke

Ref	Part No.	Qty.	Description
❶25	41 468 03-S	1	Washer-Spring (1/4)
❶26	M-545020-S	1	Screw-HHFTF (M5X0.8X20)
❶27	24 089 55-S	1	Spring-Governor
❶28	24 089 49-S	1	Spring-Governor

Air Intake and Filtration Assembly


Kohler CH750-0010



Air Intake and Filtration Assembly


Kohler CH750-0010

Ref	Part No.	Qty.	Description				
③1	25 048 07-S	1	Air Cleaner ASM (Includes 2-7)				
③2	25 096 06-S	1	Cover ASM				
③3	24 462 07-S	1	Valve-Ejector, Dust				
③4	25 154 05-S	2	Clip				
③5	25 083 01-S	1	Element-Air, Primary				
③6	25 083 04-S	1	Element-Air, Safety				
③7	25 081 01-S	1	Housing-Air Cleaner, Heavy Duty				
③8	25 139 20-S	1	Plug-Pipe				
③9	25 324 02-S	1	Hood-Cleaner, Air				
③10	M-639016-S	2	Screw-HF (M6X1.0X16)				
③11	X-25-73-S	2	Washer-Plain				
③12	25 126 02-S	1	Air Cleaner Bracket ASM				
③13	25 237 21-S	2	Clamp-Hose				
③14	24 326 81-S	1	Hose-Cleaner, Air				
③15	M-839020-S	2	Screw-HF				
③16	24 126 147-S	1	Bracket-Mounting, Air Cleaner				
③17	M-647060-S	2	Nut				
③18	24 041 60-S	1	Gasket-Manifold/Carburetor				
③19	24 041 01-S	2	Gasket-Manifold, Intake				
③20	24 164 87-S	1	Manifold-Intake (Includes 17, 18, 25)				
③21	25 086 84-S	4	Screw-HF (M6X1.0X55)				
③22	25 018 03-S	1	Retainer-Clip				
③23	M-645016-S	2	Screw-HHFTF (M6X1.0X16)				
③24	24 314 48-S	1	Shield-Debris				
③25	25 154 02-S	2	Clip				
③26	24 041 58-S	1	Gasket-Carburetor/Elbow				
③27	24 054 17-S	1	Elbow-Air Cleaner (Includes 25)				
③28	25 155 38-S	2	Connector-Hose				
③29	M-629122-S	4	Stud-Carburetor				
①③	25 113 05-S	1	Decal-Sentry, Oil				
①③	25 113 27-S	1	Decal-Cleaner, Air				



Exhaust Assembly Kohler CH750-0010

Ref	Part No.	Qty.	Description
③1	25 072 04-S	4	Stud (M8X1.25X33)
③2	24 041 49-S	2	Gasket-Manifold, Exhaust
③3	M-841080-S	4	Nut-Hex Flange (M8X1.25)



OIL COOLER MAINTENANCE

Oil cooler must be kept free of debris.

Inspect and clean every 25 hours, more frequently under severe conditions.

Artwork is representative.
Actual labels may differ depending on model and specification number.

Decal Assembly Kohler CH750-0010

Ref	Part No.	Qty.	Description
③1	25 113 39-S	1	Decal-Clear Laminate
③2	24 113 25-S	1	Decal-Cooler, Oil

Attachments and Accessories

For 74261 - Z500 Z Master, With 52in TURBO FORCE Side Discharge Mower

Product Name	Model/Part
Deck Lift Assist Kit	100-4336
1.25 Inch Spark Arrester Kit	105-1672
Blade-Recycler, 18 Inch	105-7779-03
Blade-Hi Flow, 18 Inch	105-7781
Blade-Med Flow, 18 Inch	105-7794-03
Blade-Low Flow, 18 Inch	105-7795-03
Blade-Atomic, 18 Inch	105-7796-03
52 Inch Recycler Kit	107-1610
Deluxe Suspension Seat	107-1891
Suspension Kit for Standard Seat	107-1892
Sunshade-Bimini	110-5726
Filter Minder Gauge	99-4664
Hitch Kit	99-8925

NOTES

NOTES

NOTES

