



Rear Remote Hydraulic Kit Sand/Infield Pro® 3040 and 5040 Traction Unit

Model No. 08781 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Tank Assembly	 3	Hydraulic Pump Assembly	 5
Hydraulic Manifold Assembly No. 108-5479	 4	Hydraulic Pump Assembly No. 108-2804	 6
		Quick Coupler Assembly	 7


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HS. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- ❶ Not serviced separately



Tank Assembly


Ref	Part No.	Qty.	Description
1	340-157	1	Fitting-HYD, Tee
1:1	237-79	1	O-Ring
1:2	237-30	2	O-Ring
2	32144-11	2	Screw-HWHTF
3	112-7104	1	Hose-Molded
4	321-11	2	Screw-HH
5	3296-42	2	Nut-Lock, NI
6	354-120	1	Fitting-HYD, 90 DEG
6:1	237-79	1	O-Ring
7	108-8460-01	1	Bracket-Valve
8	108-5479	1	Hydraulic Manifold ASM
9	2412-36	2	Clamp-Hose
10	87-3990	1	Strainer-Transaxle
10:1	237-123	1	O-Ring
11	112-7103	1	Hydraulic Tube ASM
11:1	237-30	1	O-Ring
11:2	340-152	1	Cap-HYD
12	340-142	1	Fitting-HYD, 90 DEG
12:1	237-58	1	O-Ring
12:2	237-81	1	O-Ring
13	340-98	1	Fitting-HYD, 90 DEG
13:1	237-79	1	O-Ring
13:2	237-30	1	O-Ring
14	112-1410	1	Hydraulic Tube ASM

Ref	Part No.	Qty.	Description
17	340-104	1	Tee-Fitting
17:1	237-30	2	O-Ring
18	110-8162	1	Dipstick ASM
19	99-7430	1	Relay
20	340-152	1	Cap-HYD




Hydraulic Manifold Assembly No. 108-5479

Ref	Part No.	Qty.	Description
1		1	Housing-Aluminum
2	110-6344	1	Coil-12V Dc
3	110-6345	1	Valve-Relief, Solenoid
3:1	110-6316	1	Seal Kit
3:2	110-2635	1	Nut-Coil




Hydraulic Pump Assembly

Ref	Part No.	Qty.	Description				
1	5-7280	1	Key				
2	108-2825	1	Hub ASM				
3	3242-4	4	Screw-Set, SQH				
4	112-1406	1	Bracket ASM				
4:2	23-2270	1	Bushing-Rubber				
5	3235-6	2	Screw-HH				
7	99-3578	1	Hose ASM				
9	112-6451-01	1	Torque Arm ASM				
11	112-1407	1	Hose-Suction				
12	104-8301	3	Nut-Flange, NI				
13	340-101	1	Fitting-HYD, 45 DEG				
13:1	237-30	1	O-Ring				
13:2	237-79	1	O-Ring				
14	108-2804	1	Pump-Hydraulic				
15	323-7	2	Screw-HH				
16	353-987	1	Fitting-HYD, 90				
16:1	237-81	1	O-Ring				
17	2412-129	2	Clamp-Hose				
18	112-1448	1	Harness-Wire, Aux Power Kit				
18:2	100-4918	1	Diode				
19	93-9999	1	Switch-PTO				
22	218-578	1	Fuse-10 Amp				
23	3256-23	2	Washer-Flat				
24	98-4700	1	Key-Square				



Hydraulic Pump Assembly No. 108-2804

Ref	Part No.	Qty.	Description				
1	110-6349	1	Kit-Seal				
1:2		1	Seal-Lip				
1:3		2	Seal-Backup				
1:4		2	Seal-Channel				
1:5		2	Seal-Oring				



Quick Coupler Assembly

Ref	Part No.	Qty.	Description
1	108-8467	1	Tube-HYD
1:1	237-30	1	O-Ring
2	108-8466	1	Tube-HYD
2:1	237-30	1	O-Ring
3	112-7105-01	1	Bracket-Hose, Suction
4	2112-11	2	Clamp-Muffler
5	105-7962	1	Plug-Dust
6	105-7963	2	Cap-Dust
7	32151-29	2	Ring-Retaining
8	108-8464	2	Fitting-Hydraulic
8:2	237-79	1	O-Ring
8:3	237-30	1	O-Ring
9	105-4170	2	Coupler-Male
10	105-4169	1	Coupler-Female
11	112-6457	1	Coupler Bracket ASM
11:2	110-1303	1	Decal-Coupler
12	32120-2	1	Ring-Retaining
13	340-4	1	Fitting-HYD, Straight
13:1	237-30	1	O-Ring
13:2	237-79	1	O-Ring
16	110-0299	1	Tube-Hydraulic
17	3296-29	1	Nut-Lock, NI
18	322-4	1	Screw-HH
19	2412-104	1	R-Clamp

Ref	Part No.	Qty.	Description
20	3296-29	4	Nut-Lock, NI

