Form Number 3356-518 Rev A

Valve Update Kit
Model 22910 Vibratory Plow Attachment

Model No. 112-4881

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2006
All Rights Reserved

Register your product at www.Toro.com



Valve Update Assembly

Ref	Part No.	Qty.	Description
1	112-4940	1	Valve Plate ASM
2	322-47	2	Screw-HH
3	112-4882	1	Flow Valve ASM
4	340-22	1	Fitting-HYD, Tee
4:1	237-65	2	O-Ring
4:2	237-80	1	O-Ring
5	112-2776-03	1	Plate-Clamp
6	3235-23	3	Screw
7	32128-35	5	Nut-HF
8	112-2766	1	HYD Hose ASM
9	105-4333	1	HYD Hose ASM
10	112-2768	1	HYD Hose ASM
10:1	237-80	1	O-Ring
11	112-2769	1	HYD Hose ASM
11:1	237-80	1	O-Ring
12	340-17	3	Fitting-HYD, 90 DEG
12:1	237-65	1	O-Ring
12:2	237-80	1	O-Ring
13	340-7	1	Adapter
13:1	237-65	1	O-Ring
13:2	237-80	1	O-Ring
14	3253-4	1	Washer-Lock
