




MODEL NO. 56133-1000001 & UP


**PARTS
CATALOG**
**WHEEL HORSE®
8-25 RIDING MOWER**


C-0004

FRONT BODY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	76-1620	Decal - Instruction	1
2	3296-29	Nut - Lock	5
3	44-7030	Tread - Foot Rest	2
4	32104-110	Screw - Cap Hex. Hd.	4
5	3290-347	Nut - U-Type	4
6	67-1590	Bracket - Brake Return	1
7	67-1430	Spring - Compression	1
8	26-9530	Washer - Pivot	1
9	67-1340	Rod - Brake, Transmission	1
10	67-1330	Lever - Brake, Bellcrank	1
11	67-1450	Spring - Extension	1
12	67-1350	Rod - Front, Brake	1

Ref. No.	Part No.	Description	No. Used
13	19-1970	Spring - Brake, Parking	1
14	67-1130	Pedal - Brake & Clutch	2
15	67-1070	Body W.A. - Front	1
16	3290-250	Pin - Hair, Cotter	2
17	65-2920	Pad - Pedal	2
18	19-1470	Bolt - Shoulder	1
19	19-1610	Lever - Brake, Parking	1
20	19-2200	Tip - Brake, Parking	1
21	76-3870	Decal	1
22	55-7102	Tower (Incl. Ref. #21)	1




C-0005

FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	322-3	Screw - Cap Hex. Hd.	6	20	3272-23	Pin - Cotter	2
2	44-7140	Mount - Bearing, Axle	1	21	3256-29	Washer - Flat	2
3	67-0520	Channel - R.H.	1	22	3290-250	Pin - Hair, Cotter	1
4	3296-29	Nut - Lock	16	23	322-14	Screw - Cap Hex. Hd.	2
5	67-0010	Lift W.A. - Front, Deck	1	24	67-0530	Channel - L.H.	1
6	67-0430	Rod - Clutch	1	25	67-0450	Frame W.A. - Front	1
7	282-27	Clevis	1	26	67-0830	Shaft W.A. - Steering	1
8	67-1530	Assembly - Pin, Clevis	1	27	67-0870	Bolt - Shoulder	2
9	3272-6	Pin - Cotter	2	28	3290-413	Washer - Belleville	4
10	76-3890	Bracket - Link, H.O.C.	1	29	67-0850	Bushing - Steering	2
11	67-0050	Tube W.A. - Support, Rear	1	30	67-0860	Washer - Steering	1
12	3296-39	Nut - Lock	5	31	32121-32	Pin - Roll	1
13	67-1510	Brace - Stop, Deck	2	32	67-0440	Spacer - Steering	1
14	3290-355	Pin - Hair, Cotter	2	33	32121-78	Pin - Roll	1
15	67-1460	Washer - Flat	2	34	49-3240	Wheel - Steering	1
16	323-10	Screw - Cap Hex. Hd.	2	35	66-6910	Insert - Wheel, Steering	1
17	68-8380	Spacer - Stop, Deck	2	36	76-4080	Decal	1
18	76-3790	Lever W.A. - H.O.C.	2	*	13-6049	Kit - Loose parts	1
19	46-2511	Bolt - Mounting, Axle	2				


*Not Illustrated



C-0002

SEAT & GAS TANK ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	66-6680	Seat	1	10	56-6360	Filter	1
2	67-1241	Base - Seat	1	11	2412-98	Clamp - Hose	5
3	38-1420	Switch - Seat	1	12	3296-29	Nut - Lock	4
4	18-2970	R-Clamp	1	13	3290-378	Tie - Cable	1
5	47-2986	Hose - Gas	1	14	322-3	Screw - Cap Hex. Hd.	4
6	67-0950	Strap - Tank, Gas	2	15	3256-23	Washer - Flat	8
7	80-4580	Tank - Gas	1	16	3230-20	Bolt - Carriage	6
8	55-3576	Assembly - Cap, Gas	1	17	66-6920	Pad - Isolator	2
9	47-2983	Hose - Gas	1	18	47-2964	Hose - Gas	1




C-0003A

FRONT AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	61-9780	Cap - Hub	2
2	28-2480	Washer - Flat	2
3	231-116	Tire	2
4	302-5	Fitting - Grease	4
5	217-80	Rim	2
6	32151-48	Ring - Retaining	2
8	3296-4	Nut - Lock	4
9	67-0990	Axle - Front	1

Ref. No.	Part No.	Description	No. Used
11	67-0880	Assembly - Tie Rod	2
12	67-0810	Spindle - L.H.	1
13	3256-26	Washer - Flat	1
14	3296-25	Nut - Lock	1
15	67-0800	Spindle - R.H.	1
16	251-210	Bearing	4
17	232-27	Valve Stem w/Cap	2
18	3272-12	Pin - Cotter	2




C-0007

REAR BODY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	71-8310	Spring - Prop, Seat	1
2	3296-29	Nut - Lock	11
3	3230-3	Bolt - Carriage	2
4	3256-22	Washer - Flat	1
5	67-1500	Bar - Stand	1
6	3256-23	Washer - Flat	4
7	322-5	Screw - Cap Hex. Hd.	4
8	67-1480	Brace - Support, Seat	2
9	322-3	Screw - Cap Hex. Hd.	4
10	67-0790	Support W.A. - Seat	1
11	3230-20	Bolt - Carriage	6
12	76-3840	Decal - Toro L.H.	1
*	76-3880	Decal - Toro R.H.	1
13	67-0231	Body W.A. - Rear	1
14	76-3850	Decal - Front	1
15	3255-7	Washer - Lock, Int. Tooth	2
16	3218-1	Nut - Jam	2
17	28-7890	Module - Interlock	1
18	28-0540	Bolt - Shoulder	1
19	3290-413	Washer - Belleville	7
20	3296-39	Nut - Lock	1
21	67-0270	Handle W.A. - H.O.C.	1
22	67-0870	Bolt - Shoulder	2

Ref. No.	Part No.	Description	No. Used
23	67-0080	Link - H.O.C.	1
24	76-3910	Decal - H.O.C. & Deck Engagement	1
25	233-22	Knob	1
26	3290-313	Screw - Pan Head	2
27	40-8200	Switch - Micro	1
28	3290-354	Nut - Double	1
29	67-1090	Support W.A. - Seat	1
30	3296-42	Nut - Lock	2
31	47-1910	Solenoid	1
32	80-4330	Prop - Seat	1
33	80-4550	Rod - Base, Seat	1
34	66-6640	Control - Throttle	1
35	233-59	Knob	1
36	23-0660	Switch - Ignition (Incl. Ref. #37 & 38)	1
37	3254-5	Washer - Lock, Int. Tooth	1
38	218-461	Nut - Hex.	1
39	67-1270	Decal - Panel, Control	1
40	63-8360	Key	2
41	32144-42	Screw - Hex. Hd. Tapping	4
42	67-1030	Cover - Panel, Control	1
43	3274-4	Pin - Cotter	1

*Not Illustrated




C-0009

TRANSMISSION & LINKAGE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296-39	Nut - Lock	2
2	3272-6	Pin - Cotter	1
3	67-0690	Flat - Deck Engage	1
4	68-8370	Link - Deck Engage	1
5	256-90	Bushing	3
6	67-0540	Tube W.A. - Pivot (Incl. Ref. #5)	1
7	3296-29	Nut - Lock	8
8	67-0930	Guide R.H. - Belt, Engine	1
9	3256-23	Washer - Flat	3
10	26-6700	Spring - Return, Brake	1
11	322-6	Screw - Cap Hex. Hd.	1
12	3230-2	Bolt - Carriage	1
13	76-4090	Plate - Engine	1
14	67-0940	Guide L.H. - Belt, Engine	1
15	68-9950	Spring - Traction	1
16	67-0410	Spacer - Pivot	1
17	321-4	Screw - Cap Hex. Hd.	2
18	67-0420	Plate - Mount, Idler	1
19	67-0400	Mount - Pivot	1
20	3296-42	Nut - Lock	5
21	12-9020	Retainer - Belt	1
22	3256-24	Washer - Flat	3
23	3296-59	Nut - Lock	1


Ref. No.	Part No.	Description	No. Used
24	323-10	Screw - Cap Hex. Hd.	1
25	12-5820	Pulley - Idler, Traction	1
26	323-8	Screw - Cap Hex. Hd.	1
27	67-0360	Bracket - Arm, Idler (Incl. Ref. #28)	1
28	256-155	Bushing	1
29	56-9870	Pulley - Idler, Deck	1
30	67-0330	Idler - Plate, Mount	1
31	67-9170	Spring	1
32	3274-4	Pin - Cotter	1
33	283-67	Pin - Clevis	1
34	322-3	Screw - Cap Hex. Hd.	2
35	67-0920	Guide - Belt	1
36	3253-4	Washer - Lock	1
37	322-10	Screw - Cap Hex. Hd.	1
38	32120-64	Ring - Retaining	1
39	67-0900	Belt - Traction	1
40	82-6450	Pulley - Transmission	1
41	3257-23	Key	1
42	32140-61	Screw - Sems, Hex. Hd.	3
43	67-0750	Bracket - Mount, Spring	1
44	32144-70	Screw - Hex. Hd. Tapping	1
45	67-0600	Lever W.A. - Deck Engage	1
46	67-0640	Handle - Deck Engage	1



C-0009

TRANSMISSION & LINKAGE ASSEMBLY (CONTINUED)


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
47	233-22	Knob	1	62	67-0670	Bracket - Engage, Deck	1
48	3256-55	Washer - Fender	2	63	28-4250	Switch - Neutral	1
49	67-1400	Transmission	1	64	3290-478	Washer - Belleville	2
50	56-7630	Gate - Shift	1	65	67-0660	Bracket - Mount, Shifter	1
51	32144-14	Screw - Wash. Hd., Tap.	4	66	20-3220	Washer - Flat	2
52	56-7620	Lever - Shift	1	67	32151-62	Ring - Retaining	1
53	329-4	Screw - Cap Hex. Hd.	1	68	3290-456	Washer - Belleville	2
54	76-3940	Lever W.A. - Shift	1	69	76-3970	Spacer - Pivot	1
55	233-48	Knob	1	70	67-1530	Assembly - Pin, Clevis	1
56	321-15	Screw - Cap Hex. Hd.	1	71	282-27	Clevis	1
57	56-7730	Spring	1	72	3218-2	Nut - Jam	1
58	56-7740	Spacer	1	73	32144-26	Screw - Thread Forming	1
59	321-8	Screw - Cap Hex. Hd.	1	74	76-3860	Decal	1
60	3253-3	Washer - Lock	1	75	76-3820	Anchor - Guide, Belt	2
61	3256-22	Washer - Flat	5	76	67-1450	Spring	1



C-0441

TRANSMISSION PEERLESS MODEL 700-025

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	770061	Case - Transmission	1	24	790006	Pad - Brake	2
2	772083	Cover - Transmission	1	25	790007	Plate - Pad, Brake	1
3	776217	Shaft - Output	1	26	786026	Pin - Dowel	2
4	778121A	Gear - Spur (20 Teeth)	1	27	780105A	Bushing - Flange	4
5	778122A	Gear - Spur (22 Teeth)	1	28	786081	Chain - Roller (No. 41 Chain, 24 Links)	1
6	778123A	Gear - Spur (25 Teeth)	1	29	780072	Washer - Thrust	5
7	778124A	Gear - Spur (30 Teeth)	1	30	780086	Bearing - Needle	2
8	778125	Gear - Spur (35 Teeth)	1	31	792072	Ring - Retaining	1
9	784266	Collar - Shift	1	32	792035	Ring - Retaining	1
10	786083	Sprocket (18 Teeth)	1	33	780109	Washer	1
11	786082	Sprocket (9 Teeth)	1	34	788040	Ring - Retaining	1
12	776134	Shaft - Counter	1	35	784267	Assy. Rod & Fork - Shift	1
13	788137A	Gear - Bevel (42 Teeth)	1	36	792073	Screw - Thread Forming	8
13A	778136	Gear - Spur (15 Teeth)	1	37	792089A	Key	2
14	778126A	Gear - Spur (20 Teeth)	1	38	792075	Nut - Lock	1
15	778127A	Gear - Spur (25 Teeth)	1	39	792076	Washer	1
16	778128A	Gear - Spur (28 Teeth)	1	40	792077	Ball - Steel	1
17	778129A	Gear - Spur (30 Teeth)	1	41	792078	Screw - Set	1
18	776135	Shaft - Input	1	42	792079	Spring	1
19	778113A	Bevel - Pinion, Input	1	43	780108	Washer - Thrust	5
20	786047	Sprocket (8 Teeth)	1	44	792001	O-Ring	1
21	790003	Disk - Brake	1	45	786086	Bracket - Lever, Brake	1
22	790008A	Lever - Brake	1	46	788069	Seal - Square Cut	1
23	790025	Holder - Pad, Brake	1				




C-0006

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3255-7	Washer - Lock, Int. Tooth	1
2	32153-3	Nut - Lock	4
3	3256-23	Washer - Flat	4
4	32103-14	Nut - Wing	1
5	56-7720	Post - Hold Down, Battery	1
6	56-2540	Tube - Drain	1
7	56-7710	Hold Down - Battery	1
8	80-2600	Battery 12V	1
9	321-4	Screw - Cap Hex. Hd.	2
10	32103-22	Nut - Wing	2
11	80-4560	Spacer	1
12	322-12	Screw - Cap Hex. Hd.	1
13	62-4300	Pad - Anti-Skid	1
14	83-4840	Pulley - Engine	1
15	3256-25	Washer - Flat	1
16	62-3760	Screw - Cap Hex. Hd.	1
17	56-7870	Assembly - Wire Battery to Ground	1

Ref. No.	Part No.	Description	No. Used
18	32144-14	Screw - Self Tapping	2
19	322-7	Screw - Cap Hex. Hd.	3
20	67-0920	Guide - Belt	1
21	322-10	Screw - Cap Hex. Hd.	1
22	67-0962	Guard - Chain	1
23		Engine - 8 H.P. B & S	1
24	3296-29	Nut - Lock	1
25	67-1170	Assembly - Wire Battery to Solenoid	1
26	67-1160	Assembly - Wire Solenoid to Starter	1
27	82-6740	Harness - Wire	1
28	3255-8	Washer - Lock	4
29	288-2	Cap - Pipe	1
30	289-34	Nipple - Pipe	1
31	2811-17	Elbow - Street	1
32	2812-1	Reducer	1
33	2210-319	Deflector - Muffler	1




C-0008

REAR AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	231-115	Tire	2
2	44-9760	Rim	2
3	3231-4	Bolt - Carriage	2
4	61-9990	Plate - Adjusting	1
5	3296-42	Nut - Lock	5
6	3231-25	Bolt - Carriage	4
7	47-1480	Mount - Bearing	2
8	321-4	Screw - Cap Hex. Hd.	4
9	2710-11	Link - Connecting	1
10	67-0910	Chain	1
		(Incl. Ref. #9)	1
11	56-9960	Differential	1
12	66-6630	Support L.H.	1

Ref. No.	Part No.	Description	No. Used
13	47-1490	Bearing	2
		(Incl. Ref. #14)	
14	3245-32	Screw - Set	4
15	3296-39	Nut - Lock	6
16	3256-24	Washer - Flat	4
17	76-1580	Guide - Chain	2
18	76-4010	Sprocket	1
19	3296-29	Nut - Lock	6
20	61-9980	Screw - Adjusting	1
21	66-6620	Support R.H.	1
22	46-2511	Bolt - Axle	2
23	232-27	Valve Stem w/Cap	2
*	11-0410	Kit - Tire Chains (Optional)	1

*Not Illustrated




C-0010

DIFFERENTIAL ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	55-7762	Axle - R.H.	1	5	55-7771	Cap - End, L.H.	1
2	32152-1	Nut - Lock	4	6	322-22	Screw - Cap Hex. Hd.	4
3	55-7770	Cap - End, R.H.	1	7	55-7763	Axle - L.H.	1
4	55-7780	Case - Gear, Transfer	1	*	56-9960	Differential - Complete	1

*Not Illustrated




C-0001

CUTTING UNIT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	28-8010	Spring	1
2	67-1150	Deflector (Incl. Ref. #3)	1
3	54-9220	Decal - Danger	1
4	67-0140	Post - Pivot	1
5	3296-8	Nut - Lock	2
6	3256-23	Washer - Lock	3
7	322-19	Screw - Cap Hex. Hd.	1
8	80-4420	Pulley - Deck	1
9	3219-6	Nut - Hex.	1
10	67-1390	V-Belt	1
11	38-7820	Bearing - Ball	2
12	80-4520	Guide - Belt	1
13	62-3660	Spacer - Bearing	1
14	67-1370	Assy. - Brake, Deck	1
15	322-6	Screw - Cap Hex. Hd.	2
16	67-0570	Rod W.A. - Brake, Deck	1
17	3296-39	Nut - Lock	2
18	61-9760	Wheel - Deck	2
19	56-6590	Bolt - Wheel	2
20	322-3	Screw - Cap Hex. Hd.	6
21	67-0710	Ball - Swivel	1

Ref. No.	Part No.	Description	No. Used
22	67-0730	Post - Mount, Brake	1
23	76-3810	Spacer - Brake, Deck	1
24	3296-29	Nut - Lock	1
25	67-0970	Hub - Spindle	1
26	80-4360	Shield - Bearing	1
27	80-4340	Shaft - Spindle	1
28	26-0671	Bolt - Blade	1
29	3290-465	Washer - Belleville	1
30	67-0200	Blade	1
31	80-4380	Spacer - Spindle	1
32	67-1440	Spring - Brake	1
33	3256-22	Washer - Flat	1
34	3234-21	Screw - Cap Hex. Hd.	1
35	3256-24	Washer - Flat	1
36	67-0130	Baffle	1
37	82-6230	Deck	1
38	321-4	Screw - Cap Hex. Hd.	1
39	67-1600	Bracket - Deflector	1
40	3296-59	Nut - Lock	1
41	3296-42	Nut - Lock	1
42	76-4070	Decal - Danger	1




C-0011A

EASY EMPTY BAGGING KIT MODEL 59047 (Optional)

Ref. No.	Part No.	Description	No. Used
1	54-9220	Decal - Chute	1
2	233-68	Knob	1
3	3234-5	Screw - Hex. Hd. Flange	8
4	3296-17	Nut - Lock	2
5	3256-2	Washer - Flat	14
6	3296-29	Nut - Lock	15
7	25-1360	Rod - Pivot	1
9	25-1470	Deflector	1
10	46-2850	Decal - Warning	1
11	25-1390	Guide - Handle	1
12	233-40	Grip - Handle	1
13	25-1380	Tube - Handle	1
14	3269-6	Washer - Backup, Rivet	14
15	25-2200	Decal - Easy Empty Bagger	1
16	321-30	Screw - Cap Hex. Hd.	2
18	321-8	Screw - Cap Hex. Hd.	1
19	3230-1	Bolt - Carriage	1
20	26-0010	Screen	1
21	3290-382	Rivet - Pop	14

Ref. No.	Part No.	Description	No. Used
22	25-1290	Hopper	1
23	32153-4	Nut - Lock	1
24	25-1370	Latch	1
25	3217-6	Nut - Hex.	2
26	67-9980	Cap	1
27	67-1540	Plate - Mounting	1
28	2830-9	Chain	2
29	3290-355	Pin - Hair, Cotter	2
30	67-9900	V-Bracket	1
31	3256-24	Washer - Flat	2
32	322-2	Screw - Cap Hex. Hd.	4
33	3290-479	Fastner - Panel	1
34	22-9741	Spacer	1
35	82-5690	Retainer - Duct	1
36	67-9890	Duct	1
37	32140-64	Screw	1
38	32103-14	Nut - Wing	1
39	67-1550	Chute (Incl. Ref. #1, 2 & 37)	1




C-0012A

TWIN BAGGER GRASS CATCHER MODEL 59053 (Optional)

Ref. No.	Part No.	Description	No. Used
1	54-9220	Decal - Chute	1
2	233-68	Knob	1
3	22-9741	Spacer	1
4	3290-479	Fastner - Panel	1
5	67-9890	Duct	1
6	57-7920	Baffle	1
7	57-7840	Decal - Twin Bagger	1
8	3269-15	Rivet - Pop	18
9	67-9960	Cover	1
10	57-7820	Seal - Foam	1
11	57-7880	Bracket - Frame, Bag	2
12	47-2550	Grip - Handle	4
13	57-7960	Frame - Bag	2
14	57-7990	Bag	2
15	3296-42	Nut - Lock	12
16	57-7980	Plate - Side	2

Ref. No.	Part No.	Description	No. Used
17	321-3	Screw - Cap Hex. Hd.	12
18	67-9960	Shield - Muffler	1
19	57-7890	Channel - Support, Bag	1
20	3296-29	Nut - Lock	4
21	2830-9	Chain	2
22	3290-355	Pin - Hair, Cotter	2
23	67-9900	V-Bracket	1
24	322-2	Screw - Cap Hex. Hd.	4
25	3296-17	Nut - Lock	2
26	3256-24	Washer - Flat	2
27	3256-1	Washer - Flat	5
28	82-5690	Retainer - Duct	1
29	32140-64	Screw	1
30	32103-14	Nut - Wing	1
31	67-1550	Assembly - Chute (Incl. Ref. #1, 2 & 29)	1



C-0795


RECYCLER KIT – MODEL NO. 59169

Ref. No.	Part No.	Description	No. Used
1	83-6610	Tab	1
2	32103-14	Nut – Wing	1
3	3296-42	Nut – Lock	9
4	3234-21	Screw	1
5	80-4530	Blade – Recycler	1
6	321-4	Screw – Cap Hex. Hd.	8
7	80-4540	Ring – Deck	4

Ref. No.	Part No.	Description	No. Used
8	80-4510	Kicker	4
9	32104-130	Screw – Special	8
10	82-6250	Decal – Recycler	1
11	80-4450	Cover – Recycler	1
*		Kit – Recycler (Incl. Ref. #1-10)	1

*Not Illustrated

309



NOTE:


To identify Briggs & Stratton manufactured starter motors, measure the housing length.

C-0784

STARTER – BRIGGS & STRATTON NO. 191707-6021-01

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
309	394805	Assembly – Motor & Drive	1	783	280104	Gear	1
310	94003	Assembly – Thru Bolt	2	801	394856	Assembly – End Cap	1
311	395538	Assembly – Brush	2	802	395537	Assembly – Commutator, End Cap	1
510	490421	Assembly – Drive (Incl. Ref. #513, 783, 876 & 896)	1	803	393825	Assembly – Housing (3-21/32" Long)	1
513	398003	Assembly – Clutch	1	876	490467	Kit – Retainer	1
544	390837	Assembly – Armature	1	896	94288	Pin – Roll	1

BRIGGS & STRATTON MODEL NO. 191707-6021-01



BRIGGS & STRATTON MODEL NO. 191707-6021-01 (Cont.)






Ref. No.	Part No.	Description	No. Used
1	396269	Assembly - Cylinder	1
2	399267	Bearing - Cylinder	1
		Note: Requires special tools for installation.	
3	294606	Seal - Oil	1
5	212286	Head - Cylinder	1
*7	272163	Gasket - Head, Cylinder	1
8	391406	Assembly - Breather	1
*9	27803	Gasket - Cover, Valve	1
10	93394	Screw	1
11	280005	Tube - Breather	1
*12	271701	Gasket - Cover, Crankcase 1/64" Thick	1
*	27876	Gasket - Cover, Crankcase .005" Thick	1
*	27877	Gasket - Cover, Crankcase .009" Thick	1
13	94565	Screw - Head, Cylinder	1
14	93723	Screw - Head, Cylinder (3" Long)	1
15	94239	Plug - Drain, Oil	1
16	396876	Crankshaft	1
		Note: Order Part 94388 for timing gear pin replacement.	
18	392548	Base - Engine	1
19	295963	Bushing - Base, Engine	1
		Note: Requires special tool for installation.	
20	391086	Seal - Oil	1
22	93585	Screw - Base, Mounting	1
24	222698	Key - Flywheel	1
25	391673	Assy. - Piston, Std.	1
	391674	Assy. - Piston, .010" O.S.	1
	391675	Assy. - Piston, .020" O.S.	1
	391676	Assy. - Piston, .030" O.S.	1
		PISTON RING SETS	
		Note: For Chrome Piston	
		Ring Set - Standard Size - Order No. 299743.	
26	391669	Ring Set - Piston, Std.	1
	391670	Ring Set - Piston, .010" O.S.	1
	391671	Ring Set - Piston, .020" O.S.	1
	391672	Ring Set - Piston, .030" O.S.	1
27	68546	Lock - Piston Pin	1
28	295840	Assy. - Piston Pin, Std.	1
	295841	Assy. - Piston Pin, .005" O.S.	1
29	390402	Assy. - Rod, Connecting	1
		Note: For Connecting Rod with .020" Undersize Crankpin Bore - Order No. 390773.	
31	222114	Lock - Screw, Conn. Rod	1
32	92659	Screw - Connecting Rod	1
33	261095	Valve - Exhaust	1
34	261055	Valve - Intake	1
35	65906	Spring - Valve, Intake	1
36	26828	Spring - Valve, Exhaust	1
40	221596	Retainer - Valve, Intake	1
41	292260	Rotocoil - Valve, Exhaust	1
42	93630	Retainer - Valve, Exhaust	1
		Rotocoil	2
45	260933	Tappet - Valve	1
46	211689	Gear - Cam	1
75	224061	Washer - Spring	1
78	93805	Screw - Sems	1

Ref. No.	Part No.	Description	No. Used
200	221760	Guide - Air	1
201	262431	Link - Governor	1
209	260871	Spring - Governor	1
219	491397	Slinger - Oil, Gov. Gear & Bracket Assembly	1
222	491594	Plate - Control, Governor	1
225	231058	Crank - Gov. (1/4" Dia.)	1
227	490927	Assy. Lever - Governor for 1/4" Dia. Crank	1
230	222450	Washer - Lever, Governor (1/4" Inside Diameter)	1
232	261911	Spring - Link, Governor	1
265	221535	Clamp - Casing	1
284	93572	Screw - Clamp, Mounting	1
300	398507	Muffler - Exhaust	1
304	491408	Housing - Blower	1
305	94608	Screw - Blower Hsg., Sems	1
306	224543	Shield - Cylinder	1
307	93868	Screw - Shield, Cylinder	1
308	222636	Cover - Head, Cylinder	1
332	92284	Nut - Flywheel	1
333	398811	Armature - Magneto	1
334	93381	Screw - Armature	1
337	802592	Plug - Spark	1
346	93705	Screw	1
356	494328	Wire - Ground	1
358	299577	Gasket Set	1
363	19165	Puller - Flywheel	1
383	89838	Wrench - Spark Plug	1
422	223394	Clamp - Tube, Oil Filler	1
455	222561	Cup - Screen Mounting	1
468	222562	Screen - Flush, Rotating	1
482	93621	Screw - Sems	1
523	391840	Cap & Dipstick - Oil Filler	1
524	68838	Seal - Tube, Filler	1
525	280133	Tube - Filler, Oil	1
552	231055	Bushing - Crank, Gov.	1
562	92613	Bolt - Lever, Governor	1
592	231082	Nut - Hex.	1
613	94042	Screw - Muffler	1
614	93306	Pin - Hair, Cotter	1
615	93307	Retainer - E-Ring	1
635	66538	Elbow - Plug, Spark	1
657	93496	Screw	1
663	93572	Screw	1
676	395700	Deflector - Exhaust	1
725	223540	Shield - Muffler	1
729	281159	Clip - Lead Wire	1
741	262479	Gear - Timing	1
757	212359	Link - Counterweight	1
758	390172	Assy. - Counterweight	1
759	298909	Pin - Counterweight	1
761	93874	Screw - Counterweight	1
836	93559	Screw	1
842	270920	Seal - Cap, Filler	1
847	392066	Filler Group - Oil	1
851	221789	Terminal - Ignition Cable	1
869	211661	Seat - Valve, Intake (Std.)	1
870	211661	Seat - Valve, Exhaust (Std.)	1
871	231218	Guide - Exhaust or Intake Valve, See repair manual	1
883	270918	Gasket - Pipe, Exhaust	1
1019	491182	Kit - Label	1
1020	261190	Eccentric	1
1021	94160	Pin - Eccentric	1

*Included in Gasket Set - Part No. 299577.

BRIGGS & STRATTON MODEL NO. 191707-6021-01 (Cont.)

121 CARBURETOR OVERHAUL KIT



Assemblies include all parts shown in frames.

BRIGGS & STRATTON MODEL NO. 191707-6021-01 (Cont.)

Ref. No.	Part No.	Description	No. Used
23	391983	Assy. - Flywheel & Ring Gear, Magneto	1
*52	270824	Gasket - Carburetor Mtg.	1
*94	292681	Assy. - Valve, Carb. Idle	1
95	93499	Screw - Throttle & Choke Valve Mounting	1
98	91920	Screw - Mach. Fil. Hd.	1
99	26157	Spring - Adjust. Throttle	1
101	93043	Pin - Stop, Throttle	1
*104	230896	Pin - Hinge, Float	1
108	222010	Valve - Choke	1
*118	396568	Valve - Needle	1
121	394698	Kit - Overhaul, Carburetor	1
123	93357	Screw - Mounting, Carb.	1
125	491590	Assembly - Carburetor	1
126	299851	Assy. - Body, Carburetor	1
*127	221997	Plug - Welch	1
128	211682	Venturi - Carburetor	1
130	221986	Valve - Throttle	1
131	491006	Shaft & Lever, Throttle	1
132	211712	Stop - Throttle	1
133	299707	Float - Carburetor	1
*134	394681	Valve - Inlet, Fuel	1
136	221995	Bowl - Float	1
*137	270511	Gasket - Bowl, Float	1
*138	222014	Washer - Bowl, Float	1
141	390684	Shaft & Lever - Choke	1
*142	299740	Nozzle - Carburetor	1
*147	231323	Screw - Nozzle	1
186	67218	Connector - Fuel Pipe	1
216	261612	Link - Choke	1
309		Motor - Starting (12 V) See Chart for Replacement Parts on Illustrated Pages.	1

Ref. No.	Part No.	Description	No. Used
423	93984	Screw - Sems	1
482	93621	Screw - Sems	1
527	221428	Clamp	2
534	93622	Screw - Cleaner, Air	1
534A	93323	Screw - Cleaner, Air	1
535	270528	Element - Cleaner, Air	1
536	391399	Assy. - Cleaner, Air Uses: 280111 Support - Air Cleaner Element Plastic	1
537	270539	Gasket - Cleaner, Air	1
618	261116	Spring - Return, Choke	1
634	270382	Washer - Shaft, Choke (Felt)	1
634A	271853	Washer - Shaft, Throttle	1
643	222149	Cup - Cleaner, Air	1
662	222027	Bracket - Carburetor	1
663	93572	Screw	1
683	94419	Screw - Hex. Washer Hd. Self-Tapping	1
726	392134	Gear - Ring (Aluminum) (Includes Mounting Parts)	1
727	395405	Cover - Starter (Incl. Mounting Screws)	1
728	93535	Screw - Sems	1
877	393814	Assy. - Diode & Connector	1
887	391529	Assy. - Stator, Alternator (D.C.)	1
952	222495	Spacer - Cleaner, Air	1
953	222022	Screen - Cleaner, Air	1
987	398970	Seal - Throttle	1

*Included in Carburetor Overhaul Kit - Part no. 394698.