

Floor Mat Kit

For Zero-Turn-Radius Riding Mowers

Model No. 79315

Installation Instructions

Installation

Loose Parts

Use the chart below to verify that all parts have been shipped.

Step	Description	Qty.	Use
1	No parts required	–	Prepare the machine.
2	Floor mat	1	Install the floor mat.

Step
1

Preparing the Machine

No Parts Required

Procedure

1. Park the machine on a level surface and disengage the blade control switch.
2. Move the motion control levers outward to the park position, stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Clean the foot area of the frame of all dirt and debris and dry thoroughly.

Step

2

Installing the Floor Mat

Parts needed for this step:

1	Floor mat
---	-----------

Procedure

1. Remove the adhesive backing of the floor mat (Figure 1).
2. Position the floor mat with the wider edge to the front, as shown in figure Figure 1. Install the floor mat to the floor of the frame with the adhesive side down.




Figure 1

1. Floor mat, tread side up
2. Wider mat edge to the front
3. Frame floor