



Platinum Series Lawn Mower

Model No. 10785 - 270000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front End and Tunnel Assembly	 3	Engine Assembly No. 1 Tecumseh LV195EA-362044D	 10
Rear Axle and Transmission Assembly	 4	Engine Assembly No. 2 Tecumseh LV195EA-362044D	 12
Upper Handle Assembly	 5	Recoil Starter Assembly No. 590739 Tecumseh LV195EA-362044D	 14
Lower Handle Assembly	 6	Recoil Starter Assembly No. 590702 (optional) Tecumseh LV195EA-362044D	 15
Blade and Engine Assembly	 7	Attachments and Accessories List	 16
Rear Bag Assembly	 8		
Carburetor Assembly No. 640350 Tecumseh LV195EA-362044D	 9		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head


Footnotes

- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain from your local Tecumseh dealer



Front End and Tunnel Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	110-9419	1	Housing ASM	28	110-9458	1	Spring-Extension
1:2	107-1941	1	Decal-Safety, Bag	29	107-1938	1	Decal-Bag Attachment
2	110-9415-03	1	Mount-Handle, LH	30	49-2040	11	Screw-HWHTF
3	614650	2	Bolt-Shoulder	31	110-9468	1	Mulch Plug ASM
4	107-3898	2	8 Inch Wheel ASM	32	110-9413	1	Baffle-Rear
5	614672	2	Bolt-Shoulder	33	3256-14	1	Washer-Flat
6	40-1940	2	Washer	34	110-9457	1	Decal-Mulch Plug
7	110-9421	1	Arm-Pivot, RH	35	3256-22	2	Washer-Flat
9	110-9434	2	Arm-Spring, Front				
10	110-0549	2	Knob-HOC				
12	108-7476	6	Screw-Plastite				
13	3296-39	2	Nut-Lock, NI				
14	108-9349	1	Cover-Rear				
14:2	107-3888	1	Decal-Safety				
15	110-9455	1	Tunnel				
16	110-9446	1	Plug-Mulch, LH				
17	110-9448	1	Latch-Mulch Plug				
18	110-9447	1	Plug-Mulch, RH				
19	110-9416-03	1	Mount-Handle, RH				
20	110-1784	1	Module-Switch				
21	94-1610	2	Nut-Clip				
23	108-0965	2	Screw-PTH				
24	110-9420	1	Arm-Pivot, LH				
27	94-8072	1	Decal-Danger				



Rear Axle and Transmission Assembly


Ref	Part No.	Qty.	Description
1	614650	2	Bolt-Shoulder
2	107-3906	2	Rear Wheel ASM
3	32151-61	2	Ring-Retaining
4	110-9417	2	Pinion
5	36-4780	2	Washer
6	108-7476	3	Screw-Plastite
7	110-1793	2	Wheel Cover ASM
7:1		1	Cover-Wheel
7:2	614426	1	Washer-Stepped
8	32151-36	2	Ring-Retaining
9	108-9344	1	Arm-Rear Pivot, LH
10	110-9445	2	Arm-Spring, Rear
11	110-0549	2	Knob-HOC
12	110-9422	2	Retainer-Bearing
13	104-8699	2	Bearing-Ball
14	110-9429	1	V-Belt
15	112-8768	1	Shield-Trailing
16	110-9414	1	Transmission ASM
17	105-3028	1	Chute-Discharge, Side
18	108-9343	1	Arm-Rear Pivot, RH
19	110-9418-03	1	Bracket-Transmission
20	99-8445	2	Screw-HWH
21	99-5293	1	Spring-Torsion
22	112-6416	1	Bracket-Cover

Ref	Part No.	Qty.	Description
23	99-5291	1	Rod-Cover
24	106-8376	1	Discharge Door ASM
24:2	107-0795	1	Latch-Door
24:3	107-7456	1	Cap-Door
24:4	107-7461	1	Screw-Plastite
25	65-2720	1	Klipring-Locking
28	24-7922	1	Cover-Shaft, Drive
29	114-2755	2	Cap-Bearing




Upper Handle Assembly

Ref	Part No.	Qty.	Description				
1	108-0974	1	Upper Handle ASM				
2	112-8754	2	Sleeve-Inner				
3	112-1544	1	Sleeve-Outer, LH				
4	107-3869	2	Spring-Compression				
5	104-0858	1	Bolt-Shoulder				
6	112-8764	1	Stop-Pivot				
7	110-1819-03	1	Bail-Brake				
8	112-1545	1	Sleeve-Outer, RH				
9	107-3937	1	Knob				
10	107-3867-03	1	Tube-Cross				
11	107-3871	1	Rod-Threaded				
12	107-3865	2	Mount-Handle, Lower				
13	110-9465	1	Cable-Traction				
14	108-0963	1	Cable-Brake				
15	108-1045	1	Support-Cable				
16	108-1046	1	Support-Guide, Cable				
17	3296-73	3	Nut-Lock, NI				
18	108-7454	1	Clamp-Cable				
19	107-3893	1	Lever-Traction				
21	321-4	1	Screw-HH				
22	108-0959	1	Pin-Handle				
23	108-1008	1	Pin-Bail, LH				
24	108-0988	1	Screw-CARR				
26	108-9378	1	Retainer-Push On				




Lower Handle Assembly

Ref	Part No.	Qty.	Description				
1	108-0988	3	Screw-CARR				
2	3296-73	8	Nut-Lock, NI				
3	107-3887-03	2	Tube-Lower				
4	108-9339-03	1	Mount-Handle, RH				
5	108-9340-03	1	Mount-Handle, LH				
6	95-4453	4	Screw				
7	112-8755	1	Handle-Rod, Release				
8	108-0994	1	Guide-Rope, Lower				
9	107-3908	1	Guide-Rope, Upper				
10	106-6805	1	Guide-Cable				
11	107-3944-03	2	Plate				
12	49-2040	1	Screw-HWHTF				
13	112-1542	1	Spring-Extension				
14	112-1539	1	Plate-Release Rod				
15	110-1823-03	1	Lever-Release				
16	107-3947	2	Washer-Nylon				




Blade and Engine Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	108-3766-03	1	Support-Blade				
3	108-0954-03	1	Blade-21 Inch				
4	106-3987	1	Blade Driver ASM				
5	106-3999	1	Spacer-Driver				
6	32144-102	3	Screw-HWH				
7	108-8110-03	1	Guide-Belt				
9	32144-85	1	Screw-HWH				
10	92-1701	1	Stop-Rope				
2 3 11		1	Engine-Tecumseh, Lv195Ea-362044D				
11:3	110-9486	1	Decal-Engine				
13	110-1778	1	Handle-Recoil				
14	106-8346-03	1	Guard-Muffler				



Rear Bag Assembly

Ref	Part No.	Qty.	Description
1	110-9483	1	Grass Bag ASM
2	112-8750-03	1	Frame-Bag



Carburetor Assembly No. 640350 Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description
❶	631615	1	Throttle Shaft And Lever ASM
❷	631767	1	Spring-Return, Throttle
❹	631184	1	Washer-Seal, Dust
❺	631183	1	Seal-Dust, Throttle
❻	640070	1	Shutter-Throttle
❼	650506	1	Screw-Shutter
❻	631807	1	Fitting-Fuel
❼	651025	1	Screw-Throttle Crack/Idle Speed
❹	630766	1	Spring-Tension
❷	640016	1	Screw-Restrictor, Idle
❷	640200	1	Cap-Screw, Restrictor Idle
❷	631867	1	Bowl-Float (No Drain)
❷	631024	1	Shaft-Float
❷	632802	1	Float (Plastic)
❷	631028	1	O-Ring-Bowl, Float
❷	631021A	1	Inlet Needle, Seat, And Clip ASM (Includes 31)
❷	631022	1	Clip-Spring
❷	640351	1	Primer Bulb/Valve Repair Kit
❷	640080	1	Tube-Nozzle, Main
❷	632766	1	Tube-Carburetor
❷	632547	2	O-Ring-Nozzle Tube, Main
❷	640030	1	Nut-Bowl, High Speed
❷	27110A	1	Washer-Nut, Bowl

Ref	Part No.	Qty.	Description
❷	630748	1	Plug-Welch, Idle Mixture Well
❷	631027	2	Plug-Welch, Atmospheric Vent
❷	632760B	1	Repair Kit (Includes 4, 5, 7, 27, 29, 30, 37, 44, 47, 48)
❷	26756	1	Gasket-Carburetor To Intake Pipe

Engine Assembly No. 1


Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
③1	37465	1	Cylinder (Includes 2, 20, 150)	③130	6021A	8	Screw (5/16-18X1-1/2)
③2	26727	2	Pin-Dowel	③135	35395	1	Spark Plug-Resistor (R J19 L M)
③6	33734	1	Element-Breather	③150	31672	2	Spring-Valve
③7	36557	1	Breather ASM (Includes 6, 12A)	③151	31673	2	Cap-Valve, Spring
③12	37944	1	Tube-Breather	③151A	40017	1	Seal-Valve, Intake
③12A	36558	1	Breather Cover And Tube ASM (Includes 12B)	③166	37813A	1	Shroud-Engine (Green)
③12B	36694	1	Elbow-Tube, Breather	③169	36783	1	Gasket-Cover, Valve
③14	28277	1	Washer-Flat	③172	36784	1	Cover-Valve
③15	30589	1	Rod-Governor (Includes 14)	③174	30200	2	Screw (10-24 X 9/16)
③16	34839A	1	Lever-Governor	③178	29752	2	Nut And Lock Washer (1/4-28)
③17	31335	1	Clamp-Lever, Governor	③179	30593	1	Retainer Clip
③18	651018	1	Screw (T-15, 8-32 X 19/64)	③182	6201	2	Screw (1/4-28 X 7/8)
③19	36281	1	Spring-Extension	③184	26756	1	Gasket-Carburetor To Intake Pipe
③20	32600	1	Seal-Oil	③185	37466	1	Pipe-Intake
③30	37692	1	Crankshaft	③186	32653	1	Link-Governor
③40	40027	1	Piston, Pin And Ring Set (STD.)	③189	650839	2	Screw (1/4-20 X 3/8)
③42	40006	1	Ring Set (STD)	③191	36559A	1	Bracket-Brake (Includes 195)
③43	20381	2	Ring-Retaining, Piston Pin	③195	610973	1	Terminal
③45	36777	1	Connecting Rod ASM (Includes 46)	③207	34336A	1	Link-Throttle
③46	32610A	2	Bolt-Rod, Connecting	③216	33086	1	Lever-Adjusting, R P M
③48	27241	2	Lifter-Valve	③223	650451	1	Screw (1/4-20 X 1)
③50	37460	1	Camshaft (Includes 104)	③223A	651074	1	Stud-Pipe, Intake
③52	29914	1	Oil Pump ASM	③224	36786	1	Gasket-Pipe, Intake
③69	37609	1	Gasket-Flange, Mounting	③238	650932	2	Screw (10-32 X 49/64)
③70	37608A	1	Flange-Mounting (Includes 72-83, 306, 309A, 311A)	③239	34338	1	Gasket-Air Cleaner
③72	37614	1	Plug-Drain, Oil	③241	36919	1	Collar-Air Cleaner
③75	27897	1	Seal-Oil	③245	36905	1	Filter-Air Cleaner
③80	30574A	1	Shaft-Governor	③250	37122	1	Cover-Air Cleaner
③81	30590A	1	Washer	③260	37696A	1	Housing-Blower
③82	30591	1	Governor Gear ASM (Includes 81)	③261	30200	2	Screw (10-24 X 9/16)
③83	30588A	1	Spool-Governor	③262	650831	2	Screw (1/4-20 X 1/2)
③86	650488	6	Screw (1/4-20 X 1-1/4)	③275	37498	1	Muffler
③89	611298	1	Key-Flywheel	③277	650988	2	Screw (1/4-20 X 2-9/32)
③90	611299	1	Flywheel	③285	35000A	1	Cup-Starter
③92	650815	1	Washer-Belleville	③287	650926	2	Screw (8-32 X 21/64)
③93	650816	1	Nut-Flywheel	③290	37962	1	Line-Fuel, Low Permeation (8.62)
③100	34443C	1	Ignition-Solid State	③292	26460	2	Clamp-Line, Fuel
③101	610118	1	Cover-Spark Plug	③298	28763	2	Screw (10-32 X 35/64)
③103	651007	2	Screw (T-15, 10-24 X 15/16)	③300	37947	1	Fuel Tank ASM
③104	37480	1	Bushing-Cam	③301	37844	1	Cap-Fuel (Black) (1-1/2 I D)
③110	37047	1	Wire-Ground (10.50 With Male And Female Flag Terminals)	③305	35647A	1	Tube-Fill, Oil
③110A	611227	1	Wire-Ground	③306	37610	1	O-Ring
③119	37796	1	Gasket-Head, Cylinder	③307	35499	1	O-Ring
③120	3771	1	Head-Cylinder	③309	650562	1	Screw (10-32 X 1/2)
③125	36780	1	Valve-Exhaust (1/32In Os) (Includes 151)	③309A	650783	1	Screw (10-24 X 3/4)
③125	37288	1	Valve-Exhaust (STD) (Includes 151)	③310	35648	1	Dipstick
③126	37289	1	Valve-Intake (STD) (Includes 151, 151A)	③311A	37611	1	Bracket-Holddown
				③313	34080	1	Spacer
				③324	33177	1	Terminal
				③347	650898A	4	Screw (10-32 X 27/32)
				③370A	36261	2	Decal-Lubrication

Engine Assembly No. 2

Tecumseh LV195EA-362044D


Tecumseh LV195EA-362044D



Engine Assembly No. 2


Tecumseh LV195EA-362044D

[illegible]



Recoil Starter Assembly No. 590739
Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description				
33	590740	1	Retainer				
36	590616	2	Dog-Starter				
37	590617	2	Spring-Dog				
38	590618A	1	Pulley And Rewind Spring ASM				
311	590638A	1	Starter Housing ASM (40 Degree Grommet)				
312	590535	1	98 Starter Rope (Cut To Length)				
313	590701	1	Handle-Starter				
314	590760	1	Clip-Spring				



Recoil Starter Assembly No. 590702 (optional)
Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description				
❶1	590599A	1	Spring Pin ASM (Includes 4)				
❷2	590600	1	Washer				
❸3	590696	1	Retainer				
❹4	590601	1	Washer				
❺5	590697	1	Spring-Brake				
❻6	590698	2	Dog-Starter				
❼7	590699	2	Spring-Dog				
❽8	590700	1	Pulley And Rewind Spring ASM				
❾11	590703A	1	Starter Housing ASM (40 Degree Grommet)				
❿12	590535	1	98 Starter Rope (Cut To Length)				
⓫13	590701	1	Handle-Starter				

Attachments and Accessories

For 10785 - Platinum Series Lawn Mower

Product Name	Model/Part
Lawn Boy Paint	110-8800
Replacement Bag	89815
Rear Bag Kit	89913
21 Inch Blade	89914
Cruise Control Kit	89919
Air Filter	89945
Spark Plug	89946

NOTES

NOTES

NOTES

