


TORO®

MODEL NO. 0644SC01-1000001 & UP

**PARTS
CATALOG****WHEEL HORSE®
44" (112cm) Snowthrower**

**ONLY COPY
DO NOT REMOVE**
Tech. Publications




C-0849

AUGER HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	57-3510	Plate - Side	2
2	111189	Decal - Danger	2
3	76-1330	Decal - Attachment	1
4	117297	Housing - Auger	1
5	57-9890	Bracket - Blade Support	2
6	322-3	Bolt	4
7	3296-29	Nut - E.S.	4
8	57-3470	Blade - Scraper	1
9	3229-25	Bolt - Carriage	6
10	3296-42	Nut - E.S.	6
11	79-0800	Skid	2
12	900038	Bolt - Carriage	4
13	3296-29	Nut - E.S.	4
14	323-6	Bolt - Nylok	2
15	2844	Washer	2
16	908003	Bolt	8
17	322-3	Bolt	20

Ref. No.	Part No.	Description	No. Used
18	3296-29	Nut - E.S.	20
19	112403	Overlay - VIN Decal	1
20	117223	Brace - L.H.	1
21	900091	Bolt - Carriage	2
22	920010	Washer	2
23	915664	Nut - E.S.	2
24	117220	Brace - Cross	1
25	324-5	Bolt	2
26	920084	Washer - Lock	2
27	117224	Brace - R.H.	1
28	117434	Frame	1
29	117553	Cover - Belt Rear	1
30	926671	Bolt	3
31	79-2530	Bracket - Bumper	1
32	101017	Lock	1
33	323-7	Bolt	3
34	3256-2	Washer	4




C-0849

AUGER HOUSING ASSEMBLY (CONTINUED)

Ref. No.	Part No.	Description	No. Used
35	915663	Nut – E.S.	4
36	908034	Bolt	2
37	104859	Spacer	2
38	932961	Pin – Clevis	1
39	933504	Cotter – Hairpin	3


Ref. No.	Part No.	Description	No. Used
40	117550	Bracket – Guard	1
41	117552	Guard – Belt	1
42	117540	Guard – Chain	1
43	926693	Bolt	2



C-0850

CHUTE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3296-29	Nut - E.S.	3	17	111314	Pin - Lock	1
2	920008	Washer	3	18	51-2650	Crank	1
3	25-5290	Ring - Chute Swivel	1	19	26-1110	Extender - Chute	1
4	27-0220	Screw - Special	6	20	322-2	Bolt	3
5	25-5450	Chute - Retainer	3	21	12-2040	Wire - Chute	1
6	49-6720	Bracket	1	22	3290-326	Nut - Push	2
7	3230-1	Bolt - Carriage	1	23	56-2600	Chute - Upper Discharge	1
8	3296-29	Nut - E.S.	1	24	900036	Bolt - Carriage	3
9	8-8600	Gear - Worm	1	25	920008	Washer	3
10	933152	Pin - Roll	1	26	915662	Nut - E.S.	3
11	3256-2	Washer	2	27	111190	Decal - Discharge Danger	2
12	932016	Pin - Cotter	3	28	11-9346	Deflector	1
13	117529	Rod - Lower	1	29	3231-2	Bolt - Carriage	2
14	117538	Coupling	1	30	20-4320	Washer - Rubber	2
15	933505	Cotter - Hairpin	1	31	3290-340	Washer - Belleville	2
16	119030	Support - Crank	1	32	3296-29	Nut - E.S.	2




C-0851

GEAR CASE AND BELT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	117219	Link - Lift	1
2	933001	Pin - Clevis	1
3	920011	Washer	2
4	932017	Pin - Cotter	4
5	117543	Arm - Lift	1
6	117556	Rod - Lift	1
7	110614	Spring	1
9	116906	Support - Spring	1
10	920262	Washer	2
11	933505	Cotter - Hairpin	3
12	4629	Spring	1
13	117539	Retainer - Spring	2
14	110568	Flange	1
15	110569	Bearing	1
16	119020	Flange w/Grease Fitting	1
17	3230-1	Bolt - Carriage	3
18	3296-29	Nut - E.S.	5
19	116919	Sprocket	1
20	6366	Key	1
21	909544	Screw - Sq. Hd. Set	2
22	117447	Chain	1
23	117517	Bracket	1
24	3231-2	Bolt - Carriage	4
25	3256-24	Washer	6
26	3296-39	Nut - E.S.	8

Ref. No.	Part No.	Description	No. Used
27	108959	Tightener - Chain	1
28	322-10	Bolt	2
29	117338	Sprocket	1
30	937221	Key	1
31	3241-5	Screw - Set	2
32	116938	Gearbox	1
33	3231-25	Bolt - Carriage	2
34	117558	Pulley - Gearbox	1
35	937089	Key	1
36	3242-2	Screw - Set	2
38	115118	Pulley - Idler	1
39	323-10	Bolt	1
40	2844	Washer	1
41	106887	Spacer	1
42	117546	Arm - Idler	1
43	7450	Bracket - Belt Guard	1
44	116859	Pulley - Flat Idler	1
45	323-8	Bolt	1
46	117770	Washer - Rubber	1
47	117544	Bracket - Pivot	1
48	920013	Washer	1
49	117545	Spring	1
50	932865	Pin - Clevis	1
51	932016	Pin - Cotter	1
52	116332	Belt - Drive	1



C-0852

AUGER ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	57-3300	Auger - R.H.	1	18	5-7180	Gear - Worm	1
*	57-3370	Auger - L.H.	1	19	252-71	Bearing - Thrust	2
2	909542	Screw - Sq. Hd. Set	2	20	51-0460	Gasket	1
3	20-1000	Flange - Bearing Rear	2	21	256-32	Bushing	1
4	20-0980	Bearing	2	22	32120-72	Ring - Retaining	1
5	20-0990	Flange - Bearing Front	2	23	3-8664	Washer - Thrust	1
6	19-8890	Impeller	1	24	5-7170	Worm	1
7	5210	Shim	1	25	252-77	Washer - Thrust	1
8	19-8540	Shaft - Impeller	1	26	252-76	Bearing - Thrust	1
9	1088	Key - Square	1	27	252-78	Washer - Thrust	1
10	57-3500	Shaft - Auger	1	28	37-8850	Gear Case & Bushing Ass'y	1
11	908027	Bolt	2	29	32144-41	Screw - Thread Forming	8
12	3296-29	Nut - E.S.	2	30	20-3210	Bushing	1
13	3257-33	Key - Woodruff	2	31	237-87	Seal	1
14	7-0045	Seal - Oil	2	32	3257-23	Key - Woodruff	1
15	256-237	Bushing	2	33	3296-42	Nut - E.S.	8
16	37-8860	Gear Case & Bushing Ass'y	1	*	822427	Gear Box Assembly Complete	1
17	281-1	Plug - Pipe	1				

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you

are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO Importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

MAINTENANCE RECORD

[illegible]

MAINTENANCE RECORD

[illegible]