


MODEL NO. 32120502-1000001 & UP
 MODEL NO. 32120E02-1000001 & UP
 MODEL NO. 3210B502-1000001 & UP
 MODEL NO. 3210BE02-1000001 & UP

**PARTS
 CATALOG**

**WHEEL HORSE®
 200 SERIES GARDEN TRACTOR**




C-0897

SEAT ASSEMBLY (210-5 & 210-H)

Ref. No.	Part No.	Description	No. Used
1	78-7600	Seat	1
2	322-5	Screw - Cap Hex. Hd.	4
3	322-41	Screw - Cap Hex. Hd.	2
4	78-7180	Knob	2
5	112837	Spring	2
6	3230-3	Bolt	2

Ref. No.	Part No.	Description	No. Used
7	78-2740	Washer - Lock	2
8	111439	Grip	2
9	3296-29	Nut - Lock	2
10	3253-4	Washer - Lock	4
11	105503	Spacer	2
12	109989	Spacer - Nylon	4

SEAT ASSEMBLY (212-5 & 212-H)




SEAT ASSEMBLY (212-5 & 212-H)

Ref. No.	Part No.	Description	No. Used
1	78-9160	Seat	1
2	322-5	Bolt	4
3	113852	Plate - Seat Pivot	1
4	112745	Bracket - Pivot L.H.	1
*	112744	Bracket - Pivot R.H.	1
6	322-4	Bolt	4
7	105503	Bushing	2
8	3296-29	Nut - Lock	6
13	108889	Bumper	2

Ref. No.	Part No.	Description	No. Used
16	112961	Plate	2
17	322-5	Bolt	6
18	3256-23	Washer	6
22	112837	Spring - Seat	2
24	3253-4	Washer - Lock	8
25	3217-6	Nut - Hex.	4
26	322-6	Bolt	4
27	109989	Spacer - Nylon	4

*Not Illustrated

FRAME ASSEMBLY




FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	78-1640	Frame	1
2	114417	Plate - Rear Drawbar	1
3	112850	Plate - Frame Support (210-H & 212-H)	1
*	114851	Plate - Frame Support (210-5 & 212-5)	1
4	111397	Plate - Front Axle Support	1
5	114610	Roller - Cam	2
6	112977	Support - Rear Axle	1
7	106488	Mat - Footrest (210-5 & 210-H)	2
*	110180	Mat - Footrest (212-5 & 212-H)	2
8	78-1820	Hoodstand (210-5 & 210-H)	1
*	78-3390	Hoodstand (212-5 & 212-H)	1
9	111467	Panel - Console	1
10	111499	Screw - Pan Hd.	6
11	117343	Keeper - Latch	2
12	117431	Rivet - Pop	4
13	111392	Clip - J	1
15	3230-16	Bolt - Carriage	5
16	3296-29	Nut - Lock	9
17	111763	Strap (210-5 & 210-H)	2
18	900037	Bolt - Carriage	1
19	3256-23	Washer	15
20	322-6	Screw - Hex. Hd.	3
21	3254-2	Washer - Lock	2
22	1278	Washer - Shim (.050")	A/R
*	5210	Washer - Shim (.015")	A/R
23	32120-93	Ring - Retaining	1
24	322-3	Screw - Hex. Hd.	4
25	915740	Nut - Hex.	4
26	910837	Screw	1
27	3217-5	Nut - Lock	1
28	3253-3	Washer - Lock	1

Ref. No.	Part No.	Description	No. Used
29	908017	Bolt	3
30	111524	Link	2
31	111527	Spring	2
32	78-1670	Cam - Adjustment	2
34	3272-16	Pin - Cotter	2
35	920242	Washer - Special	2
36	938031	Bushing	1
37	8830	Clip	1
38	113116	Retainer	2
40	908019	Bolt	1
41	109779	Nut	2
42	323-7	Bolt	1
43	3296-39	Nut - Lock	3
44	110370	Pulley - Idler (210-5 & 212-5)	1
45	323-10	Bolt	1
46	3256-24	Washer	2
47	109230	Retainer - Belt	1
48	111439	Grip	1
49	114990	Bracket - R.H. (212-5 & 212-H)	1
*	114989	Bracket - L.H. (212-5 & 212-H)	1
50	960152	Screw	2
51	3296-42	Nut - Lock	2
52	910796	Screw	2
53	915740	Nut - Lock	2
54	938050	Plug - Nylon (210-5 & 210-H) (212-5 & 212-H)	1 2
55	117142	Bracket - Fuse	1
56	78-2050	Bracket - Switch	1
57	926640	Screw - Machine	2
58	115860	Clip - Snap-In	1
59	115858	Clip - Snap-In	2
60	900036	Bolt - Carriage	2
61	926697	Bolt	4

*Not Illustrated

BODY ASSEMBLY




BODY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	78-7540	Fender (210-5 & 210-H)	1
*	79-0050	Fender (212-5)	1
*	114389	Fender (212-H)	1
2	78-8570	Hood & Grill (210-5 & 210-H)	1
*	116800	Hood & Grill (212-5 & 212-H)	1
3	111480	Rod (210-5 & 210-H)	1
4	107772	E-Ring (210-5 & 210-H)	2
5	111536	Spring (210-5 & 210-H)	2
6	117344	Handle Assembly	2
7	117432	Rivet - Pop	4
8	915551	Nut (Optional)	2
9	116591	Headlight Bar Assembly (Incl. Ref. #22-24 & 26) (212-5 & 212-H)	1
10	111392	Clip (212-5 & 212-H)	1
11	32103-19	Nut - Wing (212-5 & 212-H)	1
12	103995	Washer - Special (212-5 & 212-H)	1
14	108547	Reflector	2
15	109193	Rivet - Pop	4
16	3230-23	Bolt - Carriage	8
17	938031	Bushing	1
18	910808	Screw (Optional)	2
19	920004	Washer	2
20	920079	Washer - Lock (Optional)	2

Ref. No.	Part No.	Description	No. Used
21	915662	Nut - Lock	8
22	116601	Bar - Light (212-5 & 212-H)	1
23	111684	Bucket - Light (212-5 & 212-H)	2
24	111685	Retainer (212-5 & 212-H)	2
25	116262	Socket - Light (212-5 & 212-H)	2
26	7228	Bulb - Light (212-5 & 212-H)	2
27	114443	Cable - Hood Lanyard (210-5 & 210-H)	1
*	115414	Cable - Hood Lanyard (212-5 & 212-H)	1
28	915740	Nut - Lock	1
29	913111	Screw - Machine	1
30	112925	Washer - Backing	1
31	78-3210	Cover - Light Opening (210-5 & 210-H)	1
32	115413	Clevis (212-5 & 212-H)	2
34	920081	Washer - Lock (212-5 & 212-H)	1
35	118060	Bolt (212-5 & 212-H)	1
36	913111	Screw (212-5 & 212-H)	1
37	915740	Nut - Lock	1
38	5977	Bushing - Nyliner	2
39	3256-23	Washer	2
40	3272-6	Pin - Cotter	2
41	78-7170	Nut - Push (210-5 & 210-H)	1
42	926566	Bolt (210-5 & 210-H)	1

*Not Illustrated

ELECTRICAL SYSTEM ASSEMBLY




ELECTRICAL SYSTEM ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	104962	Battery (210-5, 210-H & 212-5)	1
*	105842	Battery (212-H)	1
2	78-1340	Harness Wire (210-5 & 210-H) (Incl. Ref. #14, 41, 46, 78 & 79)	1
*	79-0480	Harness Wire (212-5 & 212-H) (Incl. Ref. #14, 41 & 46)	1
3	106948	Tray - Battery	1
4	109547	Hook	2
5	117316	Hold-Down - Battery	1
7	111076	Wire - Solenoid/Battery (210-5 & 210-H)	2
		(212-5 & 212-H)	1
8	111682	Wire - Solenoid/Starter (210-5 & 210-H)	1
*	112757	Wire - Solenoid/Starter (212-5 & 212-H)	1
9	321-4	Bolt	2
10	3256-22	Washer	6
11	3217-5	Nut	5
13	110167	Solenoid (210-5 & 210-H) (Incl. Ref. #11)	1
14	120930	Holder - Fuse	1
15	114721	Tube - Drain	1
16	78-1630	Kit - Diode Replacement (210-5 & 210-H)	1
18	38-1420	Switch - Seat	1
22	111216	Switch - Ignition (210-5 & 210-H) (Incl. Ref. #31-32)	1
*	116338	Switch - Ignition (212-5 & 212-H) (Incl. Ref. #31-32)	1
23	116738	Key - Ignition	2
24	102138	Switch - Light (212-5 & 212-H) (Incl. Ref. #25, 26 & 64)	1

Ref. No.	Part No.	Description	No. Used
25	920262	Washer - Special	1
26	920259	Washer - Special	1
27	100571	Tie - Cable	1
28	109553	Cover - Battery Terminal	1
29	115204	Harness - Headlight (212-5 & 212-H)	1
31	101884	Nut - Switch	1
32	920160	Washer - Lock	1
33	3255-7	Washer - Lock	2
37	960151	Screw - Hex. Hd. (210-5 & 210-H)	1
38	3253-3	Washer - Lock	2
39	3218-1	Nut - Jam	2
41	105302	Connector - 5 Terminal	1
42	32103-22	Nut - Wing	2
43	109355	Fuse - 15 Amp.	1
*	109102	Fuse - 25 Amp.	1
*	NN10277	Fuse - 30 Amp. (212-5 & 212-H)	1
46	111498	Body - Connector (210-5 & 210-H) (212-5 & 212-H)	1
		(212-5 & 212-H)	2
50	104926	Body - Connector (212-5 & 212-H)	2
58	8830	Clip	1
59	3023	Clip (210-5 & 210-H) (212-5 & 212-H)	5
		(212-5 & 212-H)	4
63	78-3030	Switch - PTO	1
71	910948	Screw	2
72	915732	Nut - Lock	2
73	115230	Switch - Clutch	1
74	105490	Clamp	1
78	110459	Connector - 2 Terminal (210-5 & 210-H)	1
79	107831	Socket - Connector	1
80	116397	Relay (210-5 & 210-H) (212-5 & 212-H)	2
		(212-5 & 212-H)	3

*Not Illustrated

FRONT AXLE & STEERING ASSEMBLY




FRONT AXLE & STEERING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	114385	Axle - Front	1
2	302-5	Fitting - Grease	3
3	112847	Bracket - Support	1
4	113044	Tube	1
5	113030	Pin	2
6	111531	Spring	1
7	111406	Spindle - R.H.	1
8	111409	Spindle - L.H.	1
9	32120-93	Ring - Retaining	2
11	112981	Rod - Tie	1
12	111413	Shaft - Pinion	1
13	111417	Gear - Sector	1
14	111418	Bushing - Eccentric	1
15	111419	Washer	1
17	78-1991	Bracket - Steering Gear (210-5 & 212-5)	1
*	78-3221	Bracket - Steering Gear (210-H & 212-H)	1
18	110391	Bushing	1

Ref. No.	Part No.	Description	No. Used
19	111422	Retainer	1
20	111423	Rod - Drag Link	1
22	78-3100	Wheel - Steering	1
25	322-4	Screw - Cap Hex. Hd.	2
26	3253-4	Washer - Lock	2
27	32121-103	Pin - Spirol	2
28	915001	Nut - Lock	2
29	3765	Washer - Shim (.050")	A/R
30	3231-28	Bolt	1
31	108881	Nut - Lock	1
32	3230-22	Bolt	2
33	3229-29	Nut - Lock	3
34	3256-23	Washer	1
35	3230-2	Bolt	1
36	915002	Nut - Lock	2
37	933272	Pin - Spirol	1
39	2844	Washer - Special	2
41	32121-111	Pin- Spirol	1
42	116480	Coupler - Shaft	1

*Not Illustrated

WHEEL & TIRE ASSEMBLY




WHEEL & TIRE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	109154	Hubcap	2
2	100079	Tube - Inner	2
3	116883	Front Wheel & Tire Assy. (Incl. Ref. #4-8)	2
4	116884	Tire - Front	2
5	5108	Valve - Stem	4
6	109500	Fitting - Grease	2
7	116885	Front Wheel Assembly (Incl. Ref. #5, 6 & 8)	2
8	116887	Bushing - Flange	4
9	1278	Washer - .050"	A/R
10	5210	Washer - .015"	A/R
11	109262	Washer - Hubcap	2
12	3272-17	Pin - Cotter	2
13	109261	Hubcap	2
14	32151-48	Ring - Snap	2
15	109262	Washer - .050"	6

Ref. No.	Part No.	Description	No. Used
16	105450	Tube - Inner	2
17	116879	Rear Wheel & Tire Assy. (Incl. Ref. #5, 18 & 19)	2
18	116880	Tire - Rear	2
19	116881	Rear Wheel Assembly (Incl. Ref. #5)	2
20	1120	Key - Square	2
21	1278	Washer - .050"	4
22	920251	Washer - .050"	4
23	5-1336	Key - Square	2
24	116892	Rear Wheel & Tire Assy. (Incl. Ref. #5, 16 & 25)	2
25	116893	Rear Wheel Assembly (Incl. Ref. #5)	2
26	120860	Washer - .075"	6
27	32151-36	Ring - Snap	2

TRANSMISSION ASSEMBLY (210-5 & 212-5)




TRANSMISSION ASSEMBLY (210-5 & 212-5)

Ref. No.	Part No.	Description	No. Used
2		Transmission Assembly (Peerless Model 930-020)	1
3	112982	Strap - Torque	2
5	111430	Arm	1
6	78-2020	Shaft	1
7	5666	Bushing - Nylon	1
8	111432	Spring	1
9	112983	Knob	1
10	115198	Arm - Transmission	1
11	115042	Rod	1
12	115043	End - Rod	1
13	104869	Washer - Special	1
15	322-12	Screw - Cap Hex. Hd.	4
16	3256-23	Washer	6
17	900036	Bolt - Carriage	2
18	926720	Screw	2
19	3296-29	Nut - Lock	5
20	3253-4	Washer - Lock	2
21	915112	Nut - Lock	2

Ref. No.	Part No.	Description	No. Used
22	113025	Pointer	1
23	933273	Pin - Spirol	1
24	3765	Washer - Shim	A/R
25	3220-2	Nut - Jam	1
26	329-5	Screw - Cap Hex. Hd.	1
27	3253-3	Washer - Lock	1
28	920268	Washer	1
29	3272-6	Pin - Cotter	1
30	322-6	Bolt	1
32	108790	Pulley - Transmission	1
33	114860	Belt - Transmission Drive	1
34	937225	Key - Hi-Pro	1
35	3242-2	Screw - Sq. Hd. Set	2
36	110769	Spring - Brake Return	1
37	322-5	Bolt - Brake Stop	1
38	915112	Nut - Lock	1
39	3256-23	Washer - Flat	1
40	78-2030	Collar	1

PEERLESS TRANSMISSION MODEL NO. 930-020 (210-5 & 212-5)




PEERLESS TRANSMISSION MODEL NO. 930-020 (210-5 & 212-5)

Ref. No.	Part No.	Description	No. Used
1	772108	Cover - Transaxle	1
2	780086	Bearing - Needle	2
3	770102	Case - Transaxle	1
4	776260	Shaft - Counter	1
5	776219	Output Shaft & Pinion Assy.	1
6	778139	Gear - Output	
7	778136	Gear - Spur (15 teeth)	1
8	792136	Key - Shifter	2
9	784352	Collar - Shifter	1
10	784354	Shift Rod & Fork Assy.	1
11	778229	Gear - Bevel (42 teeth)	1
12	778113A	Bevel Pinion - Input	1
13	778221	Gear - Bevel	2
14	778068	Gear - Bevel Pinion	2
15	778260	Gear - Ring	1
16	786139	Pin - Drive	1
18	786102	Spacer	1
20	792077	Ball - Steel	1
21	792078	Set Screw	1
22	792079	Spring	1
23	788061	Ring - Seal	2
25	792073	Screw - Flanged Hex. Hd.	17
26	792125	Ring - Retainer (Pkg. of 2)	4
27	792035	Ring - Retainer	1
28	788040	Ring - Retainer	1
29	780072	Washer - Thrust	5
30	780108	Washer - Thrust	4
31	780001	Washer	4
32	792001	Seal - O-Ring	1
33	788051	Seal - Square Cut	1
34	780105A	Bushing - Flanged	4
35	780118A	Bushing - Flanged	2
36	790003	Disk - Brake	1
37	790007	Plate - Brake Pad	1
38	790006	Pad - Brake	2

Ref. No.	Part No.	Description	No. Used
39	786026	Pin - Dowel	2
40	792076	Washer - Flat	1
41	790039	Lever - Brake	1
42	792073	Screw - Flanged Hex Hd.	2
43	792075	Nut - Lock	1
44	790025	Holder - Brake Pad	1
45	776315A	Shaft - Brake (4-keyed)	1
46	776135	Shaft - Input	1
47	774688	Axle (11-5/8" long)	1
48	774747	Axle (16-1/4" long)	1
49	778191	Gear - Spur (37 teeth)	1
50	778125	Gear - Spur (35 teeth)	1
51	778124A	Gear - Spur (30 teeth)	1
52	778123A	Gear - Spur (25 teeth)	1
53	778121A	Gear - Spur (20 teeth)	1
54	778230	Gear - Spur (12 teeth)	1
55	778151	Gear - Spur (15 teeth)	1
56	778126A	Gear - Spur (20 teeth)	1
57	778127A	Gear - Spur (25 teeth)	1
58	778129A	Gear - Spur (30 teeth)	1
60	786062A	Chain - Roller	1
61	786061	Sprocket (10 teeth)	1
62	786124	Sprocket (14 teeth)	1
64	792074	Plug - Hex. Hd.	1
65	780109	Washer - Thrust	1
68	786086	Bracket - Brake Lever	1
69	780051	Washer - Thrust	2
70	786118	Spacer	1
71	788069	Seal - Square Cut	1
72	786116	Disk	1
74	786071	Spacer	1
75	786072	Spacer	1
76	780090	Washer - Thrust	1
77	788075	Ring - Retaining	1
78	788067B	Grease (32 oz. bottle)	1

BRAKE & IDLER ASSEMBLY (210-5 & 212-5)




BRAKE & IDLER ASSEMBLY (210-5 & 212-5)

Ref. No.	Part No.	Description	No. Used
1	111436	Pedal - Brake/Idler	1
2	111437	Shaft - Pedal	1
3	106288	Clamp - Shaft	2
4	110015	Spacer	1
5	111712	Washer - Wave	1
6	112984	Rod - Lock	1
7	111439	Grip	1
8	114859	Arm - Idler	1
9	111418	Bushing - Eccentric	1
10	111419	Washer	1
12	113129	Rod - Brake/Idler	1
13	111442	Pulley - Idler	1
14	111443	Guide - Belt	1
15	104525	Spacer	1

Ref. No.	Part No.	Description	No. Used
17	111445	Spring - Brake	1
18	111446	Spring - Idler	1
19	3296-29	Nut - Lock	4
20	3230-16	Bolt - Carriage	4
21	3272-16	Pin - Cotter	1
22	920215	Washer	1
23	3272-6	Pin - Cotter	3
24	3256-23	Washer	3
25	3231-25	Bolt - Carriage	1
26	3296-39	Nut - Lock	2
27	3231-33	Bolt - Carriage	1
28	3256-24	Washer	2
29	116150	Spring - Extension	1

TRANSMISSION ASSEMBLY (210-H & 212-H)




TRANSMISSION ASSEMBLY (210-H & 212-H)

Ref. No.	Part No.	Description	No. Used
1		Transmission Assembly (Eaton Model 750-032)	1
2	114433	Belt	1
3	3296-29	Nut - Lock	4
4	3256-23	Washer - Flat	8
5	322-13	Bolt	4
6	116180	Clamp - Hose	4
7	114409	Hose	1
8	114693	Hose	1
9	79-1100	Reservoir Assembly (Incl. Ref. #10-12)	1
10	114562	Cover	1
11	114563	Gasket - Cover	1
12	114564	Reservoir	1
13	937222	Key - Hi-Pro	1

Ref. No.	Part No.	Description	No. Used
14	78-2870	Pulley - Input Shaft	1
15	114638	Fan	1
16	920081	Washer - Lock	1
17	908003	Bolt	1
18	108917	Knob	1
19	116126	Cable - Push Valve	1
20	910792	Screw	2
21	915740	Nut - Lock	2
23	114400	Bracket - Reservoir	1
24	321-4	Bolt	4
25	3256-22	Washer - Flat	2
26	3296-42	Nut - Lock	4
27	8830	Clip	2
28	103995	Washer	1

TRANSMISSION LINKAGE ASSEMBLY (210-H & 212-H)




TRANSMISSION LINKAGE ASSEMBLY (210-H & 212-H)

Ref. No.	Part No.	Description	No. Used
1	114416	Plate - Neutral Return	1
2	114401	Plate - Cam	1
3	100656	Bearing - Cam Return	1
4	32120-47	E-Ring	1
5	116339	Rod - Speed Control	1
6	110189	Rod - End	1
7	3220-1	Nut - Jam	1
8	114403	Support - Cam Plate	1
9	114695	Nut - Special	1
10	100365	Washer - Spring Disc	2
11	100305	Washer - Friction	1
12	100309	Spacer - Cam	2
13	109779	Nut - Jam	2
14	911459	Bolt	1
15	114402	Spacer	1
16	116340	Arm - Motion Control	1
17	106661	Cam	1
18	109447	Gear - Spacer	1
19	114656	Support - Angle	1
20	114404	Plate - Neutral Pivot	1
21	114697	Spacer	1
22	920271	Washer - Special	1
23	104859	Spacer - Lift Link	1
25	114818	Spring	1
26	114668	Bracket - Spring	1
27	114410	Bracket - Torque	1
28	115678	Plate - Mounting	1
29	111688	Clamp	1
30	926641	Screw	1
31	114698	Spring - Brake	1
32	114666	Bracket	1
33	114670	Pivot - Brake	1
34	114663	Plate	1
35	104524	Trunnion	1
36	107677	Spring - Brake	1
37	114665	Clevis	1
38	116287	Bolt - Adjusting	1
39	32151-73	Ring - Retaining	1
43	932000	Pin - Cotter	1
46	116398	Plate - Arm	1

Ref. No.	Part No.	Description	No. Used
47	3256-23	Washer	5
48	3256-24	Washer	1
49	3256-22	Washer	1
50	3272-6	Pin - Cotter	3
51	3272-7	Pin - Cotter	1
52	3272-2	Pin - Cotter	1
53	932948	Pin - Clevis	1
54	32146-2	Nut - Lock	1
55	3296-29	Nut - Lock	3
57	3296-42	Nut - Lock	2
58	926696	Bolt	1
59	322-2	Bolt	1
60	322-3	Bolt	2
61	3231-4	Bolt - Carriage	1
62	3230-2	Bolt - Carriage	2
63	3229-2	Bolt - Carriage	1
64	926698	Screw	1
65	908016	Bolt	2
67	3253-4	Washer - Lock	4
68	32151-52	Ring - Snap	2
69	32120-50	Pin - Spirol	1
70	932948	Pin - Clevis	1
71	937082	Key - Woodruff	1
72	114821	Washer - Friction	2
73	3256-4	Washer	1
74	115677	Bracket	1
75	920259	Washer	1
76	111430	Arm	1
77	933273	Pin - Spirol	1
78	111432	Spring	1
79	3765	Washer - Shim	1
80	5666	Bushing Nylon	1
81	78-3230	Shaft	1
82	113025	Pointer	1
83	112983	Knob	1
84	117326	Spring	1
85	117325	Bracket - Spring	1
86	322-5	Screw - Cap Hex. Hd.	2
87	78-2030	Collar	1

*Not Illustrated

BRAKE & IDLER ASSEMBLY (210-H & 212-H)




BRAKE & IDLER ASSEMBLY (210-H & 212-H)

Ref. No.	Part No.	Description	No. Used
1	114418	Pedal - Brake	1
2	111437	Shaft - Pedal	1
3	106288	Clamp - Shaft	2
4	110015	Spacer	1
5	111712	Washer - Wave	1
6	114705	Rod - Lock	1
7	111070	Knob	1
8	114034	Arm - Idler	1
9	111418	Bushing - Eccentric	1
10	111419	Washer	1
12	114707	Rod - Brake	1
13	111442	Pulley - Idler	1
14	109444	Pulley - Idler	1

Ref. No.	Part No.	Description	No. Used
17	102572	Spring - Idler	1
19	3296-29	Nut - Lock	4
20	3230-1	Bolt - Carriage	4
21	3272-16	Pin - Cotter	1
22	920215	Washer	1
23	3272-6	Pin - Cotter	3
24	3256-23	Washer	3
25	3231-25	Bolt - Carriage	1
26	3296-39	Nut - Lock	3
27	3231-29	Bolt - Carriage	2
28	3256-4	Washer	2
29	3256-24	Washer - Flat	2

ENGINE PULLEY & PTO CLUTCH ASSEMBLY




ENGINE PULLEY & PTO CLUTCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	112849	Electric Clutch Assembly (Incl. Ref. #2-5)	1
2	113820	Rotor Assembly	1
3	113821	Field Assembly (Incl. Ref. #9)	1
4	113822	Armature & Pulley Assy. (Incl. Ref. #9)	1
5	113823	Spring & Nut Assembly	3

Ref. No.	Part No.	Description	No. Used
6	112843	Washer	1
7	911446	Bolt (210-5 & 210-H)	1
*	112853	Bolt (212-5 & 212-H)	1
8	112858	Pulley - Engine	1
9	114064	Bearing - Ball	2

*Not Illustrated

ENGINE FUEL & EXHAUST ASSEMBLY




ENGINE FUEL & EXHAUST ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1		Engine - 10HP (Briggs & Stratton Model No. 256707 Type 0126-01) (210-5 & 210-H)	1
2	116799	Engine - 12HP TORO Power Plus Model No. E125V Type N/1964B (212-5 & 212-H)	1
3	115391	Muffler Assembly (210-5 & 210-H)	1
4	116702	Muffler (212-5 & 212-H)	1
5	115788	Control - Throttle (210-5 & 210-H)	1
*	117256	Control - Throttle (212-5 & 212-H)	1
6	116454	Knob	1
7	112153	Fuel Tank Assembly (Incl. Ref. #8 & 9)	1
8	104047	Bushing	1
9	104048	Valve	1
10	111474	Cap - Gas	1
11	113324	Line - Fuel (210-5 & 210-H)	1
*	117225	Line - Fuel (212-5 & 212-H)	1
12	2412-98	Clamp - Hose	2
13	943420	Plug (210-5 & 210-H)	1
19	908022	Screw - Cap Hex. Hd. (210-5 & 210-H)	4

Ref. No.	Part No.	Description	No. Used
20	915662	Nut - Lock	5
22	3256-23	Washer (210-5 & 210-H) (212-5 & 212-H)	10 2
24	908001	Bolt (210-5 & 210-H)	1
25	920007	Washer	3
26	915112	Nut - Lock	1
27	910792	Screw - Pan Hd.	1
28	915740	Nut - Lock	2
29	3230-1	Bolt - Carriage	2
31	3296-29	Nut - Lock	2
32	943083	Fitting - 45° (210-5 & 210-H)	1
*	114764	Fitting - 90° (212-5 & 212-H)	1
33	NN10653	Plug - Pipe	1
34	115356	Arrester - Spark	1
35	113113	Screw - Hex. Hd.	3
37	3253-4	Washer - Lock	3
39	911652	Screw	1
40	114636	Extension - Oil Drain (212-5 & 212-H)	1
41	926696	Screw	4
42	48-7630	Bolt	2
43	111392	Clip - J	2
44	117184	Gasket (212-5 & 212-H)	1
45	803668R1	Manual - Engine (210-5 & 210-H)	1

*Not Illustrated

10HP ENGINE BRIGGS & STRATTON MODEL NO. 256707 TYPE NO. 0126-01



*REQUIRES SPECIAL TOOLS TO INSTALL.
SEE REPAIR INSTRUCTION MANUAL.

Assemblies include all parts shown in frames.

10HP ENGINE BRIGGS & STRATTON MODEL NO. 256707 TYPE NO. 0126-01





Ref. No.	Part No.	Description	No. Used
1	395705	Cylinder Assembly	1
2	399265	Bearing - Cylinder Note: Requires Special Tools for Installation.	1
3	391086	Seal - Oil	1
5	212914	Head - Cylinder	1
†7	271866	Gasket - Cylinder Head	1
8	391406	Breather Assembly	1
†9	27803	Gasket - Valve Cover	1
10	93394	Screw	1
11	280100	Tube - Breather	1
†12	271702	Gasket - Cover 1/64"	1
*†	270915	Gasket - Cover .005"	1
*†	270916	Gasket - Cover .009"	1
13	93723	Screw - Cylinder Head	1
15	91084	Plug - Oil Drain	1
16	491647	Crankshaft Note: Order Part Number 94196 For Timing Gear Key.	1
18	391784	Sump - Engine	1
20	291675	Seal - Oil	1
22	93585	Screw - Sump	1
24	222698	Key - Flywheel	1
25	394661	Piston Assy. - Standard	1
*	394662	Piston Assembly - .010" O.S.	1
*	394663	Piston Assembly - .020" O.S.	1
*	394664	Piston Assembly - .030" O.S.	1
		PISTON RING SETS: Note: For Chrome Ring Set Standard Size Order No. 392331.	
26	394665	Ring Set - Piston - Std.	1
*	391781	Ring Set - Piston - .010" O.S.	1
*	391782	Ring Set - Piston - .020" O.S.	1
*	391783	Ring Set - Piston - .030" O.S.	1
27	260924	Lock - Piston Pin	1
28	299691	Pin Assembly - Piston Standard	1
*	391286	Pin Assembly - Piston .005" O.S.	1
29	490348	Rod Assy. - Connecting Note: For Connecting Rod with .020" Undersize Crankpin Bore Order No. 490469.	1
31	222299	Lock - Connecting Rod	1
32	92909	Screw - Connecting Rod	1
33	261185	Valve - Exhaust	1
34	261462	Valve - Intake	1
35	65906	Spring - Intake Valve	1
36	26828	Spring - Exhaust Valve	1
40	221596	Retainer - Intake Valve	1
41	292260	Rotocoil - Exhaust Valve	1
42	93630	Retainer - Exhaust Valve Rotocoil	2
45	262248	Tappet - Valve	1
46	212897	Gear - Cam	1
201	262348	Link - Governor	1
209	260695	Spring - Governor	1
219	490815	Oil Slinger, Governor Gear and Bracket Assembly	1

Ref. No.	Part No.	Description	No. Used
222	491594	Plate - Governor Control	1
225	231058	Crank - Governor	1
227	490927	Lever Assy. - Governor	1
230	222450	Washer - Governor Crank	1
232	260584	Spring - Governor Link	1
265	221535	Clamp - Casing	1
284	94419	Screw - Clamp	1
304	398333	Housing - Blower	1
305	93158	Screw - Blower Housing	1
306	222744	Shield - Cylinder	1
307	93949	Screw - Cylinder Shield	1
308	222725	Cover - Cylinder Head	1
333	398811	Armature - Magneto	1
334	93381	Screw - Armature	1
337	802592	Plug - Spark	1
353	92791	Washer - Lock - Shakeproof	1
354	90576	Nut - Hex.	1
356	398808	Wire - Ground	1
358	393411	Gasket Set	1
363	19203	Puller - Flywheel	1
383	89838	Wrench - Spark Plug	1
422	223394	Clamp - Oil Filler Tube	1
520	93722	Terminal - Spade	1
523	391841	Cap and Dipstick - Oil Filler	1
524	68838	Seal - Filler Tube	1
525	280134	Tube - Oil Filler	1
534	93622	Screw - Air Cleaner	1
534A	93323	Screw - Air Cleaner	1
535	270843	Element - Air Cleaner	1
536	391786	Cleaner Assembly - Air	1
537	270853	Gasket - Air Cleaner	1
552	231597	Bushing - Governor Crank	1
562	92613	Bolt - Governor Lever	1
592	231082	Nut - Hex.	1
614	93306	Cotter - Hair Pin	1
615	93307	Retainer - E-Ring	1
635	66538	Elbow - Spark Plug	1
643	222380	Cup - Air Cleaner Support	1
643A	280118	Support - Element	1
657	93496	Screw	1
663	93572	Screw	1
741	262135	Gear - Timing	1
757	212359	Link - Counterweight	1
758	391373	Counterweight Assembly	1
759	298909	Pin - Counterweight	1
761	93875	Screw - Counterweight	1
842	270920	Seal - Oil Filler Cap	1
847	392067	Fill Group - Oil	1
635	66538	Elbow - Spark Plug	1
643	222380	Cup - Air Cleaner Support	1
643A	280118	Support - Element	1
657	93496	Screw	1
663	93572	Screw	1
741	262135	Gear - Timing	1
757	212359	Link - Counterweight	1
758	391373	Counterweight Assembly	1
759	298909	Pin - Counterweight	1
761	93875	Screw - Counterweight	1
842	270920	Seal - Oil Filler Cap	1
847	392067	Fill Group - Oil	1




*Not Illustrated

†Included in Gasket Set No. 393411

10HP ENGINE BRIGGS & STRATTON MODEL NO. 256707 TYPE NO. 0126-01 (Continued)



121 CARBURETOR OVERHAUL KIT



Assemblies include all parts shown in frames.

10HP ENGINE BRIGGS & STRATTON


MODEL NO. 256707 TYPE NO. 0126-01 (Continued)

Ref. No.	Part No.	Description	No. Used
23	391988	Flywheel and Ring Gear Assy.	1
†52	270872	Gasket - Carburetor	1
75	224061	Washer - Spring	1
78	93805	Screw	1
‡94	292681	Carburetor Idle Valve Assy.	1
95	93499	Screw - Throttle/Choke Valve	1
98	91920	Screw - Machine, Fill. Hd.	1
99	26157	Spring - Throttle Adjustment	1
101	93043	Pin - Throttle Stop	1
‡104	230896	Pin - Float Hinge	1
108	222010	Valve - Choke	1
‡118	396568	Valve - Needle	1
121	394698	Carburetor Overhaul Kit	1
123	93357	Screw - Carburetor	1
125	491562	Carburetor Assembly	1
126	391787	Body Assembly - Carburetor	1
‡127	221997	Plug - Welch	1
128	213115	Venturi - Carburetor	1
130	222433	Valve - Throttle	1
131	491006	Shaft and Lever - Throttle	1
132	211712	Stop - Throttle	1
133	299707	Float - Carburetor	1
‡134	394681	Valve - Fuel Inlet	1
136	221995	Bowl - Float	1
‡137	270511	Gasket - Float Bowl	1
‡138	222014	Washer - Float Bowl	1
141	390684	Shaft and Lever - Choke	1
‡142	299740	Nozzle - Carburetor	1
‡147	231323	Screw - Nozzle	1

Ref. No.	Part No.	Description	No. Used
186	67218	Connector - Fuel Pipe	1
187	393815	Line - Fuel (Cut to Suit)	1
188	93535	Screw	1
216	261610	Link - Choke	1
240	298090	Filter - Fuel	1
309		Motor - Starting (12 Volt) See Chart on Next Page for Replacement Parts	
332	92284	Nut - Hex.	1
423	93984	Screw	1
455	222561	Cup - Screen Mounting	1
468	222562	Screen - Flush Rotating	1
474	392595	Stator - Alternator	1
482	93621	Screw	1
601	93053	Clamp - Fuel Pipe	1
618	261116	Spring - Choke Return	1
634	270382	Washer - Choke Shaft	1
634B	271853	Washer - Throttle Shaft	1
662	222311	Bracket - Carburetor	1
663	93572	Screw	1
726	392134	Gear - Ring (Includes Mounting Parts)	1
727	395405	Cover - Starter (Includes Mounting Screws)	1
877	393537	Connector Assembly	1
883	272293	Gasket - Exhaust Pipe	1
987	398970	Seal - Throttle Shaft	1

†Included in Gasket Set No. 393411

‡Included in Carburetor Overhaul Kit No. 394698




Assemblies include all parts shown in frames.

10HP ENGINE BRIGGS & STRATTON MODEL NO. 256707 TYPE NO. 0126-01 (Continued)

Ref. No.	Part No.	Description	No. Used
309	394805	Moter & Drive Assembly	1
310	940003	Thru Bolt Assembly	1
311	395538	Brush Assembly	2
510	490421	Drive Assembly	1

Ref. No.	Part No.	Description	No. Used
544	390837	Armature Assembly	1
801	394858	Drive End Cap Assembly	1
802	395537	Commutator End Cap Assy.	1
803	393825	Housing Assembly	1




12HP ENGINE CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10666	Gasket	1
2	NN10818	Elbow - Intake	1
3	NN10668	Carburetor Assembly	1
4	NN10669	Insulator	1
5	NN10670	Gasket	2
9	79-5820	Screw - Cap Hex. Hd.	2
10	79-5830	Washer - Flat	2

Ref. No.	Part No.	Description	No. Used
12	NN10674	Clip - Link	2
14	NN10792	Screw - Hex. Washer Hd.	1
15	NN10218	Bushing	1
16	NN10794	Regulator - Voltage	1
17	NN10261	Kit - Float	1
19	NN10907	Kit - Carburetor Repair	1
20	NN10701	Stud	1

12HP ENGINE CYLINDER BLOCK ASSEMBLY




12HP ENGINE CYLINDER BLOCK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10852	Block - Cylinder	1
2	NN10626	Pin - Dowel	2
3	NN10678	Bearing - Ball	2
4	NN10569	Seal - Oil	1
5	NN10570	Bearing - Crankshaft	1
6	NN10571	Bearing - Camshaft	1
7	NN10646	Seal - Governor Shaft	1
8	79-5840	Pin - Alignment	2
9	NN10653	Plug - Pipe	1
10	NN10579	Kit - Piston (Standard) (Incl. Ref. #11 & 12)	1
*	NN10580	Kit - Piston (.25mm Oversize) (Incl. Ref. #11 & 12)	1
*	NN10581	Kit - Piston (.50mm Oversize) (Incl. Ref. #11 & 12)	1
11	NN10582	Pin - Piston	1
12	NN10583	Ring - Retaining	2
13	NN10584	Set - Piston Ring (Standard)	1
*	NN10585	Set - Piston Ring (.25mm Oversize)	1
*	NN10586	Set - Piston Ring (.50mm Oversize)	1

Ref. No.	Part No.	Description	No. Used
14	NN10587	Kit - Connecting Rod (Standard) (Incl. Ref. #15 & 16)	1
*	NN10588	Kit - Connecting Rod (.25mm Undersize) (Incl. Ref. 15 & 16)	
*	NN10589	Kit - Connecting Rod (.50mm Undersize) (Incl. Ref. #15 & 16)	1
15	NN10590	Bolt	2
16	NN10591	Washer	2
17	NN10688	Indicator (Incl. Ref. #18)	1
18	NN10323	Seal - O-Ring	1
19	NN10689	Tube	1
20	NN10690	Seal	1
21	82-1560	Screw	1
22	NN10691	Bracket - Support	1
23	82-1700	Nut - Speed	1
24	NN10740	Washer - Lock	1
25	NN10768	Nut	1

*Not Illustrated

12HP ENGINE CRANKSHAFT & CAMSHAFT ASSEMBLY




12HP ENGINE CRANKSHAFT & CAMSHAFT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10627	Camshaft Assembly (Incl. Ref. #2-5)	1
2	NN10642	Camgear Assembly	1
3	NN10643	Key - Camgear	1
4	NN10644	Pin	1
5	NN10645	Spring	1
6	NN10640	Lever	1
7	NN10641	Clip - Retaining	2
8	82-1350	Washer	1
9	NN10630	Shim - Camshaft (.50mm)	1
*	NN10631	Shim - Camshaft (.60mm)	1
*	NN10632	Shim - Camshaft (.80mm)	1
*	NN10633	Shim - Camshaft (.90mm)	1
*	NN10634	Shim - Camshaft (1.00mm)	1
*	NN10635	Shim - Camshaft (1.20mm)	1
10	NN10742	Gear - Crankshaft	1
11	NN10743	Gear - Balancer	1
12	NN10744	Crankshaft	1
13	NN10745	Key - Gear	1

Ref. No.	Part No.	Description	No. Used
14	NN10746	Shim - Crankshaft (.20mm)	1
*	NN10747	Shim - Crankshaft (.30mm)	1
*	NN10748	Shim - Crankshaft (.40mm)	1
*	NN10749	Shim - Crankshaft (.50mm)	1
*	79-5850	Shim - Crankshaft (.70mm)	1
*	79-5860	Shim - Crankshaft (.80mm)	1
15	NN10750	Plug	1
16	NN10751	Gear	1
17	NN10752	Gear	1
18	NN10753	Shaft	1
19	NN10754	Shaft	1
20	NN10755	Key - Gear	2
21	NN10756	Shim - Balancer Shaft (.50mm)	1
*	NN10757	Shim - Balancer Shaft (.60mm)	1
*	NN10758	Shim - Balancer Shaft (.70mm)	1
*	NN10759	Shim - Balancer Shaft (.80mm)	1
*	NN10760	Shim - Balancer Shaft (.90mm)	1
*	NN10761	Shim - Balancer Shaft (1.00mm)	1
*	NN10762	Shim - Balancer Shaft (1.20mm)	1

*Not Illustrated

12HP ENGINE OIL BASE & PUMP ASSEMBLY




12HP ENGINE OIL BASE & PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10680	Bolt	9
2	NN10681	Gasket - Oil Base	1
3	NN10684	Filter - Oil	1
4	NN10685	Adapter - Oil Filter	1
5	NN10675	Base - Oil	1
6	NN10133	Spring - Relief Valve	1
7	NN10572	Pump - Oil	1
8	NN10573	Cover - Oil Pump	1
9	NN10577	Screen - Oil Pickup	1
10	NN10578	Cover - Screen	1
11	NN10636	Gear - Governor	1
12	NN10637	Shaft - Governor	1
13	NN10638	Sleeve - Governor	1
14	NN10639	Stop - Governor	1
15	NN10687	Plug - Pipe	2

Ref. No.	Part No.	Description	No. Used
16	82-1130	Plug - Pipe	1
17	NN10686	Plug - Pipe	2
18	NN10575	Seal - O-Ring	1
19	NN10569	Seal - Oil	1
20	NN10534	Ball - Steel	1
21	NN10677	Bearing - Ball	1
22	NN10678	Bearing - Ball	2
23	59-0760	Plug	2
24	NN10539	Ring - Retaining	1
25	NN10628	Washer - Flat	1
26	NN10629	Washer - Flat	1
27	NN10868	Screw - Torx Pan Hd.	4
28	NN10813	Switch - Oil Pressure	1
29	NN10307	Plug - Pipe	1

12HP ENGINE CYLINDER HEAD & VALVES ASSEMBLY




12HP ENGINE CYLINDER HEAD & VALVES ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10592	Gasket - Cylinder Head	1
2	NN10593	Cylinder Head Assembly (Incl. Ref. #3-16)	1
*	NN10594	Cylinder Head Assembly (Incl. Ref. #3-6)	1
3	79-5880	Guide - Intake Valve	1
4	79-5870	Guide - Exhaust Valve	1
5		Seat - Intake Valve	1
6		Seat - Exhaust Valve	1
7	NN10597	Spring - Valve	2
8	NN10598	Valve - Intake	1
9	NN10599	Valve - Exhaust	1
10	NN10600	Retainer - Intake	1
11	NN10601	Retainer - Exhaust	1
12	NN10602	Lock - Intake	1
13	NN10603	Lock - Exhaust	1
14	NN10604	Ring	2
15	NN10605	Seal - Intake	1
16	NN10606	Washer	2
17	NN10607	Bolt	1
18	NN10608	Bolt	1

Ref. No.	Part No.	Description	No. Used
19	NN10609	Gasket	1
20	NN10610	Cover - Valve	1
21	NN10611	Fitting - 45°	1
22	NN10612	Breather	1
23	NN10613	Screw - Hex. Socket Hd.	7
24	NN10614	Washer	2
25	NN10615	Bolt	2
26	NN10616	Bolt	2
27	NN10617	Tappet	2
28	NN10618	Rod - Push	2
29	NN10619	Rocker Arm Assembly (Incl. Ref. #30 & 31)	1
30	NN10620	Screw	2
31	NN10621	Nut	2
32	NN10622	Shaft - Rocker Arm	1
33	NN10623	Washer - Rocker Arm	2
34	NN10624	Clip - Retainer	2
35	NN10625	Pin - Dowel	1
36	NN10626	Pin - Dowel (Hollow)	1
37	82-1340	Washer - Flat	7

*Not Illustrated

12HP ENGINE IGNITION ASSEMBLY




12HP ENGINE IGNITION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10735	Screw - Torx Pan Hd.	2
2	NN10734	Stator	1
3	NN10733	Bolt - Hex. Hd.	1
4	79-5890	Clamp - Cord	1
5	79-5900	Pin - Alignment	2

Ref. No.	Part No.	Description	No. Used
6	NN10820	Plug - Spark	1
7	NN10729	Lead	1
8	NN10730	Coil - Ignition	1
9	NN10731	Bolt - Hex. Hd.	2
10	NN10673	Harness - Regulator	1

12HP ENGINE AIR CLEANER ASSEMBLY




12HP ENGINE AIR CLEANER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10693	Hose - Breather	1
2	NN10694	Gasket	1
3	NN10899	Adapter	1
4	NN10872	Element	1
5	NN10697	Cover - Element	1
6	NN10698	Wrapper - Element	1
7	NN10704	Grommet	1
8	NN10703	Knob	1

Ref. No.	Part No.	Description	No. Used
10	NN10812	Clamp - Hose	2
11	82-1350	Washer - Flat	2
12	NN10702	Screw - Cap Hex. Hd.	2
13	NN10700	Knob	2
14	NN10799	Cover - Air Cleaner	1
16	79-5910	Kit - Air Cleaner (Incl. Ref. #2-8 & 13-15)	1

*Not Illustrated

12HP ENGINE GOVERNOR LINKAGE & COVER ASSEMBLY




12HP ENGINE GOVERNOR LINKAGE & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10657	Spring - Governor	1
2	NN10647	Lever - Governor	1
3	NN10816	Washer - Governor Lever	2
4	NN10648	Screw - Cap Hex. Hd.	1
5	NN10740	Washer - Lock	1
6	NN10768	Nut - Hex.	1
7	NN10674	Clip - Link	1
8	NN10651	Throttle Plate Assembly	1
9	NN10652	Screw - Machine	1
10	NN10653	Clamp - Cable	1
11	59-0720	Pin - Cotter	1
12	72-3900	Screw - Thread Forming	1
13	NN10656	Swivel - Choke Lever	1
14	59-0850	Washer - Flat	1
15	NN10658	Link - Throttle	1
16	NN10654	Spring - Choke Linkage	1
17	NN10659	Link - Choke	1

Ref. No.	Part No.	Description	No. Used
18	NN10660	Spacer	1
19	NN10661	Stud	1
20	NN10817	Screw - Thread Forming	1
21	82-1340	Washer - Flat	2
22	82-1350	Washer - Flat	2
23	NN10663	Nut - Hex.	1
24	NN10344	Ring - Retaining	1
25	NN10785	Screw - Thread Forming	1
26	NN10683	Plug - Pipe	1
27	NN10722	Housing - Cylinder Air	1
28	NN10723	Deflector - Air	1
29	NN10725	Screw - Cap Hex. Hd.	1
30	82-1340	Washer - Flat	1
31	NN10726	Screw - Cap Hex. Hd.	5
32	82-1350	Washer - Flat	6
33	NN10727	Screw - Cap Hex. Hd.	1

*Not Illustrated

12HP ENGINE FLYWHEEL & COVER ASSEMBLY




12HP ENGINE FLYWHEEL & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10711	Screen	1
2	NN10712	Blower Wheel Assembly	1
3	NN10713	Key	1
4	NN10714	Screw - Hex. Hd.	3

Ref. No.	Part No.	Description	No. Used
5	NN10715	Nut	1
6	NN10720	Housing - Blower	1
7	NN10721	Bolt	4

12HP ENGINE STARTER ASSEMBLY



12HP ENGINE STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10739	Starter	1

Ref. No.	Part No.	Description	No. Used
2	NN10738	Screw - Cap Hex. Hd.	2


DECAL & MISCELLANEOUS PARTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	117478	Decal - Hood R.H. (210-5)	1
*	117476	Decal - Hood R.H. (210-H)	1
*	117474	Decal - Hood R.H. (212-5)	1
*	117472	Decal - Hood R.H. (212-H)	1
*	117479	Decal - Hood L.H. (210-5)	1
*	117477	Decal - Hood L.H. (210-H)	1
*	117475	Decal - Hood L.H. (212-5)	1
*	117473	Decal - Hood L.H. (212-H)	1
2	117242	Decal - Made In USA	1
3	116590	Decal - Hood Rear	1
4	111327	Decal - Parking Brake	1
5	78-8440	Decal - PTO Clutch	1
6	118600	Decal - Power Plus (212-5 & 212-H)	1
7	117512	Decal - 5-Speed (210-5 & 212-5)	2
8	117511	Decal - Hydro (210-H & 212-H)	2
9	117760	Decal - Fender	1
10	78-2290	Decal - Hood Front (210-5 & 210-H)	1
*	116874	Decal - Hood Front (212-5 & 212-H)	1


Ref. No.	Part No.	Description	No. Used
13	807335	Loose Parts Package (210-5)	1
*	807336	Loose Parts Package (210-H)	1
*	807306	Loose Parts Package (212-5)	1
*	807307	Loose Parts Package (212-H)	1
14	111632	Decal - Clutch & Brake	1
15	114442	Decal - Hydro Push (210-H & 212-H)	1
16	115196	Decal - Attach-a-Matic	1
17	111926	Decal - Electrical System	1
18	115398	Decal - Maintenance	1
19	111706	Decal - Throttle	1
21	112670	Decal - Danger	1
22	120040	Decal - TORO	1
23	114944	Decal - Shift 5-Speed (210-5 & 212-5)	1
24	114051	Decal - Motion Control (210-H & 212-H)	1
25	112403	Decal - VIN Overlay	1
26	113370	Decal - PTO Adjustment	1
28	118610	Decal - Power Plus	1
33	78-8480	Decal - Ignition	1
35	78-8490	Decal - Lights (212-5 & 212-H)	1
36	78-8470	Decal - Danger	1

*Not Illustrated

WIRING DIAGRAM (210-5 & 210-H)



WIRING DIAGRAM (212-5 & 212-H)



PART NUMBER INDEX

Part No.	Description	Pg. Ref.		Part No.	Description	Pg. Ref.	
		No.	Qty.			No.	Qty.
1120	Key - Square	13	20 2	101884	Nut - Switch	9	31 1
1278	Washer - .050"	13	9 A/R	102138	Switch - Light	9	24 1
1278	Washer - .050"	13	21 4	102572	Spring - Idler	25	17 1
1278	Washer - Shim (.050")	5	22 A/R	103995	Washer	21	28 1
2844	Washer - Special	11	39 2	103995	Washer - Special	7	12 1
3023	Clip	9	59 5	104047	Bushing	29	8 1
3765	Washer - Shim	15	24 A/R	104048	Valve	29	9 1
3765	Washer - Shim	23	79 1	104524	Trunnion	23	35 1
3765	Washer - Shim (.050")	11	29 A/R	104525	Spacer	19	15 1
5108	Valve - Stem	13	5 4	104859	Spacer - Lift Link	23	23 1
5210	Washer - .015"	13	10 A/R	104869	Washer - Special	15	13 1
5210	Washer - Shim (.015")	5	* A/R	104926	Body - Connector	9	50 2
5666	Bushing Nylon	23	80 1	104962	Battery	9	1 1
5666	Bushing - Nylon	15	7 1	105302	Connector - 5 Terminal	9	41 1
5977	Bushing - Nyliner	7	38 2	105450	Tube - Inner	13	16 2
7228	Bulb - Light	7	26 2	105490	Clamp	9	74 1
8830	Clip	5	37 1	105503	Bushing	3	7 2
8830	Clip	9	58 1	105503	Spacer	1	11 2
8830	Clip	21	27 2	105842	Battery	9	* 1
19203	Puller - Flywheel	31	363 1	106288	Clamp - Shaft	19	3 2
26157	Spring - Throttle Adjustment	33	99 1	106288	Clamp - Shaft	25	3 2
26828	Spring - Exhaust Valve	31	36 1	106488	Mat - Footrest	5	7 2
27803	Gasket - Valve Cover	31	9 1	106661	Cam	23	17 1
65906	Spring - Intake Valve	31	35 1	106948	Tray - Battery	9	3 1
66538	Elbow - Spark Plug	31	635 1	107677	Spring - Brake	23	36 1
66538	Elbow - Spark Plug	31	635 1	107772	E-Ring	7	4 2
67218	Connector - Fuel Pipe	33	186 1	107831	Socket - Connector	9	79 1
68838	Seal - Filler Tube	31	524 1	108547	Reflector	7	14 2
89838	Wrench - Spark Plug	31	383 1	108790	Pulley - Transmission	15	32 1
90576	Nut - Hex.	31	354 1	108881	Nut - Lock	11	31 1
91084	Plug - Oil Drain	31	15 1	108889	Bumper	3	13 2
91920	Screw - Machine, Fill. Hd.	33	98 1	108917	Knob	21	18 1
92284	Nut - Hex.	33	332 1	109102	Fuse - 25 Amp.	9	* 1
92613	Bolt - Governor Lever	31	562 1	109154	Hubcap - Front	13	1 2
92791	Washer - Lock - Shakeproof	31	353 1	109193	Rivet - Pop	7	15 4
92909	Screw - Connecting Rod	31	32 1	109230	Retainer - Belt	5	47 1
93043	Pin - Throttle Stop	33	101 1	109261	Hubcap - Rear	13	13 2
93053	Clamp - Fuel Pipe	33	601 1	109262	Washer - .050"	13	15 6
93158	Screw - Blower Housing	31	305 1	109262	Washer - Hubcap	13	11 2
93306	Cotter - Hair Pin	31	614 1	109355	Fuse - 15 Amp.	9	43 1
93307	Retainer - E-Ring	31	615 1	109444	Pulley - Idler	25	14 1
93323	Screw - Air Cleaner	31	534A 1	109447	Gear - Spacer	23	18 1
93357	Screw - Carburetor	33	123 1	109500	Fitting - Grease	13	6 2
93381	Screw - Armature	31	334 1	109547	Hook	9	4 2
93394	Screw	31	10 1	109553	Cover - Battery Terminal	9	28 1
93496	Screw	31	657 1	109779	Nut	5	41 2
93496	Screw	31	657 1	109779	Nut - Jam	23	13 2
93499	Screw - Throttle/Choke Valve	33	95 1	109989	Spacer - Nylon	1	12 4
93535	Screw	33	188 1	109989	Spacer - Nylon	3	27 4
93572	Screw	31	663 1	110015	Spacer	19	4 1
93572	Screw	31	663 1	110015	Spacer	25	4 1
93572	Screw	33	663 1	110167	Solenoid	9	13 1
93585	Screw - Sump	31	22 1	110180	Mat - Footrest	5	* 2
93621	Screw	33	482 1	110189	Rod - End	23	6 1
93622	Screw - Air Cleaner	31	534 1	110370	Pulley - Idler	5	44 1
93630	Retainer - Exhaust Valve	31	42 2	110391	Bushing	11	18 1
93722	Terminal - Spade	31	520 1	110459	Connector - 2 Terminal	9	78 1
93723	Screw - Cylinder Head	31	13 1	110769	Spring - Brake Return	15	36 1
93805	Screw	33	78 1	111070	Knob	25	7 1
93875	Screw - Counterweight	31	761 1	111076	Wire - Solenoid/Battery	9	7 2
93875	Screw - Counterweight	31	761 1	111216	Switch - Ignition	9	22 1
93949	Screw - Cylinder Shield	31	307 1	111327	Decal - Parking Brake	55	4 1
93984	Screw	33	423 1	111392	Clip	7	10 1
94419	Screw - Clamp	31	284 1	111392	Clip - J	5	13 1
100079	Tube - Inner	13	2 2	111392	Clip - J	29	43 2
100305	Washer - Friction	23	11 1	111397	Plate - Front Axle Support	5	4 1
100309	Spacer - Cam	23	12 2	111406	Spindle - R.H.	11	7 1
100365	Washer - Spring Disc	23	10 2	111409	Spindle - L.H.	11	8 1
100571	Tie - Cable	9	27 1	111413	Shaft - Pinion	11	12 1
100656	Bearing - Cam Return	23	3 1	111417	Gear - Sector	11	13 1

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
111418	Bushing - Eccentric	11	14	1	113129	Rod - Brake/Idler	19	12	1
111418	Bushing - Eccentric	19	9	1	113324	Line - Fuel	29	11	1
111418	Bushing - Eccentric	25	9	1	113370	Decal - PTO Adjustment	55	26	1
111419	Washer	11	15	1	113820	Rotor Assembly	27	2	1
111419	Washer	19	10	1	113821	Field Assembly	27	3	1
111419	Washer	25	10	1	113822	Armature & Pulley Assy.	27	4	1
111422	Retainer	11	19	1	113823	Spring & Nut Assembly	27	5	3
111423	Rod - Drag Link	11	20	1	113852	Plate - Seat Pivot	3	3	1
111430	Arm	15	5	1	114034	Arm - Idler	25	8	1
111430	Arm	23	76	1	114051	Decal - Motion Control	55	24	1
111432	Spring	15	8	1	114064	Bearing - Ball	27	9	2
111432	Spring	23	78	1	114385	Axle - Front	11	1	1
111436	Pedal - Brake/Idler	19	1	1	114389	Fender	7	*	1
111437	Shaft - Pedal	19	2	1	114400	Bracket - Reservoir	21	23	1
111437	Shaft - Pedal	25	2	1	114401	Plate - Cam	23	2	1
111439	Grip	1	8	2	114402	Spacer	23	15	1
111439	Grip	5	48	1	114403	Support - Cam Plate	23	8	1
111439	Grip	19	7	1	114404	Plate - Neutral Pivot	23	20	1
111442	Pulley - Idler	19	13	1	114409	Hose	21	7	1
111442	Pulley - Idler	25	13	1	114410	Bracket - Torque	23	27	1
111443	Guide - Belt	19	14	1	114416	Plate - Neutral Return	23	1	1
111445	Spring - Brake	19	17	1	114417	Plate - Rear Drawbar	5	2	1
111446	Spring - Idler	19	18	1	114418	Pedal - Brake	25	1	1
111467	Panel - Console	5	9	1	114433	Belt	21	2	1
111474	Cap - Gas	29	10	1	114442	Decal - Hydro Push	55	15	1
111480	Rod	7	3	1	114443	Cable - Hood Lanyard	7	27	1
111498	Body - Connector	9	46	1	114562	Cover	21	10	1
111499	Screw - Pan Hd.	5	10	6	114563	Gasket - Cover	21	11	1
111524	Link	5	30	2	114564	Reservoir	21	12	1
111527	Spring	5	31	2	114610	Roller - Cam	5	5	2
111531	Spring	11	6	1	114636	Extension - Oil Drain	29	40	1
111536	Spring	7	5	2	114638	Fan	21	15	1
111632	Decal - Clutch & Brake	55	14	1	114656	Support - Angle	23	19	1
111682	Wire - Solenoid/Starter	9	8	1	114663	Plate	23	34	1
111684	Bucket - Light	7	23	2	114665	Clevis	23	37	1
111685	Retainer	7	24	2	114666	Bracket	23	32	1
111688	Clamp	23	29	1	114668	Bracket - Spring	23	26	1
111706	Decal - Throttle	55	19	1	114670	Pivot - Brake	23	33	1
111712	Washer - Wave	19	5	1	114693	Hose	21	8	1
111712	Washer - Wave	25	5	1	114695	Nut - Special	23	9	1
111763	Strap	5	17	2	114697	Spacer	23	21	1
111926	Decal - Electrical System	55	17	1	114698	Spring - Brake	23	31	1
112153	Fuel Tank Assembly	29	7	1	114705	Rod - Lock	25	6	1
112403	Decal - VIN Overlay	55	25	1	114707	Rod - Brake	25	12	1
112670	Decal - Danger	55	21	1	114721	Tube - Drain	9	15	1
112744	Bracket - Pivot R.H.	3	*	1	114764	Fitting - 90°	29	*	1
112745	Bracket - Pivot L.H.	3	4	1	114818	Spring	23	25	1
112757	Wire - Solenoid/Starter	9	*	1	114821	Washer - Friction	23	72	2
112837	Spring	1	5	2	114851	Plate - Frame Support	5	*	1
112837	Spring - Seat	3	22	2	114859	Arm - Idler	19	8	1
112843	Washer	27	6	1	114860	Belt - Transmission Drive	15	33	1
112847	Bracket - Support	11	3	1	114944	Decal - Shift 5-Speed	55	23	1
112849	Electric Clutch Assembly	27	1	1	114989	Bracket - L.H.	5	*	1
112850	Plate - Frame Support	5	3	1	114990	Bracket - R.H.	5	49	1
112853	Bolt	27	*	1	115042	Rod	15	11	1
112858	Pulley - Engine	27	8	1	115043	End - Rod	15	12	1
112925	Washer - Backing	7	30	1	115196	Decal - Attach-a-Matic	55	16	1
112961	Plate	3	16	2	115198	Arm - Transmission	15	10	1
112977	Support - Rear Axle	5	6	1	115204	Harness - Headlight	9	29	1
112981	Rod - Tie	11	11	1	115230	Switch - Clutch	9	73	1
112982	Strap - Torque	15	3	2	115356	Arrester - Spark	29	34	1
112983	Knob	15	9	1	115391	Muffler Assembly	29	3	1
112983	Knob	23	83	1	115398	Decal - Maintenance	55	18	1
112984	Rod - Lock	19	6	1	115413	Clevis	7	32	2
113025	Pointer	15	22	1	115414	Cable - Hood Lanyard	7	*	1
113025	Pointer	23	82	1	115677	Bracket	23	74	1
113030	Pin	11	5	2	115678	Plate - Mounting	23	28	1
113044	Tube	11	4	1	115788	Control - Throttle	29	5	1
113113	Screw - Hex. Hd.	29	35	3	115858	Clip - Snap-In	5	59	2
113116	Retainer	5	38	2					

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref.			Part No.	Description	Pg. Ref.		
		No.	No.	Qty.			No.	No.	Qty.
115860	Clip - Snap-in	5	58	1	222014	Washer - Float Bowl	33	138	1
116126	Cable - Push Valve	21	19	1	222299	Lock - Connecting Rod	31	31	1
116150	Spring - Extension	19	29	1	222311	Bracket - Carburetor	33	662	1
116180	Clamp - Hose	21	6	4	222380	Cup - Air Cleaner Support	31	643	1
116262	Socket - Light	7	25	2	222380	Cup - Air Cleaner Support	31	643	1
116287	Bolt - Adjusting	23	38	1	222433	Valve - Throttle	33	130	1
116338	Switch - Ignition	9	*	1	222450	Washer - Governor Crank	31	230	1
116339	Rod - Speed Control	23	5	1	222561	Cup - Screen Mounting	33	455	1
116340	Arm - Motion Control	23	16	1	222562	Screen - Flush Rotating	33	468	1
116397	Relay	9	80	2	222698	Key - Flywheel	31	24	1
116398	Plate - Arm	23	46	1	222725	Cover - Cylinder Head	31	308	1
116454	Knob	29	6	1	222744	Shield - Cylinder	31	306	1
116480	Coupler - Shaft	11	42	1	223394	Clamp - Oil Filler Tube	31	422	1
116590	Decal - Hood Rear	55	3	1	224061	Washer - Spring	33	75	1
116591	Headlight Bar Assembly	7	9	1	230896	Pin - Float Hinge	33	104	1
116601	Bar - Light	7	22	1	231058	Crank - Governor	31	225	1
116702	Muffler	29	4	1	231082	Nut - Hex.	31	592	1
116738	Key - Ignition	9	23	2	231323	Screw - Nozzle	33	147	1
116799	Engine - 12HP	29	2	1	231597	Bushing - Governor Crank	31	552	1
116800	Hood & Grill	7	*	1	260584	Spring - Governor Link	31	232	1
116874	Decal - Hood Front	55	*	1	260695	Spring - Governor	31	209	1
116879	Rear Wheel & Tire Assy.	13	17	2	260924	Lock - Piston Pin	31	27	1
116880	Tire - Rear	13	18	2	261116	Spring - Choke Return	33	618	1
116881	Rear Wheel Assembly	13	19	2	261185	Valve - Exhaust	31	33	1
116883	Front Wheel & Tire Assy.	13	3	2	261462	Valve - Intake	31	34	1
116884	Tire - Front	13	4	2	261610	Link - Choke	33	216	1
116885	Front Wheel Assembly	13	7	2	262135	Gear - Timing	31	741	1
116887	Bushing - Flange	13	8	4	262135	Gear - Timing	31	741	1
116892	Rear Wheel & Tire Assy.	13	24	2	262248	Tappet - Valve	31	45	1
116893	Rear Wheel Assembly	13	25	2	262348	Link - Governor	31	201	1
117142	Bracket - Fuse	5	55	1	270382	Washer - Choke Shaft	33	634	1
117184	Gasket	29	44	1	270511	Gasket - Float Bowl	33	137	1
117225	Line - Fuel	29	*	1	270843	Element - Air Cleaner	31	535	1
117242	Decal - Made In USA	55	2	1	270853	Gasket - Air Cleaner	31	537	1
117256	Control - Throttle	29	*	1	270872	Gasket - Carburetor	33	52	1
117316	Hold-Down - Battery	9	5	1	270915	Gasket - Cover .005"	31	*	1
117325	Bracket - Spring	23	85	1	270916	Gasket - Cover .009"	31	*	1
117326	Spring	23	84	1	270920	Seal - Oil Filler Cap	31	842	1
117343	Keeper - Latch	5	11	2	270920	Seal - Oil Filler Cap	31	842	1
117344	Handle Assembly	7	6	2	271702	Gasket - Cover 1/64"	31	12	1
117431	Rivet - Pop	5	12	4	271853	Washer - Throttle Shaft	33	634B	1
117432	Rivet - Pop	7	7	4	271866	Gasket - Cylinder Head	31	7	1
117472	Decal - Hood R.H.	55	*	1	272293	Gasket - Exhaust Pipe	33	883	1
117473	Decal - Hood L.H.	55	*	1	280100	Tube - Breather	31	11	1
117474	Decal - Hood R.H.	55	*	1	280118	Support - Element	31	643A	1
117475	Decal - Hood L.H.	55	*	1	280118	Support - Element	31	643A	1
117476	Decal - Hood R.H.	55	*	1	280134	Tube - Oil Filler	31	525	1
117477	Decal - Hood L.H.	55	*	1	291675	Seal - Oil	31	20	1
117478	Decal - Hood R.H.	55	1	1	292260	Rotocoil - Exhaust Valve	31	41	1
117479	Decal - Hood L.H.	55	*	1	292681	Carburetor Idle Valve Assy.	33	94	1
117511	Decal - Hydro	55	8	2	298090	Filter - Fuel	33	240	1
117512	Decal - 5-Speed	55	7	2	298909	Pin - Counterweight	31	759	1
117760	Decal - Fender	55	9	1	298909	Pin - Counterweight	31	759	1
118060	Bolt	7	35	1	299691	Pin Assembly - Piston	31	28	1
118600	Decal - Power Plus	55	6	1	299707	Float - Carburetor	33	133	1
118610	Decal - Power Plus	55	28	1	299740	Nozzle - Carburetor	33	142	1
120040	Decal - TORO	55	22	1	390684	Shaft and Lever - Choke	33	141	1
120860	Washer - .075"	13	26	6	390837	Armature Assembly	34	544	1
120930	Holder - Fuse	9	14	1	391086	Seal - Oil	31	3	1
211712	Stop - Throttle	33	132	1	391286	Pin Assembly - Piston	31	*	1
212359	Link - Counterweight	31	757	1	391373	Counterweight Assembly	31	758	1
212359	Link - Counterweight	31	757	1	391373	Counterweight Assembly	31	758	1
212897	Gear - Cam	31	46	1	391406	Breather Assembly	31	8	1
212914	Head - Cylinder	31	5	1	391781	Ring Set - Piston - .010" O.S.	31	*	1
213115	Venturi - Carburetor	33	128	1	391782	Ring Set - Piston - .020" O.S.	31	*	1
221535	Clamp - Casing	31	265	1	391783	Ring Set - Piston - .030" O.S.	31	*	1
221596	Retainer - Intake Valve	31	40	1	391784	Sump - Engine	31	18	1
221995	Bowl - Float	33	136	1	391786	Cleaner Assembly - Air	31	536	1
221997	Plug - Welch	33	127	1	391787	Body Assembly - Carburetor	33	126	1
222010	Valve - Choke	33	108	1	391841	Cap and Dipstick - Oil Filler	31	523	1

* Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
391988	Flywheel and Ring Gear Assy.	33	23	1	784352	Collar - Shifter	17	9	1
392067	Fill Group - Oil	31	847	1	784354	Shift Rod & Fork Assy.	17	10	1
392067	Fill Group - Oil	31	847	1	786026	Pin - Dowel	17	39	2
392134	Gear - Ring	33	726	1	786061	Sprocket (10 teeth)	17	61	1
392595	Stator - Alternator	33	474	1	786062A	Chain - Roller	17	60	1
393411	Gasket Set	31	358	1	786071	Spacer	17	74	1
393537	Connector Assembly	33	877	1	786072	Spacer	17	75	1
393815	Line - Fuel	33	187	1	786086	Bracket - Brake Lever	17	68	1
393825	Housing Assembly	34	803	1	786102	Spacer	17	18	1
394661	Piston Assy. - Standard	31	25	1	786116	Disk	17	72	1
394662	Piston Assembly - .010" O.S.	31	*	1	786118	Spacer	17	70	1
394663	Piston Assembly - .020" O.S.	31	*	1	786124	Sprocket (14 teeth)	17	62	1
394664	Piston Assembly - .030" O.S.	31	*	1	786139	Pin - Drive	17	16	1
394665	Ring Set - Piston - Std.	31	26	1	788040	Ring - Retainer	17	28	1
394681	Valve - Fuel Inlet	33	134	1	788051	Seal - Square Cut	17	33	1
394698	Carburetor Overhaul Kit	33	121	1	788061	Ring - Seal	17	23	2
394805	Motor & Drive Assembly	34	309	1	788067B	Grease (32 oz. bottle)	17	78	1
394858	Drive End Cap Assembly	34	801	1	788069	Seal - Square Cut	17	71	1
395405	Cover - Starter	33	727	1	788075	Ring - Retaining	17	77	1
395537	Commutator End Cap Assy.	34	802	1	790003	Disk - Brake	17	36	1
395538	Brush Assembly	34	311	2	790006	Pad - Brake	17	38	2
395705	Cylinder Assembly	31	1	1	790007	Plate - Brake Pad	17	37	1
396568	Valve - Needle	33	118	1	790025	Holder - Brake Pad	17	44	1
398333	Housing - Blower	31	304	1	790039	Lever - Brake	17	41	1
398808	Wire - Ground	31	356	1	792001	Seal - O-Ring	17	32	1
398811	Armature - Magneto	31	333	1	792035	Ring - Retainer	17	27	1
398970	Seal - Throttle Shaft	33	987	1	792073	Screw - Flanged Hex Hd.	17	42	2
399265	Bearing - Cylinder	31	2	1	792073	Screw - Flanged Hex. Hd.	17	25	17
490348	Rod Assy. - Connecting	31	29	1	792074	Plug - Hex. Hd.	17	64	1
490421	Drive Assembly	34	510	1	792075	Nut - Lock	17	43	1
490815	Oil Slinger, Governor Gear	31	219	1	792076	Washer - Flat	17	40	1
490927	Lever Assy. - Governor	31	227	1	792077	Ball - Steel	17	20	1
491006	Shaft and Lever - Throttle	33	131	1	792078	Set Screw	17	21	1
491562	Carburetor Assembly	33	125	1	792079	Spring	17	22	1
491594	Plate - Governor Control	31	222	1	792125	Ring - Retainer (Pkg. of 2)	17	26	4
491647	Crankshaft	31	16	1	792136	Key - Shifter	17	8	2
770102	Case - Transaxle	17	3	1	802592	Plug - Spark	31	337	1
772108	Cover - Transaxle	17	1	1	803668R1	Manual - Engine	29	45	1
774688	Axle (11-5/8" long)	17	47	1	807306	Loose Parts Package	55	*	1
774747	Axle (16-1/4" long)	17	48	1	807307	Loose Parts Package	55	*	1
776135	Shaft - Input	17	46	1	807335	Loose Parts Package	55	13	1
776219	Output Shaft & Pinion Assy.	17	5	1	807336	Loose Parts Package	55	*	1
776260	Shaft - Counter	17	4	1	900036	Bolt - Carriage	5	60	2
776315A	Shaft - Brake (4-keyed)	17	45	1	900036	Bolt - Carriage	15	17	2
778068	Gear - Bevel Pinion	17	14	2	900037	Bolt - Carriage	5	18	1
778113A	Bevel Pinion - Input	17	12	1	908001	Bolt	29	24	1
778121A	Gear - Spur (20 teeth)	17	53	1	908003	Bolt	21	17	1
778123A	Gear - Spur (25 teeth)	17	52	1	908016	Bolt	23	65	2
778124A	Gear - Spur (30 teeth)	17	51	1	908017	Bolt	5	29	3
778125	Gear - Spur (35 teeth)	17	50	1	908019	Bolt	5	40	1
778126A	Gear - Spur (20 teeth)	17	56	1	908022	Screw - Cap Hex. Hd.	29	19	4
778127A	Gear - Spur (25 teeth)	17	57	1	910792	Screw	21	20	2
778129A	Gear - Spur (30 teeth)	17	58	1	910792	Screw - Pan Hd.	29	27	1
778136	Gear - Spur (15 teeth)	17	7	1	910796	Screw	5	52	2
778139	Gear - Output	17	6	1	910808	Screw	7	18	2
778151	Gear - Spur (15 teeth)	17	55	1	910837	Screw	5	26	1
778191	Gear - Spur (37 teeth)	17	49	1	910948	Screw	9	71	2
778221	Gear - Bevel	17	13	2	911446	Bolt	27	7	1
778229	Gear - Bevel (42 teeth)	17	11	1	911459	Bolt	23	14	1
778230	Gear - Spur (12 teeth)	17	54	1	911652	Screw	29	39	1
778260	Gear - Ring	17	15	1	913111	Screw	7	36	1
780001	Washer	17	31	4	913111	Screw - Machine	7	29	1
780051	Washer - Thrust	17	69	2	915001	Nut - Lock	11	28	2
780072	Washer - Thrust	17	29	5	915002	Nut - Lock	11	36	2
780086	Bearing - Needle	17	2	2	915112	Nut - Lock	15	21	2
780090	Washer - Thrust	17	76	1	915112	Nut - Lock	15	38	1
780105A	Bushing - Flanged	17	34	4	915112	Nut - Lock	29	26	1
780108	Washer - Thrust	17	30	4	915551	Nut	7	8	2
780109	Washer - Thrust	17	65	1	915662	Nut - Lock	7	21	8
780118A	Bushing - Flanged	17	35	2	915662	Nut - Lock	29	20	5

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref.		Part No.	Description	Pg. Ref.	
		No.	Qty.			No.	Qty.
915732	Nut - Lock	9	2	NN10582	Pin - Piston	37	11
915740	Nut - Hex.	5	25	NN10583	Ring - Retaining	37	12
915740	Nut - Lock	5	53	NN10584	Set - Piston Ring	37	13
915740	Nut - Lock	7	28	NN10585	Set - Piston Ring	37	*
915740	Nut - Lock	7	37	NN10586	Set - Piston Ring	37	*
915740	Nut - Lock	21	21	NN10587	Kit - Connecting Rod	37	14
915740	Nut - Lock	29	28	NN10588	Kit - Connecting Rod	37	*
920004	Washer	7	19	NN10589	Kit - Connecting Rod	37	*
920007	Washer	29	25	NN10590	Bolt	37	15
920079	Washer - Lock	7	20	NN10591	Washer	37	16
920081	Washer - Lock	7	34	NN10592	Gasket - Cylinder Head	43	1
920081	Washer - Lock	21	16	NN10593	Cylinder Head Assembly	43	2
920160	Washer - Lock	9	32	NN10594	Cylinder Head Assembly	43	*
920215	Washer	19	22	NN10597	Spring - Valve	43	7
920215	Washer	25	22	NN10598	Valve - Intake	43	8
920242	Washer - Special	5	35	NN10599	Valve - Exhaust	43	9
920251	Washer - .050"	13	22	NN10600	Retainer - Intake	43	10
920259	Washer	23	75	NN10601	Retainer - Exhaust	43	11
920259	Washer - Special	9	26	NN10602	Lock - Intake	43	12
920262	Washer - Special	9	25	NN10603	Lock - Exhaust	43	13
920268	Washer	15	28	NN10604	Ring	43	14
920271	Washer - Special	23	22	NN10605	Seal - Intake	43	15
926566	Bolt	7	42	NN10606	Washer	43	16
926640	Screw - Machine	5	57	NN10607	Bolt	43	17
926641	Screw	23	30	NN10608	Bolt	43	18
926696	Bolt	23	58	NN10609	Gasket	43	19
926696	Screw	29	41	NN10610	Cover - Valve	43	20
926697	Bolt	5	61	NN10611	Fitting - 45°	43	21
926698	Screw	23	64	NN10612	Breather	43	22
926720	Screw	15	18	NN10613	Screw - Hex. Socket Hd.	43	23
932000	Pin - Cotter	23	43	NN10614	Washer	43	24
932948	Pin - Clevis	23	53	NN10615	Bolt	43	25
932948	Pin - Clevis	23	70	NN10616	Bolt	43	26
933272	Pin - Spirol	11	37	NN10617	Tappet	43	27
933273	Pin - Spirol	15	23	NN10618	Rod - Push	43	28
933273	Pin - Spirol	23	77	NN10619	Rocker Arm Assembly	43	29
937082	Key - Woodruff	23	71	NN10620	Screw	43	30
937222	Key - Hi-Pro	21	13	NN10621	Nut	43	31
937225	Key - Hi-Pro	15	34	NN10622	Shaft - Rocker Arm	43	32
938031	Bushing	5	36	NN10623	Washer - Rocker Arm	43	33
938031	Bushing	7	17	NN10624	Clip - Retainer	43	34
938050	Plug - Nylon	5	54	NN10625	Pin - Dowel	43	35
940003	Thru Bolt Assembly	34	310	NN10626	Pin - Dowel	37	2
943083	Fitting - 45°	29	32	NN10626	Pin - Dowel	43	36
943420	Plug	29	13	NN10627	Camshaft Assembly	39	1
960151	Screw - Hex. Hd.	9	37	NN10628	Washer - Flat	41	25
960152	Screw	5	50	NN10629	Washer - Flat	41	26
5-1336	Key - Square	13	23	NN10630	Shim - Camshaft	39	9
NN10133	Spring - Relief Valve	41	6	NN10631	Shim - Camshaft	39	*
NN10218	Bushing	35	15	NN10632	Shim - Camshaft	39	*
NN10261	Kit - Float	35	17	NN10633	Shim - Camshaft	39	*
NN10277	Fuse - 30 Amp.	9	*	NN10634	Shim - Camshaft	39	*
NN10307	Plug - Pipe	41	29	NN10635	Shim - Camshaft	39	*
NN10323	Seal - O-Ring	37	18	NN10636	Gear - Governor	41	11
NN10344	Ring - Retaining	49	24	NN10637	Shaft - Governor	41	12
NN10534	Ball - Steel	41	20	NN10638	Sleeve - Governor	41	13
NN10539	Ring - Retaining	41	24	NN10639	Stop - Governor	41	14
NN10569	Seal - Oil	37	4	NN10640	Lever	39	6
NN10569	Seal - Oil	41	19	NN10641	Clip - Retaining	39	7
NN10570	Bearing - Crankshaft	37	5	NN10642	Camgear Assembly	39	2
NN10571	Bearing - Camshaft	37	6	NN10643	Key - Camgear	39	3
NN10572	Pump - Oil	41	7	NN10644	Pin	39	4
NN10573	Cover - Oil Pump	41	8	NN10645	Spring	39	5
NN10575	Seal - O-Ring	41	18	NN10646	Seal - Governor Shaft	37	7
NN10577	Screen - Oil Pickup	41	9	NN10647	Lever - Governor	49	2
NN10578	Cover - Screen	41	10	NN10648	Screw - Cap Hex. Hd.	49	4
NN10579	Kit - Piston	37	10	NN10651	Throttle Plate Assembly	49	8
NN10580	Kit - Piston	37	*	NN10652	Screw - Machine	49	9
NN10581	Kit - Piston	37	*	NN10653	Clamp - Cable	49	10

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref.		Part No.	Description	Pg. Ref.	
		No.	No. Qty.			No.	No. Qty.
NN10653	Plug - Pipe	29	33 1	NN10749	Shim - Crankshaft	39	* 1
NN10653	Plug - Pipe	37	9 1	NN10750	Plug	39	15 1
NN10654	Spring - Choke Linkage	49	16 1	NN10751	Gear	39	16 1
NN10656	Swivel - Choke Lever	49	13 1	NN10752	Gear	39	17 1
NN10657	Spring - Governor	49	1 1	NN10753	Shaft	39	18 1
NN10658	Link - Throttle	49	15 1	NN10754	Shaft	39	19 1
NN10659	Link - Choke	49	17 1	NN10755	Key - Gear	39	20 2
NN10660	Spacer	49	18 1	NN10756	Shim - Balancer Shaft	39	21 1
NN10661	Stud	49	19 1	NN10757	Shim - Balancer Shaft	39	* 1
NN10663	Nut - Hex.	49	23 1	NN10758	Shim - Balancer Shaft	39	* 1
NN10666	Gasket	35	1 1	NN10759	Shim - Balancer Shaft	39	* 1
NN10668	Carburetor Assembly	35	3 1	NN10760	Shim - Balancer Shaft	39	* 1
NN10669	Insulator	35	4 1	NN10761	Shim - Balancer Shaft	39	* 1
NN10670	Gasket	35	5 2	NN10762	Shim - Balancer Shaft	39	* 1
NN10673	Harness - Regulator	45	10 1	NN10768	Nut	37	25 1
NN10674	Clip - Link	35	12 2	NN10768	Nut - Hex.	49	6 1
NN10674	Clip - Link	49	7 1	NN10785	Screw - Thread Forming	49	25 1
NN10675	Base - Oil	41	5 1	NN10792	Screw - Hex. Washer Hd.	35	14 1
NN10677	Bearing - Ball	41	21 1	NN10794	Regulator - Voltage	35	16 1
NN10678	Bearing - Ball	37	3 2	NN10799	Cover - Air Cleaner	47	14 1
NN10678	Bearing - Ball	41	22 2	NN10812	Clamp - Hose	47	10 2
NN10680	Bolt	41	1 9	NN10813	Switch - Oil Pressure	41	28 1
NN10681	Gasket - Oil Base	41	2 1	NN10816	Washer - Governor Lever	49	3 2
NN10683	Plug - Pipe	49	26 1	NN10817	Screw - Thread Forming	49	20 1
NN10684	Filter - Oil	41	3 1	NN10818	Elbow - Intake	35	2 1
NN10685	Adapter - Oil Filter	41	4 1	NN10820	Plug - Spark	45	6 1
NN10686	Plug - Pipe	41	17 2	NN10852	Block - Cylinder	37	1 1
NN10687	Plug - Pipe	41	15 2	NN10868	Screw - Torx Pan Hd.	41	27 4
NN10688	Indicator	37	17 1	NN10872	Element	47	4 1
NN10689	Tube	37	19 1	NN10899	Adapter	47	3 1
NN10690	Seal	37	20 1	NN10907	Kit - Carburetor Repair	35	19 1
NN10691	Bracket - Support	37	22 1	38-1420	Switch - Seat	9	18 1
NN10693	Hose - Breather	47	1 1	48-7630	Bolt	29	42 2
NN10694	Gasket	47	2 1	59-0720	Pin - Cotter	49	11 1
NN10697	Cover - Element	47	5 1	59-0760	Plug	41	23 2
NN10698	Wrapper - Element	47	6 1	59-0850	Washer - Flat	49	14 1
NN10700	Knob	47	13 2	72-3900	Screw - Thread Forming	49	12 1
NN10701	Stud	35	20 1	78-1340	Harness Wire	9	2 1
NN10702	Screw - Cap Hex. Hd.	47	12 2	78-1630	Kit - Diode Replacement	9	16 1
NN10703	Knob	47	8 1	78-1640	Frame	5	1 1
NN10704	Grommet	47	7 1	78-1670	Cam - Adjustment	5	32 2
NN10711	Screen	51	1 1	78-1820	Hoodstand	5	8 1
NN10712	Blower Wheel Assembly	51	2 1	78-1991	Bracket - Steering Gear	11	17 1
NN10713	Key	51	3 1	78-2020	Shaft	15	6 1
NN10714	Screw - Hex. Hd.	51	4 3	78-2030	Collar	15	40 1
NN10715	Nut	51	5 1	78-2030	Collar	23	87 1
NN10720	Housing - Blower	51	6 1	78-2050	Bracket - Switch	5	56 1
NN10721	Bolt	51	7 4	78-2290	Decal - Hood Front	55	10 1
NN10722	Housing - Cylinder Air	49	27 1	78-2740	Washer - Lock	1	7 2
NN10723	Deflector - Air	49	28 1	78-2870	Pulley - Input Shaft	21	14 1
NN10725	Screw - Cap Hex. Hd.	49	29 1	78-3030	Switch - PTO	9	63 1
NN10726	Screw - Cap Hex. Hd.	49	31 5	78-3100	Wheel - Steering	11	22 1
NN10727	Screw - Cap Hex. Hd.	49	33 1	78-3210	Cover - Light Opening	7	31 1
NN10729	Lead	45	7 1	78-3221	Bracket - Steering Gear	11	* 1
NN10730	Coil - Ignition	45	8 1	78-3230	Shaft	23	81 1
NN10731	Bolt - Hex. Hd.	45	9 2	78-3390	Hoodstand	5	* 1
NN10733	Bolt - Hex. Hd.	45	3 1	78-7170	Nut - Push	7	41 1
NN10734	Stator	45	2 1	78-7180	Knob	1	4 2
NN10735	Screw - Torx Pan Hd.	45	1 2	78-7540	Fender	7	1 1
NN10738	Screw - Cap Hex. Hd.	53	2 2	78-7600	Seat	1	1 1
NN10739	Starter	53	1 1	78-8440	Decal - PTO Clutch	55	5 1
NN10740	Washer - Lock	37	24 1	78-8470	Decal - Danger	55	36 1
NN10740	Washer - Lock	49	5 1	78-8480	Decal - Ignition	55	33 1
NN10742	Gear - Crankshaft	39	10 1	78-8490	Decal - Lights	55	35 1
NN10743	Gear - Balancer	39	11 1	78-8570	Hood & Grill	7	2 1
NN10744	Crankshaft	39	12 1	78-9160	Seat	3	1 1
NN10745	Key - Gear	39	13 1	79-0050	Fender	7	* 1
NN10746	Shim - Crankshaft	39	14 1	79-0480	Harness Wire	9	* 1
NN10747	Shim - Crankshaft	39	* 1	79-1100	Reservoir Assembly	21	9 1
NN10748	Shim - Crankshaft	39	* 1	79-5820	Screw - Cap Hex. Hd.	35	9 2

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
79-5830	Washer - Flat	35	10	2	3253-3	Washer - Lock	15	27	1
79-5840	Pin - Alignment	37	8	2	3253-4	Washer - Lock	1	10	4
79-5850	Shim - Crankshaft	39	*	1	3253-4	Washer - Lock	3	24	8
79-5860	Shim - Crankshaft	39	*	1	3253-4	Washer - Lock	11	26	2
79-5870	Guide - Exhaust Valve	43	4	1	3253-4	Washer - Lock	15	20	2
79-5880	Guide - Intake Valve	43	3	1	3253-4	Washer - Lock	23	67	4
79-5890	Clamp - Cord	45	4	1	3253-4	Washer - Lock	29	37	3
79-5900	Pin - Alignment	45	5	2	3254-2	Washer - Lock	5	21	2
79-5910	Kit - Air Cleaner	47	16	1	3255-7	Washer - Lock	9	33	2
82-1130	Plug - Pipe	41	16	1	3256-4	Washer	23	73	1
82-1340	Washer - Flat	43	37	7	3256-4	Washer	25	28	2
82-1340	Washer - Flat	49	21	2	3256-22	Washer	9	10	6
82-1340	Washer - Flat	49	30	1	3256-22	Washer	23	49	1
82-1350	Washer	39	8	1	3256-22	Washer - Flat	21	25	2
82-1350	Washer - Flat	47	11	2	3256-23	Washer	3	18	6
82-1350	Washer - Flat	49	22	2	3256-23	Washer	5	19	15
82-1350	Washer - Flat	49	32	6	3256-23	Washer	7	39	2
82-1560	Screw	37	21	1	3256-23	Washer	11	34	1
82-1700	Nut - Speed	37	23	1	3256-23	Washer	15	16	6
2412-98	Clamp - Hose	29	12	2	3256-23	Washer	19	24	3
302-5	Fitting - Grease	11	2	3	3256-23	Washer	23	47	5
321-4	Bolt	9	9	2	3256-23	Washer	25	24	3
321-4	Bolt	21	24	4	3256-23	Washer	29	22	10
322-2	Bolt	23	59	1	3256-23	Washer - Flat	15	39	1
322-3	Bolt	23	60	2	3256-23	Washer - Flat	21	4	8
322-3	Screw - Hex. Hd.	5	24	4	3256-24	Washer	5	46	2
322-4	Bolt	3	6	4	3256-24	Washer	19	28	2
322-4	Screw - Cap Hex. Hd.	11	25	2	3256-24	Washer	23	48	1
322-5	Bolt	3	2	4	3256-24	Washer - Flat	25	29	2
322-5	Bolt	3	17	6	3272-2	Pin - Cotter	23	52	1
322-5	Bolt - Brake Stop	15	37	1	3272-6	Pin - Cotter	7	40	2
322-5	Screw - Cap Hex. Hd.	1	2	4	3272-6	Pin - Cotter	15	29	1
322-5	Screw - Cap Hex. Hd.	23	86	2	3272-6	Pin - Cotter	19	23	3
322-6	Bolt	3	26	4	3272-6	Pin - Cotter	23	50	3
322-6	Bolt	15	30	1	3272-6	Pin - Cotter	25	23	3
322-6	Screw - Hex. Hd.	5	20	3	3272-7	Pin - Cotter	23	51	1
322-12	Screw - Cap Hex. Hd.	15	15	4	3272-16	Pin - Cotter	5	34	2
322-13	Bolt	21	5	4	3272-16	Pin - Cotter	19	21	1
322-41	Screw - Cap Hex. Hd.	1	3	2	3272-16	Pin - Cotter	25	21	1
323-7	Bolt	5	42	1	3272-17	Pin - Cotter	13	12	2
323-10	Bolt	5	45	1	3296-29	Nut - Lock	1	9	2
329-5	Screw - Cap Hex. Hd.	15	26	1	3296-29	Nut - Lock	3	8	6
3217-5	Nut	9	11	5	3296-29	Nut - Lock	5	16	9
3217-5	Nut - Lock	5	27	1	3296-29	Nut - Lock	15	19	5
3217-6	Nut - Hex.	3	25	4	3296-29	Nut - Lock	19	19	4
3218-1	Nut - Jam	9	39	2	3296-29	Nut - Lock	21	3	4
3220-1	Nut - Jam	23	7	1	3296-29	Nut - Lock	23	55	3
3220-2	Nut - Jam	15	25	1	3296-29	Nut - Lock	25	19	4
3229-2	Bolt - Carriage	23	63	1	3296-29	Nut - Lock	29	31	2
3229-29	Nut - Lock	11	33	3	3296-39	Nut - Lock	5	43	3
3230-1	Bolt - Carriage	25	20	4	3296-39	Nut - Lock	19	26	2
3230-1	Bolt - Carriage	29	29	2	3296-39	Nut - Lock	25	26	3
3230-2	Bolt	11	35	1	3296-42	Nut - Lock	5	51	2
3230-2	Bolt - Carriage	23	62	2	3296-42	Nut - Lock	21	26	4
3230-3	Bolt	1	6	2	3296-42	Nut - Lock	23	57	2
3230-16	Bolt - Carriage	5	15	5	32103-19	Nut - Wing	7	11	1
3230-16	Bolt - Carriage	19	20	4	32103-22	Nut - Wing	9	42	2
3230-22	Bolt	11	32	2	32120-47	E-Ring	23	4	1
3230-23	Bolt - Carriage	7	16	8	32120-50	Pin - Spirol	23	69	1
3231-4	Bolt - Carriage	23	61	1	32120-93	Ring - Retaining	5	23	1
3231-25	Bolt - Carriage	19	25	1	32120-93	Ring - Retaining	11	9	2
3231-25	Bolt - Carriage	25	25	1	32121-103	Pin - Spirol	11	27	2
3231-28	Bolt	11	30	1	32121-111	Pin - Spirol	11	41	1
3231-29	Bolt - Carriage	25	27	2	32146-2	Nut - Lock	23	54	1
3231-33	Bolt - Carriage	19	27	1	32151-36	Ring - Snap	13	27	2
3242-2	Screw - Sq. Hd. Set	15	35	2	32151-48	Ring - Snap	13	14	2
3253-3	Washer - Lock	5	28	1	32151-52	Ring - Snap	23	68	2
3253-3	Washer - Lock	9	38	2	32151-73	Ring - Retaining	23	39	1

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The 200 Series Garden Tractors have two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the 200 Series Garden Tractor, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the 200 Series Garden Tractor.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Seat Assembly (210-5 & 210-H)	1	Engine Pulley & PTO Clutch Assembly	26-27
Seat Assembly (212-5 & 212-H)	2-3	Engine Fuel & Exhaust Assembly	28-29
Frame Assembly	4-5	10hp Engine Briggs & Stratton Model No. 256707 Type No. 0126-01	30-34
Body Assembly	6-7	12hp Engine Carburetor Assembly	35
Electrical System Assembly	8-9	12hp Engine Cylinder Block Assembly	36-37
Front Axle & Steering Assembly	10-11	12hp Engine Crankshaft & Camshaft Assembly	38-39
Wheel & Tire Assembly	12-13	12hp Engine Oil Base & Pump Assembly ...	40-41
Transmission Assembly (210-5 & 212-5)	14-15	12hp Engine Cylinder Head & Valves Assembly	42-43
Peerless Transmission Model No. 930-020 (210-5 & 212-5) ...	16-17	12hp Engine Ignition Assembly	44-45
Brake & Idler Assembly (210-5 & 212-5)	18-19	12hp Engine Air Cleaner Assembly	46-47
Transmission Assembly (210-H & 212-H)	20-21	12hp Governor Linkage & Cover Assembly	48-49
Transmission Linkage Assembly (210-H & 212-H)	22-23	12hp Engine Flywheel & Cover Assembly ..	50-51
Brake & Idler Assembly (210-H & 212-H)	24-25	12hp Engine Starter Assembly	52-53
		Decal & Miscellaneous Parts Assembly ...	54-55
		Wiring Diagram (210-5 & 210-H)	56
		Wiring Diagram (212-5 & 212-H)	57
		Part Number Index	58-64

