



Groundsmaster® 4500-D and 4700-D

Groundsmaster Traction Unit

Form No. 3358-103 Rev. A

Model No. 30856—Serial No. 270000401 and Up

Model No. 30868—Serial No. 270000401 and Up

CE Compliance Set Up Instructions

Note: Determine the left and right sides of the machine from the normal operating position.

Loose Parts

Note: Use this chart as a checklist to ensure that all parts necessary for assembly have been received. Without these parts, total setup cannot be completed. Some parts may have already been assembled at the factory.

Description	Qty.	Use
Lock bracket	1	Install on hood latch for CE compliance
Screw 1/4-20 x 1/2"	1	
Washer .281 x .625	1	
Lock nut 1/4-20	1	
Lift latch	1	Install on control console for CE compliance
Latch bracket -R.H.	1	
Latch bracket -L.H.	1	
Flange lock nut 1/4-20	2	
EEC decals	2	Apply to machine for CE compliance.
EEC certificate	2	

Installing the Hood Latch

1. Unhook the hood latch from the hood latch bracket (Fig. 1).
2. Slide the hood lock bracket onto the latch (Fig. 1).
3. Hook the latch onto the hood latch bracket (Fig. 1).
4. Insert a bolt (1/4 x 1-1/2 in.) through the hood lock bracket and secure it with a flat washer and locknut (Fig. 1).




Figure 1

1. Hood latch
2. Hood latch bracket
3. Hood lock bracket

Install Cutting Unit Lift Latch

1. Rotate latches and remove control panel cover (Fig. 2).
2. Under front of control panel, locate ends of capscrews securing control panel to frame (Fig. 2).
3. Insert left hand latch bracket up thru lift lever slot and onto capscrew. Loosely secure with 1/4–20 flange nut (Fig. 2).
4. Insert right hand latch bracket up thru lift lever slot and onto capscrew. Loosely secure with 1/4–20 flange nut (Fig. 2).
5. On top of control panel, insert each end tab of lift latch into holes in latch brackets (Fig. 2). Tighten flange nuts.




Figure 2

- | | |
|------------------------|-----------------------|
| 1. Control panel cover | 4. L.H. latch bracket |
| 2. Control panel | 5. R.H. latch bracket |
| 3. Capscrews | 6. Lift latch |