



48in and 52in Bagger Titan Zero-Turn-Radius Riding Mower

Model No. 79155 - 270000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Bagger Hood and Upper Tube Assembly	 3	Lower Tube Assembly No. 109-6769	 7
Hood Assembly No. 109-6796	 4	Bag Frame Assembly	 8
Bagger Mount Assembly No. 109-6771	 5	Bag Assembly No. 112-3994	 9
Baffle and Boot Mount Assembly	 6	Bagger Weight Assembly	 10


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head




Ref	Part No.	Qty.	Description				
1	109-1939	1	Upper Tube ASM				
1:1	103-4081	2	Latch-Keeper				
1:3	3290-500	2	Screw-PPH				
1:4	3256-14	2	Washer-Flat				
2	109-6796	1	Hood ASM				
3	104-7201	2	Nut-HF				
4	321-4	2	Screw-HH				
5	109-6771	1	Bagger Mount ASM				




Hood Assembly No. 109-6796

Ref	Part No.	Qty.	Description				
1	1-653561	1	Seal-Chute				
2	1-653598-03	1	Clamp-Seal				
3	92-1736-03	1	Support-Screen				
5	105-9100	1	Top-Bagger				
6	3250-27	4	Screw-PPH				
7	3256-61	14	Washer-Flat				
8	3296-2	4	Nut-Lock				
9	114439	26	Rivet-Pop				
10	109-6861	1	Stiffener And Decal				
10:2	109-6809	1	Decal-Caution Bagger				
11	115481-03	2	Latch-Bagger, Top				
12	115880	2	Grip				
14	114967	1	Screen-Bagger				




Bagger Mount Assembly No. 109-6771

Ref	Part No.	Qty.	Description				
1	114955-03	1	Frame ASM				
2	109-1077-03	1	Hinge-Bagger Top				
3	114960	1	Pin-Spring				
4	9790944	2	Spacer				
5	114962	2	Spring-Extension				
6	323-6	2	Screw-HH				
7	104-8301	2	Nut-Flange, NI				




Baffle and Boot Mount Assembly

Ref	Part No.	Qty.	Description
1	109-6769	1	Tube And Strap ASM
2	109-6091-03	1	Bracket-Boot Mount, 48 Inch
2	109-5387-03	1	Bracket-Boot Mount, 52 Inch
3	104-8300	3	Nut-Flange, NI
4	3230-23	3	Screw-CARR
5	109-5383-03	1	Baffle-Discharge, 52 Inch




Lower Tube Assembly No. 109-6769

Ref	Part No.	Qty.	Description				
1	109-5381	1	Boot-Lower				
2	103-4080	2	Latch-Rubber				
3	3290-500	4	Screw-PPH				
4	3256-14	16	Washer-Flat				
5	109-6089-03	1	Boot Frame ASM				
6	1-353054	1	Latch-Catcher, Grass				
7	323-6	1	Screw-HH				
8	3296-59	1	Nut-Lock, NI				
9	32105-13	6	Screw-SHH				
10	3296-2	6	Nut-Lock				




Bag Frame Assembly

Ref	Part No.	Qty.	Description				
1	109-6094-03	1	Bagger Hitch ASM				
2	109-5379-03	2	Tube-Hitch, Bagger				
3	109-6092-03	4	Plate-Stiffener				
4	109-6093-03	2	Plate-Stiffener				
5	104-8301	8	Nut-Flange, NI				
6	109-6795	4	Bolt-Carriage				
7	3231-10	4	Screw-CARR				
8	112-3994	2	Bag ASM				



Bag Assembly No. 112-3994

Ref	Part No.	Qty.	Description
1	114972-03	1	Frame-Bag
2	112-4012-03	1	Hanger ASM
3	114974-03	1	Clamp
4	3230-1	2	Bolt-CARR
5	3296-29	2	Nut-Lock, NI
6	110-6674	1	Bag



Bagger Weight Assembly

Ref	Part No.	Qty.	Description				
1	109-6494-03	1	Weight-Bagger, 25 Lb				
2	109-6767	1	Bracket And Bumper ASM				
2:2	100-6547	2	Cushion-Rubber				
3	109-6107	1	Rod-Weight Lock				
4	3274-94	2	Screw-HSBH				
5	104-8301	2	Nut-Flange, NI				

NOTES

