




MODEL NO. R2120E01-1000001 & UP
MODEL NO. R2120501-1000001 & UP

PARTS CATALOG

WHEEL HORSE® 200 SERIES GARDEN TRACTOR




C-0950

BODY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	114389	Fender	1
2	116800	Hood & Grill	1
6	117344	Handle Assembly	2
7	117432	Rivet - Pop	4
8	915551	Nut (Optional)	2
9	116591	Headlight Bar Assembly (Incl. Ref. #22-24 & 26)	1
10	111392	Clip	1
11	32103-19	Nut - Wing	1
12	103995	Washer - Special	1
14	108547	Reflector	2
15	109193	Rivet - Pop	4
16	3230-23	Bolt - Carriage	4
17	938031	Bushing	1
18	910808	Screw (Optional)	4

Ref. No.	Part No.	Description	No. Used
20	920079	Washer - Lock (Optional)	4
21	3217-6	Nut - Lock	4
22	116601	Bar - Light	1
23	111684	Bucket - Light	1
24	111685	Retainer	1
25	116262	Socket - Light	1
26	7228	Bulb - Light	2
27	115414	Cable - Hood Lanyard	1
28	915740	Nut - Lock	1
29	913111	Screw - Machine	2
30	112925	Washer - Backing	1
32	115413	Clevis	2
38	5977	Bushing - Nyliner	2
39	3256-23	Washer	2
40	3272-6	Pin - Cotter	2
41	3230-2	Screw - Carriage	4

SEAT ASSEMBLY




SEAT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	76-0670	Seat	1
2	322-5	Bolt	4
3	113852	Plate - Seat Pivot	1
4	112745	Bracket - Pivot L.H.	1
*	112744	Bracket - Pivot R.H.	1
6	322-4	Bolt	4
7	105503	Bushing	2
8	3296-29	Nut - Lock	6
13	108889	Bumper	2

Ref. No.	Part No.	Description	No. Used
16	112961	Plate	2
17	322-5	Bolt	6
18	3256-23	Washer	8
22	112837	Spring - Seat	2
24	3253-4	Washer - Lock	8
25	3217-6	Nut - Hex.	4
26	322-6	Bolt	2
27	109989	Spacer - Nylon	4

*Not Illustrated

FRAME ASSEMBLY




FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	78-1640	Frame	1
2	114417	Plate - Rear Drawbar	1
3	112850	Plate - Frame Support (212-H)	1
4	111397	Plate - Front Axle Support	1
5	114610	Roller - Cam	2
6	112977	Support - Rear Axle	1
7	110180	Mat - Footrest	2
8	78-8430	Hoodstand	1
9	111467	Panel - Console	1
10	111499	Screw - Pan Hd.	4
11	117343	Keeper - Latch	2
12	117431	Rivet - Pop	4
15	3230-16	Bolt - Carriage (212-5)	7
		(212-H)	11
16	3296-29	Nut - Lock	13
19	3256-23	Washer	14
20	322-6	Screw - Hex. Hd.	2
21	3254-2	Washer - Lock	2
22	1278	Washer - Shim (.050")	A/R
*	5210	Washer - Shim (.015")	A/R
23	32120-93	Ring - Retaining	1
24	322-3	Screw - Hex. Hd.	4
25	915740	Nut - Hex.	4
26	910837	Screw	1
27	3217-5	Nut - Lock	1
28	3253-3	Washer - Lock	1
30	111524	Link	2
31	111527	Spring	2
32	78-1670	Cam - Adjustment	2
34	3272-16	Pin - Cotter	2
35	920242	Washer - Special	2

Ref. No.	Part No.	Description	No. Used
36	938031	Bushing	1
37	8830	Clip (212-5)	1
		(212-H)	2
38	113116	Retainer	2
41	109779	Nut	2
42	323-7	Bolt	1
43	3296-39	Nut - Lock	2
44	110370	Pulley - Idler (212-5)	1
45	323-10	Bolt	1
46	3256-24	Washer	2
47	109230	Retainer - Belt	1
48	111439	Grip	1
49	114989	Bracket - L.H.	1
*	114990	Bracket - R.H.	1
50	960152	Screw	2
51	3296-42	Nut - Lock	2
52	910796	Screw	2
53	915740	Nut - Lock	2
54	938050	Plug - Nylon	2
55	117142	Bracket - Fuse	1
56	78-2050	Bracket - Switch	1
57	926640	Screw - Machine	2
58	115860	Clip - Snap-In	1
59	115858	Clip - Snap-In	2
60	900036	Bolt - Carriage	2
61	926697	Bolt	4
62	915112	Nut - Hex.	2
63	114851	Plate - Frame Support (212-5)	1
64	106634	Pin - Tool	1
65	933505	Pin - Hair	1

*Not Illustrated

ELECTRICAL SYSTEM ASSEMBLY




ELECTRICAL SYSTEM ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	104962	Battery (212-5)	1
*	105842	Battery (212-H)	1
2	79-0500	Harness Wire (Incl. Ref. #14, 41 & 46)	1
3	106948	Tray - Battery	1
4	109547	Hook	2
5	117316	Hold-Down - Battery	1
7	111076	Wire - Solenoid/Battery	1
8	112757	Wire - Solenoid/Starter	1
9	321-4	Bolt	2
10	3256-22	Washer	4
11	3217-5	Nut	2
14	120930	Holder - Fuse	1
15	114721	Tube - Drain	1
18	38-1420	Switch - Seat	1
22	116338	Switch - Ignition (Incl. Ref. #31-32)	1
23	116738	Key - Ignition	2
24	102138	Switch - Light (Incl. Ref. #64 & 65)	1
25	920262	Washer - Special	1
26	920259	Washer - Special	1
27	100571	Tie - Cable	1
28	109553	Cover - Battery Terminal	1

Ref. No.	Part No.	Description	No. Used
29	115204	Harness - Headlight	1
31	101884	Nut - Switch	1
32	920160	Washer - Lock	1
38	3253-3	Washer - Lock	2
41	105302	Connector - 5 Terminal	1
42	32103-22	Nut - Wing	2
43	109355	Fuse - 15 Amp.	1
*	109102	Fuse - 25 Amp.	1
*	NN10277	Fuse - 30 Amp.	1
46	111498	Body - Connector	2
50	104926	Body - Connector	2
59	3023	Clip	4
63	78-3030	Switch - PTO	1
64	113179	Nut - Hex.	1
65	102950	Washer - Tab	1
66	78-0020	Hourmeter	1
67	78-3320	Clamp - Hourmeter	1
68	3253-15	Washer - Lock	2
69	915564	Nut - Hex.	2
71	910948	Screw	2
72	915732	Nut - Lock	2
73	115230	Switch - Clutch	1
74	105490	Clamp	1
79	107831	Socket - Connector	1
80	116397	Relay	3

*Not Illustrated

FRONT AXLE & STEERING ASSEMBLY




FRONT AXLE & STEERING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	114385	Axle - Front	1
2	302-5	Fitting - Grease	3
3	112847	Bracket - Support	1
4	113044	Tube	1
5	113030	Pin	2
6	111531	Spring	1
7	111406	Spindle - R.H.	1
8	111409	Spindle - L.H.	1
9	32120-93	Ring - Retaining	2
11	112981	Rod - Tie	1
12	111413	Shaft - Pinion	1
13	111417	Gear - Sector	1
14	111418	Bushing - Eccentric	1
15	111419	Washer	1
17	78-1991	Bracket - Steering Gear (212-5)	1
*	78-3221	Bracket - Steering Gear (212-H)	1
18	110391	Bushing	1

Ref. No.	Part No.	Description	No. Used
19	111422	Retainer	1
20	111423	Rod - Drag Link	1
22	78-3100	Wheel - Steering	1
25	322-4	Screw - Cap Hex. Hd.	2
26	3253-4	Washer - Lock	2
27	32121-103	Pin - Spirol	2
28	915001	Nut - Lock	2
29	3765	Washer - Shim (.050")	A/R
30	3231-28	Bolt	1
31	108881	Nut - Lock	1
32	3230-22	Bolt	2
33	3229-29	Nut - Lock	3
34	3256-23	Washer	1
35	3230-2	Bolt	1
36	915002	Nut - Lock	2
37	933272	Pin - Spirol	1
39	2844	Washer - Special	2
41	32121-111	Pin- Spirol	1
42	116480	Coupler - Shaft	1

*Not Illustrated

WHEEL & TIRE ASSEMBLY




C-0903

WHEEL & TIRE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	109154	Hubcap	2
2	100079	Tube - Inner	2
3	116883	Front Wheel & Tire Assy. (Incl. Ref. #4-8)	2
4	116884	Tire - Front	2
5	5108	Valve - Stem	4
6	109500	Fitting - Grease	2
7	116885	Front Wheel Assembly (Incl. Ref. #5, 6 & 8)	2
8	116887	Bushing - Flange	4
9	1278	Washer - .050"	A/R
10	5210	Washer - .015"	A/R
11	109262	Washer - Hubcap	2
12	3272-17	Pin - Cotter	2
13	109261	Hubcap	2
14	32151-48	Ring - Snap	2
15	109262	Washer - .050"	6

Ref. No.	Part No.	Description	No. Used
16	105450	Tube - Inner	2
17	116879	Rear Wheel & Tire Assy. (Incl. Ref. #5, 18 & 19)	2
18	116880	Tire - Rear	2
19	116881	Rear Wheel Assembly (Incl. Ref. #5)	2
20	1120	Key - Square	2
21	1278	Washer - .050"	4
22	920251	Washer - .050"	4
23	5-1336	Key - Square	2
24	116892	Rear Wheel & Tire Assy. (Incl. Ref. #5, 16 & 25)	2
25	116893	Rear Wheel Assembly (Incl. Ref. #5)	2
26	120860	Washer - .075"	6
27	32151-36	Ring - Snap	2

TRANSMISSION ASSEMBLY (212-5)




TRANSMISSION ASSEMBLY (212-5)

Ref. No.	Part No.	Description	No. Used
2		Transmission Assembly (Peerless Model 930-020)	1
3	112982	Strap - Torque	2
5	111430	Arm	1
6	78-2020	Shaft	1
7	5666	Bushing - Nylon	1
8	111432	Spring	1
9	112983	Knob	1
10	115198	Arm - Transmission	1
11	115042	Rod	1
12	115043	End - Rod	1
13	104869	Washer - Special	1
15	322-12	Screw - Cap Hex. Hd.	4
16	3256-23	Washer	8
17	900036	Bolt - Carriage	2
18	926720	Screw	2
19	3296-29	Nut - Lock	5
20	3253-4	Washer - Lock	2
21	915112	Nut - Lock	2

Ref. No.	Part No.	Description	No. Used
22	113025	Pointer	1
23	933273	Pin - Spirol	1
24	3765	Washer - Shim	A/R
25	3220-2	Nut - Jam	1
26	329-5	Screw - Cap Hex. Hd.	1
27	3253-3	Washer - Lock	1
28	920268	Washer	1
29	3272-6	Pin - Cotter	1
30	322-6	Bolt	1
32	116120	Pulley - Transmission	1
33	114860	Belt - Transmission Drive	1
34	937225	Key	1
35	3242-2	Screw - Sq. Hd. Set	2
36	110769	Spring - Brake Return	1
37	322-5	Bolt - Brake Stop	1
38	915112	Nut - Lock	1
39	3256-23	Washer - Flat	1
40	78-2030	Collar	1


PEERLESS TRANSMISSION MODEL NO. 930-020 (212-5)



PEERLESS TRANSMISSION MODEL NO. 930-020 (212-5)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	772108	Cover - Transaxle	1	39	786026	Pin - Dowel	2
2	780086	Bearing - Needle	2	40	792076	Washer - Flat	1
3	770102	Case - Transaxle	1	41	790039	Lever - Brake	1
4	776260	Shaft - Counter	1	42	792073	Screw - Flanged Hex Hd.	2
5	776219	Output Shaft & Pinion Assy.	1	43	792075	Nut - Lock	1
6	778139	Gear - Output		44	790025	Holder - Brake Pad	1
7	778136	Gear - Spur (15 teeth)	1	45	776315A	Shaft - Brake (4-keyed)	1
8	792136	Key - Shifter	2	46	776135	Shaft - Input	1
9	784352	Collar - Shifter	1	47	774688	Axle (11-5/8" long)	1
10	784354	Shift Rod & Fork Assy.	1	48	774747	Axle (16-1/4" long)	1
11	778229	Gear - Bevel (42 teeth)	1	49	778191	Gear - Spur (37 teeth)	1
12	778113A	Bevel Pinion - Input	1	50	778125	Gear - Spur (35 teeth)	1
13	778221	Gear - Bevel	2	51	778124A	Gear - Spur (30 teeth)	1
14	778068	Gear - Bevel Pinion	2	52	778123A	Gear - Spur (25 teeth)	1
15	778260	Gear - Ring	1	53	778121A	Gear - Spur (20 teeth)	1
16	786139	Pin - Drive	1	54	778230	Gear - Spur (12 teeth)	1
18	786102	Spacer	1	55	778151	Gear - Spur (15 teeth)	1
20	792077	Ball - Steel	1	56	778126A	Gear - Spur (20 teeth)	1
21	792078	Set Screw	1	57	778127A	Gear - Spur (25 teeth)	1
22	792079	Spring	1	58	778129A	Gear - Spur (30 teeth)	1
23	788061	Ring - Seal	2	60	786062A	Chain - Roller	1
25	792073	Screw - Flanged Hex. Hd.	17	61	786061	Sprocket (10 teeth)	1
26	792125	Ring - Retainer (Pkg. of 2)	4	62	786124	Sprocket (14 teeth)	1
27	792035	Ring - Retainer	1	64	792074	Plug - Hex. Hd.	1
28	788040	Ring - Retainer	1	65	780109	Washer - Thrust	1
29	780072	Washer - Thrust	5	68	786086	Bracket - Brake Lever	1
30	780108	Washer - Thrust	4	69	780051	Washer - Thrust	2
31	780001	Washer	4	70	786118	Spacer	1
32	792001	Seal - O-Ring	1	71	788069	Seal - Square Cut	1
33	788051	Seal - Square Cut	1	72	786116	Disk	1
34	780105A	Bushing - Flanged	4	74	786071	Spacer	1
35	780118A	Bushing - Flanged	2	75	786072	Spacer	1
36	790003	Disk - Brake	1	76	780090	Washer - Thrust	1
37	790007	Plate - Brake Pad	1	77	788075	Ring - Retaining	1
38	790006	Pad - Brake	2	78	788067B	Grease (32 oz. bottle)	1

SWEEPER P.T.O. ASSEMBLY (212-5)




SWEEPER P.T.O. ASSEMBLY (212-5)

Ref. No.	Part No.	Description	No. Used
1	119350	Guide - Belt	1
2	3256-23	Washer - Flat	4
3	322-5	Screw - Cap Hex. Hd.	1
4	3253-3	Washer - Lock	3
5	321-2	Screw - Cap Hex. Hd.	3
6	3242-2	Screw - Set	1
7	6366	Key - Square	1
8	3253-21	Washer - Lock	1
9	323-6	Screw - Cap Hex. Hd.	1
10	2844	Washer	1
11	114740	Pulley	1
12	114741	Spacer - Shaft	1
13	1-2533	Cup - Bearing	1
14	322-3	Screw - Cap Hex. Hd.	5
15	114686	Plate - Mounting	1
16	102534	Bearing - Ball	1
17	102536	Bering Cup & Nuts	1
18	116119	Shjaft - Drive	1
19	920267	Washer - Special	2

Ref. No.	Part No.	Description	No. Used
20	3296-29	Nut - Lock	7
21	3296-42	Nut - Lock	4
22	114762	Spacer - Rubber	2
23	114756	Block - Rubber	2
24	910842	Screw - Pan Hd.	4
25	3296-39	Nut - Lock	6
26	116784	Bar - Pivot	2
27	114757	Spacer	2
28	323-7	Screw - Cap Hex. Hd.	4
29	915112	Nut - Hex.	2
30	114723	Bracket - L.H.	1
*	114724	Bracket - R.H.	1
31	106634	Pin - Tool	2
32	933505	Pin - Cotter Hair	2
33	3231-25	Bolt - Carriage	2
34	117389	Brace - L.H.	1
*	117390	Brace - R.H.	1
35	1336	Washer	2

*Not Illustrated

BRAKE & IDLER ASSEMBLY (212-5)




BRAKE & IDLER ASSEMBLY (212-5)

Ref. No.	Part No.	Description	No. Used
1	111436	Pedal - Brake/Idler	1
2	111437	Shaft - Pedal	1
3	106288	Clamp - Shaft	2
4	110015	Spacer	1
5	111712	Washer - Wave	1
6	112984	Rod - Lock	1
7	111439	Grip	1
8	114859	Arm - Idler	1
9	111418	Bushing - Eccentric	1
10	111419	Washer	1
12	113129	Rod - Brake/Idler	1
13	111442	Pulley - Idler	1
14	111443	Guide - Belt	1
15	104525	Spacer	1

Ref. No.	Part No.	Description	No. Used
17	111445	Spring - Brake	1
18	111446	Spring - Idler	1
19	3296-29	Nut - Lock	4
20	3230-16	Bolt - Carriage	4
21	3272-16	Pin - Cotter	1
22	920215	Washer	1
23	3272-6	Pin - Cotter	3
24	3256-23	Washer	3
25	3231-25	Bolt - Carriage	1
26	3296-39	Nut - Lock	2
27	3231-33	Bolt - Carriage	1
28	3256-24	Washer	2
29	116150	Spring - Extension	1

TRANSMISSION ASSEMBLY (212-H)




C-0956

TRANSMISSION ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used
1		Transmission Assembly (Eaton Model 750-019)	1
2	114433	Belt	1
3	3296-29	Nut - Lock	4
4	3256-23	Washer - Flat	8
5	322-13	Bolt	4
6	116180	Clamp - Hose	4
7	114409	Hose	1
8	114693	Hose	1
9	79-1100	Reservoir Assembly (Incl. Ref. #10-12)	1
10	79-1080	Cover	1
11	114563	Gasket - Cover	1
12	114564	Reservoir	1

Ref. No.	Part No.	Description	No. Used
13	937222	Key - Hi-Pro	1
14	115688	Pulley - Input Shaft	1
15	115687	Fan	1
18	108917	Knob	1
19	116126	Cable - Push Valve	1
20	910792	Screw	2
21	915740	Nut - Lock	2
23	116007	Bracket - Reservoir	1
24	321-4	Bolt	4
25	3256-22	Washer - Flat	2
26	3296-42	Nut - Lock	4
27	8830	Clip	2
28	911910	Screw - Flat Hd.	2

SWEEPER P.T.O. ASSEMBLY (212-H)




SWEEPER P.T.O. ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used
1	115686	Pulley - Drive	1
2	115191	Guide - Belt	1
3	3256-23	Washer - Flat	7
4	3272-2	Pin - Cotter	1
5	114812	Spacer	1
6	113589	Tie - Plastic	2
7	2534	Clip - Spring	2
8	322-5	Screw - Cap Hex. Hd.	3
9	115990	Guide - Belt	1
10	3253-3	Washer - Lock	1
11	908011	Screw - Cap Hex. Hd.	1
12	115968	Belt - V	1
13	321-4	Screw - Cap Hex. Hd.	2
14	116005	Shoe - Belt	1
15	3256-22	Washer - Flat	2
16	3296-42	Nut - Lock	6
17	114762	Spacer - Rubber	2
18	114756	Block - Rubber	2

Ref. No.	Part No.	Description	No. Used
19	910842	Screw - Pan Hd.	4
20	3296-39	Nut - Lock	6
21	116784	Bar - Pivot	2
22	114757	Spacer	2
23	323-7	Screw - Cap Hex. Hd.	4
24	915112	Nut - Hex.	2
25	114723	Bracket - L.H.	1
*	114724	Bracket - R.H.	1
26	3296-29	Nut - Lock	6
27	106634	Pin - Tool	2
28	933505	Pin - Cotter Hair	2
29	117389	Brace - L.H.	1
*	117390	Brace - R.H.	1
30	3231-25	Bolt - Carriage	2
31	1336	Washer	2
32	920267	Washer - Special	2
33	322-3	Screw - Cap Hex. Hd.	2
34	937222	Key - Hi-Pro	1

*Not Illustrated

TRANSMISSION LINKAGE ASSEMBLY (212-H)




TRANSMISSION LINKAGE ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used
1	114416	Plate - Neutral Return	1
2	114401	Plate - Cam	1
3	100656	Bearing - Cam Return	1
4	32120-47	E-Ring	1
5	116339	Rod - Speed Control	1
6	110189	Rod - End	1
7	3220-1	Nut - Jam	1
8	114403	Support - Cam Plate	1
9	114695	Nut - Special	1
10	100365	Washer - Spring Disc	2
11	100305	Washer - Friction	1
12	100309	Spacer - Cam	2
13	109779	Nut - Jam	2
14	911459	Bolt	1
15	114402	Spacer	1
16	116340	Arm - Motion Control	1
17	106661	Cam	1
18	109447	Gear - Spacer	1
19	114656	Support - Angle	1
20	114404	Plate - Neutral Pivot	1
21	114697	Spacer	1
22	920271	Washer - Special	1
23	104859	Spacer - Lift Link	1
25	114818	Spring	1
26	114668	Bracket - Spring	1
27	114410	Bracket - Torque	1
28	115678	Plate - Mounting	1
29	111688	Clamp	1
30	926641	Screw	1
31	114698	Spring - Brake	1
32	114666	Bracket	1
33	114670	Pivot - Brake	1
34	114663	Plate	1
35	104524	Trunnion	1
36	107677	Spring - Brake	1
37	114665	Clevis	1
38	116287	Bolt - Adjusting	1
39	32151-73	Ring - Retaining	1
43	932000	Pin - Cotter	1
46	116398	Plate - Arm	1

Ref. No.	Part No.	Description	No. Used
47	3256-23	Washer	5
48	3256-24	Washer	1
49	3256-22	Washer	1
50	3272-6	Pin - Cotter	3
51	3272-7	Pin - Cotter	1
52	3272-2	Pin - Cotter	1
53	932948	Pin - Clevis	1
54	32146-2	Nut - Lock	1
55	3296-29	Nut - Lock	3
57	3296-42	Nut - Lock	2
58	926696	Bolt	1
59	322-2	Bolt	1
60	322-3	Bolt	2
61	3231-4	Bolt - Carriage	1
62	3230-2	Bolt - Carriage	2
63	3229-2	Bolt - Carriage	1
64	926698	Screw	1
65	908016	Bolt	2
67	3253-4	Washer - Lock	4
68	32151-52	Ring - Snap	2
69	32120-50	Pin - Spirol	1
70	932948	Pin - Clevis	1
71	937082	Key - Woodruff	1
72	114821	Washer - Friction	2
73	3256-4	Washer	1
74	115677	Bracket	1
75	920259	Washer	1
76	111430	Arm	1
77	933273	Pin - Spirol	1
78	111432	Spring	1
79	3765	Washer - Shim	1
80	5666	Bushing Nylon	1
81	78-3230	Shaft	1
82	113025	Pointer	1
83	112983	Knob	1
84	117326	Spring	1
85	117325	Bracket - Spring	1
86	322-5	Screw - Cap Hex. Hd.	2
87	78-2030	Collar	1

*Not Illustrated

BRAKE & IDLER ASSEMBLY (212-H)




BRAKE & IDLER ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used
1	114418	Pedal - Brake	1
2	111437	Shaft - Pedal	1
3	106288	Clamp - Shaft	2
4	110015	Spacer	1
5	111712	Washer - Wave	1
6	114705	Rod - Lock	1
7	111070	Knob	1
8	114034	Arm - Idler	1
9	111418	Bushing - Eccentric	1
10	111419	Washer	1
12	114707	Rod - Brake	1
13	111442	Pulley - Idler	1
14	109444	Pulley - Idler	1

Ref. No.	Part No.	Description	No. Used
17	102572	Spring - Idler	1
19	3296-29	Nut - Lock	4
20	3230-1	Bolt - Carriage	4
21	3272-16	Pin - Cotter	1
22	920215	Washer	1
23	3272-6	Pin - Cotter	3
24	3256-23	Washer	3
25	3231-25	Bolt - Carriage	1
26	3296-39	Nut - Lock	3
27	3231-29	Bolt - Carriage	2
28	3256-4	Washer	2
29	3256-24	Washer - Flat	2

ENGINE PULLEY & PTO CLUTCH ASSEMBLY




ENGINE PULLEY & PTO CLUTCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	112849	Electric Clutch Assembly (Incl. Ref. #2-5)	1
2	113820	Rotor Assembly	1
3	113821	Field Assembly (Incl. Ref. #9)	1
4	113822	Armature & Pulley Assy. (Incl. Ref. #9)	1

Ref. No.	Part No.	Description	No. Used
5	113823	Spring & Nut Assembly	3
6	112843	Washer	1
7	112853	Bolt	1
8	112858	Pulley - Engine	1
9	114064	Bearing - Ball	2

*Not Illustrated

ENGINE FUEL & EXHAUST ASSEMBLY




ENGINE FUEL & EXHAUST ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	78-8550	Engine - 12HP TORO Power Plus Model No. E125V Type N/10964B	1
4	116702	Muffler	1
5	117256	Control - Throttle	1
6	116454	Knob	1
7	112153	Fuel Tank Assembly (Incl. Ref. #8 & 9)	1
8	104047	Bushing	1
9	104048	Valve	1
10	111474	Cap - Gas	1
11	117225	Line - Fuel	1
12	2412-98	Clamp - Hose	2
22	3256-23	Washer	2
27	111499	Screw - Pan Hd.	2

Ref. No.	Part No.	Description	No. Used
28	915740	Nut - Lock	2
29	3230-1	Bolt - Carriage	2
31	3296-29	Nut - Lock	2
32	114764	Fitting - 90°	1
33	NN10653	Plug - Pipe	1
34	115356	Arrester - Spark	1
35	113113	Screw - Hex. Hd.	3
37	3253-4	Washer - Lock	2
39	911652	Screw	1
40	114636	Extension - Oil Drain	1
41	926696	Screw	4
42	48-7630	Bolt	2
43	111392	Clip - J	2
44	117184	Gasket	1
45	3253-3	Washer - Lock	1

*Not Illustrated

12HP ENGINE CYLINDER BLOCK ASSEMBLY




12HP ENGINE CYLINDER BLOCK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10852	Block - Cylinder	1
2	NN10626	Pin - Dowel	2
3	NN10678	Bearing - Ball	2
4	NN10569	Seal - Oil	1
5	NN10570	Bearing - Crankshaft	1
6	NN10571	Bearing - Camshaft	1
7	NN10646	Seal - Governor Shaft	1
8	79-5840	Pin - Alignment	2
9	NN10653	Plug - Pipe	1
10	NN10579	Kit - Piston (Standard) (Incl. Ref. #11 & 12)	1
*	NN10580	Kit - Piston (.25mm Oversize) (Incl. Ref. #11 & 12)	1
*	NN10581	Kit - Piston (.50mm Oversize) (Incl. Ref. #11 & 12)	1
11	NN10582	Pin - Piston	1
12	NN10583	Ring - Retaining	2
13	NN10584	Set - Piston Ring (Standard)	1
*	NN10585	Set - Piston Ring (.25mm Oversize)	1
*	NN10586	Set - Piston Ring (.50mm Oversize)	1

Ref. No.	Part No.	Description	No. Used
14	NN10587	Kit - Connecting Rod (Standard) (Incl. Ref. #15 & 16)	1
*	NN10588	Kit - Connecting Rod (.25mm Undersize) (Incl. Ref. 15 & 16)	
*	NN10589	Kit - Connecting Rod (.50mm Undersize) (Incl. Ref. #15 & 16)	1
15	NN10590	Bolt	2
16	NN10591	Washer	2
17	NN10688	Indicator (Incl. Ref. #18)	1
18	NN10323	Seal - O-Ring	1
19	NN10689	Tube	1
20	NN10690	Seal	1
21	82-1560	Screw	1
22	NN10691	Bracket - Support	1
23	82-1700	Nut - Speed	1
24	NN10740	Washer - Lock	1
25	NN10768	Nut	1

*Not Illustrated

12HP ENGINE CRANKSHAFT & CAMSHAFT ASSEMBLY




12HP ENGINE CRANKSHAFT & CAMSHAFT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10627	Camshaft Assembly (Incl. Ref. #2-5)	1
2	NN10642	Camgear Assembly	1
3	NN10643	Key - Camgear	1
4	NN10644	Pin	1
5	NN10645	Spring	1
6	NN10640	Lever	1
7	NN10641	Clip - Retaining	2
8	82-1350	Washer	1
9	NN10630	Shim - Camshaft (.50mm)	1
*	NN10631	Shim - Camshaft (.60mm)	1
*	NN10632	Shim - Camshaft (.80mm)	1
*	NN10633	Shim - Camshaft (.90mm)	1
*	NN10634	Shim - Camshaft (1.00mm)	1
*	NN10635	Shim - Camshaft (1.20mm)	1
10	NN10742	Gear - Crankshaft	1
11	NN10743	Gear - Balancer	1
12	NN10744	Crankshaft	1
13	NN10745	Key - Gear	1

Ref. No.	Part No.	Description	No. Used
14	NN10746	Shim - Crankshaft (.20mm)	1
*	NN10747	Shim - Crankshaft (.30mm)	1
*	NN10748	Shim - Crankshaft (.40mm)	1
*	NN10749	Shim - Crankshaft (.50mm)	1
*	79-5850	Shim - Crankshaft (.70mm)	1
*	79-5860	Shim - Crankshaft (.80mm)	1
15	NN10750	Plug	1
16	NN10751	Gear	1
17	NN10752	Gear	1
18	NN10753	Shaft	1
19	NN10754	Shaft	1
20	NN10755	Key - Gear	2
21	NN10756	Shim - Balancer Shaft (.50mm)	1
*	NN10757	Shim - Balancer Shaft (.60mm)	1
*	NN10758	Shim - Balancer Shaft (.70mm)	1
*	NN10759	Shim - Balancer Shaft (.80mm)	1
*	NN10760	Shim - Balancer Shaft (.90mm)	1
*	NN10761	Shim - Balancer Shaft (1.00mm)	1
*	NN10762	Shim - Balancer Shaft (1.20mm)	1

*Not Illustrated

12HP ENGINE OIL BASE & PUMP ASSEMBLY




12HP ENGINE OIL BASE & PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10680	Bolt	9
2	NN10681	Gasket - Oil Base	1
3	NN10684	Filter - Oil	1
4	NN10685	Adapter - Oil Filter	1
5	NN10675	Base - Oil	1
6	NN10133	Spring - Relief Valve	1
7	NN10572	Pump - Oil	1
8	NN10573	Cover - Oil Pump	1
9	NN10577	Screen - Oil Pickup	1
10	NN10578	Cover - Screen	1
11	NN10636	Gear - Governor	1
12	NN10637	Shaft - Governor	1
13	NN10638	Sleeve - Governor	1
14	NN10639	Stop - Governor	1
15	NN10687	Plug - Pipe	2

Ref. No.	Part No.	Description	No. Used
16	82-1130	Plug - Pipe	1
17	NN10686	Plug - Pipe	2
18	NN10575	Seal - O-Ring	1
19	NN10569	Seal - Oil	1
20	NN10534	Ball - Steel	1
21	NN10677	Bearing - Ball	1
22	NN10678	Bearing - Ball	2
23	59-0760	Plug	2
24	NN10539	Ring - Retaining	1
25	NN10628	Washer - Flat	1
26	NN10629	Washer - Flat	1
27	NN10868	Screw - Torx Pan Hd.	4
28	NN10813	Switch - Oil Pressure	1
29	NN10307	Plug - Pipe	1

12HP ENGINE CYLINDER HEAD & VALVES ASSEMBLY




12HP ENGINE CYLINDER HEAD & VALVES ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10592	Gasket - Cylinder Head	1
2	NN10593	Cylinder Head Assembly (Incl. Ref. #3-16)	1
*	NN10594	Cylinder Head Assembly (Incl. Ref. #3-6)	1
3	79-5880	Guide - Intake Valve	1
4	79-5870	Guide - Exhaust Valve	1
5		Seat - Intake Valve	1
6		Seat - Exhaust Valve	1
7	NN10597	Spring - Valve	2
8	NN10598	Valve - Intake	1
9	NN10599	Valve - Exhaust	1
10	NN10600	Retainer - Intake	1
11	NN10601	Retainer - Exhaust	1
12	NN10602	Lock - Intake	1
13	NN10603	Lock - Exhaust	1
14	NN10604	Ring	2
15	NN10605	Seal - Intake	1
16	NN10606	Washer	2
17	NN10607	Bolt	1
18	NN10608	Bolt	1

Ref. No.	Part No.	Description	No. Used
19	NN10609	Gasket	1
20	NN10610	Cover - Valve	1
21	NN10611	Fitting - 45°	1
22	NN10612	Breather	1
23	NN10613	Screw - Hex. Socket Hd.	7
24	NN10614	Washer	2
25	NN10615	Bolt	2
26	NN10616	Bolt	2
27	NN10617	Tappet	2
28	NN10618	Rod - Push	2
29	NN10619	Rocker Arm Assembly (Incl. Ref. #30 & 31)	1
30	NN10620	Screw	2
31	NN10621	Nut	2
32	NN10622	Shaft - Rocker Arm	1
33	NN10623	Washer - Rocker Arm	2
34	NN10624	Clip - Retainer	2
35	NN10625	Pin - Dowel	1
36	NN10626	Pin - Dowel (Hollow)	1
37	82-1340	Washer - Flat	7

*Not Illustrated

12HP ENGINE IGNITION ASSEMBLY




12HP ENGINE IGNITION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10735	Screw – Torx Pan Hd.	2
2	NN10734	Stator	1
3	NN10733	Bolt – Hex. Hd.	1
4	79-5890	Clamp – Cord	1
5	79-5900	Pin – Alignment	2

Ref. No.	Part No.	Description	No. Used
6	NN10820	Plug – Spark	1
7	NN10729	Lead	1
8	NN10730	Coil – Ignition	1
9	NN10731	Bolt – Hex. Hd.	2
10	NN10673	Harness – Regulator	1

12HP ENGINE AIR CLEANER ASSEMBLY




12HP ENGINE AIR CLEANER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10693	Hose – Breather	1
2	NN10694	Gasket	1
3	NN10899	Adapter	1
4	NN10872	Element	1
5	NN10697	Cover – Element	1
6	NN10698	Wrapper – Element	1
7	NN10704	Grommet	1
8	NN10703	Knob	1

Ref. No.	Part No.	Description	No. Used
10	NN10812	Clamp – Hose	2
11	82-1350	Washer – Flat	2
12	NN10702	Screw – Cap Hex. Hd.	2
13	NN10700	Knob	2
14	NN10799	Cover – Air Cleaner	1
16	79-5910	Kit – Air Cleaner (Incl. Ref. #2-8 & 13-15)	1

*Not Illustrated

12HP ENGINE GOVERNOR LINKAGE & COVER ASSEMBLY




12HP ENGINE GOVERNOR LINKAGE & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10657	Spring - Governor	1
2	NN10647	Lever - Governor	1
3	NN10816	Washer - Governor Lever	2
4	NN10648	Screw - Cap Hex. Hd.	1
5	NN10740	Washer - Lock	1
6	NN10768	Nut - Hex.	1
7	NN10674	Clip - Link	1
8	NN10651	Throttle Plate Assembly	1
9	NN10652	Screw - Machine	1
10	NN10653	Clamp - Cable	1
11	59-0720	Pin - Cotter	1
12	72-3900	Screw - Thread Forming	1
13	NN10656	Swivel - Choke Lever	1
14	59-0850	Washer - Flat	1
15	NN10658	Link - Throttle	1
16	NN10654	Spring - Choke Linkage	1
17	NN10659	Link - Choke	1

Ref. No.	Part No.	Description	No. Used
18	NN10660	Spacer	1
19	NN10661	Stud	1
20	NN10817	Screw - Thread Forming	1
21	82-1340	Washer - Flat	2
22	82-1350	Washer - Flat	2
23	NN10663	Nut - Hex.	1
24	NN10344	Ring - Retaining	1
25	NN10785	Screw - Thread Forming	1
26	NN10683	Plug - Pipe	1
27	NN10722	Housing - Cylinder Air	1
28	NN10723	Deflector - Air	1
29	NN10725	Screw - Cap Hex. Hd.	1
30	82-1340	Washer - Flat	1
31	NN10726	Screw - Cap Hex. Hd.	5
32	82-1350	Washer - Flat	6
33	NN10727	Screw - Cap Hex. Hd.	1

*Not Illustrated

12HP ENGINE FLYWHEEL & COVER ASSEMBLY




12HP ENGINE FLYWHEEL & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10711	Screen	1
2	NN10712	Blower Wheel Assembly	1
3	NN10713	Key	1
4	NN10714	Screw – Hex. Hd.	3

Ref. No.	Part No.	Description	No. Used
5	NN10715	Nut	1
6	NN10720	Housing – Blower	1
7	NN10721	Bolt	4


12HP ENGINE STARTER ASSEMBLY



12HP ENGINE STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10739	Starter	1

Ref. No.	Part No.	Description	No. Used
2	NN10738	Screw - Cap Hex. Hd.	2




12HP ENGINE CARBURETOR ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1	NN10666	Gasket	1
2	NN10818	Elbow - Intake	1
3	NN10668	Carburetor Assembly	1
4	NN10669	Insulator	1
5	NN10670	Gasket	2
9	79-5820	Screw - Cap Hex. Hd.	2
10	79-5830	Washer - Flat	2

Ref. No.	Part No.	Description	No. Used
12	NN10674	Clip - Link	2
14	NN10792	Screw - Hex. Washer Hd.	1
15	NN10218	Bushing	1
16	NN10794	Regulator - Voltage	1
17	NN10261	Kit - Float	1
19	NN10907	Kit - Carburetor Repair	1
20	NN10701	Stud	1

WIRING DIAGRAM (212-5 & 212-H)



DECAL & MISCELLANEOUS PARTS ASSEMBLY



DECAL & MISCELLANEOUS PARTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	117474	Decal - Hood R.H. (212-5)	1
*	117472	Decal - Hood R.H. (212-H)	1
*	117475	Decal - Hood L.H. (212-5)	1
*	117473	Decal - Hood L.H. (212-H)	1
3	116590	Decal - Hood Rear	1
4	111327	Decal - Parking Brake	1
5	78-8440	Decal - PTO Clutch	1
6	118600	Decal - Power Plus	1
7	117512	Decal - 5-Speed (212-5)	2
8	117511	Decal - Hydro (212-H)	2
9	117760	Decal - Fender	1
10	116874	Decal - Hood Front	1
*	807322	Loose Parts Package (212-5)	1
*	807323	Loose Parts Package (212-H)	1

Ref. No.	Part No.	Description	No. Used
14	111632	Decal - Clutch & Brake	1
15	114442	Decal - Hydro Push (212-H)	1
16	115196	Decal - Attach-a-Matic	1
17	111926	Decal - Electrical System	1
18	115398	Decal - Maintenance	1
19	111706	Decal - Throttle	1
21	112670	Decal - Danger	1
22	120040	Decal - TORO	1
23	114944	Decal - Shift 5-Speed (212-5)	1
24	114051	Decal - Motion Control (212-H)	1
25	112403	Decal - VIN Overlay	1
26	113370	Decal - PTO Adjustment	1
28	118610	Decal - Power Plus	1
33	78-8480	Decal - Ignition	1
35	78-8490	Decal - Lights	1
37	114621	Decal - Noise	1
38	117800	Decal - Engine Spec.	1

*Not Illustrated

PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
1120	Key - Square	11 20 2	109355	Fuse - 15 Amp.	7 43 1
1278	Washer - .050"	11 9 A/R	109444	Pulley - Idler	27 14 1
1278	Washer - .050"	11 21 4	109447	Gear - Spacer	25 18 1
1278	Washer - Shim (.050")	5 22 A/R	109500	Fitting - Grease	11 6 2
1336	Washer	17 35 2	109547	Hook	7 4 2
1336	Washer	23 31 2	109553	Cover - Battery Terminal	7 28 1
2534	Clip - Spring	23 7 2	109779	Nut	5 41 2
2844	Washer	17 10 1	109779	Nut - Jam	25 13 2
2844	Washer - Special	9 39 2	109989	Spacer - Nylon	3 27 4
3023	Clip	7 59 4	110015	Spacer	19 4 1
3765	Washer - Shim	13 24 A/R	110015	Spacer	27 4 1
3765	Washer - Shim	25 79 1	110180	Mat - Footrest	5 7 2
3765	Washer - Shim (.050")	9 29 A/R	110189	Rod - End	25 6 1
5108	Valve - Stem	11 5 4	110370	Pulley - Idler	5 44 1
5210	Washer - .015"	11 10 A/R	110391	Bushing	9 18 1
5210	Washer - Shim (.015")	5 * A/R	110769	Spring - Brake Return	13 36 1
5666	Bushing Nylon	25 80 1	111070	Knob	27 7 1
5666	Bushing - Nylon	13 7 1	111076	Wire - Solenoid/Battery	7 7 1
5977	Bushing - Nyliner	1 38 2	111327	Decal - Parking Brake	53 4 1
6366	Key - Square	17 7 1	111392	Clip	1 10 1
7228	Bulb - Light	1 26 2	111392	Clip - J	31 43 2
8830	Clip	5 37 1	111397	Plate - Front Axle Support	5 4 1
8830	Clip	21 27 2	111406	Spindle - R.H.	9 7 1
100079	Tube - Inner	11 2 2	111409	Spindle - L.H.	9 8 1
100305	Washer - Friction	25 11 1	111413	Shaft - Pinion	9 12 1
100309	Spacer - Cam	25 12 2	111417	Gear - Sector	9 13 1
100365	Washer - Spring Disc	25 10 2	111418	Bushing - Eccentric	9 14 1
100571	Tie - Cable	7 27 1	111418	Bushing - Eccentric	19 9 1
100656	Bearing - Cam Return	25 3 1	111418	Bushing - Eccentric	27 9 1
101884	Nut - Switch	7 31 1	111419	Washer	9 15 1
102138	Switch - Light	7 24 1	111419	Washer	19 10 1
102534	Bearing - Ball	17 16 1	111419	Washer	27 10 1
102536	Bering Cup & Nuts	17 17 1	111422	Retainer	9 19 1
102572	Spring - Idler	27 17 1	111423	Rod - Drag Link	9 20 1
102950	Washer - Tab	7 65 1	111430	Arm	13 5 1
103995	Washer - Special	1 12 1	111430	Arm	25 76 1
104047	Bushing	31 8 1	111432	Spring	13 8 1
104048	Valve	31 9 1	111432	Spring	25 78 1
104524	Trunnion	25 35 1	111436	Pedal - Brake/Idler	19 1 1
104525	Spacer	19 15 1	111437	Shaft - Pedal	19 2 1
104859	Spacer - Lift Link	25 23 1	111437	Shaft - Pedal	27 2 1
104869	Washer - Special	13 13 1	111439	Grip	5 48 1
104926	Body - Connector	7 50 2	111439	Grip	19 7 1
104962	Battery	7 1 1	111442	Pulley - Idler	19 13 1
105302	Connector - 5 Terminal	7 41 1	111442	Pulley - Idler	27 13 1
105450	Tube - Inner	11 16 2	111443	Guide - Belt	19 14 1
105490	Clamp	7 74 1	111445	Spring - Brake	19 17 1
105503	Bushing	3 7 2	111446	Spring - Idler	19 18 1
105842	Battery	7 * 1	111467	Panel - Console	5 9 1
106288	Clamp - Shaft	19 3 2	111474	Cap - Gas	31 10 1
106288	Clamp - Shaft	27 3 2	111498	Body - Connector	7 46 2
106634	Pin - Tool	5 64 1	111499	Screw - Pan Hd.	5 10 4
106634	Pin - Tool	17 31 2	111499	Screw - Pan Hd.	31 27 2
106634	Pin - Tool	23 27 2	111524	Link	5 30 2
106661	Cam	25 17 1	111527	Spring	5 31 2
106948	Tray - Battery	7 3 1	111531	Spring	9 6 1
107677	Spring - Brake	25 36 1	111632	Decal - Clutch & Brake	53 14 1
107831	Socket - Connector	7 79 1	111684	Bucket - Light	1 23 1
108547	Reflector	1 14 2	111685	Retainer	1 24 1
108881	Nut - Lock	9 31 1	111688	Clamp	25 29 1
108889	Bumper	3 13 2	111706	Decal - Throttle	53 19 1
108917	Knob	21 18 1	111712	Washer - Wave	19 5 1
109102	Fuse - 25 Amp.	7 * 1	111712	Washer - Wave	27 5 1
109154	Hubcap	11 1 2	111926	Decal - Electrical System	53 17 1
109193	Rivet - Pop	1 15 4	112153	Fuel Tank Assembly	31 7 1
109230	Retainer - Belt	5 47 1	112403	Decal - VIN Overlay	53 25 1
109261	Hubcap	11 13 2	112670	Decal - Danger	53 21 1
109262	Washer - .050"	11 15 6	112744	Bracket - Pivot R.H.	3 * 1
109262	Washer - Hubcap	11 11 2	112745	Bracket - Pivot L.H.	3 4 1

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
112757	Wire - Solenoid/Starter	7 8 1	114724	Bracket - R.H.	23 * 1
112837	Spring - Seat	3 22 2	114740	Pulley	17 11 1
112843	Washer	29 6 1	114741	Spacer - Shaft	17 12 1
112847	Bracket - Support	9 3 1	114756	Block - Rubber	17 23 2
112849	Electric Clutch Assembly	29 1 1	114756	Block - Rubber	23 18 2
112850	Plate - Frame Support	5 3 1	114757	Spacer	17 27 2
112853	Bolt	29 7 1	114757	Spacer	23 22 2
112858	Pulley - Engine	29 8 1	114762	Spacer - Rubber	17 22 2
112925	Washer - Backing	1 30 1	114762	Spacer - Rubber	23 17 2
112961	Plate	3 16 2	114764	Fitting - 90°	31 32 1
112977	Support - Rear Axle	5 6 1	114812	Spacer	23 5 1
112981	Rod - Tie	9 11 1	114818	Spring	25 25 1
112982	Strap - Torque	13 3 2	114821	Washer - Friction	25 72 2
112983	Knob	13 9 1	114851	Plate - Frame Support	5 63 1
112983	Knob	25 83 1	114859	Arm - Idler	19 8 1
112984	Rod - Lock	19 6 1	114860	Belt - Transmission Drive	13 33 1
113025	Pointer	13 22 1	114944	Decal - Shift 5-Speed	53 23 1
113025	Pointer	25 82 1	114989	Bracket - L.H.	5 49 1
113030	Pin	9 5 2	114990	Bracket - R.H.	5 * 1
113044	Tube	9 4 1	115042	Rod	13 11 1
113113	Screw - Hex. Hd.	31 35 3	115043	End - Rod	13 12 1
113116	Retainer	5 38 2	115191	Guide - Belt	23 2 1
113129	Rod - Brake/Idler	19 12 1	115196	Decal - Attach-a-Matic	53 16 1
113179	Nut - Hex.	7 64 1	115198	Arm - Transmission	13 10 1
113370	Decal - PTO Adjustment	53 26 1	115204	Harness - Headlight	7 29 1
113589	Tie - Plastic	23 6 2	115230	Switch - Clutch	7 73 1
113820	Rotor Assembly	29 2 1	115356	Arrester - Spark	31 34 1
113821	Field Assembly	29 3 1	115398	Decal - Maintenance	53 18 1
113822	Armature & Pulley Assy.	29 4 1	115413	Clevis	1 32 2
113823	Spring & Nut Assembly	29 5 3	115414	Cable - Hood Lanyard	1 27 1
113852	Plate - Seat Pivot	3 3 1	115677	Bracket	25 74 1
114034	Arm - Idler	27 8 1	115678	Plate - Mounting	25 28 1
114051	Decal - Motion Control	53 24 1	115686	Pulley - Drive	23 1 1
114064	Bearing - Ball	29 9 2	115687	Fan	21 15 1
114385	Axle - Front	9 1 1	115688	Pulley - Input Shaft	21 14 1
114389	Fender	1 1 1	115858	Clip - Snap-In	5 59 2
114401	Plate - Cam	25 2 1	115860	Clip - Snap-In	5 58 1
114402	Spacer	25 15 1	115968	Belt - V	23 12 1
114403	Support - Cam Plate	25 8 1	115990	Guide - Belt	23 9 1
114404	Plate - Neutral Pivot	25 20 1	116005	Shoe - Belt	23 14 1
114409	Hose	21 7 1	116007	Bracket - Reservoir	21 23 1
114410	Bracket - Torque	25 27 1	116119	Shaft - Drive	17 18 1
114416	Plate - Neutral Return	25 1 1	116120	Pulley - Transmission	13 32 1
114417	Plate - Rear Drawbar	5 2 1	116126	Cable - Push Valve	21 19 1
114418	Pedal - Brake	27 1 1	116150	Spring - Extension	19 29 1
114433	Belt	21 2 1	116180	Clamp - Hose	21 6 4
114442	Decal - Hydro Push	53 15 1	116262	Socket - Light	1 25 1
114563	Gasket - Cover	21 11 1	116287	Bolt - Adjusting	25 38 1
114564	Reservoir	21 12 1	116338	Switch - Ignition	7 22 1
114610	Roller - Cam	5 5 2	116339	Rod - Speed Control	25 5 1
114621	Decal - Noise	53 37 1	116340	Arm - Motion Control	25 16 1
114636	Extension - Oil Drain	31 40 1	116397	Relay	7 80 3
114656	Support - Angle	25 19 1	116398	Plate - Arm	25 46 1
114663	Plate	25 34 1	116454	Knob	31 6 1
114665	Clevis	25 37 1	116480	Coupler - Shaft	9 42 1
114666	Bracket	25 32 1	116590	Decal - Hood Rear	53 3 1
114668	Bracket - Spring	25 26 1	116591	Headlight Bar Assembly	1 9 1
114670	Pivot - Brake	25 33 1	116601	Bar - Light	1 22 1
114686	Plate - Mounting	17 15 1	116702	Muffler	31 4 1
114693	Hose	21 8 1	116738	Key - Ignition	7 23 2
114695	Nut - Special	25 9 1	116784	Bar - Pivot	17 26 2
114697	Spacer	25 21 1	116784	Bar - Pivot	23 21 2
114698	Spring - Brake	25 31 1	116800	Hood & Grill	1 2 1
114705	Rod - Lock	27 6 1	116874	Decal - Hood Front	53 10 1
114707	Rod - Brake	27 12 1	116879	Rear Wheel & Tire Assy.	11 17 2
114721	Tube - Drain	7 15 1	116880	Tire - Rear	11 18 2
114723	Bracket - L.H.	17 30 1	116881	Rear Wheel Assembly	11 19 2
114723	Bracket - L.H.	23 25 1	116883	Front Wheel & Tire Assy.	11 3 2
114724	Bracket - R.H.	17 * 1	116884	Tire - Front	11 4 2

* Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
116885	Front Wheel Assembly	11 7 2	786026	Pin - Dowel	15 39 2
116887	Bushing - Flange	11 8 4	786061	Sprocket (10 teeth)	15 61 1
116892	Rear Wheel & Tire Assy.	11 24 2	786062A	Chain - Roller	15 60 1
116893	Rear Wheel Assembly	11 25 2	786071	Spacer	15 74 1
117142	Bracket - Fuse	5 55 1	786072	Spacer	15 75 1
117184	Gasket	31 44 1	786086	Bracket - Brake Lever	15 68 1
117225	Line - Fuel	31 11 1	786102	Spacer	15 18 1
117256	Control - Throttle	31 5 1	786116	Disk	15 72 1
117316	Hold-Down - Battery	7 5 1	786118	Spacer	15 70 1
117325	Bracket - Spring	25 85 1	786124	Sprocket (14 teeth)	15 62 1
117326	Spring	25 84 1	786139	Pin - Drive	15 16 1
117343	Keeper - Latch	5 11 2	788040	Ring - Retainer	15 28 1
117344	Handle Assembly	1 6 2	788051	Seal - Square Cut	15 33 1
117389	Brace - L.H.	17 34 1	788061	Ring - Seal	15 23 2
117389	Brace - L.H.	23 29 1	788067B	Grease (32 oz. bottle)	15 78 1
117390	Brace - R.H.	17 * 1	788069	Seal - Square Cut	15 71 1
117390	Brace - R.H.	23 * 1	788075	Ring - Retaining	15 77 1
117431	Rivet - Pop	5 12 4	790003	Disk - Brake	15 36 1
117432	Rivet - Pop	1 7 4	790006	Pad - Brake	15 38 2
117472	Decal - Hood R.H.	53 * 1	790007	Plate - Brake Pad	15 37 1
117473	Decal - Hood L.H.	53 * 1	790025	Holder - Brake Pad	15 44 1
117474	Decal - Hood R.H.	53 1 1	790039	Lever - Brake	15 41 1
117475	Decal - Hood L.H.	53 * 1	792001	Seal - O-Ring	15 32 1
117511	Decal - Hydro	53 8 2	792035	Ring - Retainer	15 27 1
117512	Decal - 5-Speed	53 7 2	792073	Screw - Flanged Hex Hd.	15 42 2
117760	Decal - Fender	53 9 1	792073	Screw - Flanged Hex. Hd.	15 25 17
117800	Decal - Engine Spec.	53 38 1	792074	Plug - Hex. Hd.	15 64 1
118600	Decal - Power Plus	53 6 1	792075	Nut - Lock	15 43 1
118610	Decal - Power Plus	53 28 1	792076	Washer - Flat	15 40 1
119350	Guide - Belt	17 1 1	792077	Ball - Steel	15 20 1
120040	Decal - TORO	53 22 1	792078	Set Screw	15 21 1
120860	Washer - .075"	11 26 6	792079	Spring	15 22 1
120930	Holder - Fuse	7 14 1	792125	Ring - Retainer (Pkg. of 2)	15 26 4
770102	Case - Transaxle	15 3 1	792136	Key - Shifter	15 8 2
772108	Cover - Transaxle	15 1 1	807322	Loose Parts Package	53 * 1
774688	Axle (11-5/8" long)	15 47 1	807323	Loose Parts Package	53 * 1
774747	Axle (16-1/4" long)	15 48 1	900036	Bolt - Carriage	5 60 2
776135	Shaft - Input	15 46 1	900036	Bolt - Carriage	13 17 2
776219	Output Shaft & Pinion Assy.	15 5 1	908011	Screw - Cap Hex. Hd.	23 11 1
776260	Shaft - Counter	15 4 1	908016	Bolt	25 65 2
776315A	Shaft - Brake (4-keyed)	15 45 1	910792	Screw	21 20 2
778068	Gear - Bevel Pinion	15 14 2	910796	Screw	5 52 2
778113A	Bevel Pinion - Input	15 12 1	910808	Screw	1 18 4
778121A	Gear - Spur (20 teeth)	15 53 1	910837	Screw	5 26 1
778123A	Gear - Spur (25 teeth)	15 52 1	910842	Screw - Pan Hd.	17 24 4
778124A	Gear - Spur (30 teeth)	15 51 1	910842	Screw - Pan Hd.	23 19 4
778125	Gear - Spur (35 teeth)	15 50 1	910948	Screw	7 71 2
778126A	Gear - Spur (20 teeth)	15 56 1	911459	Bolt	25 14 1
778127A	Gear - Spur (25 teeth)	15 57 1	911652	Screw	31 39 1
778129A	Gear - Spur (30 teeth)	15 58 1	911910	Screw - Flat Hd.	21 28 2
778136	Gear - Spur (15 teeth)	15 7 1	913111	Screw - Machine	1 29 2
778139	Gear - Output	15 6 1	915001	Nut - Lock	9 28 2
778151	Gear - Spur (15 teeth)	15 55 1	915002	Nut - Lock	9 36 2
778191	Gear - Spur (37 teeth)	15 49 1	915112	Nut - Hex.	5 62 2
778221	Gear - Bevel	15 13 2	915112	Nut - Hex.	17 29 2
778229	Gear - Bevel (42 teeth)	15 11 1	915112	Nut - Hex.	23 24 2
778230	Gear - Spur (12 teeth)	15 54 1	915112	Nut - Lock	13 21 2
778260	Gear - Ring	15 15 1	915112	Nut - Lock	13 38 1
780001	Washer	15 31 4	915551	Nut	1 8 2
780051	Washer - Thrust	15 69 2	915564	Nut - Hex.	7 69 2
780072	Washer - Thrust	15 29 5	915732	Nut - Lock	7 72 2
780086	Bearing - Needle	15 2 2	915740	Nut - Hex.	5 25 4
780090	Washer - Thrust	15 76 1	915740	Nut - Lock	1 28 1
780105A	Bushing - Flanged	15 34 4	915740	Nut - Lock	5 53 2
780108	Washer - Thrust	15 30 4	915740	Nut - Lock	21 21 2
780109	Washer - Thrust	15 65 1	915740	Nut - Lock	31 28 2
780118A	Bushing - Flanged	15 35 2	920079	Washer - Lock	1 20 4
784352	Collar - Shifter	15 9 1	920160	Washer - Lock	7 32 1
784354	Shift Rod & Fork Assy.	15 10 1	920215	Washer	19 22 1

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
920215	Washer	27	22	1	NN10594	Cylinder Head Assembly	39	*	1
920242	Washer - Special	5	35	2	NN10597	Spring - Valve	39	7	2
920251	Washer - .050"	11	22	4	NN10598	Valve - Intake	39	8	1
920259	Washer	25	75	1	NN10599	Valve - Exhaust	39	9	1
920259	Washer - Special	7	26	1	NN10600	Retainer - Intake	39	10	1
920262	Washer - Special	7	25	1	NN10601	Retainer - Exhaust	39	11	1
920267	Washer - Special	17	19	2	NN10602	Lock - Intake	39	12	1
920267	Washer - Special	23	32	2	NN10603	Lock - Exhaust	39	13	1
920268	Washer	13	28	1	NN10604	Ring	39	14	2
920271	Washer - Special	25	22	1	NN10605	Seal - Intake	39	15	1
926640	Screw - Machine	5	57	2	NN10606	Washer	39	16	2
926641	Screw	25	30	1	NN10607	Bolt	39	17	1
926696	Bolt	25	58	1	NN10608	Bolt	39	18	1
926696	Screw	31	41	4	NN10609	Gasket	39	19	1
926697	Bolt	5	61	4	NN10610	Cover - Valve	39	20	1
926698	Screw	25	64	1	NN10611	Fitting - 45°	39	21	1
926720	Screw	13	18	2	NN10612	Breather	39	22	1
932000	Pin - Cotter	25	43	1	NN10613	Screw - Hex. Socket Hd.	39	23	7
932948	Pin - Clevis	25	53	1	NN10614	Washer	39	24	2
932948	Pin - Clevis	25	70	1	NN10615	Bolt	39	25	2
933272	Pin - Spirol	9	37	1	NN10616	Bolt	39	26	2
933273	Pin - Spirol	13	23	1	NN10617	Tappet	39	27	2
933273	Pin - Spirol	25	77	1	NN10618	Rod - Push	39	28	2
933505	Pin - Cotter Hair	17	32	2	NN10619	Rocker Arm Assembly	39	29	1
933505	Pin - Cotter Hair	23	28	2	NN10620	Screw	39	30	2
933505	Pin - Hair	5	65	1	NN10621	Nut	39	31	2
937082	Key - Woodruff	25	71	1	NN10622	Shaft - Rocker Arm	39	32	1
937222	Key - Hi-Pro	21	13	1	NN10623	Washer - Rocker Arm	39	33	2
937222	Key - Hi-Pro	23	34	1	NN10624	Clip - Retainer	39	34	2
937225	Key	13	34	1	NN10625	Pin - Dowel	39	35	1
938031	Bushing	1	17	1	NN10626	Pin - Dowel	33	2	2
938031	Bushing	5	36	1	NN10626	Pin - Dowel	39	36	1
938050	Plug - Nylon	5	54	2	NN10627	Camshaft Assembly	35	1	1
960152	Screw	5	50	2	NN10628	Washer - Flat	37	25	1
1-2533	Cup - Bearing	17	13	1	NN10629	Washer - Flat	37	26	1
5-1336	Key - Square	11	23	2	NN10630	Shim - Camshaft	35	9	1
NN10133	Spring - Relief Valve	37	6	1	NN10631	Shim - Camshaft	35	*	1
NN10218	Bushing	50	15	1	NN10632	Shim - Camshaft	35	*	1
NN10261	Kit - Float	50	17	1	NN10633	Shim - Camshaft	35	*	1
NN10277	Fuse - 30 Amp.	7	*	1	NN10634	Shim - Camshaft	35	*	1
NN10307	Plug - Pipe	37	29	1	NN10635	Shim - Camshaft	35	*	1
NN10323	Seal - O-Ring	33	18	1	NN10636	Gear - Governor	37	11	1
NN10344	Ring - Retaining	45	24	1	NN10637	Shaft - Governor	37	12	1
NN10534	Ball - Steel	37	20	1	NN10638	Sleeve - Governor	37	13	1
NN10539	Ring - Retaining	37	24	1	NN10639	Stop - Governor	37	14	1
NN10569	Seal - Oil	33	4	1	NN10640	Lever	35	6	1
NN10569	Seal - Oil	37	19	1	NN10641	Clip - Retaining	35	7	2
NN10570	Bearing - Crankshaft	33	5	1	NN10642	Camgear Assembly	35	2	1
NN10571	Bearing - Camshaft	33	6	1	NN10643	Key - Camgear	35	3	1
NN10572	Pump - Oil	37	7	1	NN10644	Pin	35	4	1
NN10573	Cover - Oil Pump	37	8	1	NN10645	Spring	35	5	1
NN10575	Seal - O-Ring	37	18	1	NN10646	Seal - Governor Shaft	33	7	1
NN10577	Screen - Oil Pickup	37	9	1	NN10647	Lever - Governor	45	2	1
NN10578	Cover - Screen	37	10	1	NN10648	Screw - Cap Hex. Hd.	45	4	1
NN10579	Kit - Piston	33	10	1	NN10651	Throttle Plate Assembly	45	8	1
NN10580	Kit - Piston	33	*	1	NN10652	Screw - Machine	45	9	1
NN10581	Kit - Piston	33	*	1	NN10653	Clamp - Cable	45	10	1
NN10582	Pin - Piston	33	11	1	NN10653	Plug - Pipe	31	33	1
NN10583	Ring - Retaining	33	12	2	NN10653	Plug - Pipe	33	9	1
NN10584	Set - Piston Ring	33	13	1	NN10654	Spring - Choke Linkage	45	16	1
NN10585	Set - Piston Ring	33	*	1	NN10656	Swivel - Choke Lever	45	13	1
NN10586	Set - Piston Ring	33	*	1	NN10657	Spring - Governor	45	1	1
NN10587	Kit - Connecting Rod	33	14	1	NN10658	Link - Throttle	45	15	1
NN10588	Kit - Connecting Rod	33	*	1	NN10659	Link - Choke	45	17	1
NN10589	Kit - Connecting Rod	33	*	1	NN10660	Spacer	45	18	1
NN10590	Bolt	33	15	2	NN10661	Stud	45	19	1
NN10591	Washer	33	16	2	NN10663	Nut - Hex.	45	23	1
NN10592	Gasket - Cylinder Head	39	1	1	NN10666	Gasket	50	1	1
NN10593	Cylinder Head Assembly	39	2	1	NN10668	Carburetor Assembly	50	3	1

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
NN10669	Insulator	50 4 1	NN10760	Shim - Balancer Shaft	35 * 1
NN10670	Gasket	50 5 2	NN10761	Shim - Balancer Shaft	35 * 1
NN10673	Harness - Regulator	41 10 1	NN10762	Shim - Balancer Shaft	35 * 1
NN10674	Clip - Link	45 7 1	NN10768	Nut	33 25 1
NN10674	Clip - Link	50 12 2	NN10768	Nut - Hex.	45 6 1
NN10675	Base - Oil	37 5 1	NN10785	Screw - Thread Forming	45 25 1
NN10677	Bearing - Ball	37 21 1	NN10792	Screw - Hex. Washer Hd.	50 14 1
NN10678	Bearing - Ball	33 3 2	NN10794	Regulator - Voltage	50 16 1
NN10678	Bearing - Ball	37 22 2	NN10799	Cover - Air Cleaner	43 14 1
NN10680	Bolt	37 1 9	NN10812	Clamp - Hose	43 10 2
NN10681	Gasket - Oil Base	37 2 1	NN10813	Switch - Oil Pressure	37 28 1
NN10683	Plug - Pipe	45 26 1	NN10816	Washer - Governor Lever	45 3 2
NN10684	Filter - Oil	37 3 1	NN10817	Screw - Thread Forming	45 20 1
NN10685	Adapter - Oil Filter	37 4 1	NN10818	Elbow - Intake	50 2 1
NN10686	Plug - Pipe	37 17 2	NN10820	Plug - Spark	41 6 1
NN10687	Plug - Pipe	37 15 2	NN10852	Block - Cylinder	33 1 1
NN10688	Indicator	33 17 1	NN10868	Screw - Torx Pan Hd.	37 27 4
NN10689	Tube	33 19 1	NN10872	Element	43 4 1
NN10690	Seal	33 20 1	NN10899	Adapter	43 3 1
NN10691	Bracket - Support	33 22 1	NN10907	Kit - Carburetor Repair	50 19 1
NN10693	Hose - Breather	43 1 1	38-1420	Switch - Seat	7 18 1
NN10694	Gasket	43 2 1	48-7630	Bolt	31 42 2
NN10697	Cover - Element	43 5 1	59-0720	Pin - Cotter	45 11 1
NN10698	Wrapper - Element	43 6 1	59-0760	Plug	37 23 2
NN10700	Knob	43 13 2	59-0850	Washer - Flat	45 14 1
NN10701	Stud	50 20 1	72-3900	Screw - Thread Forming	45 12 1
NN10702	Screw - Cap Hex. Hd.	43 12 2	76-0670	Seat	3 1 1
NN10703	Knob	43 8 1	78-0020	Hourmeter	7 66 1
NN10704	Grommet	43 7 1	78-1640	Frame	5 1 1
NN10711	Screen	47 1 1	78-1670	Cam - Adjustment	5 32 2
NN10712	Blower Wheel Assembly	47 2 1	78-1991	Bracket - Steering Gear	9 17 1
NN10713	Key	47 3 1	78-2020	Shaft	13 6 1
NN10714	Screw - Hex. Hd.	47 4 3	78-2030	Collar	13 40 1
NN10715	Nut	47 5 1	78-2030	Collar	25 87 1
NN10720	Housing - Blower	47 6 1	78-2050	Bracket - Switch	5 56 1
NN10721	Bolt	47 7 4	78-3030	Switch - PTO	7 63 1
NN10722	Housing - Cylinder Air	45 27 1	78-3100	Wheel - Steering	9 22 1
NN10723	Deflector - Air	45 28 1	78-3221	Bracket - Steering Gear	9 * 1
NN10725	Screw - Cap Hex. Hd.	45 29 1	78-3230	Shaft	25 81 1
NN10726	Screw - Cap Hex. Hd.	45 31 5	78-3320	Clamp - Hourmeter	7 67 1
NN10727	Screw - Cap Hex. Hd.	45 33 1	78-8430	Hoodstand	5 8 1
NN10729	Lead	41 7 1	78-8440	Decal - PTO Clutch	53 5 1
NN10730	Coil - Ignition	41 8 1	78-8480	Decal - Ignition	53 33 1
NN10731	Bolt - Hex. Hd.	41 9 2	78-8490	Decal - Lights	53 35 1
NN10733	Bolt - Hex. Hd.	41 3 1	78-8550	Engine - 12HP	31 2 1
NN10734	Stator	41 2 1	79-0500	Harness Wire	7 2 1
NN10735	Screw - Torx Pan Hd.	41 1 2	79-1080	Cover	21 10 1
NN10738	Screw - Cap Hex. Hd.	49 2 2	79-1100	Reservoir Assembly	21 9 1
NN10739	Starter	49 1 1	79-5820	Screw - Cap Hex. Hd.	50 9 2
NN10740	Washer - Lock	33 24 1	79-5830	Washer - Flat	50 10 2
NN10740	Washer - Lock	45 5 1	79-5840	Pin - Alignment	33 8 2
NN10742	Gear - Crankshaft	35 10 1	79-5850	Shim - Crankshaft	35 * 1
NN10743	Gear - Balancer	35 11 1	79-5860	Shim - Crankshaft	35 * 1
NN10744	Crankshaft	35 12 1	79-5870	Guide - Exhaust Valve	39 4 1
NN10745	Key - Gear	35 13 1	79-5880	Guide - Intake Valve	39 3 1
NN10746	Shim - Crankshaft	35 14 1	79-5890	Clamp - Cord	41 4 1
NN10747	Shim - Crankshaft	35 * 1	79-5900	Pin - Alignment	41 5 2
NN10748	Shim - Crankshaft	35 * 1	79-5910	Kit - Air Cleaner	43 16 1
NN10749	Shim - Crankshaft	35 * 1	82-1130	Plug - Pipe	37 16 1
NN10750	Plug	35 15 1	82-1340	Washer - Flat	39 37 7
NN10751	Gear	35 16 1	82-1340	Washer - Flat	45 21 2
NN10752	Gear	35 17 1	82-1340	Washer - Flat	45 30 1
NN10753	Shaft	35 18 1	82-1350	Washer	35 8 1
NN10754	Shaft	35 19 1	82-1350	Washer - Flat	43 11 2
NN10755	Key - Gear	35 20 2	82-1350	Washer - Flat	45 22 2
NN10756	Shim - Balancer Shaft	35 21 1	82-1350	Washer - Flat	45 32 6
NN10757	Shim - Balancer Shaft	35 * 1	82-1560	Screw	33 21 1
NN10758	Shim - Balancer Shaft	35 * 1	82-1700	Nut - Speed	33 23 1
NN10759	Shim - Balancer Shaft	35 * 1	2412-98	Clamp - Hose	31 12 2

*Not Illustrated

PART NUMBER INDEX (Continued)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
302-5	Fitting - Grease	9	2	3	3254-2	Washer - Lock	5	21	2
321-2	Screw - Cap Hex. Hd.	17	5	3	3256-4	Washer	25	73	1
321-4	Bolt	7	9	2	3256-4	Washer	27	28	2
321-4	Bolt	21	24	4	3256-22	Washer	7	10	4
321-4	Screw - Cap Hex. Hd.	23	13	2	3256-22	Washer	25	49	1
322-2	Bolt	25	59	1	3256-22	Washer - Flat	21	25	2
322-3	Bolt	25	60	2	3256-22	Washer - Flat	23	15	2
322-3	Screw - Cap Hex. Hd.	17	14	5	3256-23	Washer	1	39	2
322-3	Screw - Cap Hex. Hd.	23	33	2	3256-23	Washer	3	18	8
322-3	Screw - Hex. Hd.	5	24	4	3256-23	Washer	5	19	14
322-4	Bolt	3	6	4	3256-23	Washer	9	34	1
322-4	Screw - Cap Hex. Hd.	9	25	2	3256-23	Washer	13	16	8
322-5	Bolt	3	2	4	3256-23	Washer	19	24	3
322-5	Bolt	3	17	6	3256-23	Washer	25	47	5
322-5	Bolt - Brake Stop	13	37	1	3256-23	Washer	27	24	3
322-5	Screw - Cap Hex. Hd.	17	3	1	3256-23	Washer	31	22	2
322-5	Screw - Cap Hex. Hd.	23	8	3	3256-23	Washer - Flat	13	39	1
322-5	Screw - Cap Hex. Hd.	25	86	2	3256-23	Washer - Flat	17	2	4
322-6	Bolt	3	26	2	3256-23	Washer - Flat	21	4	8
322-6	Bolt	13	30	1	3256-23	Washer - Flat	23	3	7
322-6	Screw - Hex. Hd.	5	20	2	3256-24	Washer	5	46	2
322-12	Screw - Cap Hex. Hd.	13	15	4	3256-24	Washer	19	28	2
322-13	Bolt	21	5	4	3256-24	Washer	25	48	1
323-6	Screw - Cap Hex. Hd.	17	9	1	3256-24	Washer - Flat	27	29	2
323-7	Bolt	5	42	1	3272-2	Pin - Cotter	23	4	1
323-7	Screw - Cap Hex. Hd.	17	28	4	3272-2	Pin - Cotter	25	52	1
323-7	Screw - Cap Hex. Hd.	23	23	4	3272-6	Pin - Cotter	1	40	2
323-10	Bolt	5	45	1	3272-6	Pin - Cotter	13	29	1
329-5	Screw - Cap Hex. Hd.	13	26	1	3272-6	Pin - Cotter	19	23	3
3217-5	Nut	7	11	2	3272-6	Pin - Cotter	25	50	3
3217-5	Nut - Lock	5	27	1	3272-6	Pin - Cotter	27	23	3
3217-6	Nut - Hex.	3	25	4	3272-7	Pin - Cotter	25	51	1
3217-6	Nut - Lock	1	21	4	3272-16	Pin - Cotter	5	34	2
3220-1	Nut - Jam	25	7	1	3272-16	Pin - Cotter	19	21	1
3220-2	Nut - Jam	13	25	1	3272-16	Pin - Cotter	27	21	1
3229-2	Bolt - Carriage	25	63	1	3272-17	Pin - Cotter	11	12	2
3229-29	Nut - Lock	9	33	3	3296-29	Nut - Lock	3	8	6
3230-1	Bolt - Carriage	27	20	4	3296-29	Nut - Lock	5	16	13
3230-1	Bolt - Carriage	31	29	2	3296-29	Nut - Lock	13	19	5
3230-2	Bolt	9	35	1	3296-29	Nut - Lock	17	20	7
3230-2	Bolt - Carriage	25	62	2	3296-29	Nut - Lock	19	19	4
3230-2	Screw - Carriage	1	41	4	3296-29	Nut - Lock	21	3	4
3230-16	Bolt - Carriage	5	15	7	3296-29	Nut - Lock	23	26	6
3230-16	Bolt - Carriage	19	20	4	3296-29	Nut - Lock	25	55	3
3230-22	Bolt	9	32	2	3296-29	Nut - Lock	27	19	4
3230-23	Bolt - Carriage	1	16	4	3296-29	Nut - Lock	31	31	2
3231-4	Bolt - Carriage	25	61	1	3296-39	Nut - Lock	5	43	2
3231-25	Bolt - Carriage	17	33	2	3296-39	Nut - Lock	17	25	6
3231-25	Bolt - Carriage	19	25	1	3296-39	Nut - Lock	19	26	2
3231-25	Bolt - Carriage	23	30	2	3296-39	Nut - Lock	23	20	6
3231-25	Bolt - Carriage	27	25	1	3296-39	Nut - Lock	27	26	3
3231-28	Bolt	9	30	1	3296-42	Nut - Lock	5	51	2
3231-29	Bolt - Carriage	27	27	2	3296-42	Nut - Lock	17	21	4
3231-33	Bolt - Carriage	19	27	1	3296-42	Nut - Lock	21	26	4
3242-2	Screw - Set	17	6	1	3296-42	Nut - Lock	23	16	6
3242-2	Screw - Sq. Hd. Set	13	35	2	3296-42	Nut - Lock	25	57	2
3253-3	Washer - Lock	5	28	1	32103-19	Nut - Wing	1	11	1
3253-3	Washer - Lock	7	38	2	32103-22	Nut - Wing	7	42	2
3253-3	Washer - Lock	13	27	1	32120-47	E-Ring	25	4	1
3253-3	Washer - Lock	17	4	3	32120-50	Pin - Spirol	25	69	1
3253-3	Washer - Lock	23	10	1	32120-93	Ring - Retaining	5	23	1
3253-3	Washer - Lock	31	45	1	32120-93	Ring - Retaining	9	9	2
3253-4	Washer - Lock	3	24	8	32121-103	Pin - Spirol	9	27	2
3253-4	Washer - Lock	9	26	2	32121-111	Pin - Spirol	9	41	1
3253-4	Washer - Lock	13	20	2	32146-2	Nut - Lock	25	54	1
3253-4	Washer - Lock	25	67	4	32151-36	Ring - Snap	11	27	2
3253-4	Washer - Lock	31	37	2	32151-48	Ring - Snap	11	14	2
3253-15	Washer - Lock	7	68	2	32151-52	Ring - Snap	25	68	2
3253-21	Washer - Lock	17	8	1	32151-73	Ring - Retaining	25	39	1

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The 200 Series Garden Tractors have two Identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the 200 Series Garden Tractor, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the 200 Series Garden Tractor.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Body Assembly	1	Engine Fuel & Exhaust Assembly	30-31
Seat Assembly	2-3	12hp Engine Cylinder Block Assembly	32-33
Frame Assembly	4-5	12hp Engine Crankshaft & Camshaft Assembly	34-35
Electrical System Assembly	6-7	12hp Engine Oil Base & Pump Assembly ...	36-37
Front Axle & Steering Assembly	8-9	12hp Engine Cylinder Head & Valves Assembly	38-39
Wheel & Tire Assembly	10-11	12hp Engine Ignition Assembly	40-41
Transmission Assembly (212-5)	12-13	12hp Engine Air Cleaner Assembly	42-43
Peerless Transmission Model No. 930-020 (212-5)	14-15	12hp Governor Linkage & Cover Assembly	44-45
Sweeper P.T.O. Assembly (212-5)	16-17	12hp Engine Flywheel & Cover Assembly ...	46-47
Brake & Idler Assembly (212-5)	18-19	12hp Engine Starter Assembly	48-49
Transmission Assembly (212-H)	20-21	12hp Engine Carburetor Assembly	50
Sweeper P.T.O. Assembly (212-H)	22-23	Wiring Diagram	51
Transmission Linkage Assembly (212-H)	24-25	Decal & Miscellaneous Parts Assembly	52-53
Brake & Idler Assembly (212-H)	26-27	Part Number Index	54-59
Engine Pulley & PTO Clutch Assembly	28-29		