



## ProLine Walk-Behind Mower Fixed Deck T-Bar Gear with 32in Cutting Unit

Model No. 30692 - 270000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

| Description                                          | Page     | Description                                          | Page     |
|------------------------------------------------------|----------|------------------------------------------------------|----------|
| Engine and Fuel Tank Assembly                        | ..... 3  | Lubrication Equipment Assembly Kawasaki FH430V-CS25  | ..... 17 |
| Transmission Drive Assembly                          | ..... 4  | Cooling Equipment Assembly Kawasaki FH430V-CS25      | ..... 18 |
| Drive Wheel and Brake Assembly                       | ..... 6  | Electric Equipment Assembly Kawasaki FH430V-CS25     | ..... 19 |
| Handle and Control Assembly                          | ..... 7  | Control Equipment Assembly Kawasaki FH430V-CS25      | ..... 20 |
| Deck and Shield Assembly                             | ..... 8  | Carburetor Assembly Kawasaki FH430V-CS25             | ..... 21 |
| Deck Assembly No. 110-6901                           | ..... 9  | Air Filter and Muffler Assembly Kawasaki FH430V-CS25 | ..... 22 |
| Deflector Assembly No. 107-4140                      | ..... 10 | Fuel Tank and Valve Assembly Kawasaki FH430V-CS25    | ..... 23 |
| Idle Arm and Caster Wheel Assembly                   | ..... 11 | Starter Assembly Kawasaki FH430V-CS25                | ..... 24 |
| Spindle and Blade Assembly                           | ..... 13 | Label Assembly Kawasaki FH430V-CS25                  | ..... 25 |
| Cylinder and Crankcase Assembly Kawasaki FH430V-CS25 | ..... 14 | Attachments and Accessories List                     | ..... 26 |
| Piston and Crankshaft Assembly Kawasaki FH430V-CS25  | ..... 15 |                                                      |          |
| Valve and Camshaft Assembly Kawasaki FH430V-CS25     | ..... 16 |                                                      |          |


## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HYD. .... hydraulic                          |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HD. .... heavy-duty                        | PTH. .... phillips truss head                |
| HF. .... hex flange                        | PTO. .... power-take-off                     |
| HH. .... hex head                          | RH. .... right hand                          |
| HHF. .... hex head flange                  | ROPS. .... roll-over protection system       |
| HHFTF. .... hex head flange thread forming | SFH. .... slotted fillister head             |
| HJ. .... hex jam                           | SHH. .... slotted hex head                   |
| HLH. .... hex lag head                     | SHWH. .... slotted hex washer head           |
| HOC. .... height-of-cut                    | SPH. .... slotted pan head                   |
| HSBH. .... hex socket button head          | SQH. .... square head                        |
| HSFH. .... hex socket flat head            | SRH. .... slotted round head                 |
| HSH. .... hex socket head                  | STD. .... standard                           |
| HWH. .... hex washer head                  | TAP. .... self tapping                       |
| HWHTF. .... hex washer head thread forming | TTH. .... torx truss head                    |

## Footnotes


- |                                                             |                                          |
|-------------------------------------------------------------|------------------------------------------|
| ❶ Not serviced separately                                   | ❷ Optional Equipment                     |
| ❸ Obtain parts from Peerless Transmissions (model 700-070A) | ❹ Obtain from your local Kawasaki dealer |



## Engine and Fuel Tank Assembly

| Ref   | Part No. | Qty. | Description                    |
|-------|----------|------|--------------------------------|
| 1     | 1-633023 | 2    | Stud                           |
| 2     | 3256-23  | 4    | Washer-Flat                    |
| 3     | 1-633349 | 2    | Spring-Tank, Fuel              |
| 4     | 3296-47  | 2    | Nut-Lock, NI                   |
| 5     | 1-303077 | 4    | Clamp                          |
| 1 4 9 |          |      |                                |
| 9     |          |      | 1 Engine-Kawasaki, FH430V-Cs25 |
| 10    | 106-0699 | 1    | Decal-Warning                  |
| 11    | 3290-357 | 1    | Nut-HHF, Whiz                  |
| 12    | 323-14   | 1    | Screw-HH                       |
| 13    | 322-7    | 3    | Screw-HH                       |
| 14    | 1-303334 | 3    | Washer-Spring                  |
| 15    | 103-1966 | 1    | Adapter                        |
| 16    | 92-6877  | 1    | Valve-Drain, Oil               |
| 17    | 98-5975  | 2    | Washer-Belleville              |
| 18    | 109-0293 | 1    | Hose-Fuel                      |
| 19    | 1-603770 | 1    | Valve-Fuel                     |
| 20    | 109-0306 | 1    | Hose-Fuel                      |
| 21    | 32128-21 | 1    | Nut-HF                         |
| 22    | 322-3    | 2    | Screw-HH                       |
| 24    | 1-805005 | 2    | Washer-Lock                    |
| 26    | 106-0730 | 1    | Fuel Tank ASM                  |
| 26:2  | 103-2605 | 1    | Fitting-Fuel, Bulkhead         |
| 27    | 88-3980  | 1    | Gas Cap ASM                    |
| 27:3  | 88-4010  | 1    | Gasket-Cap, Gas                |


| Ref | Part No. | Qty. | Description           |
|-----|----------|------|-----------------------|
| 28  | 32128-20 | 5    | Nut-HF                |
| 30  | 322-9    | 1    | Screw-HH              |
| 31  | 3254-2   | 1    | Washer-Lock, Internal |
| 34  | 323-8    | 8    | Screw-HH              |
| 35  | 98-5975  | 8    | Washer-Belleville     |
| 36  | 3290-357 | 8    | Nut-HHF, Whiz         |
| 99  | 103-1964 | 1    | Hose-Drain, Oil       |



## Transmission Drive Assembly


| Ref | Part No.    | Qty. | Description               |
|-----|-------------|------|---------------------------|
| 1   | 103-9897-01 | 1    | Deck-Engine               |
| 2   | 1-323252    | 2    | Bearing-Shaft             |
| 3   | 1-323254    | 2    | Flange-Output             |
| 4   | 1-803310    | 2    | Screw-Set                 |
| 5   | 103-6512    | 2    | Sheave-Transmission       |
| 6   | 321-3       | 6    | Screw-HH                  |
| 7   | 103-4177    | 1    | Key                       |
| 9   | 3296-39     | 1    | Nut-Lock, NI              |
| 10  | 3256-24     | 1    | Washer-Flat               |
| 11  | 1-323285    | 1    | Idler-Drive, Transmission |
| 12  | 3256-5      | 2    | Washer-Flat               |
| 13  | 322-3       | 4    | Screw-HH                  |
| 14  | 1-805005    | 4    | Washer-Lock               |
| 15  | 1-633181    | 1    | Plate-Tapped              |
| 16  | 1-513152    | 1    | Switch-Closed, Normally   |
| 17  | 32151-62    | 2    | Ring-Retaining            |
| 18  | 3257-5      | 3    | Key-Woodruff              |
| 19  | 1-323502    | 2    | Shaft-Transmission        |
| 20  | 51-4220     | 2    | Guard-Coupler             |
| 21  | 1-323680    | 2    | Coupler                   |
| 22  | 1-323630    | 1    | V-Belt                    |
| 23  | 3245-41     | 2    | Screw-HSH                 |
| 24  | 1-323278    | 1    | Sheave-Transmission       |
| 25  | 302-19      | 2    | Fitting-Grease            |

| Ref | Part No.    | Qty. | Description           |
|-----|-------------|------|-----------------------|
| 26  | 1-323500    | 1    | Transmission          |
| 27  | 3230-1      | 2    | Bolt-CARR             |
| 28  | 1-323387-03 | 1    | Plate-Shift           |
| 29  | 98-3256     | 1    | Decal-Speed, Ground   |
| 30  | 1-303020    | 1    | Grip-Lever            |
| 31  | 98-3274-03  | 1    | Lever-Shift           |
| 32  | 98-5975     | 1    | Washer-Belleville     |
| 33  | 3296-6      | 1    | Nut-Lock              |
| 35  | 1-323379    | 1    | Washer                |
| 36  | 32128-20    | 2    | Nut-HF                |
| 37  | 9264964     | 4    | Screw-HWH, Thread Cut |
| 38  | 1-603403    | 1    | Bolt-Shoulder         |
| 39  | 1-323389-03 | 2    | Bracket-Plate, Shift  |
| 40  | 1-806003    | 3    | Pin-Hair              |
| 41  | 1-303186    | 1    | Bellcrank             |
| 42  | 32128-21    | 1    | Nut-HF                |
| 43  | 95-2814     | 1    | Decal-Shut Off, Fuel  |
| 44  | 3290-500    | 2    | Screw-PPH             |
| 45  | 1-543296    | 1    | Grommet               |
| 46  | 3231-6      | 1    | Screw-CARR            |
| 47  | 3296-42     | 4    | Nut-Lock, NI          |
| 48  | 98-0776     | 1    | Decal-Caution         |
| 49  | 103-1666    | 1    | Sheave-Transmission   |
| 50  | 103-1667    | 1    | Sheave                |



## Transmission Drive Assembly (continued)


| Ref | Part No.    | Qty. | Description          |
|-----|-------------|------|----------------------|
| 56  | 1-603610    | 2    | Washer-Spring        |
| 57  | 3212-6      | 1    | Screw-HH             |
| 58  | 1-633453    | 1    | Spacer-Clutch        |
| 59  | 1-373034    | 2    | Washer               |
| 62  | 32128-33    | 2    | Nut-HF               |
| 64  | 103-1797-01 | 1    | Bracket-Cable, Choke |
| 65  | 103-1796    | 1    | Cable-Choke          |
| 67  | 1-323303    | 1    | Linkage-Arm          |
| 68  | 1-323745    | 1    | Belt-Blade, Drive    |
| 69  | 1-808280    | 1    | Pin-Clevis           |
| 70  | 1-303105    | 1    | Yoke-Adjustable      |
| 71  | 3219-2      | 1    | Nut-Hex              |
| 72  | 1-303335    | 2    | Tie-Plastic          |



## Drive Wheel and Brake Assembly

| Ref | Part No.    | Qty. | Description              |
|-----|-------------|------|--------------------------|
| 1   | 98-3273     | 2    | Spring-Extension         |
| 2   | 323-10      | 2    | Screw-HH                 |
| 3   | 32151-47    | 2    | Ring-Retaining           |
| 4   | 1-806003    | 4    | Pin-Hair                 |
| 5   | 3256-23     | 2    | Washer-Flat              |
| 6   | 110-4925-03 | 1    | RH Idler Arm ASM         |
| 7   | 110-4926-03 | 1    | LH Idler Arm ASM         |
| 8   | 74-0521     | 2    | Fitting-Rod              |
| 9   | 283-6       | 2    | Pin-Clevis               |
| 10  | 1-323296    | 2    | Rod-Brake                |
| 11  | 110-5866    | 2    | Swivel-Brake             |
| 12  | 1-513959    | 2    | Wingnut-Nylock           |
| 13  | 3290-357    | 10   | Nut-HHF, Whiz            |
| 14  | 323-16      | 4    | Screw-HH                 |
| 16  | 98-5131-01  | 2    | Shield-Wheel, Drive      |
| 17  | 1-323694    | 4    | Spacer-Shield            |
| 18  | 1-323634    | 2    | Idler-Drive, Wheel       |
| 19  | 302-19      | 2    | Fitting-Grease           |
| 21  | 1-323307    | 4    | Pin-Clevis               |
| 22  | 1-322209-03 | 2    | Arm-Brake                |
| 23  | 32120-47    | 2    | Ring-Retaining, External |
| 24  | 1-803051    | 4    | Nut-Push                 |
| 25  | 1-323595    | 2    | Band-Brake               |
| 26  | 1-322232-03 | 1    | Axle ASM                 |


| Ref    | Part No. | Qty. | Description          |
|--------|----------|------|----------------------|
| 27     | 1-523157 | 6    | Washer-Spacer        |
| 27     | 1-543436 | 8    | Washer-Spacer, 18 GA |
| 28     | 1-323261 | 2    | Drum-Brake           |
| 29     | 1-323349 | 2    | Sheave-Wheel, Drive  |
| 30     | 1-323346 | 2    | Wheel And Tire ASM   |
| 30:1   | 1-323361 | 1    | Tire                 |
| 30:2   | 1-323360 | 1    | Wheel And Hub ASM    |
| 30:2:1 | 1-323329 | 2    | Bearing-Flanged      |
| 30:2:2 |          | 1    | Rim ASM              |
| 30:2:3 |          | 1    | Fitting-Grease       |
| 30:2:4 |          | 1    | Valve Stem And Cap   |
| 34     | 1-808519 | 2    | Ring-Snap            |
| 36     | 322-5    | 8    | Screw-HH             |
| 38     | 1-323744 | 2    | Belt-Drive, Wheel    |
| 39     | 3296-29  | 2    | Nut-Lock, NI         |
| 40     | 2412-104 | 2    | R-Clamp              |
| 41     | 98-3259  | 1    | Shield-Trailing      |
| 42     | 322-3    | 2    | Screw-HH             |
| 43     | 98-5975  | 4    | Washer-Bellevalle    |
| 44     | 323-6    | 4    | Screw-HH             |
| 45     | 1-373034 | 8    | Washer               |
| 46     | 1-805005 | 8    | Washer-Lock          |



## Handle and Control Assembly

| Ref | Part No.   | Qty. | Description          |
|-----|------------|------|----------------------|
| 1   | 98-3282    | 2    | Rod-Control          |
| 2   | 95-5522-03 | 1    | Control Bar ASM      |
| 3   | 3296-2     | 5    | Nut-Lock             |
| 4   | 82-2290    | 1    | Decal                |
| 5   | 32105-1    | 1    | Screw-SHH            |
| 6   | 82-7680-03 | 1    | Bail ASM             |
| 7   | 82-2280    | 1    | Decal                |
| 8   | 3272-11    | 2    | Pin-Cotter           |
| 9   | 99-8501-03 | 1    | Control-Pivot        |
| 10  | 218-595    | 1    | Connector-Body       |
| 11  | 98-3261-03 | 1    | Lever-Brake, Parking |
| 12  | 98-3266    | 1    | Decal                |
| 13  | 740275     | 1    | Switch-Seat          |
| 14  | 1-806003   | 3    | Pin-Hair             |
| 15  | 237-141    | 2    | Grommet-Rubber       |
| 16  | 98-3267-03 | 1    | Upper Handle ASM     |
| 17  | 283-55     | 2    | Pin-Clevis           |
| 18  | 100-6450   | 1    | Control-Throttle     |
| 19  | 2412-120   | 2    | R-Clamp              |
| 20  | 95-5537    | 1    | Decal-Engage, Deck   |
| 21  | 1-303335   | 1    | Tie-Plastic          |
| 22  | 1-303160   | 1    | Spring-Compression   |
| 23  | 3256-24    | 2    | Washer-Flat          |
| 24  | 3296-39    | 1    | Nut-Lock, NI         |

| Ref  | Part No.   | Qty. | Description             |
|------|------------|------|-------------------------|
| 25   | 106-0678   | 1    | Harness-Wire            |
| 26   | 98-3279    | 1    | Linkage-Drive, Blade    |
| 27   | 98-3287-03 | 1    | Lever-Engagement, Blade |
| 28   | 3234-11    | 4    | Screw-HHF               |
| 29   | 32104-76   | 2    | Screw                   |
| 30   | 110-6905   | 1    | Control Panel ASM       |
| 30:2 | 110-6916   | 1    | Decal-Panel, Control    |
| 30:3 | 105-0884   | 1    | Decal-Danger            |
| 31   | 104-7050   | 1    | Housing-Manual          |
| 32   | 32105-14   | 4    | Screw-SHH               |
| 33   | 32128-21   | 4    | Nut-HF                  |
| 34   | 99-8509    | 1    | Spacer                  |
| 35   | 1-303020   | 1    | Grip-Lever              |
| 36   | 323-10     | 1    | Screw-HH                |
| 37   | 98-4387    | 1    | Decal-Protection, Ear   |
| 39   | 29-5560    | 1    | Switch-On / Off         |
| 39:1 | 218-461    | 1    | Nut-HH                  |
| 39:2 | 3254-5     | 1    | Washer-Tooth            |
| 40   | 63-8360    | 1    | Key-Ignition            |
| 41   | 104-7048   | 1    | Cap-Housing             |




Deck and Shield Assembly

| Ref | Part No.    | Qty. | Description               |  |  |  |  |
|-----|-------------|------|---------------------------|--|--|--|--|
| 1   | 1-324407    | 1    | Shield-Belt               |  |  |  |  |
| 1:2 | 106-0710    | 1    | Decal                     |  |  |  |  |
| 3   | 106-4161    | 4    | Knob-Handle               |  |  |  |  |
| 4   | 1-323417    | 4    | Washer                    |  |  |  |  |
| 5   | 1-303536    | 2    | Stud-Shield, Belt (Long)  |  |  |  |  |
| 6   | 1-303537    | 2    | Stud-Shield, Belt (Short) |  |  |  |  |
| 9   | 110-6901    | 1    | 32 Inch Deck ASM          |  |  |  |  |
| 10  | 322-2       | 7    | Screw-HH                  |  |  |  |  |
| 11  | 322-50      | 1    | Screw-HH                  |  |  |  |  |
| 12  | 32128-20    | 11   | Nut-HF                    |  |  |  |  |
| 13  | 1-302189-01 | 1    | Baffle-Dogleg             |  |  |  |  |
| 14  | 107-4140    | 1    | Deflector ASM             |  |  |  |  |
| 16  | 104-8554    | 1    | Spring-Torsion            |  |  |  |  |
| 17  | 105-4622    | 1    | Spacer                    |  |  |  |  |
| 18  | 3296-29     | 1    | Nut-Lock, NI              |  |  |  |  |








# Deflector Assembly No. 107-4140


| Ref | Part No.    | Qty. | Description                 |
|-----|-------------|------|-----------------------------|
| 1   | 3231-4      | 3    | Screw-CARR                  |
| 2   | 107-4138-01 | 1    | Strap-Deflector, Top        |
| 3   | 107-4139-01 | 1    | Strap-Discharge             |
| 4   | 107-4137    | 1    | Deflector-Rubber            |
| 5   | 107-4164-01 | 1    | Bracket-Mounting, Deflector |
| 6   | 3296-39     | 3    | Nut-Lock, NI                |



## Idler Arm and Caster Wheel Assembly

| Ref  | Part No.    | Qty. | Description        |
|------|-------------|------|--------------------|
| 3    | 1-513338    | 2    | Washer-Flat        |
| 5    | 1-303314    | 8    | Spacer-Caster      |
| 6    | 1-809020    | 2    | Pin                |
| 7    | 1-322145-01 | 2    | Fork               |
| 8    | 325-20      | 2    | Screw-HH           |
| 9    | 110-5023    | 2    | Wheel And Tire ASM |
| 9:1  |             | 1    | Tire               |
| 9:2  | 1-513809    | 1    | Bearing            |
| 9:3  | 1-513810    | 2    | Bushing            |
| 9:4  | 302-61      | 1    | Zerk               |
| 9:5  |             | 1    | Wheel              |
| 10   | 1-513547    | 2    | Spacer             |
| 11   | 3217-9      | 2    | Nut-HH             |
| 12   | 3253-7      | 2    | Washer-Lock        |
| 15   | 323-6       | 8    | Screw-HH           |
| 16   | 3290-357    | 8    | Nut-HHF, Whiz      |
| 17   | 3296-42     | 2    | Nut-Lock, NI       |
| 18   | 302-19      | 1    | Fitting-Grease     |
| 19   | 32128-20    | 3    | Nut-HF             |
| 20   | 1-323071    | 1    | Spring-Extension   |
| 21   | 322-6       | 1    | Screw-HH           |
| 22   | 103-3600    | 1    | Idler Arm ASM      |
| 22:2 | 1-323729    | 2    | Sleeve-Bearing     |
| 24   | 1-303348    | 1    | Eyebolt-Thread, LH |


| Ref | Part No.  | Qty. | Description         |
|-----|-----------|------|---------------------|
| 25  | 1-303434  | 1    | Bushing-Engagement  |
| 26  | 1-603843  | 1    | Pulley-Idler        |
| 27  | 98-5975   | 1    | Washer-Belleville   |
| 28  | 702809    | 1    | Screw-Cap           |
| 31  | 1-806003  | 1    | Pin-Hair            |
| 33  | 1-322235  | 1    | Arm-Assist          |
| 34  | 1-303238  | 1    | Eyebolt-Thread, RH  |
| 35  | 1-303236  | 1    | Body-Turnbuckle     |
| 36  | 32151-103 | 1    | Ring-Snap           |
| 37  | 3296-29   | 1    | Nut-Lock, NI        |
| 38  | 3256-3    | 1    | Washer-Flat         |
| 39  | 1-403179  | 1    | Tube-Pivot          |
| 40  | 3256-23   | 1    | Washer-Flat         |
| 41  | 32120-35  | 1    | Ring-Retaining, EXT |
| 42  | 1-323718  | 1    | Rod-Brake           |
| 43  | 321-4     | 2    | Screw-HH            |
| 44  | 1-323747  | 1    | Spring-Compression  |
| 45  | 1-323746  | 1    | Spacer-Flanged      |
| 46  | 1-324372  | 1    | Pad And Spring ASM  |
| 47  | 1-303334  | 1    | Washer-Spring       |
| 48  | 322-10    | 1    | Screw-HH            |
| 49  | 1-303352  | 1    | Washer-Spindle      |
| 50  | 1-323748  | 1    | Ring-Push On        |
| 51  | 1-302203  | 2    | Support ASM         |



## Idler Arm and Caster Wheel Assembly (continued)


| Ref    | Part No. | Qty. | Description     |
|--------|----------|------|-----------------|
| ①51:1  |          | 1    | Support-Caster  |
| 51:1:1 | 302-52   | 1    | Fitting-Grease  |
| 51:2   | 1-303514 | 2    | Bearing-Flanged |
| 52     | 3296-56  | 1    | Nut-Lock, NI    |
| 53     | 3256-24  | 8    | Washer-Flat     |

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |



Spindle and Blade Assembly


| Ref    | Part No. | Qty. | Description             |  |  |  |  |
|--------|----------|------|-------------------------|--|--|--|--|
| 1      | 1-800861 | 2    | Screw-Cap, HH           |  |  |  |  |
| 2      | 1-513208 | 2    | Washer-Spring           |  |  |  |  |
| 23     | 103-2527 | 2    | Blade-Notched           |  |  |  |  |
| 3      | 103-2507 | 2    | Blade-Lift, Low         |  |  |  |  |
| 4      | 1-323539 | 8    | Spacer                  |  |  |  |  |
| 5      | 1-323529 | 2    | Tube-Spindle, Short     |  |  |  |  |
| 6      | 1-807267 | 2    | Key                     |  |  |  |  |
| 13     | 107-4065 | 2    | Cutter Housing ASM      |  |  |  |  |
| 13:1   |          | 1    | Housing-Cutter          |  |  |  |  |
| 13:1:2 | 103-2477 | 2    | Bearing-Ball            |  |  |  |  |
| 13:1:3 | 103-2534 | 1    | Spacer-Bearing          |  |  |  |  |
| 13:1:4 | 32120-8  | 1    | Ring-Snap               |  |  |  |  |
| 13:2   | 103-1330 | 1    | Guard-Bearing, Top      |  |  |  |  |
| 13:3   | 103-2535 | 1    | Spacer-Guard, Bottom    |  |  |  |  |
| 14     | 32128-20 | 8    | Nut-HF                  |  |  |  |  |
| 15     | 1-303334 | 8    | Washer-Spring           |  |  |  |  |
| 16     | 322-6    | 8    | Screw-HH                |  |  |  |  |
| 17     | 1-403183 | 2    | Sheave                  |  |  |  |  |
| 18     | 1-803310 | 2    | Screw-Set               |  |  |  |  |
| 19     | 1-323339 | 2    | Washer-Retainer, Sheave |  |  |  |  |
| 20     | 3219-6   | 2    | Nut-Hex                 |  |  |  |  |



# Cylinder and Crankcase Assembly


## Kawasaki FH430V-CS25

| Ref      | Part No.   | Qty. | Description                   |  |  |  |  |
|----------|------------|------|-------------------------------|--|--|--|--|
| ④ 11004A | 11004-7018 | 2    | Gasket-Head                   |  |  |  |  |
| ④ 11008B | 11008-7021 | 1    | Head-Cylinder, No. 2          |  |  |  |  |
| ④ 11008D | 11008-7022 | 1    | Head-Cylinder, No. 1          |  |  |  |  |
| ④ 11022  | 11022-7003 | 2    | Case-Rocker                   |  |  |  |  |
| ④ 11060  | 11060-7001 | 2    | Gasket-Case, Rocker           |  |  |  |  |
| ④ 11061  | 11061-7007 | 1    | Gasket-Cover, Crankcase       |  |  |  |  |
| ④ 11061A | 11061-7008 | 1    | Gasket-Breather               |  |  |  |  |
| ④ 14091  | 14091-7007 | 1    | Cover                         |  |  |  |  |
| ④ 49015  | 49015-7032 | 1    | Cover-Crankcase               |  |  |  |  |
| ④ 49120  | 49120-7015 | 1    | Crankcase                     |  |  |  |  |
| ④ 59071  | 59071-2079 | 1    | Joint                         |  |  |  |  |
| ④ 92043  | 92043-7001 | 6    | Pin                           |  |  |  |  |
| ④ 92049  | 92049-7001 | 4    | Seal-Oil, R V C2 (6X11X10.2)  |  |  |  |  |
| ④ 92049B | 92049-7015 | 1    | Seal-Oil, S D (35X62X8 L HSH) |  |  |  |  |
| ④ 92049C | 92049-7016 | 1    | Seal-Oil, S D (35X48X8 R HSH) |  |  |  |  |
| ④ 92049D | 92049-7019 | 1    | Seal-Oil, S O (8X14X5 HSH)    |  |  |  |  |
| ④ 92139A | 92139-7008 | 1    | Bushing                       |  |  |  |  |
| ④ 130    | 130B0612   | 4    | Bolt-Flanged (6X12)           |  |  |  |  |
| ④ 130A   | 130B0640   | 4    | Bolt-Flanged (6X40)           |  |  |  |  |
| ④ 130B   | 130T0850   | 17   | Bolt-Flanged (8X50)           |  |  |  |  |
| ④ 130C   | 130T0875   | 2    | Bolt-Flanged (8X75)           |  |  |  |  |
| ④ 172    | 172G0818   | 4    | Bolt-Stud (8X18)              |  |  |  |  |



**Piston and Crankshaft Assembly**  
**Kawasaki FH430V-CS25**


| Ref      | Part No.   | Qty. | Description               |  |  |  |  |
|----------|------------|------|---------------------------|--|--|--|--|
| ④ 13001  | 13001-7009 | 2    | Piston-Engine             |  |  |  |  |
| ④ 13002  | 13002-7001 | 2    | Pin-Piston                |  |  |  |  |
| ④ 13008  | 13008-7001 | 2    | Ring Set-Piston           |  |  |  |  |
| ④ 13025  | 13025-7003 | 1    | Ring Set-Piston (L 0.50)  |  |  |  |  |
| ④ 13029  | 13029-7005 | 1    | Piston-Engine (L 0.50)    |  |  |  |  |
| ④ 13031  | 13031-7033 | 1    | Crankshaft                |  |  |  |  |
| ④ 13251  | 13251-7007 | 2    | Connecting Rod ASM        |  |  |  |  |
| ④ 13251A | 13251-7008 | 2    | Connecting Rod ASM (0.50) |  |  |  |  |
| ④ 92033  | 92033-7005 | 4    | Ring-Snap                 |  |  |  |  |
| ④ 130    | 130G0630   | 4    | Bolt-Flanged (6X30)       |  |  |  |  |



# Valve and Camshaft Assembly Kawasaki FH430V-CS25


| Ref     | Part No.   | Qty. | Description            |  |  |  |  |
|---------|------------|------|------------------------|--|--|--|--|
| ④12004A | 12004-7005 | 2    | Valve-Intake           |  |  |  |  |
| ④12005A | 12005-7006 | 2    | Valve-Exhaust          |  |  |  |  |
| ④12009  | 12009-7001 | 4    | Retainer-Spring, Valve |  |  |  |  |
| ④12011  | 12011-2056 | 8    | Collet                 |  |  |  |  |
| ④12016B | 12016-7008 | 4    | Arm-Rocker             |  |  |  |  |
| ④12032  | 12032-7001 | 4    | Tappet                 |  |  |  |  |
| ④13070  | 13070-7001 | 2    | Guide                  |  |  |  |  |
| ④13070A | 13070-7004 | 1    | Guide                  |  |  |  |  |
| ④13116  | 13116-2057 | 4    | Rod-Push               |  |  |  |  |
| ④13271  | 13271-7007 | 1    | Plate                  |  |  |  |  |
| ④13271A | 13271-7021 | 1    | Plate-Governor         |  |  |  |  |
| ④42036B | 42036-7010 | 1    | Sleeve                 |  |  |  |  |
| ④49078  | 49078-7001 | 4    | Spring-Valve, Engine   |  |  |  |  |
| ④49118  | 49118-7009 | 1    | Camshaft               |  |  |  |  |
| ④92009  | 92009-2341 | 4    | Screw                  |  |  |  |  |
| ④92015  | 92015-2253 | 4    | Nut                    |  |  |  |  |
| ④92033  | 92033-7001 | 2    | Ring-Snap              |  |  |  |  |
| ④92140  | 92140-7002 | 6    | Ball                   |  |  |  |  |
| ④92145  | 92145-7001 | 1    | Spring                 |  |  |  |  |
| ④92153  | 92153-7019 | 4    | Bolt                   |  |  |  |  |
| ④92200  | 92200-7001 | 1    | Washer                 |  |  |  |  |






**Lubrication Equipment Assembly**  
**Kawasaki FH430V-CS25**

| Ref     | Part No.   | Qty. | Description         |  |  |  |  |
|---------|------------|------|---------------------|--|--|--|--|
| ④13107  | 13107-7009 | 1    | Shaft               |  |  |  |  |
| ④13271  | 13271-7017 | 1    | Plate               |  |  |  |  |
| ④14075  | 14075-7009 | 1    | Cap ASM             |  |  |  |  |
| ④16154  | 16154-2053 | 1    | Rotor-Pump (In)     |  |  |  |  |
| ④16154A | 16154-2054 | 1    | Rotor-Pump (Out)    |  |  |  |  |
| ④49065  | 49065-2078 | 1    | Filter-Oil          |  |  |  |  |
| ④49065A | 49065-7004 | 1    | Filter-Oil          |  |  |  |  |
| ④59051  | 59051-7011 | 1    | Gear-Spur           |  |  |  |  |
| ④59231  | 59231-7003 | 1    | Filler              |  |  |  |  |
| ④92043  | 92043-7003 | 2    | Pin                 |  |  |  |  |
| ④92066  | 92066-7003 | 2    | Plug                |  |  |  |  |
| ④92140  | 92140-7003 | 1    | Ball                |  |  |  |  |
| ④92145  | 92145-7002 | 1    | Spring              |  |  |  |  |
| ④130    | 130B0612   | 3    | Bolt-Flanged (6X12) |  |  |  |  |
| ④670    | 670D2016   | 3    | O-Ring (16Mm)       |  |  |  |  |



# Cooling Equipment Assembly Kawasaki FH430V-CS25

| Ref     | Part No.      | Qty. | Description         |  |  |  |  |
|---------|---------------|------|---------------------|--|--|--|--|
| ④13270  | 13270-7007    | 1    | Plate               |  |  |  |  |
| ④14037A | 14037-7025-9H | 1    | Screen              |  |  |  |  |
| ④14091  | 14091-7009    | 1    | Cover               |  |  |  |  |
| ④49089  | 49089-7044    | 1    | Shroud-Engine       |  |  |  |  |
| ④49089C | 49089-7061    | 1    | Shroud-Engine       |  |  |  |  |
| ④59041B | 59041-7012    | 1    | Fan                 |  |  |  |  |
| ④59066B | 59066-7036    | 1    | Housing-Fan         |  |  |  |  |
| ④92004  | 92004-7007    | 2    | Stud                |  |  |  |  |
| ④92153  | 92153-7007    | 3    | Bolt                |  |  |  |  |
| ④92153A | 92153-7008    | 1    | Bolt                |  |  |  |  |
| ④130    | 130B0612      | 4    | Bolt-Flanged (6X12) |  |  |  |  |
| ④130A   | 130B0616      | 2    | Bolt-Flanged (6X16) |  |  |  |  |
| ④130B   | 130B0816      | 1    | Bolt-Flanged (8X16) |  |  |  |  |
| ④311    | 311F0600      | 2    | Nut-Hex (6Mm)       |  |  |  |  |




# Electric Equipment Assembly

## Kawasaki FH430V-CS25


| Ref     | Part No.   | Qty. | Description                   |
|---------|------------|------|-------------------------------|
| ④21171D | 21171-7026 | 1    | Coil-Assy-Ignition            |
| ④21171E | 21171-7027 | 1    | Coil-Assy-Ignition            |
| ④21194  | 21194-7013 | 1    | Flywheel                      |
| ④26030  | 26030-7001 | 1    | Harness                       |
| ④92004  | 92004-7008 | 2    | Stud                          |
| ④92009  | 92009-2308 | 2    | Screw                         |
| ④92066  | 92066-7002 | 1    | Plug                          |
| ④92066A | 92066-7005 | 1    | Plug                          |
| ④92070  | 92070-7003 | 2    | Plug-Spark (R C J 8 Y, Solid) |
| ④92151  | 92151-2097 | 1    | Bolt (12X30)                  |
| ④92200  | 92200-7002 | 1    | Washer                        |
| ④130    | 130B0620   | 2    | Bolt-Flanged (6X20)           |
| ④311    | 311F0600   | 2    | Nut-Hex (6Mm)                 |
| ④510    | 510A5100   | 1    | Key-Woodruff                  |

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |



## Control Equipment Assembly Kawasaki FH430V-CS25


| Ref     | Part No.   | Qty. | Description         |  |  |  |  |
|---------|------------|------|---------------------|--|--|--|--|
| ④13107  | 13107-7010 | 1    | Shaft               |  |  |  |  |
| ④13271B | 13271-7032 | 1    | Plate               |  |  |  |  |
| ④16169  | 16169-7012 | 1    | Link-Choke          |  |  |  |  |
| ④16171  | 16171-7007 | 1    | Link                |  |  |  |  |
| ④39129  | 39129-7003 | 1    | Spring-Governor     |  |  |  |  |
| ④49103  | 49103-7004 | 1    | Arm-Governor        |  |  |  |  |
| ④49113  | 49113-7024 | 1    | Panel-Control       |  |  |  |  |
| ④92009  | 92009-7007 | 1    | Screw (4X35)        |  |  |  |  |
| ④92145  | 92145-7003 | 1    | Spring              |  |  |  |  |
| ④92145A | 92145-7005 | 1    | Spring              |  |  |  |  |
| ④92150  | 92150-2182 | 2    | Bolt (5X18)         |  |  |  |  |
| ④92153A | 92153-7033 | 1    | Bolt (6X35)         |  |  |  |  |
| ④92170  | 92170-7001 | 2    | Clamp               |  |  |  |  |
| ④130    | 130B0612   | 2    | Bolt-Flanged (6X12) |  |  |  |  |
| ④214    | 214B0408   | 2    | Screw-Pan (4X8)     |  |  |  |  |
| ④311    | 311B0600   | 1    | Nut-Hex (6Mm)       |  |  |  |  |
| ④411    | 411B0600   | 1    | Washer-Plain (6Mm)  |  |  |  |  |



## Carburetor Assembly Kawasaki FH430V-CS25

| Ref      | Part No.   | Qty. | Description                |
|----------|------------|------|----------------------------|
| ④ 11061  | 11061-7004 | 1    | Gasket-Insulator           |
| ④ 11061A | 11061-7009 | 1    | Gasket-Chamber             |
| ④ 11061B | 11061-7010 | 1    | Gasket-Screw               |
| ④ 11061C | 11061-7018 | 1    | Gasket-Cleaner, Air        |
| ④ 13107  | 13107-7018 | 1    | Shaft                      |
| ④ 15003  | 15003-7061 | 1    | Carburetor ASM             |
| ④ 16014  | 16014-7002 | 1    | Screw-Pilot                |
| ④ 16020  | 16020-7003 | 1    | Chamber-Float              |
| ④ 16025  | 16025-7006 | 1    | Valve-Throttle             |
| ④ 16030  | 16030-7003 | 1    | Valve-Float                |
| ④ 16031  | 16031-7002 | 1    | Float                      |
| ④ 16041  | 16041-7016 | 1    | Shaft-Choke, Carburetor    |
| ④ 16041A | 16041-7018 | 1    | Shaft-Throttle, Carburetor |
| ④ 16186  | 16186-7002 | 1    | Choke Valve ASM            |
| ④ 39076  | 39076-7001 | 1    | Limiter                    |
| ④ 49121  | 49121-7001 | 1    | Nozzle-Main                |
| ④ 59076  | 59076-7005 | 1    | Manifold-Intake            |
| ④ 92009  | 92009-2083 | 2    | Screw                      |
| ④ 92009A | 92009-2349 | 1    | Screw                      |
| ④ 92055  | 92055-7007 | 2    | O-Ring (I D 31)            |
| ④ 92063  | 92063-7026 | 1    | Jet-Main, No. 88           |
| ④ 92063A | 92063-7028 | 1    | Jet-Main, No. 85           |
| ④ 92063C | 92063-7029 | 1    | Jet-Main, No. 82           |
| ④ 92081  | 92081-2234 | 1    | Spring                     |


| Ref      | Part No.   | Qty. | Description |
|----------|------------|------|-------------|
| ④ 92093  | 92093-2100 | 1    | Seal        |
| ④ 92093A | 92093-7003 | 1    | Seal        |
| ④ 92145  | 92145-7015 | 1    | Spring      |
| ④ 92153  | 92153-7009 | 4    | Bolt        |
| ④ 92172  | 92172-7002 | 1    | Screw       |



## Air Filter and Muffler Assembly Kawasaki FH430V-CS25


| Ref      | Part No.      | Qty. | Description         |
|----------|---------------|------|---------------------|
| ④ 11011B | 11011-7045    | 1    | Case-Filter, Air    |
| ④ 11013  | 11013-7025    | 1    | Element-Filter, Air |
| ④ 11013A | 11013-7031    | 1    | Element-Filter, Air |
| ④ 11053  | 11053-7022    | 1    | Bracket             |
| ④ 11054  | 11054-7002-9H | 1    | Bracket             |
| ④ 11060  | 11060-7021    | 2    | Gasket-Muffler      |
| ④ 13271  | 13271-7022    | 1    | Plate               |
| ④ 16060  | 16060-7016    | 1    | Pipe-Intake         |
| ④ 18088  | 18088-7001    | 1    | Pipe-Exhaust        |
| ④ 32154  | 32154-7006    | 1    | Pipe                |
| ④ 49070B | 49070-7021    | 1    | Muffler             |
| ④ 92015  | 92015-1193    | 2    | Nut                 |
| ④ 92026  | 92026-7001    | 2    | Spacer (6.2X7.9X5)  |
| ④ 92055  | 92055-7015    | 1    | O-Ring              |
| ④ 92072B | 92072-7012    | 1    | Band                |
| ④ 92170  | 92170-7002    | 1    | Clamp               |
| ④ 92192  | 92192-7010    | 1    | Tube                |
| ④ 92200  | 92200-2070    | 2    | Washer              |
| ④ 92210  | 92210-7004    | 2    | Nut                 |
| ④ 92210A | 92210-7019    | 1    | Nut                 |
| ④ 130    | 130B0610      | 1    | Bolt-Flanged (6X10) |
| ④ 130A   | 130B0612      | 2    | Bolt-Flanged (6X12) |
| ④ 130B   | 130B0816      | 3    | Bolt-Flanged (8X16) |

| Ref   | Part No. | Qty. | Description              |
|-------|----------|------|--------------------------|
| ④ 220 | 220B0614 | 2    | Screw-Pan (Cross) (6X14) |
| ④ 233 | 233B0416 | 1    | Screw (4X16)             |
| ④ 311 | 311B0400 | 1    | Nut-Hex (4Mm)            |
| ④ 317 | 317R0800 | 4    | Nut-Hex (8Mm)            |
| ④ 461 | 461F0800 | 4    | Washer-Spring (8Mm)      |
| ④ 670 | 670B2010 | 1    | O-Ring (10Mm)            |



# Fuel Tank and Valve Assembly Kawasaki FH430V-CS25

| Ref     | Part No.      | Qty. | Description          |  |  |  |  |
|---------|---------------|------|----------------------|--|--|--|--|
| ④23062  | 23062-7004-9H | 1    | Bracket              |  |  |  |  |
| ④42036  | 42036-7012    | 1    | Sleeve               |  |  |  |  |
| ④49019  | 49019-7001    | 1    | Filter-Fuel          |  |  |  |  |
| ④49040  | 49040-7001    | 1    | Pump-Fuel            |  |  |  |  |
| ④92170B | 92170-2088    | 4    | Clamp                |  |  |  |  |
| ④92191  | 92191-7002    | 1    | Tube                 |  |  |  |  |
| ④92192  | 92192-7035    | 1    | Tube (6.35X12.7X170) |  |  |  |  |
| ④92192A | 92192-7037    | 1    | Tube (6.35X12.7X160) |  |  |  |  |
| ④130    | 130B0620      | 2    | Bolt-Flanged (6X20)  |  |  |  |  |



# Starter Assembly Kawasaki FH430V-CS25

| Ref      | Part No.      | Qty. | Description          |  |  |  |  |
|----------|---------------|------|----------------------|--|--|--|--|
| ④ 13165  | 13165-7001    | 2    | Pawl-Starter, Recoil |  |  |  |  |
| ④ 13271  | 13271-7003-9H | 1    | Plate                |  |  |  |  |
| ④ 14020  | 14020-7001    | 1    | Retainer             |  |  |  |  |
| ④ 32099  | 32099-7002    | 1    | Case-Starter, Recoil |  |  |  |  |
| ④ 46075  | 46075-7001    | 1    | Grip-Starter, Recoil |  |  |  |  |
| ④ 49080  | 49080-7001    | 1    | Pulley-Starting      |  |  |  |  |
| ④ 49088  | 49088-7013    | 1    | Starter-Recoil       |  |  |  |  |
| ④ 59101  | 59101-7001    | 1    | Reel-Starter, Recoil |  |  |  |  |
| ④ 59106A | 59106-7005    | 1    | Rope                 |  |  |  |  |
| ④ 92145  | 92145-7006    | 1    | Spring               |  |  |  |  |
| ④ 92145A | 92145-7007    | 2    | Spring               |  |  |  |  |
| ④ 92145B | 92145-7008    | 1    | Spring               |  |  |  |  |
| ④ 92151  | 92151-7008    | 1    | Bolt                 |  |  |  |  |
| ④ 92200  | 92200-7004    | 1    | Washer               |  |  |  |  |
| ④ 92200A | 92200-7005    | 1    | Washer               |  |  |  |  |
| ④ 92210  | 92210-0003    | 4    | Nut                  |  |  |  |  |
| ④ 130    | 130B0608      | 3    | Bolt-Flanged (6X8)   |  |  |  |  |





# Attachments and Accessories

For 30692 - ProLine Walk-Behind Mower, Fixed Deck T-Bar Gear with 32in Cutting Unit

| Product Name                            | Model/Part |
|-----------------------------------------|------------|
| Atomic Blade and Decal Assembly .....   | 104-8595   |
| Blade-16.25 Inch (6 Pack) .....         | 108-1119   |
| Blade-Atomic, 16.25 Inch (6 Pack) ..... | 110-0407   |
| 32 Inch Recycler Kit .....              | 110-4915   |
| Soft Bag (3 Bushel) .....               | 30198      |

## NOTES

