


TORO®

MODEL NO. 38080-2000001 & UP

**PARTS
CATALOG****824 SNOWTHROWER**


C-0041

AUGER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	43-7440	Sideplate - Auger Right	1
2	26-6140	Auger - Right	1
*	26-6150	Auger - Left	1
3	40-8120	Housing - Auger	1
5	321-44	Screw - Hex. Hd. Cap	2
6	66-8010	Spacer	2
7	3242-4	Screw - Set	4
8	3230-1	Bolt - Carriage	3
9	3296-39	Nut - Lock	3
10	32152-2	Nut - Lock	2
11	20-4320	Washer - Rubber	2
12	63-3760	Decal - Discharge	1
13	20-1410	Handle - Deflector	1
14	11-9379	Deflector Chute (Incl. Ref.#12)	1
15	3-0737	Washer - Thrust	2
16	20-1310	Pulley - Impeller	1

Ref. No.	Part No.	Description	No. Used
17	3257-23	Key - Woodruff	2
18	3231-27	Bolt Carriage	4
19	56-2450	Chute	1
20	54-9770	Wire - Chute	1
21	27-0210	Screw - Special	4
22	43-7470	Gear - Chute Swivel	1
23	40-8150	Retainer - Chute	2
24	3290-326	Pushnut	2
25	3290-340	Washer - Belleville	2
26	3296-29	Nut - Lock	15
27		Bearing - Flange Rear	1
28	63-3450	Bearing - Impeller	1
29		Bearing - Flange, Front	1
30	26-6400	Positioner - Scraper, Blade	2
31	5-7290	Spring - Scraper, Blade	2
32	20-0300	Spacer - Scraper Blade	2
33	3296-8	Nut - Lock	9

*Not Illustrated




C-0041

AUGER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
34	20-0990	Bearing - Flange Auger	2	58	252-71	Bearing - Thrust	2
35	20-0980	Bearing - Auger	2	59	252-78	Washer - Thrust	1
36	20-1000	Bearing - Flange Auger	2	60	252-76	Bearing - Thrust	1
37	3234-14	Screw - Hex. Hd. Cap	2	61	3-8664	Washer - Thrust	1
38	17-6500	Decal - Auger Side Plate	2	62	32120-72	Ring - Retaining	1
39	321-3	Screw - Hex. Hd. Cap	8	63	256-32	Bushing	1
40	3-0750	Washer - Flat	2	64	5-7170	Worm	1
41	323-6	Screw - Hex. Hd. Cap	2	65	252-77	Washer - Thrust	1
42	3234-11	Bolt - Hex. Flange	2	66	51-0460	Gasket	1
43	20-2840	Skid - Auger	2	67	37-8850	Gear Case	
44	3290-357	Nut - Flange	4			(Incl. Ref. #68 & 69)	1
45	43-7430	Sideplate - Auger L.H.	1	68	256-237	Bushing	2
46	25-5140	Standoff - Scraper Blade	2	69	7-0045	Seal - Oil	2
47	25-5150	Bumper - Scraper Blade	2	70	32144-41	Screw - Thread Forming	8
48	20-1320	Blade - Scraper	1	71	20-3210	Bushing	1
49	32128-21	Nut - Lock	2	72	237-87	Seal	1
50	25-5090	Spacer - Auger Hub	2	73	53-7670	Decal - Warning Auger	1
51	17-7030	Bolt - Auger	2	74	66-6930	Impeller	1
52	66-6941	Shaft - Impeller	1	75	6-8590	Key - Impeller	1
53	3257-33	Key - Woodruff	2	76	3242-4	Screw - Sq. Hd. Set	1
54	20-1170	Shaft - Auger	1	*	19-7002	Gear Case Assembly	1
55	37-8860	Case - Gear		*	20-0690	Drift Breaker Kit (Optional)	1
		(Incl. Ref. #68 & 69)	1	*	12-8789	Bearing Assembly	
56	281-1	Plug - Pipe	1			(Incl. Ref. #27 & 29)	1
57	5-7180	Gear - Worm	1				

* Not Illustrated




C-0042

TRACTION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290-383	Pushnut	1
2	3256-25	Washer - Flat	1
3	20-1420	Side Plate Traction	1
4	20-1160	Spring - Clutch Torsion	1
5	8-9019	Rod - Clutch (Incl. Ref.#66)	1
6	3296-59	Nut - Lock	1
7	32144-69	Screw - Thd. Form	8
8	3-4244	Pulley Idler	1
9	3256-45	Washer - Flat	2
10	323-8	Screw - Hex. Hd. Cap	1
11	32108-94	Screw - Flat Hd.	4
12	20-1620	Bearing - Friction Wheel	2
13	11-4640	Spring - Clutch Control	1
14	20-1580	Pivot Shaft	1
15	32144-11	Screw - Thread Forming	9
16	3245-32	Screw - Set	2
17	3296-29	Nut - Lock	7
18	3256-23	Washer	4
19	36-9990	Bracket - Shaft Support	1
20	322-2	Screw - Hex. Hd. Cap	2
21	322-3	Screw - Hex. Hd. Cap	2

Ref. No.	Part No.	Description	No. Used
22	321-33	Screw - Hex. Hd. Cap	1
23	32121-6	Pin - Roll	1
24	3-0737	Washer - Thrust	5
25	26-6370	Spacer - Drive Shaft	1
26	20-1080	Support - Clutch Shaft	1
27	322-9	Screw - Hex. Hd. Cap	2
28	26-6360	Frame - Center	1
29	20-1760	Bracket - Pivot	1
30	26-6380	Standoff - Drive Shaft	2
31	20-1730	Bearing - Axle	3
32	20-1550	Plate - Friction	1
33	3296-8	Nut - Lock	1
34	36-9980	Bearing - Pillow Block	1
35	5-9820	Sprocket	1
36	3-7384	Spacer	1
37	2710-6	Link - Connecting	1
38	20-1810	Chain	1
39	20-1640	Gear & Bushing Assembly (Incl. Ref. #40)	1
40	3-1506	Bushing - Flanged	2
41	20-1430	Side Plate Traction	1
42	11-8140	Screw - Shoulder	3




C-0042

TRACTION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
43	231-120	Tire	2
44	232-46	Tube	2
45	3290-243	Pin - Klik	2
46	241-128	Wheel	2
47	32144-10	Screw - Thread Forming	4
48	20-1680	Axle & Gear Assembly	1
49	20-1630	Shaft - Friction Wheel	1
50	3-6168	Key - Square	1
51	20-1780	Linkage - Shaft	1
52	20-1770	Plate - Pivot	1
53	32151-36	Ring - Snap	1
54	252-71	Bearing - Thrust	1
55	11-8050	Slider Ring Collar	1
56	11-8080	Ring - Slider	2

Ref. No.	Part No.	Description	No. Used
57	32121-9	Pin - Roll	1
58	32128-12	Nut - Flange	1
59	3290-212	Washer - Lock	2
60	3296-6	Nut	1
61	22-7930	Shaft - Drive	1
62	20-1840	Shield - Lower	1
63	20-3310	Hub - Traction Drive	1
64	40-8170	Wheel - Friction	1
65	3296-47	Nut - Lock	4
66	66-8060	Pad - Brake Moulded	1
67	66-6750	Bracket - Spring	1
69	32153-2	Nut - Lock	1
*	12-0179	Loose Parts Kit	1
*	56-2700	Tire Chain Kit (Optional)	1


*Not Illustrated



C-0058

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3255-8	Washer - Lock	3	16	32144-69	Screw - Hex.Thread Form	4
2	20-1800	Arm - Idler	1	17	37-0320	Plate - Engine Mounting	1
3	52-2670	Fuel Tank Assembly	1	18	322-7	Screw - Hex. Hd. Cap	4
4	40-8490	Spacer	1	19	17-5530	Retainer - Belt	1
5	5-0930	Key	1	20	3256-23	Washer	3
6	74-1170	Decal - danger	1	21	20-1820	V-Belt Traction	1
7		Engine	1	22	26-9670	V-Belt Auger	1
8	63-3190	Decal - Throttle	1	23	32144-10	Screw - Thread Forming	2
9	53-7680	Decal - Warning	1	24	20-1830	Guard - Belt	1
10	39-3850	Decal - Choke	1	25	21-4100	Pulley	1
11	32144-4	Screw - Thread Forming	1	26	323-8	Screw - Hex. Hd. Cap	1
12	41-8601	Module - Interlock	1	27	3-4244	Pulley - Idler	1
13	3296-29	Nut - Lock	4	28	3246-18	Screw - Set	2
14	289-52	Nipple - Pipe	1	29	3296-59	Nut - Lock	1
15	288-2	Cap - Pipe	1	30	3210-3	Screw - Hex. Hd. Cap	3




HANDLE ASSEMBLY

C-0059

Ref. No.	Part No.	Description	No. Used
1	14-5469	Escutcheon Plate	1
2	237-130	Bushing - Snap	1
3	3290-354	Clip	2
4	29-6360	Decal - Safety Interlock	1
5	3290-313	Screw - Pan Hd. Machine	4
6	40-8200	Switch - Micro	2
7	22-7950	Pad - Switch Mounting	1
8	12-3270	Screw - Special	1
9	40-9690	Handle - Interlock Switch	1
13	63-8360	Key	2
14	218-461	Nut - Hex.	1
15	3254-5	Washer - Lock	1
16	3296-2	Nut Lock	2
17	3251-5	Screw - Machine	2
18	22-9740	Spacer Interlock	2
19	22-9730	Spring Interlock	1
20	233-21	Knob	2
21	22-9751	Slide Interlock	1
22	40-8241	Switch - On /Off (Incl. Ref. #14 &15)	1
23	74-1390	Decal - Instructions	1
24	3296-42	Nut Lock	4

Ref. No.	Part No.	Description	No. Used
25	43-4750	Clamp - Wire	5
26	3290-257	Washer - Pyramidal	2
27	43-4760	Stud - Mounting	5
28	25-6040	Handle - L.H.	1
29	74-1380	Grip - Handle	2
30	32151-43	Ring - Klip	2
31	321-11	Screw - Hex. Hd. Cap	3
32	321-9	Screw - Hex. Hd. Cap	1
33	63-3510	Decal - Chute Direction	1
34	3290-320	Pushnut	2
35	66-6540	Grip - Chute Control	1
36	40-8311	Rod - Chute Control	1
37	256-249	Nyliner	1
38	3296-29	Nut Lock	2
39	12-7739	Bracket - Chute Control (Incl. Ref. #33 & 37)	1
40	17-5630	Spring - Conical	1
41	323-4	Screw - Hex. Hd. Cap	4
42	3230-2	Bolt - Carriage	1
43	3290-238	Washer - Pyramidal	1
44	40-8280	Bracket - Worm	1
45	40-8250	Gear - Worm, Chute	1




C-0059

HANDLE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
46	3220-3	Nut - Jam	3	60	40-8630	Wire Harness Interlock	1
47	40-8180	Clevis	3	61	322-9	Screw - Hex. Hd. Cap	1
48	3290-433	Retainer - Nut	4	62	3256-25	Washer	2
49	40-8430	Handle R.H.	1	63	3290-213	Washer - Lock	1
50	3272-6	Pin - Cotter	3	64	11-8140	Screw - Shoulder	1
51	281-1	Pin - Clevis	3	65	20-1910	Rod - Pivot	1
52	20-1980	Rod - Speed Control	1	66	28-5660	Spacer - Shift Rod	1
53	237-89	Grommet	1	67	20-1920	Lever	1
54	3256-24	Washer	3	68	66-6580	Decal - Escutcheon	1
55	3272-6	Pin - Cotter	3	69	28-5670	Spacer - Auger Lever	1
56	20-2020	Shift - Lever	1	70	25-9760	Strap - Escutcheon Support	1
57	20-2010	Bracket - Shift	1	71	3290-461	Washer - Belleville	4
58	20-1970	Rod Traction Control	1	*	3290-378	Tie - Wrap	2
59	32152-1	Nut - Lock	1				

*Not Illustrated




C-0044

SNOW CAB ASSEMBLY MODEL 42-3380 (Optional)

Ref. No.	Part No.	Description	No. Used
1	12-8040	Post - Front Corner	2
2	32153-4	Nut - Lock	12
3	321-4	Screw - Hex. Hd. Cap	8
4	12-8010	Frame - Top	1
5	12-8030	Bow - Rear Vertical	1
6	42-4060	Bracket - Attaching L.H.	1

Ref. No.	Part No.	Description	No. Used
7	12-8050	"U" Clamp	2
8	321-11	Screw - Hex. Hd. Cap	4
9	12-8020	Bow - Horizontal Curved	1
10	42-4050	Bracket - Attaching R.H.	1
*		Cover - Vinyl	1

*Not Illustrated




C-0037

LIGHT KIT NO. 54-9822 (Optional)


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	218-473	Boot - Switch	1	12	2210-274	Alternator	1
2	218-553	Switch Assembly	1	14	2210-268	Shaft - Alternator 4''	1
3	218-552	Bucket - Headlamp	1	15	3217-7	Nut - Hex.	1
4	2118-554	Bracket	1	16	3253-31	Washer - Lock	1
5	3255-8	Washer - Lock	2	17	218-556	Bracket - U	1
6	322-13	Screw - Hex. Hd. Flanged	1	18	3231-2	Bolt - Carriage	1
7	54-9830	Mount - Lamp	1	19	32128-35	Nut - Flange Lock	1
8	3290-378	Tie - Wrap	2	20	218-16	Lens - Seal Beam	1
†9		Fuse - 7-1/2 Amp	1	*	54-9871	Head Lamp Assembly (Incl. Ref.#1-6,9-10, & 15 -20)	1
10	218-555	Wire Assembly	1				
11	2210-272	Connector - Wire	1				
12	2210-273	Screw - Self Tapping	3				

*Not Illustrated
† Obtain Locally



ELECTRIC START MOTOR KIT NO. 37-4810

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	33842	Ring - Retaining	1	14	33441	Screw - Ground	1
2	33430	Retainer - Spring	1	15	35453	Cap Assembly Commutator End (Incl. Ref.#7)	1
3	33431	Spring - Anti-drift	1	16	35454	Switch Box Assembly	1
4	33432	Gear	1	22	35455	Bolt - Case	2
5	33433	Nut - Engagement	1	23	35456	Screw - Grounding	1
6	35449	Cap Assembly - Cap End (Incl. Ref. #7)	1	24	33451	Cover - Dust	1
7	35450	"O" Ring	2	26	650819	Screw - Self Tapping	2
8	335541A	Armature	1	29	32450A	Cord - Power (10'6")	1
9	35451	Housing Assembly	1	30	30063	Screw - Fil. Hd.	2
10	35452	Card Assembly - Brush	1	31	650820	Screw - Hex.Hd. Shoulder	2
13	590500	Washer - Thrust	1				




CARBURETOR NO. 632334A

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	631776A	Shaft & Lever Assembly	1	*30	631021	Inlet Needle - Seat & Spring Clip (Incl. Ref. #31)	1
2	631970	Spring - Throttle Return	1	31	631022	Clip - Spring	1
6	631778	Throttle - Shutter	1	32	27136A	Bowl Drain Assembly (Incl. Ref. # 33)	1
7	650506	Screw - Throttle & Choke Shutter	4	33	27554	Gasket - Drain Plunger	1
10	632112	Choke Shaft & Lever Ass'y	1	40	632239	High Speed Mixture Screw Assembly	1
14	632174	Shutter - Choke	1	*41	630740	O-Ring - High Speed Mixture Screw	1
15	630735	Spring - Choke Positioning	1	42	630739	Washer - High Speed Mixture Screw	1
16	632164	Fitting - Fuel	1	43	630738	Tension Spring - High Speed Mixture Screw	1
17	650417	Screw - Idle Speed	1	*44	27110	Washer - Bowl Nut	1
18	630766	Spring - Tension	1	*47	630748	Welch Plug - Idle Mixing Well	1
20	632281	Screw - Idle Mixture	1	*48	631027	Welch Plug - Atmospheric Vent	1
21	630766	Spring - Idle Mixture Screw	1	60	632347	Repair Kit	1
22	630739	Washer - Idle Screw	1				
*23	630740	O-Ring - Idle Screw	1				
25	631951	Bowl - Float (Incl. Ref. #32, & 33)	1				
*27	631024	Shaft - Float	1				
28	632019	Float	1				
*29	631028	O-Ring - Float Bowl to Body	1				

*Included in Carburetor Repair Kit Ref. #60

ENGINE TECUMSEH MODEL NO. HM80-155438 P




ENGINE TECUMSEH MODEL NO.HM80-155438 P

Ref. No.	Part No.	Description	No. Used
1	35385	Cylinder (Incl. Ref. #2, 20, & 72)	1
2	27652	Pin - Dowel	2
3	650820	Screw - Hex Hd. Shoulder	2
15	30699C	Rod Ass'y - Governor (Incl. Ref. #15A & 15B)	1
15A	30700	Yoke - Governor	1
15B	650494	Screw - Fil. Hd. Sems	1
16	33454	Lever - Governor	1
17	29916	Clamp - Governor Lever	1
18	650548	Screw - Hex Washer Hd.	1
19	34663	Spring - Speed Control	1
20	35319	Seal - Oil	1
25	35326	Baffle - Blower Housing	1
26	650561	Screw - Hex Washer Hd. Durluk	2
30	35372	Crankshaft	1
35	29826	Screw - Hex Washer Hd.	1
36	29918	Washer - E.T. Lock	1
37	29216	Nut & Lockwasher Keps	1
37A	30322	Locknut - Hex Keps	1
38	29642	Ring - Retaining	1
40	34552	Piston - Pin & Ring Ass'y Std. (Incl. Ref. #41, 42, & 43)	1
40	34553	Piston - Pin & Ring Ass'y (.010 Oversize) (Incl. Ref. #41, 42, & 43)	1
40	34554	Piston - Pin & Ring Ass'y (.020 Oversize) (Incl. Ref. #42, 42, & 43)	1
41	34329A	Piston & Pin Ass'y (Std.) (Incl. Ref. #43)	1
41	34330A	Piston & Pin Ass'y (.010 Oversize) (Incl. Ref. #43)	1
41	34331A	Piston & Pin Ass'y (.020 Oversize) (Incl. Ref. #43)	1
42	34332	Ring Set - Piston (Std.)	1
42	34333	Ring Set - Piston (.010 Oversize)	1
42	34334	Ring Set - Piston (.020 Oversize)	1
43	27888	Ring - Piston Pin Retaining	2
45	35373A	Rod Ass'y - Connecting (incl. Ref. #46, 47, & 49)	1
46	650908	Bolt - Connecting Rod	1
47	650882	Bolt - Connecting Rod	1
48	34034	Lifter - Valve	2
49	35374	Dipper - Oil	1
50	35375	Camshaft (Mechanical Compression Release)	1
60	33273A	Extension - Blower Housing	1
61	34126	Bracket - Grommet Mounting	1
62	650760	Screw - Pan Hd. Taptite	1
63	28545	Grommet - Plastic	1
65	650128	Screw - Hex Hd. Sems	1
*69	35262	Gasket - Cylinder Cover	1
70	35376	Cover Ass'y - Cylinder (Incl. Ref. #75 & 80)	1

Ref. No.	Part No.	Description	No. Used
71	35377	Bushing - Cylinder Cover	1
72	27642	Plug - Pipe	2
75	35319	Seal - Oil	1
80	31845	Shaft - Governor	1
81	30590A	Washer - Flat	1
82	35378	Gear - Governor (Incl. Ref. #81)	1
83	30588A	Spool - Governor	1
84	29193	Ring - Retaining	1
86	650833	Screw - Hex Washer Hd. Powerlok	7
87	650832	Screw - Hex Washer Hd. Powerlok	1
89	32589	Key - Flywheel	1
90	611091	Flywheel (w/ring gear)	1
92	650880	Washer - Lock	1
93	650881	Nut - Flywheel	1
100	35135	Solid State Ass'y	1
101	610118	Cover - Spark Plug	1
102	650872	Stud - Solid State Mounting	2
103	650814	Screw T-15 Torx Hex Washer Hd. Sems	1
110	35253	Wire - Ground	1
*119	34041A	Gasket - Cylinder Head	1
120	34030	Head - Cylinder	1
125	27878A	Valve - Exhaust (Std.) (Incl. Ref. #151)	1
125	27880A	Valve - Exhaust (1/32" Oversize) (Incl. Ref. #151)	1
126	34035	Valve - Intake (Std.) (Incl. Ref. No. 151)	1
126	34036	Valve - Intake (1/32" Oversize) (Incl. Ref. #151)	1
127	650691	Washer - Flat	2
129	650727	Screw - Special Hex Hd. Tapped	2
130	6021A	Screw - Hex Flange Hd.	7
130A	650802	Screw - Hex Washer Hd. Taptite	1
131A	650713	Screw - Hex Hd.	2
135	35395	Spark Plug (Champion RJ-19LM or equiv.)	1
139	33369	Bracket - Governor Gear	1
140	650836	Screw - Hex Washer Hd. Thread Forming	2
149	27882	Cap - Upper Valve Spring	1
149A	35862	Seal Ass'y - Intake Valve	1
150	27881	Spring - Valve	2
151	32581	Cap - Lower Valve Spring	2
*169	27896A	Gasket - Breather	2
170	28423	Body - Breather	1
171	28424	Element - Breather	1
172	28425	Cover - Breather	1
173	35350	Tube - Breather	1
174	650128	Screw - Hex Hd. Sems	2
178	29752	Nut & Lockwasher	1
182	30088A	Screw - Fil. Hd. Sems	2
183	34587	Bracket - Choke	1

*Indicates Parts included in Gasket Set Ref. #400

ENGINE TECUMSEH MODEL NO. HM80-155438 P




ENGINE TECUMSEH MODEL NO.HM80-155438 P

Ref. No.	Part No.	Description	No. Used
*184	33263	Gasket - Carburetor	1
185	33877	Pipe - Intake	1
186	34667	Link - Governor	1
200	34677	Bracket Ass'y - Control (Incl. Ref. #19, 203, 204, & 206)	1
203	31342	Spring - Compression	1
204	650549	Screw - Fil. Hd.	1
206	610973	Terminal Ass'y	1
207	33878	Link - Governor-to-Throttle	1
209	650821	Screw - Hex Washer Hd. Thread Cutting	2
215	35440	Knob - Control	1
219	34586	Rod - Choke	1
220	35438	Knob - Choke	1
222	28820	Screw - Fil. Hd. Sems	2
223	650378	Screw - T-30 Torx Fil Hd. Sems	2
*224	27915A	Gasket - Intake Pipe	1
260	34822A	Housing - Blower	1
261	650788	Screw - Hex Hd. Spinlock Thread Forming	2
262	29747B	Screw - Hex Hd. Sems	2
265	33272A	Cover - Cylinder Head	1
275	35056	Muffler	1
276	31588	Plate - Lock	1
277	792093	Screw - Flanged Hex Hd.	2
281	33013	Cover - Starter Hole	1
282	650760	Screw - Pan Hd. Taptite	1
285	35287	Hub - Starter	1
286	35446	Screen - Starter	1
287	29752	Nut & Lockwasher	4
290	29774	Line - Fuel (8 1/4")	1
291	30705	Line - Fuel (16")	1
292	26460	Clamp - Fuel Line	4
295	35857	Valve - Fuel Shut-Off	1
298	650665	Screw - Hex Washer Hd. Thread Cutting	2

Ref. No.	Part No.	Description	No. Used
300	34156A	Tank - Fuel (Incl. Ref. #292 & 301)	1
301	35355	Cap - Fuel Tank	1
305	35554	Tube - Oil Fill	1
306	35499	O-Ring	1
308	35540	Clip - Fill Tube	1
310	35555	Dipstick - Oil	1
325	29443	Clip - Spring	1
327	35392	Plug - Starter	1
336	650765	Screw - Hex Washer Hd. Self-Drilling	1
337	35057A	Cover - Carburetor	1
338	28942	Screw - Hex Washer Hd. Sems	2
340	34155	Bracket - Fuel Tank	1
342	650561	Screw - Hex Washer Hd. Durlok	1
345	34154	Plate - Fuel Tank Mounting	1
350	570682	Primer Ass'y	1
351	32180C	Line - Primer	1
355	590574	Starter Handle - Mitten Grip	1
364	33377	Bracket - Carburetor Cover Mounting	1
365	650767	Screw - Hex Washer Hd. Sems Taptite	2
380	632334A	Carburetor (Incl. Ref. #184)	1
390	590630	Starter - Rewind	1
395	33329C	Motor Kit -Electric Starter (120 Volt) (Order as an accessory)	1
400	33279G	Gasket Set	1
421	730226	SAE5W30 4 Cycle Oil (Quart) RPM Setting: Low Speed 1700, High Speed 3450	1

*Indicates Parts included in Gasket Set Ref. #400



REWIND STARTER NO.590630

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	590599A	Pin - Spring	1	8	590628	Pulley	1
2	590600	Washer	1	9	590451A	Rope ,Starter	1
3	590651	Spring Assembly	1	10	590629	Spring & Keeper Assembly	1
4	590627	Retainer	1	11	590574	Handle, Mitten Grip (Not Included With Starter	1
5	590641	Dog - Starter	1	12	590631	Housing Assembly,Starter	1
7	590601	Washer	8				