


TORO®

MODEL NO. 38025-2000001 & UP

**PARTS
CATALOG****1800 POWER CURVE SNOWTHROWER****HOUSING & ROTOR ASSEMBLY**


C-0455

Ref. No.	Part No.	Description	No. Used
1	73-0220	Plate - Side	2
2	32104-121	Screw - Pan Hd.	23
3	32112-1	Push Nut	2
4	73-5720	Wheel	2
5	249-42	U-Clip - Tinnerman	4
6	73-0250	Sleeve - Axle	1
7	73-0370	Shaft - Axle	1
8	64-5820	Relief - Strain	1
9	73-0450	Decal - Danger	1
11	218-511	Connector	2
12	73-0302	Shroud - Housing	1
13	256-307	Bushing	1
14	73-0280	Tube - Lower Handle	1
15	73-3630	Wire Harness	1

Ref. No.	Part No.	Description	No. Used
17	73-1800	Filter - Foam	1
18	32144-88	Screw - Pan Hd.	4
19	73-0120	Strap - Motor	1
20	73-3520	Motor	1
21	73-3700	Motor Plate Assembly	1
23	32144-100	Screw - Hex. Washer Hd.	2
24	73-3660	Pulley - Driver	1
25	73-0160	Belt - Timing	1
26	73-3580	Washer	1
27	252-102	Bearing - Needle	2
28	73-3810	Pulley Assembly - Idler (Incl. Ref. #27)	1
29	73-0041	Washer - Thrust	2
30	75-3530	Bolt - Idler	1

* Not Illustrated

TPS




C-0455

HOUSING & ROTOR ASSEMBLY (CONTINUED)

Ref. No.	Part No.	Description	No. Used
31	61-8801	Belt - Drive	1
33	73-5730	Bearing Assembly (Incl. Ref. #40)	1
34	27-0411	Screw - Shoulder	1
37	25-5641	Washer	1
38	73-3600	Bracket - Idler	1
39	73-3680	Spring	1
40	3296-29	Nut - Lock	1
41	73-3550	Pulley - Driven	1
42	73-3650	Clamp - Motor Bracket	2
43	32104-97	Screw - Hex. Hd.	2
44	73-3640	Housing - Rotor	1

Ref. No.	Part No.	Description	No. Used
45	73-0990	Shaft - Rotor Driver	1
46	73-0860	Coupler - Rotor	1
47	73-0400	Rotor	1
48	73-3690	Scraper	1
49	73-0040	Washer	1
50	73-1900	Bracket - Wheel (Incl. Ref.#52)	2
51	3290-271	Rivet - Pop	2
52	61-8780	Bearing - Ball	2
53	73-0020	Shaft - Rotor	1
54	73-1570	Skid - Housing	2
55	32144-108	Screw - Pan Hd.	2

* Not Illustrated




C-0456

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	73-3510	Bar - Switch	1
2	64-4930	Switch	1
3	73-5700	Handle - Upper Control	1
4	73-5190	Key	1
5	73-5710	Handle - Lower Control	1
6	73-5690	Tab - Lock	1
7	32104-121	Screw - Pan Hd. Form.	11
8	73-5640	Cord - Supply	1
9	73-3460	Tube - Upper Handle	10
10	32112-1	Push Nut	1

Ref. No.	Part No.	Description	No. Used
11	73-0251	Sleeve - Chute Crank	1
12	33-8951	Screw - Hex. Hd. Mach.	2
13	3296-12	Nut - Lock	2
14	73-0490	Decal - Escutcheon	1
15	73-0240	Rod - Chute Crank	1
16	73-0230	Gear - Chute Crank	1
17	73-0310	Plate - Escutcheon	1
18	256-306	Bushing - Snap In	1
20	73-3450	Spring	2
21	73-3710	Brake - Gear	1



C-0457

CHUTE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	73-0190	Chute - Deflector	1
2	3256-68	Washer - Flat	2
3	3296-29	Nut - Lock	2
4	73-0260	Handle - Middle	1
5	32104-121	Screw - Pan Hd. Form.	4
6	20-4320	Washer - Rubber	2

Ref. No.	Part No.	Description	No. Used
7	73-0180	Chute - Lower	1
8	3230-2	Bolt - Carriage	2
*	73-0520	Loose Parts (Incl. Ref.# 2,3,6,8 Page 4 & # 12,13 Page 3)	1

* Not Illustrated