Form Number 3356-532 Rev B

TimeCutter™ Z5000
Riding Mower

Model No. 74370 - 270000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2007
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page
Frame Assembly	3
Deck Lift and Seat Support Assembly	4
Seat Assembly	5
Control Assembly	6
Hydro Drive Assembly	7
Engine and Clutch Assembly	8
Styling and Fuel System Assembly	9
50in Deck and Side Discharge Assembly	10
50in Deck Assembly No. 110-6790	11
50in Deck Spindle and Belt Drive Assembly	12
Electrical Assembly	13
Crankshaft Assembly Kohler SV610-0020	14
Crankcase Assembly Kohler SV610-0020	15
Air Intake and Filtration Assembly Kohler SV610-0020	16
Exhaust Stud, Gasket and Decal Assembly Kohler SV610-0020	17
Oil Pan and Lubrication Assembly Kohler SV610-0020	18
Head, Valve and Breather Assembly Kohler SV610-0020	19
Ignition and Electrical Assembly Kohler SV610-0020	20
Blower Housing Assembly Kohler SV610-0020	21
Starter Assembly Kohler SV610-0020	22
Fuel System Assembly Kohler SV610-0020	23
Engine Control Assembly Kohler SV610-0020	24
Attachments and Accessories List	25


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

Footnotes


❶ Not illustrated
❷ Not serviced separately
❸ Obtain from your local Kohler dealer



Frame Assembly


Ref	Part No.	Qty.	Description
1	110-6780-01	1	Frame
2	110-6899-03	1	Bumper-Rear
3	110-6872-03	1	Seat Control ASM
4	108-7882-01	1	Front Axle ASM
5	110-6785	2	Castor Wheel ASM
5:1	110-6791	1	Tire-Smooth
5:2	302-5	1	Fitting-Grease
5:3	232-27	1	Stem-Valve
5:5	114-1640	2	Bushing-Flange
❶5:99	93-4244	1	Tube-Inner (W/Valve)
6	104-3667	2	Spanner-Wheel
7	325-22	2	Screw-HH
8	32128-23	2	Nut-HF
9	108-7851-01	2	Caster Fork ASM
10	110-6767	2	Washer-Thrust
11	1-303514	4	Bearing-Flanged
12	104-8076	2	Washer
13	32151-103	2	Ring-Snap
14	61-9780	2	Cap-Hub
15	3234-47	7	Screw-HHF
16	108-7855-03	1	Footrest
17	3296-29	7	Nut-Lock, NI
18	32104-32	2	Screw-HWH
19	302-5	2	Fitting-Grease

Ref	Part No.	Qty.	Description
20	323-8	4	Screw-HH
21	80-6990	2	Washer-Hardened
22	3296-39	8	Nut-Lock, NI
23	323-13	4	Screw-HH
24	99-2385	1	Decal
25	3256-24	10	Washer-Flat




Deck Lift and Seat Support Assembly

Ref	Part No.	Qty.	Description
1	112-4027-03	1	Sector-HOC
2	322-10	2	Screw-HH
3	322-6	3	Screw-HH
4	112-3960-03	1	Lift Arm ASM
5	108-7841-03	1	Lift Lever ASM
6	110-6800-03	1	Plate-Lift
7	110-6805-03	1	Bracket-Seat/Pods
8	110-1937-03	1	Tray-Battery
9	3296-29	8	Nut-Lock, NI
10	108-7840	1	Link-Lift
11	108-7839	1	Arm-Lift, Rear
12	108-7845	2	Block-Pivot
13	112-9802	1	Decal-HOC
14	105-3450	1	Grip-Lever, Lift
15	3272-10	1	Pin-Cotter
16	3256-26	1	Washer-Flat
17	3296-58	3	Nut-Lock, NI
18	3234-47	6	Screw-HHF
19	3256-23	3	Washer-Flat
20	106-8743	1	Decal
21	32104-32	1	Screw-HWH



Seat Assembly


Ref	Part No.	Qty.	Description
1	110-6679-03	1	Base-Seat
2	110-6772	1	Seat-18 Inch
3	701178	2	Cap-Protector
4	3234-47	2	Screw-HHF
6	92-7054	2	Spring-Compression
7	3296-58	2	Nut-Lock, NI
8	5-4460	1	Washer-Pivot
9	92-9674	1	Knob
10	94-7582	2	Bolt-Shoulder
11	32128-21	2	Nut-HF
12	37-8771	4	Bolt-Shoulder
13	110-6825	1	Decal-Danger
14	110-6797	1	Decal-Timecutter
15	99-2385	1	Decal
16	106-8717	1	Decal-Service



Control Assembly

Ref	Part No.	Qty.	Description
❶1	110-6814	1	RH Handle ASM
❶1:1	108-6187	1	Grip
2	110-6815	1	LH Handle ASM
2:1	108-6187	1	Grip
3	3256-24	4	Washer-Flat
4	323-6	4	Screw-HH
5	112-4004	2	Screw-Shoulder
6	110-6828	2	Activator Arm ASM
6:2	105-3455	2	Bushing
7	110-6810	2	Stud-Damper
8	103-2913	2	Damper-Control, Motion
9	3296-42	6	Nut-Lock, NI
10	46-8560	2	Screw-HHF
11	3296-48	2	Nut-Lock, NI
12	3256-22	4	Washer-Flat
13	32128-23	2	Nut-HF
14	3256-5	2	Washer-Flat
15	110-6693	2	Link-Hydro
16	1-303105	2	Yoke-Adjustable
17	1-808280	2	Pin-Clevis
18	1-806003	2	Pin-Hair
19	3220-2	2	Nut-Jam
20	110-6845	2	Gear-Control
21	110-6783	1	Arm-Actuator, LH


Ref	Part No.	Qty.	Description
❶22	110-6782	1	Arm-Actuator, RH
23	110-6856	2	Tab-Stop
24	110-6873	2	Eccentric
25	110-6874	2	Screw-Eccentric
26	110-6875	2	Bolt-Shoulder
27	110-6858	2	Cable-Brake, Parking
28	110-6751	2	Bracket-Return
29	110-6750	2	Plate-Return
30	110-6752	2	Spring
31	110-6894	6	Washer-Pivot
32	3290-221	2	Washer-Spring
33	94-7582	2	Bolt-Shoulder
34	110-0863	2	Screw-Torx
35	110-6784	2	Bolt-Shoulder
36	112-9750	1	Decal-Contol Lever, LH
37	112-9751	1	Decal-Control Lever, RH
38	37-8771	2	Bolt-Shoulder
39	3296-58	2	Nut-Lock, NI
40	112-9771	2	Washer-Teflon



Hydro Drive Assembly


Ref	Part No.	Qty.	Description
1	110-6771	1	Hydro-RH
2	110-6770	1	Hydro-LH
3	322-4	2	Screw-HH
4	322-11	2	Screw-HH
5	3230-9	4	Screw-CARR
6	3296-58	17	Nut-Lock, NI
7	322-6	1	Screw-HH
8	322-7	1	Screw-HH
9	110-6677	2	Clip-Spring
10	110-6774	1	V-Belt
11	63-1590	1	Spring-Idler
12	110-6775	2	Pulley-Idler
13	5-4460	3	Washer-Pivot
14	110-1925	1	Arm-Idler
15	37-8771	1	Bolt-Shoulder
16	110-6883	2	Wheel And Tire ASM
16:1	110-6887	1	Tire
16:3	232-27	1	Stem-Valve
❶16:99	232-37	1	Tube
17	242-50	8	Nut-Lug
18	110-6807	1	Shaft-Cross
19	110-1926	1	Plate-Pivot
20	110-6806-03	2	Strap-Torque
21	110-6878-03	2	Support-Hydro

Ref	Part No.	Qty.	Description
22	110-6787	2	Rod-Bypass
23	1-806003	2	Pin-Hair
24	3256-22	2	Washer-Flat
25	324-8	4	Screw-HH
26	3296-48	2	Nut-Lock, NI
27	112-3979	2	Hub ASM
28	112-3982	2	Nut-Lock
29	110-6680	1	Decal-Transport, LH
❶30	110-6690	1	Decal-Transport, RH
31	3234-47	8	Screw-HHF




Engine and Clutch Assembly

Ref	Part No.	Qty.	Description
❷❸1		1	Engine-Kohler, Sv610-0020
2	32128-33	1	Nut-HF
3	3274-10	2	Screw-HSH
4	108-7829	1	Muffler-Kohler
5	112-3976	1	Isolator
6	110-6758	1	Pulley-Engine
7	112-3974	1	Bumper
8	110-6896	1	Stop-Clutch
9	322-4	2	Screw-HH
10	3296-29	2	Nut-Lock, NI
11	110-6766	1	Clutch-Electric, PTO
12	3253-4	2	Washer-Lock
13	3212-11	1	Screw-HH
14	32144-109	3	Screw
15	322-11	1	Screw-HH
16	3296-58	1	Nut-Lock, NI
17	5-7280	1	Key
18	2412-98	2	Clamp
19	109-0306	1	Hose-Fuel
20	110-6798	1	Support-Hydro, RH
21	110-6799	1	Support-Hydro, LH
22	3296-42	1	Nut-Lock, NI
23	3256-22	1	Washer-Flat



Styling and Fuel System Assembly


Ref	Part No.	Qty.	Description
1	110-1901	1	Pod-RH
2	110-1902	1	Pod-LH
3	110-6823	1	Decal-Panel, Control
4	104-3626	1	Cable-Throttle
5	3258-166	4	Screw-PRH
6	107069	4	Clip
7	93-7198	1	Gas Cap ASM
8	110-1927-03	1	Panel-Control
9	110-6890	1	Fuel Tank ASM
9:2	46-6560	1	Bushing
9:3	95-3970	1	Fitting-90 Degree
10	112-4004	6	Screw-Shoulder
11	110-6786	2	Cover-Control
12	112-9760	1	Washer-Rubber
13	55-9310	1	Seal-Foam
17	100-9064	1	Tie-Cable
19	32180-037	1	Clip-Harness
20	110-6685-03	1	Support-Cover, Rear
21	99-2385	1	Decal
22	325-8	2	Screw-HH
23	3256-26	4	Washer-Flat
24	3296-23	2	Nut-Lock, NI



50in Deck and Side Discharge Assembly


Ref	Part No.	Qty.	Description
1	110-6790	1	50 Inch Deck ASM
2	108-7836	1	Bracket-Hanger, Right Rear
3	108-7838	1	Bracket-Hanger, Left Rear
4	3231-2	3	Screw-CARR
5	112-3980	1	Eccentric
6	80-6990	3	Washer-Hardened
7	95-2747	2	Fitting-Washout
8	46-6290	2	O-Ring
9	3256-22	4	Washer-Flat
10	3296-42	4	Nut-Lock, NI
11	3229-1	4	Screw-CARR
12	95-3270	1	Connector-Hose
13	1-808284	1	Pin-Clevis
14	108-7847	1	Rod-Lift
15	87-7270	1	Washer-Thrust
16	3231-28	1	Screw-CARR
17	3296-23	1	Nut-Lock, NI
18	9335054	1	Pin-Hair
19	108-7895	1	Deflector-50 Inch
20	110-6694	1	Spring-Torsion
21	112-3950	1	Rod-Pivot
22	3296-39	8	Nut-Lock, NI
23	1-603299	3	Roller-Scalp, Anti
24	112-3977	3	Bolt-Shoulder

Ref	Part No.	Qty.	Description
25	32104-76	6	Screw
26	108-7890	2	Cover-Belt



50in Deck Assembly No. 110-6790


Ref	Part No.	Qty.	Description
2	114-1606	2	Decal-Danger, Pulley
3	93-7009	1	Decal-Danger
4	110-6691	2	Decal-Danger
5	105-7015	1	Decal-Routing, Belt
6	3290-282	2	Rivet-Pop
7	322-2	1	Screw-HH
8	3230-23	1	Screw-CARR
9	3296-58	2	Nut-Lock, NI



50in Deck Spindle and Belt Drive Assembly

Ref	Part No.	Qty.	Description
1	110-6892	1	V-Belt
2	323-8	2	Screw-HH
3	3256-24	3	Washer-Flat
4	106-2175	3	Pulley-Idler, Flat
5	3296-39	1	Nut-Lock, NI
6	110-6867-03	1	Arm-Idler
7	3230-3	2	Screw-CARR
8	108-7881	1	Bushing-Pivot
9	3296-29	2	Nut-Lock, NI
10	5-4460	1	Washer-Pivot
11	3219-6	3	Nut-Hex
12	110-6865	3	Pulley
13	32144-41	12	Screw-Taptite
14	26-0671	3	Screw-Blade
15	3290-465	3	Washer-Belleville
16	106-2248-03	3	Stiffener-Blade
17	110-6837-03	3	Blade-17.5 Inch, High Lift
18	3296-58	1	Nut-Lock, NI
19	80-4360	3	Shield-Bearing
20	80-4380	3	Spacer
21	110-6866	3	Shaft-Spindle
❷22		3	Spindle ASM
22:1	88-4510	1	Housing-Spindle
22:2	100-1048	2	Bearing-Ball


Ref	Part No.	Qty.	Description
22:3	62-3661	1	Spacer-Bearing
23	112-3973	1	Hook-Return, Spring
24	1-603414	1	Spring-Extension
25	110-6897	1	Bolt-Shoulder
26	323-10	1	Screw-HH



Electrical Assembly


Ref	Part No.	Qty.	Description
1	104-2493	1	Battery
2	110-6764	1	Switch-Ignition
3	63-8360	1	Key-Ignition
4	93-9998	1	Switch-PTO
5	32103-22	1	Nut-Wing
6	110-6765	2	Switch-Single Pole No
7	82-2190	1	Switch-Bail
8	1-513075	1	Switch-Solenoid
8:1	3253-17	2	Washer-Lock
8:2	3253-4	2	Washer-Lock
8:3	3219-14	2	Nut-Hex
8:4	3220-2	2	Nut-Jam
9	110-6794	1	Cable-Battery, Red
10	3229-1	1	Screw-CARR
11	110-6793	1	Cable-Battery, Black
12	104-2466	1	Holddown-Battery
13	321-3	1	Screw-HH
14	110-1923	1	Harness-Wire
15	3256-22	2	Washer-Flat
16	32144-1	3	Screw-Taptite
17	110-6792	1	Cable-Battery, Red
18	32128-33	2	Nut-HF
19	98-7249	1	Relay
20	46-8560	2	Screw-HHF

Ref	Part No.	Qty.	Description
24	614249	1	Strap-Tie



Crankshaft Assembly
Kohler SV610-0020


Ref	Part No.	Qty.	Description
❸1	20 014 20-S	1	Crankshaft
❸2	X-42-15-S	1	Key (3/16 X 5/8)
❸3	20 043 12-S	1	Gear-Crankshaft



Crankcase Assembly
Kohler SV610-0020


Ref	Part No.	Qty.	Description
❸1		1	Crankcase (Use: Short Block 22 522 02)
❸2	25 139 57-S	1	Plug-Square Head Solid (.38)
❸3	20 032 01-S	1	Seal-Oil
❸4	20 067 04-S	1	Rod-Connecting
❸5	20 874 01-S	1	Piston W/Ring Set (94Mm) (Includes 6,7)
❸6	20 108 01-S	1	Ring Set (94 Mm)
❸7	20 018 04-S	2	Retainer-Pin, Piston
❸8	20 123 02-S	1	Tube-Back, Drain
❸9	20 755 04-S	2	Balance Weight Kit (Includes 10,11)
❸10	20 380 16-S	1	Locating Pin Kit
❸11	20 186 02-S	1	Linkage-Weight, Balance
❸12	12 154 05-S	1	Clip-Pin, Hitch
❸13	M-631015-S	1	Washer-Flat (6Mm)
❸14	X-25-102-S	1	Washer-Flat (1/4)
❸15	20 144 02-S	1	Shaft-Cross, Governor
❸16	20 393 02-S	1	Oil Pump ASM (Includes 17, 18)
❸17	20 112 02-S	2	Spacer-Screw, Oil Pump
❸18	20 086 13-S	2	Screw-Pump, Oil
❸19	20 144 06-S	1	Exhaust Camshaft Center ASM (Includes 20)
❸20	20 468 08-S	1	Washer-Thrust

Ref	Part No.	Qty.	Description
❸21	20 090 01-S	2	Cam Lever Assembly (Includes 22)
❸22	20 086 06-S	2	Bolt-Shoulder (M5X0.8X36)
❸23	20 010 06-S	1	Cam Gear ASM (Exhaust) (Includes 24-26)
❸24	20 089 06-S	1	Spring-A C R
❸25	20 044 16-S	1	Weight-A C R
❸26	20 468 03-S	1	Washer-Thrust, A C R
❸27	20 010 05-S	1	Cam Gear Assembly (Intake)



Air Intake and Filtration Assembly
Kohler SV610-0020


Ref	Part No.	Qty.	Description
❸1	20 096 04-S	1	Cover-Air Cleaner
❸2	25 341 04-S	2	Knob-Cover
❸3	20 083 02-S	1	Element-Cleaner, Air
❸4	20 094 01-S	1	Air Cleaner Base Kit (Includes 5, 6)
❸5	12 041 02-S	1	Gasket-Base, Air Cleaner
❸6	M-641060-S	1	Nut-Hex, Flange (M6X1.0)



Artwork is representative
Actual labels may differ depending on model and specification number


Exhaust Stud, Gasket and Decal Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	25 072 04-S	2	Stud (M8X1.25X33)
❸2	20 041 12-S	1	Gasket-Exhaust
❸3	M-841080-S	2	Nut-Hex, Flange (M8X1.25)
❸4	25 113 39-S	1	Decal-Laminate, Clear
❸5	20 113 13-S	1	Decal (19 H P)
❶❸	20 522 02	1	Short Block (S V 530/540)
❶❸	20 755 05-S	1	Gasket Set




Oil Pan and Lubrication Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	20 040 02-S	1	Dipstick Blade Kit (Yellow) (Includes 2)
❸2	20 153 01-S	2	O Ring-Dipstick
❸3	20 009 10-S	1	Closure Plate ASM (Includes 6, 15)
❸4	25 139 60-S	2	Plug-Hex, Countersunk (.125)
❸5	12 050 01-S	1	Filter-Oil
❸6	20 041 01-S	1	Gasket-Plate, Closure
❸7	20 096 02-S	1	Oil Passage Cover Kit (Includes 8)
❸8	20 041 02-S	1	Gasket-Passage, Oil
❸9	20 144 03-S	1	Shaft-Gear, Governor
❸10	20 310 03-S	1	Governor Gear ASM (Includes 11)
❸11	12 380 01-S	1	Pin-Regulating, Governor
❸12	M-545013-S	6	Screw-Flange, Hex (M5X0.8X13)
❸13	M-851030-S	14	Screw-Flange, Hex (M8X1.25X30)
❸14	20 032 01-S	1	Seal-Oil
❸15	25 155 02-S	1	Connector-Hose, 90 DEG




Head, Valve and Breather Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	20 096 07-S	1	Valve Cover Kit (Includes 2)
❸2	20 041 13-S	1	Gasket-Valve Cover
❸3	M-645020-S	7	Screw-Flange, Hex (M6X1.0X20)
❸4	20 326 01-S	1	Hose-Breather
❸5	20 599 02-S	2	Pivot-Arm, Rocker (Includes 6)
❸6	20 086 04-S	2	Screw-Set
❸7	20 186 01-S	2	Arm-Rocker
❸8	20 086 03-S	2	Stud-Rocker
❸9	20 146 03-S	2	Plate-Guide, Push Rod
❸10	20 062 01-S	2	Lock-Retainer
❸11	20 173 01-S	2	Cap-Spring, Valve
❸12	20 089 03-S	2	Spring-Valve
❸13	20 086 02-S	6	Screw-Flange, Hex (M10X1.5X37)
❸14	12 468 05-S	1	Washer-Flat (1/2)
❸15	20 318 05-S	1	Cylinder Head ASM
❸16	20 016 01-S	1	Valve-Exhaust
❸17	20 017 01-S	1	Valve-Intake
❸18	20 841 01-S	1	Cylinder Head Gasket Kit (Includes 2, 13, 14)
❸19	20 411 04-S	2	Rod-Push




Ignition and Electrical Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	20 162 02-S	1	Screen-Grass
❸2	12 086 14-S	1	Screw-Hex, Flange (M10X1.5X45)
❸3	12 468 03-S	1	Washer-Flat (.38)
❸4	20 146 04-S	1	Plate-Mounting, Fan
❸5	20 157 01-S	1	Fan
❸6	X-42-15-S	1	Key (.19 X .62)
❸7	20 025 05-S	1	Flywheel
❸8	20 086 17-S	2	Screw-Socket, Hex (M5X0.8X25)
❸9	20 154 03-S	1	Clip-Wire, Stator
❸10	237878-S	1	Stator Kit (15 Amp)
❸11	236602-S	1	Connector (3 Contact)
❸12	M-545020-S	2	Screw-HHFTF (M5X0.8X20)
❸13	41 403 09-S	1	Rectifier-Regulator
❸14	231285-S	2	Clip-Cable
❸15	20 584 01-S	1	Module-Ignition
❸16	M-561025-S	2	Screw-Socket, Hex (M5X0.8X25)
❸17	20 707 01-S	1	R F I Suppression Kit (Includes 18-20)
❸18	25 132 14-S	1	Spark Plug (R F I)
❸19	25 154 08-S	1	Clip-Cable
❸20	20 123 01-S	1	Tube (R F I)
❶❸	20 176 01-S	1	Harness-Wiring (Six Pin)




Blower Housing Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	20 755 11-S	1	Blower Housing And Guard ASM (Includes 2-4, 20 113 29-S, 41 037 10-S)
❸2	24 086 41-S	3	Screw-Phl HD (11-16X1/2)
❸3	20 314 06-S	1	Guard-Fixed
❸4	20 086 06-S	4	Bolt-Shoulder (M5X0.8X36)
❸5	24 468 10-S	3	Washer-Plain (1/4)
❶❸	20 113 29-S	1	Label-Round, Kohler
❶❸	41 037 10-S	1	Nameplate-Service



Starter Assembly
Kohler SV610-0020


Ref	Part No.	Qty.	Description
❸1	20 098 05-S	1	Starter ASM
❸2	25 100 31-S	2	Nut-Flange, Hex Serrated (10-24)
❸3	12 100 07-S	1	Nut-Flange, Hex (1/4-20)



Fuel System Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	20 041 07-S	1	Gasket-Deflector, Heat
❸2	20 332 01-S	1	Insert-Port, Intake
❸3	20 265 03-S	1	Deflector-Heat
❸4	M-651020-S	1	Screw-Flange, Hex (M6X1.0X20)
❸5	20 853 14-S	1	Carburetor ASM W/Gaskets (Includes 6, 7)
❸6	12 041 01-S	1	Gasket-Carburetor
❸7	12 041 02-S	1	Gasket-Base, Air Cleaner
❸8	20 072 05-S	2	Stud-Mounting, Carburetor (M6X1.0X100)
❸9	M-641060-S	2	Nut-Hex, Flange (M6X1.0)
❸10	M-545010-S	2	Screw-HHFTF (M5X0.8X10)
❸11	20 126 02-S	1	Bracket-Mounting, Fuel Pump
❸12	24 393 16-S	1	Pump-Pulse, Fuel
❸13	M-645016-S	2	Screw-HHFTF (M6X1.0X16)
❸14	25 237 14-S	6	Clamp-Hose
❸15	25 050 22-S	1	Filter-Fuel
❸16	25 111 34-S	2	Line-Fuel (24 Inch, Cut to needed Length)
❸17	52 353 20-S	1	Line-Fuel (10 Inch)
❶❸	25 454 05-S	1	Tie
❶❸	X-22-11-S	1	Washer-Lock, Internal Tooth (1/4)
❶❸	25 431 12-S	1	Sleeve, Fuel Line
❶❸	12 755 110-S	1	Choke Shaft Kit
❶❸	12 757 02-S	1	Float Repair Kit

Ref	Part No.	Qty.	Description
❶❸	12 757 03-S	1	Carburetor Repair Kit
❶❸	12 757 33-S	1	Solenoid Repair Kit
❶❸	12 757 37-S	1	Bowl Replacement Repair Kit
❶❸	20 755 06-S	1	High Altitude Kit (5, 000 Ft)
❶❸	20 755 07-S	1	High Altitude Kit (10, 000 Ft)



Engine Control Assembly
Kohler SV610-0020

Ref	Part No.	Qty.	Description
❸1	20 536 05-S	1	Speed Control ASM (Includes 2, 3, 6-9)
❸2	20 086 10-S	1	Screw-Thread Forming (M4X0.7X25)
❸3	12 089 11-S	1	Spring-Control, Speed (Short)
❸4	12 237 01-S	1	Clamp-Cable
❸5	M-545016-S	1	Screw-HHFTF (M5X0.8X16)
❸6	M-664020-S	2	Screw-Socket, 6 Lobed (Thread Forming, M6X1.0X20)
❸7	12 089 11-S	2	Spring-Control, Speed (Short)
❸8	20 086 10-S	2	Screw-Thread Forming (M4X0.7X25)
❸9	20 089 11-S	1	Spring-Governor
❸10	20 090 02-S	1	Lever-Governor
❸11	52 211 04-S	1	Bolt-Square Neck, Round Head (1/4-20X1)
❸12	X-22-11-S	1	Washer-Lock, Internal Tooth (1/4)
❸13	12 100 07-S	1	Nut-Flange, Hex (1/4-20)
❸14	25 158 11-S	1	Bushing-Linkage, Throttle
❸15	20 079 04-S	1	Linkage-Throttle
❸16	25 158 08-S	1	Bushing-Retaining, Linkage
❸17	20 089 10-S	1	Spring-Linkage
❸18	20 079 05-S	1	Linkage-Choke (Single Wire)

Attachments and Accessories

For 74370 - TimeCutter Z5000 Riding Mower

Product Name	Model/Part
Hour Meter Kit	112-9801
Deck Ring Kit	114-1608
Armrest Kit	79212
50 Inch Recycler Kit	79312
Foot Assist Cutting Unit Lift Kit	79313
Engine Cover Kit	79314
Floor Mat Kit	79315
42 Inch and 50 Inch Twin Bagger	79324

NOTES

NOTES


TORO®