Form Number 3356-244 Rev C

Rear Quick Attach System
Groundsmaster® 7200 Series Mower

Model No. 30377 - 270000001 and up.

Parts Catalog

Ordering Replacement Parts
To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers
Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers
Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity
In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2007
All Rights Reserved

Register your product at www.Toro.com


Contents

Description	Page	Description	Page
Rear Quick Attach System Assembly	 3	Hydraulic Manifold Assembly No. 112-1493	 6
Hydraulic Cylinder Assembly No. 110-5424	 5		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head



Rear Quick Attach System Assembly


Ref	Part No.	Qty.	Description
1	110-3520-03	1	Arm-Lift, Rear
1:1	95-3577	2	Bushing
2	112-6320-03	1	Adapter ASM
3	110-5367	1	Tube-Hex
4	110-5362	1	Pin ASM
5	110-5424	1	Cylinder-Hydraulic
6	61-3540	1	Bearing-Rod End, LH
7	61-3530	1	Bearing-Rod End, RH
8	325-6	2	Screw-HH
9	323-5	1	Screw-HH
10	3253-4	2	Washer-Lock
11	112-1493	1	Hydraulic Manifold ASM
12	98-9062	2	Screw
13	3234-24	2	Screw-HHF
14	3253-28	2	Washer-Lock/Sp
15	98-2654	2	Pivot Pin ASM
16	103-8496	2	Nut-Jam
17	302-5	1	Fitting-Grease
18	322-3	2	Screw-HH
19	104-8301	6	Nut-Flange, NI
20	3296-45	2	Nut-Lock, NI
21	302-60	2	Fitting-Grease, 90 DEG
22	3296-42	2	Nut-Lock, NI
23	95-8999	1	Switch

Ref	Part No.	Qty.	Description
24	100-1535	1	Switch
25	112-3505	1	Harness-Wire, Rear Lift And Blower
26	112-6340-03	1	Link Mount ASM
27	323-6	3	Screw-HH
28	3220-5	1	Nut-Jam
29	3220-12	1	Nut-HJ (LH Thread)
30	321-2	2	Screw-HH
31	110-8268	1	Aux Decal Kit
32	340-138	1	Fitting-HYD, 45 DEG
32:1	237-79	1	O-Ring
32:2	237-22	1	O-Ring
33	340-101	1	Fitting-HYD, 45 DEG
33:1	237-30	1	O-Ring
33:2	237-79	1	O-Ring
34	340-137	2	Fitting
34:1	237-21	1	O-Ring
34:2	237-42	1	O-Ring
35	340-18	1	Fitting-HYD, 90 DEG
35:1	237-79	1	O-Ring
35:2	237-22	1	O-Ring
36	2412-36	3	Clamp-Hose
37	112-9547	1	HYD Hose ASM
38	112-9546	1	HYD Hose ASM




Rear Quick Attach System Assembly (continued)

Ref	Part No.	Qty.	Description
39	112-9548	1	HYD Hose ASM
40	105-4340	1	HYD Hose ASM
41	112-6348	1	Fitting-HYD, Tee
42	3290-378	6	Tie-Cable
43	99-7430	2	Relay
46	110-5471	1	Power Beyond Sleeve Kit
47	1481	2	Fitting-Grease
48	1-303352	4	Washer-Spindle
49	114-4053	1	Sleeve-Protective



Hydraulic Cylinder Assembly No. 110-5424

Ref	Part No.	Qty.	Description
1	112-6352	1	Seal Kit



Hydraulic Manifold Assembly No. 112-1493

Ref	Part No.	Qty.	Description
2	106-1025	2	Plug-HYD
2:1	237-78	1	O-Ring
3	106-1026	4	Plug-HYD
3:1	237-42	1	O-Ring
4	107-7516	2	Valve-Solenoid
4:1	105-9156	1	Seal Kit
5	107-7517	1	Valve-Solenoid
5:1	105-9156	1	Seal Kit
5:2	107-7812	1	Nut-Solenoid
6	353-551	1	Plug-HH
6:1	237-80	1	O-Ring
7	110-8904	2	Orifice-Control, Flow
8	340-92	2	Fitting-HYD, Straight
8:1	237-78	1	O-Ring
8:2	237-21	1	O-Ring
9	105-9333	5	Coil-12Vdc
10	110-8898	2	Valve-Solenoid
10:1	110-8907	1	Seal Kit
10:2	110-2634	1	Nut-Coil
10:3	110-8909	1	Spacer-Coil
12	353-989	1	Plug-Hex, Hollow
12:1	237-42	1	O-Ring
13	353-988	2	Plug-Hex
13:1	237-79	1	O-Ring

NOTES


TORO®