


TORO®


MODEL NO. 20215-2000001 & UP

**PARTS
CATALOG****21" REAR BAGGING MOWER**

C-0763

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	71-0560	Spring Arm Ass'y - R.H.	2	14	44-0580	Shield - Rear	1
2	39-5770	Decal - Danger	1	15	33-3208	Rod - Shield	1
3	46-6810	Screw - Hex Washer Hd. Thread Forming	1	16	25-7740	Knob - Spring Arm	4
4	82-9150	Tunnel - Discharge	1	17	71-0570	Spring Arm Ass'y - L.H.	2
5	80-3780	Bracket - Spring	1	18	66-0561	Screw - Pivot	4
6	46-6811	Screw w/Washer	3	19	11-9509	Wheel & Tire Assembly (Incl. Ref. #20)	4
7	80-3770	Retainer - Door	1	20	27-6250	Bushing - Wheel	8
8	76-4660	Spring - Door	1	21	27-6231	Bolt - Wheel	4
9	77-0200	Discharge Door Assembly	1	22	40-1940	Washer - Wheel	8
10	76-4570	Plate - Latch	1	23	66-0580	Arm - Pivot	4
11	46-8090	Screw - Hex Washer Hd. Self Tapping	2	24	52-3620	Nut - Lock	8
12	32144-70	Screw - Hex Washer Hd. Thread Forming	1	25	32144-85	Screw - Hex Hd. Cap	4
13	2412-93	R-Clamp	1	26	14-3479	Housing Assembly (Incl. Ref. #2 & 6)	1
				27	71-0600	Decal - Toro	1




C-0764

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	80-2860	Decal - Engine	1	6	32144-102	Screw - Thread Forming	3
†2	2210-316	Stop - Rope	1	7	42-1000	Blade - 21"	1
3		Engine	1	8	3253-22	Washer - Lock	1
†4	2210-249	Clamp - Casing	1	9	26-0670	Screw - Blade	1
†5	2210-313	Screw - Clamp	1	10	62-7540	Retainer - Blade	1

†Provided with Engine




C-0570

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	14-0699	Handle - Upper (Incl. Ref. #2)	1	9	3-3287	Spacer	2
2	56-6280	Decal - Warning	1	10	43-1361	Lower Handle Assembly	1
3	3296-42	Nut - Lock	2	11	3296-29	Nut - Lock	4
4	76-3248	Control - Throttle (Bend Type #3) (Sheath Lg. 47") (Wire Lg. 1-3/4")	1	†12	3296-47	Nut - Lock	2
5	46-6430	Screw - Handle	1	†13	49-2750	Pin - Handle	2
6	27-7210	Screw - Shoulder	2	14	17-9421	Screw - Handle	2
7	27-7211	Screw - Shoulder	2	15	3290-378	Tie - Cable	1
8	84-8360	Latch - Handle L.H.	1	16	19-4050	Knob - Handle Release	2
				17	46-6433	Screw - Handle	1
				18	46-8080	Guide - Rope	1
				19	84-8400	Latch - Handle R.H.	1

†Service Replacement Part




TRACTION CONTROL ASSEMBLY

C-0571

Ref. No.	Part No.	Description	No. Used
1	321-3	Screw - Hex Hd. Cap	1
2	49-1630	Support - Spacer	2
3	17-9421	Screw - Handle	2
4	46-6434	Screw - Handle	1
5	256-276	Spacer - Nylon	2
6	76-4331	Cable - Brake	1

Ref. No.	Part No.	Description	No. Used
7	46-6980	Support - Cable	1
8	3256-22	Washer - Flat	1
9	3296-42	Nut - Lock	2
10	66-5350	Lever - Control	1
11	3296-58	Nut - Lock	2
12	71-3080	Bar - Control	1




C-0301

GRASS BAG ASSEMBLY 11-0159

Ref. No.	Part No.	Description	No. Used
1	3290-422	Nut - Push	2
2	42-4030	Bag Frame - Upper	1
3	33-4820	Hinge - Bag Door	1
4	44-0522	Bag - Grass	1

Ref. No.	Part No.	Description	No. Used
5	36-6910	Spring	2
6	42-4020	Frame - Bag	1
7	37-1393	Door - Grass Bag	1




T-0716

SIDE DISCHARGE CHUTE MODEL NO. 59168 (OPTIONAL)

Ref. No.	Part No.	Description	No. Used
1	76-4780	Decal - Caution	1
2	13-2239	Chute - Discharge (Incl. Ref. #1)	1

Ref. No.	Part No.	Description	No. Used




C-0304

WEAR PLATE MODEL NO. 49-4080 (OPTIONAL)

Ref. No.	Part No.	Description	No. Used
1	49-4070	Plate - Rear Wear	2
2	32104-17	Screw - Thread Forming	8

Ref. No.	Part No.	Description	No. Used
3	43-5050	Plate - Wear Front	2
4	33-0390	Washer	2




C-0302

LEAF SHREDDER KIT MODEL NO. 59157 (OPTIONAL)

Ref. No.	Part No.	Description	No. Used
1	47-6260	Bracket	1
2	47-6230	Screen	1
3	46-4880	Bracket - Mounting	2
4	32144-11	Screw - Self Tapping	3

Ref. No.	Part No.	Description	No. Used
5	321-3	Screw - Hex Hd. Cap	2
6	321-5	Screw - Hex Hd. Cap	1
7	3256-1	Washer	1




C-0616

RECYCLER KIT MODEL NO. 59173 (OPTIONAL)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	76-2130	Plate - Kicker Left Front	1	13	46-8090	Screw - Hex Washer Hd. Self Tapping	2
2	32144-111	Screw - Pan Hd.	8	14	82-9150	Tunnel - Discharge	1
3	46-6810	Screw - Hex Washer Hd. Thread Forming	1	15	76-4660	Spring - Door	1
4	80-3780	Bracket - Spring	1	16	82-8120	Decal	1
5	46-6811	Screw - Hex Washer Hd. Thread Forming	1	17	76-2150	Plate - Kicker Left Rear (S.P. Models Only)	1
6	80-3770	Retainer - Door	1	*	76-2160	Plate - Kicker Left Rear (H.P. Models Only)	1
7	77-0200	Discharge Door Assembly	1	18	76-2140	Plate - Kicker Right Rear	1
8	77-0500	Plug Assembly (Incl. Ref. #9-11)	1	19	80-2770	Anti - Scalp Cup	1
9	76-4650	Grip - Latch	1	20	80-0510	Stiffener - Blade	1
10	76-4640	Latch - Plug	1	21	14-1659	Blade Assembly (Incl. Ref. #20)	1
11	3295-35	Rivet	1	22	76-2120	Plate - Kicker Right Front	1
12	76-4570	Plate - Latch	1				

*Not Illustrated



Assemblies include all parts shown in frames.


★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL.

ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used
1	493260	Cylinder Assembly	1
2	293708	Bushing-Cylinder	1
		Note: Requires Special Tools for Installation.	
★3	393862	Seal-Oil	1
5	213861	Head-Cylinder	1
★7	272200	Gasket-Cylinder Hd.	1
8	399717	Breather-Valve Chamber	1
★9	271904	Gasket-Valve Cover	1
★9A	272238	Gasket-Baffle Plate	1
10	94222	Mounting Sem	1
11	231685	Tube-Breather	1
13	94547	Screw-Cylinder Hd.	1
★52	272199	Gasket-Intake Elbow	1
54	94526	Screw-Intake Elbow Mounting	1
227	492349	Lever Assembly-Gov.	1
230	67072	Washer-Governor Crank	1
284	94511	Screw-Hex. Head	1
307	94515	Screw-Hex. Head	1
337	802592	Plug-Spark	1
383	89838	Wrench-Spark Plug	1

Ref. No.	Part No.	Description	No. Used
523	493950	Cap with Dipstick-Oil Filler	1
524	280393	Seal-Filler Tube	1
525	493952	Tube-Oil Filler	1
562	92613	Bolt-Governor Lever	1
572	224328	Baffle-Cylinder	1
592	231082	Nut-Hex.	1
615	94474	Pushnut	
		(Governor Crank)	1
616	262578	Crank-Governor	1
625	492717	Tube-Fuel Intake	1
635	66538	Elbow-Spark Plug	1
842	280966	Seal-O-Ring	1
847	493459	Oil Fill Tube and Dipstick Assy.	1
869	213512	Seat-Intake Valve	1
870	213513	Seat-Exhaust Valve	11
871	262001	Guide-Exhaust Valve	1
		Note: 63709 Guide-Intake Valve See Repair Instruction Manual.	
1019	494256	Label Kit	1

★ Included in Gasket Set- Part No. 493263.




Assemblies include all parts shown in frames.


ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
★12	272198	Gasket-Crankcase	1		493388	Ring Set-.010" O.S. Piston	1
15	94613	Plug-Oil Drain	1		493389	Ring Set-.020" O.S. Piston	1
16	493731	Crankshaft	1		493390	Ring Set-.030" O.S. Piston	27
		Note: Order 94388 For			26026	Lock-Piston Pin	28
		Timing Gear Key	1		298909	Pin Assembly-Piston-Standard	1
18	493279	Sump-Engine	1		298908	Pin Assembly-Piston-.005" O.S.	1
★20	399781	Seal-Oil	1	29	490566	Rod Assembly- Connecting	1
22	94220	Screw-Sump Mtg. Sem	1			Note: For Connecting Rod with .020" Undersize Crankpin	
		Note: 94612 Screw-Hex. Washer Head				Bearing- Order No. 490743.	1
		(One (1) Used in Hole Nearest Breather)	1	32	94405	Screw-Connecting Rod	1
24	222698	Key-Flywheel	1	33	262651	Valve-Exhaust	1
25	493262	Piston Assy.-Standard	1	34	262652	Valve-Intake	1
	493385	Piston Assy.-.010" O.S.	1	35	262224	Spring-Valve	1
	493386	Piston Assy.-.020" O.S.	1	40	93312	Retainer-Valve Spring	1
	493387	Piston Assy.-.030" O.S.	1	45	262204	Tappet-Valve	1
		PISTON RING SETS:	1	46	492828	Gear-Cam	1
		Note: For Chrome Piston Ring Set-Standard Size-Order		47	493737	Oil Slinger Gear and Bracket	1
		Part No. 493391.	1	741	262598	Gear-Timing	1
26	493261	Ring Set-Std. Piston	1				

★ Included in Gasket Set- Part No. 493263.



Assemblies include all parts shown in frames.



ENGINE BRIGGS & STRATTON MODEL 122702-3171-01


Ref. No.	Part No.	Description	No. Used
95	94098	Screw-Throttle Valve Mounting Sem	1
98	398185	Screw-Idle Adjustment	1
• 104	231371	Pin-Float Hinge	1
108	223471	Valve-Choke	1
• 116		Gasket-Sealing (Sold in Kit Only).	1
• 117		Jet (Sold in Kit Only).	1
118	493765	Valve and Spring- Needle	1
124	94525	Screw-Carburetor Mtg.	1
125	494216	Carburetor Assembly	1
• 127		Plug-Welch (Sold in Kit Only).	1
130	223470	Valve-Throttle	1
131	493267	Shaft and Lever- Throttle	1
133	398187	Float Assy.-Carburetor	1
• 134	398188	Valve-Inlet (Includes Seat)	1

Ref. No.	Part No.	Description	No. Used
• 137		Gasket-Bowl (Sold in Kit Only).	1
141	494218	Shaft-Choke	1
★ 163	272296	Gasket-Air Cleaner	1
529	280943	Grommet-Breather	1
• 617	270344	Seal-Fuel Intake Tube	1
• 634		Washer-Shaft (Sold in Kit Only)	1
955	493763	Screw-Bowl Mtg.	1
966	492363	Base-Air Cleaner	1
967	491588	Filter-Air	1
968	280937	Cover-Air Cleaner	1
969	94120	Screw-Cover Mtg.	1
971	94269	Screw-Air Cleaner	1
971A	94121	Screw-Base to Carburetor	1
975	493640	Bowl Assy.	1

• Included in Carburetor Overhaul Kit- Part No. 493762.

◆ Included in Carburetor Gasket Set- Part No. 490937.

★ Included on Gasket Set- Part No. 493263.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used
98A	493280	Screw Assy.- Speed Adj.	1
201	262579	Link-Governor	1
209	262661	Spring-Governor	1
305	94513	Screw-Hex. Head Sem	

Ref. No.	Part No.	Description	No. Used
618	262749	Spring-Choke Return	1
620	493894	Bracket Assembly- Carburetor Control	1
670A	493823	Spacer-Carburetor Bracket	1




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used
55	492831	Housing-Rewind Starter	1
56	492832	Pulley-Rewind Starter	1
57	262594	Spring-Rewind Starter	1
58	280399	Rope-Rewind Starter	1
60	393152	Handle-Rewind Starter	1
69	280973	Washer-Rewind Starter	1
69A	224322	Washer-Rewind Starter	1
456	224321	Retainer-Rewind Starter	1

Ref. No.	Part No.	Description	No. Used
459	492833	Pawl-Starter	1
461	262626	Pin-Starter	1
515	262556	Spring-Pawl	1
515A	262625	Spring-Torsion	1
608	493295	Starter Assy.-Rewind	1
946	223294	Stop Rope	1
1016	224278	Cover-Rewind Starter	1




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used
23	492177	Flywheel-Magneto	1
258	94512	Screw-Hex. Hd.	1
304	493293	Housing- Blower	1
305	94513	Screw-Hex. Head Sem	1
332	92284	Nut-Flywheel	1
333	802574	Armature-Magneto	1
334	93381	Screw-Armature Mounting Sem	1

Ref. No.	Part No.	Description	No. Used
356	398808	Wire-Ground	1
363	19069	Puller-Flywheel (Optional Accessory)	1
455	224250	Cup-Starter	1
621	396847	Switch-Stop	1
851	221798	Terminal-Ignition Cable	1
922	262640	Spring-Brake	1
923	492918	Brake Assy.	1






Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used
81	223664	Lock-Muffler Screw	1
187	492790	Hose-Fuel	1
188	398540	Screw-Tank Mounting (Includes Washer)	1
265	221535	Clamp-Casing	1
267	94204	Screw-Clamp Mtg.	1
284	94511	Screw-Hex. Head	1
300	490547	Muffler-Exhaust	1

Ref. No.	Part No.	Description	No. Used
346	93705	Screw-Hex. Head	1
601	93807	Clamp-Hose	1
613	94231	Screw-Muffler Mtg.	1
670	280512	Spacer-Fuel Tank	1
676	493871	Deflector-Muffler	1
949	281136	Screen-Static	1
957	397974	Cap Assy.-Fuel	1
972	494358	Tank Assembly-Fuel	1



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 122702-3171-01

Ref. No.	Part No.	Description	No. Used
★3	393862	Seal-Oil	1
★7	272200	Gasket-Cylinder Hd.	1
★9	271904	Gasket-Valve Cover	1
★9A	272238	Gasket-Baffle Plate	1
★12	272198	Gasket-Crankcase	1
★20	399781	Seal-Oil	1
★52	272199	Gasket-Intake Elbow	1
●104	231371	Pin-Float Hinge	1
●●116		Gasket-Sealing (Sold in Kit Only).	1
●117		Jet (Sold in Kit Only).	1
121	493762	Carburetor Overhaul Kit	1

Ref. No.	Part No.	Description	No. Used
●127		Plug-Welch (Sold in Kit Only).	1
●134	398188	Valve-Inlet (Includes Seat)	1
●●137		Gasket-Bowl (Sold in Kit Only).	1
★163	272296	Gasket-Air Cleaner	1
358	493263	Gasket Set	1
●●617	270344	Seal-Fuel Intake Tube	1
●●634		Washer-Shaft (Sold in Kit Only)	1
977	490937	Gasket Set-Carburetor	1

● Included in Carburetor Overhaul Kit- Part No. 493762.

●● Included in Carburetor Gasket Set- Part No. 490937.

★ Included in Gasket Set- Part No. 493263.

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you

are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.

MAINTENANCE RECORD

[illegible]

MAINTENANCE RECORD

[illegible]