Form Number 3351-334 Rev C

Hose Reel Kit
Workman® 200 Spray System

Model No. 41097 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts
To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers
Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers
Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity
In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2007
All Rights Reserved

Register your product at www.Toro.com


Contents

Description	Page	Description	Page
Hose Reel and Electrical Assembly	 3	Spray Gun Assembly No. 100-6733	 6
Hose Reel Assembly No. 106-5083	 4	3-Way Valve and Gauge Assembly	 7
Hose Reel Frame Assembly No. 104-8714	 5	3-Way Valve Assembly No. 104-9069	 8

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head



Hose Reel and Electrical Assembly


Ref	Part No.	Qty.	Description
1	106-5083	1	Hose Reel ASM
2	104-8300	5	Nut-Flange, NI
3	92538	1	Hosebarb-Pressure, Low
4	99-0772	2	Clamp-Hose
5	322-5	4	Screw-HH
6	100-3815	1	Grommet-Rubber
7	42397-03	1	Electrical Box ASM
8	3234-17	1	Screw-HHF
9	3219-14	6	Nut-Hex
10	42206	1	Harness-Wire (Solenoid To Breaker)
11	42201	1	Breaker-Circuit
12	42207	1	Harness-Wire (Solenoid To Switch)
13	42208	1	Harness-Wire (Switch To Solenoid)
14	42202	1	Switch-Momentary
15	3217-5	2	Nut-Hex
16	106-5078	1	Harness-Wire
17	95-2495-03	1	Electrical Box Cover ASM
18	104-9026-03	1	Hose Reel Mounting ASM
19	107-8757	1	Decal-Reel, Hose
20	3250-31	6	Screw-PPH
21	32104-95	2	Screw-HWH
22	3256-14	6	Washer-Flat

Ref	Part No.	Qty.	Description
23	111674	1	Solenoid
25	3256-3	4	Washer-Flat
26	3234-32	4	Screw-HHF
27	32128-49	4	Nut-HHF
29	107-8756	1	Hose-Hose Reel ASM
30	100-6733	1	Sprayer-Handheld
35	106-5089	1	Conduit-12 Inch
36	3290-378	10	Tie-Cable



Hose Reel Assembly No. 106-5083


Ref	Part No.	Qty.	Description
1	104-8714	1	Reel-Hose
2	104-8715	1	Chainguard-Reel, Hose
2:1	322-5	4	Screw-HH
2:2	3256-23	4	Washer-Flat
2:3	3296-29	4	Nut-Lock, NI
3	104-8799	1	Guide-Reel, Hose
3:2	104-8820	1	Bracket-Roller Guide, Right
3:3	322-5	8	Screw-HH
3:4	3256-23	8	Washer-Flat
3:5	3296-29	8	Nut-Lock, NI
3:6	104-8821	1	Bracket-Roller Guide, Left



Hose Reel Frame Assembly No. 104-8714

Ref	Part No.	Qty.	Description
1	104-8803	1	Hose Reel Frame ASM
2	104-8804	1	Disc And Gear ASM
3	104-8805	1	Disc-Crank, Side
4	104-8806	1	Drum-Center
5	104-8807	1	Axle ASM
6	104-8808	1	Swivel ASM
6:1	104-8812	1	Ring-Retainer
6:2	104-8864	1	Swivel Seal Kit
7	104-8809	2	Block-Pillow, Top
8	104-8810	2	Block-Pillow, Bottom
9	104-8811	2	Bearing
10	104-8812	2	Ring-Retainer
11	104-8813	1	Cap-Pipe
12	322-3	8	Screw-HH
13	104-8814	1	Trim-Edge, Drum
14	3296-29	4	Nut-Lock, NI
15	3256-23	8	Washer-Flat
16	3253-21	4	Washer-Lock
17	323-6	4	Screw-HH
18	32128-21	1	Nut-HF
19	104-8815	1	Bracket-12V Dc
20	104-8816	1	Motor-12V Dc
21	104-8817	1	Pinion
22	104-8818	4	Key


Ref	Part No.	Qty.	Description
23	322-5	4	Screw-HH
24	3253-4	1	Washer-Lock
25	104-8819	4	Screw-Set
26	3256-23	4	Washer-Flat



Spray Gun Assembly No. 100-6733

Ref	Part No.	Qty.	Description
1	100-6649	3	O-Ring
2	99-0885	1	Extension-Lance
4	99-0884	1	Seal-Valve, On/Off
5	99-0779	1	Repair Kit
6	99-0887	1	Pin
7	99-0890	1	Housing-Nozzle
8	99-0889	1	Nozzle-Ceramic
9	100-6650	1	O-Ring
10	99-0886	1	Housing-Swirl
11	100-6646	1	O-Ring
12	100-6644	1	O-Ring
13	99-0780	1	Swirl
14	99-0772	1	Clamp-Hose
15	107-8734	1	Nut-Swivel
16	99-0883	1	Housing-Valve
17	104-8860	1	Cone
18	104-8861	1	Sleeve-Rubber
19	100-6647	1	O-Ring
20	99-0882	1	Valve ASM
21	99-0877	1	Handle-LH
22	99-0878	1	Stop-Trigger, Rubber
23	99-0880	1	Arm-Trigger
24	99-0879	1	Arm-Safety, Trigger
25	99-0881	1	Handle-RH


Ref	Part No.	Qty.	Description
26	100-6666	1	Screw
27	100-6648	1	O-Ring
28	106-5093	1	Hosebarb-Brass



3-Way Valve and Gauge Assembly

Ref	Part No.	Qty.	Description
1	32128-33	2	Nut-HF
2	106-1359-03	1	Bracket-Support
3	3234-4	2	Screw-HHF
4	106-5072	1	Reducer ASM
4:1	100-6645	1	O-Ring
5	99-0850	1	Nut
6	100-8576	1	Gauge-Pressure
7	100-8699	1	Tee
8	100-6655	2	Gasket
9	99-0770	1	Nipple-Reducing
10	99-0769	1	Nut
11	100-6653	1	O-Ring
12	106-5074	1	Reel Feed Hose ASM
12:1	99-0766	1	Nut
12:2	104-8797	1	Hosebarb
12:3	2412-36	1	Clamp-Hose
12:4	104-8859	1	Hose
13	100-8669	1	Nut
14	104-9067	1	Adapter-Valve
15	100-8671	1	O-Ring
16	104-9069	1	3-Way Valve ASM
17	100-8635	1	Fork
18	106-5081	1	Decal-Control, Spray
19	32144-32	2	Screw

Ref	Part No.	Qty.	Description
20	104-8727-03	1	Bracket-Valve



3-Way Valve Assembly No. 104-9069

Ref	Part No.	Qty.	Description
1	100-6644	2	O-Ring
2	100-8671	1	O-Ring
3	100-8637	1	O-Ring
4	100-8694	2	O-Ring
5	106-5068	2	O-Ring
6	106-5069	1	Cover-End, 3-Way Valve
7	104-8858	1	Nipple
8	100-8687	1	Cover-End, 3-Way Valve
9	100-8683	1	Handle-Valve, 3-Way
10	100-8682	1	Button
11	100-8686	1	Spindle-Valve, 3-Way
12	106-5070	1	Ball-Valve, 3-Way
13	104-8857	1	Nut
14	106-1323	1	Housing
15	33113-080	4	Screw-HH
16	100-8688	1	Screw-Plastic
17	48-7900	1	Nut
18	100-8692	8	Washer
19	100-8695	2	Seat-Ball

NOTES

NOTES

NOTES


TORO®