Form Number 3351-309 Rev B

# Hose Reel Kit
## Multi-Pro® 5600/5700 Turf Sprayer

**Model No. 41569 - 240000001 and up.**

# Parts Catalog

**Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2007
All Rights Reserved

Register your product at www.Toro.com

# Contents


| Description | Page |
|---|---|
| Valve Box Assembly | 3 |
| Hardi Ball Valve Assembly No. 106-1268 | 4 |
| Rear Assembly | 5 |
| Hose Reel, Spray Gun and Electrical Box Assembly | 6 |
| Handgun Assembly No. 100-6733 | 7 |
| Hose Reel Assembly No. 106-5083 | 8 |
| Hose Reel Frame Assembly No. 104-8714 | 9 |



# Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

# Footnotes


❶ Not illustrated




# Valve Box Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32128-33 | 7 | Nut-HF |
| 2 | 106-1322-03 | 1 | Box-Switch |
| 3 | 3234-4 | 14 | Screw-HHF |
| 4 | 100-8589 | 1 | Switch-Rocker |
| 5 | 100-1535 | 1 | Switch |
| 6 | 106-1278 | 1 | Decal-Panel, Switch |
| 7 | 106-1277 | 1 | Decal-Control, Valve |
| 8 | 106-1258-03 | 1 | Cover Plate ASM |
| 9 | 100-8576 | 1 | Gauge-Pressure |
| 10 | 100-8665 | 1 | Reducer-Gauge, Pressure |
| 11 | 100-8666 | 1 | Nut-Reducer |
| 12 | 100-8667 | 1 | Coupler-Reducer |
| 13 | 106-1312 | 1 | Tube |
| 14 | 106-1279 | 1 | Decal-Instructional |
| 15 | 106-1294-03 | 1 | Bracket-Valve |
| 16 | 100-8635 | 4 | Fork |
| 17 | 100-6708 | 1 | Fork |
| 18 | 106-4937 | 1 | Hosebarb ASM |
| 18:1 | 100-6712 | 1 | O-Ring |
| 19 | 99-0772 | 3 | Clamp-Hose |
| 20 | 106-4938 | 1 | Reducer ASM |
| 20:1 | 100-8637 | 1 | O-Ring |
| 21 | 104-8859 | 3 | Hose |
| 22 | 3251-1 | 2 | Screw-PPH |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 23 | 3256-21 | 2 | Washer-Flat |
| 24 | 106-1275-03 | 1 | Bracket-Valve |
| 25 | 42046 | 2 | Elbow-90 DEG |
| 26 | 106-1265 | 1 | Valve-Ball, Precision |
| 27 | 106-1293 | 1 | Washer-Flat |
| 28 | 106-1263-03 | 1 | Plate-Lever, Valve |
| 29 | 106-1262-03 | 1 | Valve Lever ASM |
| 30 | 106-1268 | 1 | Valve-Ball |
| 32 | 106-5073 | 1 | Hose ASM |
| 32:1 | 99-0782 | 2 | Clamp-Hose |
| 32:2 | 106-4932 | 1 | Hosebarb-Straight |
| 32:2:1 | 100-8637 | 1 | O-Ring |
| 32:3 | 106-4933 | 1 | Hosebarb ASM |
| 32:3:1 | 100-8637 | 1 | O-Ring |
| 32:4 | 106-1318 | 1 | Hose |
| 34 | 92-8564 | 1 | Knob |
| 35 | 106-1256-03 | 1 | Plate-Mount, Valve |
| 36 | 3234-5 | 2 | Screw-HHF |
| 37 | 100-7050 | 1 | Bulkhead |
| 38 | 106-4932 | 1 | Hosebarb-Straight |
| 38:1 | 100-8637 | 1 | O-Ring |
| 39 | 32128-20 | 2 | Nut-HF |
| ❶99 | 106-1307 | 1 | Harness-Reel, Hose |





# Hardi Ball Valve Assembly No. 106-1268

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 100-6644 | 2 | O-Ring |
| 2 | 100-8671 | 1 | O-Ring |
| 3 | 100-8637 | 1 | O-Ring |
| 4 | 100-8693 | 2 | O-Ring |
| 5 | 100-8694 | 2 | O-Ring |
| 6 | 104-8857 | 1 | Nut |
| 7 | 104-8858 | 1 | Nipple |
| 8 | 100-8687 | 2 | Cover-End, 3-Way Valve |
| 9 | 100-8686 | 1 | Spindle-Valve, 3-Way |
| 10 | 100-8697 | 1 | Ball-3 Way Valve |
| 11 | 106-1323 | 1 | Housing |
| 12 | 33113-080 | 4 | Screw-HH |
| 13 | 48-7900 | 4 | Nut |
| 14 | 100-8692 | 8 | Washer |
| 15 | 100-8695 | 2 | Seat-Ball |




# Rear Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32128-49 | 1 | Nut-HHF |
| 2 | 3234-32 | 1 | Screw-HHF |
| 3 | 106-1315-03 | 1 | Angle-Valve Mount |
| 4 | 106-1320 | 1 | Trim |
| 5 | 99-0782 | 4 | Clamp-Hose |
| 7 | 106-4935 | 4 | Hosebarb ASM |
| 7:1 | 100-6712 | 1 | O-Ring |
| 8 | 104-9041 | 2 | Tee |
| 9 | 100-6708 | 6 | Fork |
| 10 | 106-4934 | 2 | Hosebarb ASM |
| 10:1 | 100-6712 | 1 | O-Ring |
| 11 | 99-0772 | 2 | Clamp-Hose |
| 12 | 100-8674 | 1 | Coupler-Tube |




# Hose Reel, Spray Gun and Electrical Box Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 100-6733 | 1 | Sprayer-Handheld |
| 2 | 106-1233-03 | 1 | Hand Spray Mounting ASM |
| 3 | 106-5083 | 1 | Hose Reel ASM |
| 4 | 95-2213 | 1 | Decal-Unsecured Hose |
| 5 | 3234-11 | 10 | Screw-HHF |
| 6 | 32128-20 | 1 | Nut-HF |
| 7 | 92538 | 1 | Hosebarb-Pressure, Low |
| 8 | 99-0772 | 2 | Clamp-Hose |
| 9 | 106-5078 | 1 | Harness-Wire |
| 10 | 3217-5 | 2 | Nut-Hex |
| 11 | 106-1228-03 | 1 | Hose Reel Support ASM |
| 12 | 111674 | 1 | Solenoid |
| 13 | 32128-43 | 10 | Nut-Flange |
| 14 | 106-1227-03 | 2 | Strap-Hose Reel |
| 15 | 87-0540 | 1 | Decal-Reel, Hose |
| 16 | 3250-31 | 6 | Screw-PPH |
| 17 | 42202 | 1 | Switch-Momentary |
| 18 | 32104-95 | 2 | Screw-HWH |
| 19 | 95-2495-03 | 1 | Electrical Box Cover ASM |
| 20 | 42201 | 1 | Breaker-Circuit |
| 22 | 42206 | 1 | Harness-Wire (Solenoid To Breaker) |
| 23 | 3219-14 | 6 | Nut-Hex |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 24 | 42208 | 1 | Harness-Wire (Switch To Solenoid) |
| 25 | 104-8730 | 1 | Hose ASM |
| 26 | 95-2282 | 1 | Grommet |
| 27 | 3234-17 | 1 | Screw-HHF |
| 28 | 42207 | 1 | Harness-Wire (Solenoid To Switch) |
| 29 | 42397-03 | 1 | Electrical Box ASM |
| 31 | 3256-14 | 6 | Washer-Flat |
| 33 | 32128-20 | 2 | Nut-HF |
| 34 | 106-5089 | 1 | Conduit-12 Inch |
| 35 | 3290-378 | 10 | Tie-Cable |




# Handgun Assembly No. 100-6733


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 100-6649 | 3 | O-Ring |
| 2 | 99-0885 | 1 | Extension-Lance |
| 4 | 99-0884 | 1 | Seal-Valve, On/Off |
| 5 | 99-0779 | 1 | Repair Kit |
| 6 | 99-0887 | 1 | Pin |
| 7 | 99-0890 | 1 | Housing-Nozzle |
| 8 | 99-0889 | 1 | Nozzle-Ceramic |
| 9 | 100-6650 | 1 | O-Ring |
| 10 | 99-0886 | 1 | Housing-Swirl |
| 11 | 100-6646 | 1 | O-Ring |
| 12 | 100-6644 | 1 | O-Ring |
| 13 | 99-0780 | 1 | Swirl |
| 14 | 99-0772 | 1 | Clamp-Hose |
| 15 | 99-0766 | 1 | Nut |
| 16 | 99-0883 | 1 | Housing-Valve |
| 17 | 104-8860 | 1 | Cone |
| 18 | 104-8861 | 1 | Sleeve-Rubber |
| 19 | 100-6647 | 1 | O-Ring |
| 20 | 99-0882 | 1 | Valve ASM |
| 21 | 99-0877 | 1 | Handle-LH |
| 22 | 99-0878 | 1 | Stop-Trigger, Rubber |
| 23 | 99-0880 | 1 | Arm-Trigger |
| 24 | 99-0879 | 1 | Arm-Safety, Trigger |
| 25 | 99-0881 | 1 | Handle-RH |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 26 | 100-6666 | 1 | Screw |
| 27 | 100-6648 | 1 | O-Ring |
| 28 | 106-5093 | 1 | Hosebarb-Brass |




# Hose Reel Assembly No. 106-5083

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-8714 | 1 | Reel-Hose |
| 2 | 104-8715 | 1 | Chainguard-Reel, Hose |
| 2:1 | 322-5 | 4 | Screw-HH |
| 2:2 | 3256-23 | 4 | Washer-Flat |
| 2:3 | 3296-29 | 4 | Nut-Lock, NI |
| 3 | 104-8799 | 1 | Guide-Reel, Hose |
| 3:2 | 104-8820 | 1 | Bracket-Roller Guide, Right |
| 3:3 | 322-5 | 8 | Screw-HH |
| 3:4 | 3256-23 | 8 | Washer-Flat |
| 3:5 | 3296-29 | 8 | Nut-Lock, NI |
| 3:6 | 104-8821 | 1 | Bracket-Roller Guide, Left |




# Hose Reel Frame Assembly No. 104-8714

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 104-8803 | 1 | Hose Reel Frame ASM |
| 2 | 104-8804 | 1 | Disc And Gear ASM |
| 3 | 104-8805 | 1 | Disc-Crank, Side |
| 4 | 104-8806 | 1 | Drum-Center |
| 5 | 104-8807 | 1 | Axle ASM |
| 6 | 104-8808 | 1 | Swivel ASM |
| 6:1 | 104-8812 | 1 | Ring-Retainer |
| 6:2 | 104-8864 | 1 | Swivel Seal Kit |
| 7 | 104-8809 | 2 | Block-Pillow, Top |
| 8 | 104-8810 | 2 | Block-Pillow, Bottom |
| 9 | 104-8811 | 2 | Bearing |
| 10 | 104-8812 | 2 | Ring-Retainer |
| 11 | 104-8813 | 1 | Cap-Pipe |
| 12 | 322-3 | 8 | Screw-HH |
| 13 | 104-8814 | 1 | Trim-Edge, Drum |
| 14 | 3296-29 | 4 | Nut-Lock, NI |
| 15 | 3256-23 | 8 | Washer-Flat |
| 16 | 3253-21 | 4 | Washer-Lock |
| 17 | 323-6 | 4 | Screw-HH |
| 18 | 32128-21 | 1 | Nut-HF |
| 19 | 104-8815 | 1 | Bracket-12V Dc |
| 20 | 104-8816 | 1 | Motor-12V Dc |
| 21 | 104-8817 | 1 | Pinion |
| 22 | 104-8818 | 4 | Key |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 23 | 322-5 | 4 | Screw-HH |
| 24 | 3253-4 | 1 | Washer-Lock |
| 25 | 104-8819 | 4 | Screw-Set |
| 26 | 3256-23 | 4 | Washer-Flat |

# NOTES

# NOTES


TORO®