


TORO®

MODEL NO. R212OE02-2000001 & UP
MODEL NO. R212O502-2000001 & UP

PARTS CATALOG

WHEEL HORSE® 200 SERIES LAWN TRACTOR




C-1159

BODY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	114389	Fender	1
2	79-3840	Hood & Grill	1
6	117344	Handle Assembly	2
7	117432	Rivet - Pop	4
8	3219-14	Nut	2
9	116591	Headlight Bar Assembly (Incl. Ref. #22-24 & 26)	1
10	111392	Clip	1
11	32103-19	Nut - Wing	1
12	103995	Washer - Special	1
14	108547	Reflector	2
15	109193	Rivet - Pop	4
16	3230-23	Bolt - Carriage	8
17	938031	Bushing	1
18	910808	Screw	4

Ref. No.	Part No.	Description	No. Used
20	3253-17	Washer - Lock	4
21	3217-6	Nut - Lock	8
22	116601	Bar - Light	1
23	111684	Bucket - Light	2
24	111685	Retainer	4
25	116262	Socket - Light	2
26	7228	Bulb - Light	2
27	115414	Cable - Hood Lanyard	1
28	915740	Nut - Lock	1
29	913111	Screw - Machine	1
30	112925	Washer - Backing	1
32	115413	Clevis	2
38	5977	Bushing - Nylon	2
39	111536	Spring	2
40	79-2590	Push Nut	2

SEAT ASSEMBLY




SEAT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	79-0670	Seat	1
2	322-5	Bolt	4
3	113852	Plate - Seat Pivot	1
4	112745	Bracket - Pivot L.H.	1
*	112744	Bracket - Pivot R.H.	1
6	322-4	Bolt	4
7	105503	Bushing	2
8	3296-29	Nut - Lock	6
13	108889	Bumper	2

Ref. No.	Part No.	Description	No. Used
16	112961	Plate	2
17	322-5	Bolt	6
18	3256-23	Washer	8
22	112837	Spring - Seat	2
24	3253-4	Washer - Lock	8
25	3217-6	Nut - Hex.	4
26	322-6	Bolt	2
27	109989	Spacer - Nylon	4

*Not Illustrated

FRAME ASSEMBLY




FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	78-1640	Frame	1
2	114417	Plate - Rear Drawbar	1
3	112850	Plate - Frame Support (212-H)	1
4	111397	Plate - Front Axle Support	1
5	114610	Roller - Cam	2
6	112977	Support - Rear Axle	1
7	110180	Mat - Footrest	2
8	78-3390	Hoodstand	1
9	111467	Panel - Console	1
10	111499	Screw - Pan Hd.	4
11	117343	Keeper - Latch	2
12	117431	Rivet - Pop	4
15	3230-16	Bolt - Carriage (212-5)	7
		(212-H)	11
16	3296-29	Nut - Lock	14
19	3256-23	Washer	15
20	322-6	Screw - Hex. Hd.	2
21	3254-2	Washer - Lock	2
22	1278	Washer - Shim (.050")	A/R
*	5210	Washer - Shim (.015")	A/R
23	32120-93	Ring - Retaining	1
24	322-3	Screw - Hex. Hd.	4
25	915740	Nut - Hex.	2
26	910837	Screw	1
27	3217-5	Nut - Lock	1
28	3253-3	Washer - Lock	1
30	111524	Link	2
31	111527	Spring	2
32	78-1670	Cam - Adjustment	2
34	3272-16	Pin - Cotter	2
35	920242	Washer - Special	2

Ref. No.	Part No.	Description	No. Used
36	938031	Bushing	1
37	8830	Clip (212-5)	1
		(212-H)	2
38	113116	Retainer	4
41	109779	Nut	2
42	323-7	Bolt	1
43	3296-39	Nut - Lock	2
44	110370	Pulley - Idler (212-5)	1
45	323-10	Bolt	1
46	3256-24	Washer	2
47	109230	Retainer - Belt	1
48	111439	Grip	1
49	114989	Bracket - L.H.	1
*	114990	Bracket - R.H.	1
50	960151	Screw	2
51	3296-42	Nut - Lock	2
52	910796	Screw	2
53	915740	Nut - Lock	2
54	938050	Plug - Nylon	2
55	117142	Bracket - Fuse	1
56	78-2050	Bracket - Switch	1
57	926640	Screw - Machine	2
58	115860	Clip - Snap-In	1
59	115858	Clip - Snap-In	2
60	900036	Bolt - Carriage	2
61	926697	Bolt - Carriage	4
62	915112	Nut - Hex.	2
63	114851	Plate - Frame Support (212-5)	1
64	106634	Pin - Tool	1
65	933505	Pin - Hair	1

*Not Illustrated

ELECTRICAL SYSTEM ASSEMBLY




ELECTRICAL SYSTEM ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	104962	Battery (212-5)	1
*	105842	Battery (212-H)	1
2	79-3920	Harness Wire (Incl. Ref. #12, 26 & 29)	1
3	106948	Tray - Battery	1
4	109547	Hook	2
5	117316	Hold-Down - Battery	1
6	111076	Cable - Battery	1
7	111076	Wire - Solenoid/Battery	1
8	112757	Wire - Solenoid/Starter	1
9	321-4	Bolt	2
10	3256-22	Washer	4
11	3217-5	Nut	4
12	120930	Holder - Fuse	1
13	114721	Tube - Drain	1
14	38-1420	Switch - Seat	1
15	116338	Switch - Ignition (Incl. Ref. #23-24)	1
16	116738	Key - Ignition	2
17	102138	Switch - Light (Incl. Ref. #33 & 34)	1
18	920262	Washer - Special	1

Ref. No.	Part No.	Description	No. Used
19	920259	Washer - Special	1
20	100571	Tie - Cable	1
21	109553	Cover - Battery Terminal	1
22	115204	Harness - Headlight	1
23	101884	Nut - Switch	1
24	920160	Washer - Lock	1
25	3253-3	Washer - Lock	1
26	105302	Connector - 5 Terminal	1
27	32103-22	Nut - Wing	2
28	109355	Fuse - 15 Amp.	1
*	109102	Fuse - 25 Amp.	1
*	NN10277	Fuse - 30 Amp.	1
29	111498	Body - Connector	2
30	104926	Body - Connector	2
31	3023	Clip	4
32	78-3030	Switch - PTO	1
33	113179	Nut - Hex.	1
34	102950	Washer - Tab	1
35	910948	Screw	2
36	915732	Nut - Lock	2
37	115230	Switch - Clutch	1
38	105490	Clamp	1
39	107831	Socket - Connector	1
40	116397	Relay	3

*Not Illustrated

FRONT AXLE & STEERING ASSEMBLY




FRONT AXLE & STEERING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	114385	Axle - Front	1
2	302-5	Fitting - Grease	3
3	112847	Bracket - Support	1
4	113044	Tube	1
5	113030	Pin	2
6	111531	Spring	1
7	111406	Spindle - R.H.	1
8	111409	Spindle - L.H.	1
9	32120-93	Ring - Retaining	2
11	112981	Rod - Tie	1
12	79-5660	Shaft - Pinion	1
13	111417	Gear - Sector	1
14	111418	Bushing - Eccentric	1
15	111419	Washer	1
17	78-1991	Bracket - Steering Gear (212-5)	1
*	78-3221	Bracket - Steering Gear (212-H)	1
18	110391	Bushing	1

Ref. No.	Part No.	Description	No. Used
19	111422	Retainer	1
20	111423	Rod - Drag Link	1
22	78-3100	Wheel - Steering	1
25	322-4	Screw - Cap Hex. Hd.	2
26	3253-4	Washer - Lock	2
27	32121-103	Pin - Spirol	2
28	915001	Nut - Lock	2
29	3765	Washer - Shim (.050")	A/R
30	3231-28	Bolt	1
31	108881	Nut - Lock	1
32	3230-22	Bolt	2
33	3229-29	Nut - Lock	3
34	3256-23	Washer	1
35	3230-2	Bolt	1
36	915002	Nut - Lock	2
37	32121-111	Pin	1
39	2844	Washer - Special	2
40	78-0370	Insert - Steering Wheel	1

*Not Illustrated

WHEEL & TIRE ASSEMBLY




WHEEL & TIRE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	109154	Hubcap	2
2	100079	Tube - Inner	2
3	116883	Front Wheel & Tire Assy. (Incl. Ref. #4-8)	2
4	116884	Tire - Front	2
5	5108	Valve - Stem	4
6	109500	Fitting - Grease	2
7	116885	Front Wheel Assembly (Incl. Ref. #5, 6 & 8)	2
8	116887	Bushing - Flange	4
9	1278	Washer - .050"	A/R
10	5210	Washer - .015"	A/R
11	109262	Washer - Hubcap	2
12	3272-17	Pin - Cotter	2
13	109261	Hubcap	2
14	32151-48	Ring - Snap	2
15	109262	Washer - .050"	6

Ref. No.	Part No.	Description	No. Used
16	105450	Tube - Inner	2
17	116879	Rear Wheel & Tire Assy. (Incl. Ref. #5, 18 & 19)	2
18	116880	Tire - Rear	2
19	79-5590	Rear Wheel Assembly (Incl. Ref. #5)	2
20	1120	Key - Square	2
21	1278	Washer - .050"	A/R
22	920251	Washer - .050"	4
23	5-1336	Key - Square	2
24	79-5560	Rear Wheel & Tire Assy. (Incl. Ref. #5, 16 & 25)	2
25	79-5570	Rear Wheel Assembly (Incl. Ref. #5)	2
26	120860	Washer - .075"	6
27	32151-36	Ring - Snap	2

TRANSMISSION ASSEMBLY (212-5)




TRANSMISSION ASSEMBLY (212-5)

Ref. No.	Part No.	Description	No. Used
2	78-3340	Transmission Assembly (Peerless Model 930-020)	1
3	112982	Strap - Torque	2
5	111430	Arm	1
6	78-2020	Shaft	1
7	5666	Bushing - Nylon	1
8	111432	Spring	1
9	112983	Knob	1
10	115198	Arm - Transmission	1
11	115042	Rod	1
12	115043	End - Rod	1
13	104869	Washer - Special	1
15	322-12	Screw - Cap Hex. Hd.	4
16	3256-23	Washer	8
17	900036	Bolt - Carriage	2
18	926720	Screw	2
19	3296-29	Nut - Lock	5
20	3253-4	Washer - Lock	2
21	915112	Nut - Lock	2

Ref. No.	Part No.	Description	No. Used
22	113025	Pointer	1
23	933273	Pin - Spirol	1
24	3765	Washer - Shim	A/R
25	3220-2	Nut - Jam	1
26	329-5	Screw - Cap Hex. Hd.	1
27	3253-3	Washer - Lock	1
28	920268	Washer	1
29	3272-6	Pin - Cotter	1
30	322-6	Bolt	1
32	116120	Pulley - Transmission	1
33	114860	Belt - Transmission Drive	1
34	937225	Key	1
35	3242-2	Screw - Sq. Hd. Set	2
36	110769	Spring - Brake Return	1
37	322-5	Bolt - Brake Stop	1
38	915112	Nut - Lock	1
39	3256-23	Washer - Flat	1
40	78-2030	Collar	1

PEERLESS TRANSMISSION MODEL NO. 930-020 (212-5)




PEERLESS TRANSMISSION MODEL NO. 930-020* **(212-5)**

Ref. No.	Part No.	Description	No. Used
1	772108	Cover - Transaxle	1
2	780086	Bearing - Needle	2
3	770102	Case - Transaxle	1
4	776260	Shaft - Counter	1
5	776219	Output Shaft & Pinion Assy.	1
6	778139	Gear - Output	1
7	778136	Gear - Spur (15 teeth)	1
8	792136	Key - Shifter	2
9	784352	Collar - Shifter	1
10	784354	Shift Rod & Fork Assy.	1
11	778229	Gear - Bevel (42 teeth)	1
12	778113A	Bevel Pinion - Input	1
13	778221	Gear - Bevel	2
14	778068	Gear - Bevel Pinion	2
15	778260	Gear - Ring	1
16	786139	Pin - Drive	1
18	786102	Spacer	1
20	792077	Ball - Steel	1
21	792078	Set Screw	1
22	792079	Spring	1
23	788061	Ring - Seal	2
25	792073	Screw - Flanged Hex. Hd.	17
26	792125	Ring - Retainer (Pkg. of 2)	4
27	792035	Ring - Retainer	1
28	788040	Ring - Retainer	1
29	780072	Washer - Thrust	5
30	780108	Washer - Thrust	4
31	780001	Washer	4
32	792001	Seal - O-Ring	1
33	788051	Seal - Square Cut	1
34	780105A	Bushing - Flanged	4
35	780118A	Bushing - Flanged	2
36	790003	Disk - Brake	1
37	790007	Plate - Brake Pad	1
38	790006	Pad - Brake	2

Ref. No.	Part No.	Description	No. Used
39	786026	Pin - Dowel	2
40	792076	Washer - Flat	1
41	790039	Lever - Brake	1
42	792073	Screw - Flanged Hex Hd.	2
43	792075	Nut - Lock	1
44	790025	Holder - Brake Pad	1
45	776315A	Shaft - Brake (4-keyed)	1
46	776135	Shaft - Input	1
47	774688	Axle (11-5/8" long)	1
48	774747	Axle (16-1/4" long)	1
49	778191	Gear - Spur (37 teeth)	1
50	778125	Gear - Spur (35 teeth)	1
51	778124A	Gear - Spur (30 teeth)	1
52	778123A	Gear - Spur (25 teeth)	1
53	778121A	Gear - Spur (20 teeth)	1
54	778230	Gear - Spur (12 teeth)	1
55	778151	Gear - Spur (15 teeth)	1
56	778126A	Gear - Spur (20 teeth)	1
57	778127A	Gear - Spur (25 teeth)	1
58	778129A	Gear - Spur (30 teeth)	1
60	786062A	Chain - Roller	1
61	786061	Sprocket (10 teeth)	1
62	786124	Sprocket (14 teeth)	1
64	792074	Plug - Hex. Hd.	1
65	780109	Washer - Thrust	1
68	786086	Bracket - Brake Lever	1
69	780051	Washer - Thrust	2
70	786118	Spacer	1
71	788069	Seal - Square Cut	1
72	786116	Disk	1
74	786071	Spacer	1
75	786072	Spacer	1
76	780090	Washer - Thrust	1
77	788075	Ring - Retaining	1
78	788067B	Grease (32 oz. bottle)	1

* Order from Peerless

SWEEPER P.T.O. ASSEMBLY (212-5)




SWEEPER P.T.O. ASSEMBLY (212-5)

Ref. No.	Part No.	Description	No. Used
1	119350	Guide - Belt	1
2	3256-23	Washer - Flat	4
3	322-5	Screw - Cap Hex. Hd.	1
4	3253-3	Washer - Lock	3
5	321-2	Screw - Cap Hex. Hd.	3
6	3242-2	Screw - Set	1
7	6366	Key - Square	1
8	3253-21	Washer - Lock	1
9	323-6	Screw - Cap Hex. Hd.	1
10	2844	Washer	1
11	114740	Pulley	1
12	114741	Spacer - Shaft	1
13	102533	Cup - Bearing	1
14	322-3	Screw - Cap Hex. Hd.	5
15	114686	Plate - Mounting	1
16	102534	Bearing - Ball	1
17	102536	Bearing Cup & Nuts	1
18	116119	Shaft - Drive	1
19	920267	Washer - Special	2

Ref. No.	Part No.	Description	No. Used
20	3296-29	Nut - Lock	7
21	3296-42	Nut - Lock	4
22	114762	Spacer - Rubber	2
23	114756	Block - Rubber	2
24	910842	Screw - Pan Hd.	4
25	3296-39	Nut - Lock	6
26	116784	Bar - Pivot	2
27	114757	Spacer	2
28	323-7	Screw - Cap Hex. Hd.	4
29	915112	Nut - Hex.	2
30	114723	Bracket - L.H.	1
*	114724	Bracket - R.H.	1
31	106634	Pin - Tool	2
32	933505	Pin - Cotter Hair	2
33	3231-25	Bolt - Carriage	2
34	117389	Brace - L.H.	1
*	117390	Brace - R.H.	1
35	1336	Washer	2

*Not Illustrated

BRAKE & IDLER ASSEMBLY (212-5)




BRAKE & IDLER ASSEMBLY (212-5)

Ref. No.	Part No.	Description	No. Used
1	111436	Pedal - Brake/Idler	1
2	111437	Shaft - Pedal	1
3	106288	Clamp - Shaft	2
4	110015	Spacer	1
5	111712	Washer - Wave	1
6	112984	Rod - Lock	1
7	111439	Grip	1
8	114859	Arm - Idler	1
9	111418	Bushing - Eccentric	1
10	111419	Washer	1
12	113129	Rod - Brake/Idler	1
13	111442	Pulley - Idler	1
14	111443	Guide - Belt	1
15	104525	Spacer	1

Ref. No.	Part No.	Description	No. Used
17	111445	Spring - Brake	1
18	111446	Spring - Idler	1
19	3296-29	Nut - Lock	4
20	3230-16	Bolt - Carriage	4
21	3272-16	Pin - Cotter	1
22	920215	Washer	1
23	3272-6	Pin - Cotter	3
24	3256-23	Washer	3
25	3231-25	Bolt - Carriage	1
26	3296-39	Nut - Lock	2
27	3231-33	Bolt - Carriage	1
28	3256-24	Washer	2
29	116150	Spring - Extension	1

TRANSMISSION ASSEMBLY (212-H)




TRANSMISSION ASSEMBLY (210-H & 212-H)

Ref. No.	Part No.	Description	No. Used
1	78-2710	Transmission Assembly (Eaton Model 750-019)	1
2	114433	Belt	1
3	3296-29	Nut - Lock	4
4	3256-23	Washer - Flat	8
5	322-13	Bolt	4
6	116180	Clamp - Hose	4
7	114409	Hose	1
8	114693	Hose	1
9	79-1100	Reservoir Assembly (Incl. Ref. #10-12)	1
10	79-1080	Cover	1
11	114563	Gasket - Cover	1
12	114564	Reservoir	1

Ref. No.	Part No.	Description	No. Used
13	937222	Key - Hi-Pro	1
14	78-2870	Pulley - Input Shaft	1
15	115687	Fan	1
18	108917	Knob	1
19	116126	Cable - Push Valve	1
20	910792	Screw	2
21	915740	Nut - Lock	2
23	114400	Bracket - Reservoir	1
24	321-4	Bolt	4
25	3256-22	Washer - Flat	2
26	3296-42	Nut - Lock	4
27	8830	Clip	2
28	911910	Screw - Flat H.D.	2

SWEEPER P.T.O. ASSEMBLY (212-H)




SWEEPER P.T.O. ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	115686	Pulley - Drive	1	19	910842	Screw - Pan Hd.	4
2	115991	Guide - Belt	1	20	3296-39	Nut - Lock	6
3	3256-23	Washer - Flat	8	21	116784	Bar - Pivot	2
4	3272-2	Pin - Cotter	1	22	114757	Spacer	2
5	114812	Spacer	1	23	323-7	Screw - Cap Hex. Hd.	4
6	113589	Tie - Plastic	2	24	915112	Nut - Hex.	2
7	2534	Clip - Spring	2	25	114723	Bracket - L.H.	1
8	322-5	Screw - Cap Hex. Hd.	3	*	114724	Bracket - R.H.	1
9	115990	Guide - Belt	1	26	3296-29	Nut - Lock	3
10	3253-3	Washer - Lock	1	27	106634	Pin - Tool	2
11	908011	Screw - Cap Hex. Hd.	1	28	933505	Pin - Cotter Hair	2
12	115968	Belt - V	1	29	117389	Brace - L.H.	1
13	321-4	Screw - Cap Hex. Hd.	2	*	117390	Brace - R.H.	1
14	116005	Shoe - Belt	1	30	3231-25	Bolt - Carriage	2
15	3256-22	Washer - Flat	2	31	1336	Washer	2
16	3296-42	Nut - Lock	6	32	920267	Washer - Special	2
17	114762	Spacer - Rubber	2	33	322-3	Screw - Cap Hex. Hd.	2
18	114756	Block - Rubber	2	34	937222	Key - Hi-Pro	1

*Not Illustrated

TRANSMISSION LINKAGE ASSEMBLY (212-H)




TRANSMISSION LINKAGE ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	114416	Plate - Neutral Return	1	47	3256-23	Washer	5
2	114401	Plate - Cam	1	48	3256-24	Washer	1
3	100656	Bearing - Cam Return	1	49	3256-22	Washer	1
4	32120-47	E-Ring	1	50	3272-6	Pin - Cotter	3
5	116339	Rod - Speed Control	1	51	3272-7	Pin - Cotter	1
6	110189	Rod - End	1	52	3272-2	Pin - Cotter	1
7	3220-1	Nut - Jam	1	53	932948	Pin - Clevis	1
8	114403	Support - Cam Plate	1	54	32146-2	Nut - Lock	1
9	114695	Nut - Special	1	55	3296-29	Nut - Lock	3
10	100365	Washer - Spring Disc	2	57	3296-42	Nut - Lock	2
11	100305	Washer - Friction	1	58	926696	Bolt	1
12	100309	Spacer - Cam	2	59	322-2	Bolt	1
13	109779	Nut - Jam	2	60	322-3	Bolt	2
14	911459	Bolt	1	61	3231-4	Bolt - Carriage	1
15	114402	Spacer	1	62	3230-2	Bolt - Carriage	2
16	116340	Arm - Motion Control	1	63	3229-2	Bolt - Carriage	1
17	106661	Cam	1	64	926698	Screw	1
18	109447	Gear - Spacer	1	65	908016	Bolt	2
19	114656	Support - Angle	1	67	3253-4	Washer - Lock	4
20	114404	Plate - Neutral Pivot	1	68	32151-57	Ring - Snap	2
21	114697	Spacer	1	69	32120-50	Pin - Spirol	1
22	920271	Washer - Special	1	70	932948	Pin - Clevis	1
23	104859	Spacer - Lift Link	1	71	937082	Key - Woodruff	1
25	114818	Spring	1	72	114821	Washer - Friction	2
26	114668	Bracket - Spring	1	73	3256-4	Washer	1
27	114410	Bracket - Torque	1	74	115677	Bracket	1
28	115678	Plate - Mounting	1	75	920259	Washer	1
29	111688	Clamp	1	76	111430	Arm	1
30	926641	Screw	1	77	933273	Pin - Spirol	1
31	114698	Spring - Brake	1	78	111432	Spring	1
32	114666	Bracket	1	79	3765	Washer - Shim	1
33	114670	Pivot - Brake	1	80	5666	Bushing Nylon	1
34	114663	Plate	1	81	78-3230	Shaft	1
35	104524	Trunnion	1	82	113025	Pointer	1
36	107677	Spring - Brake	1	83	112983	Knob	1
37	114665	Clevis	1	84	117326	Spring	1
38	116287	Bolt - Adjusting	1	85	117325	Bracket - Spring	1
39	32151-73	Ring - Retaining	1	86	322-5	Screw - Cap Hex. Hd.	2
43	932000	Pin - Cotter	1	87	78-2030	Collar	1
46	116398	Plate - Arm	1				

*Not Illustrated

BRAKE & IDLER ASSEMBLY (212-H)




BRAKE & IDLER ASSEMBLY (212-H)

Ref. No.	Part No.	Description	No. Used
1	114418	Pedal - Brake	1
2	111437	Shaft - Pedal	1
3	106288	Clamp - Shaft	2
4	110015	Spacer	1
5	111712	Washer - Wave	1
6	114705	Rod - Lock	1
7	111070	Knob	1
8	114034	Arm - Idler	1
9	111418	Bushing - Eccentric	1
10	111419	Washer	1
12	114707	Rod - Brake	1
13	111442	Pulley - Idler	1
14	109444	Pulley - Idler	1

Ref. No.	Part No.	Description	No. Used
17	102572	Spring - Idler	1
19	3296-29	Nut - Lock	4
20	3230-1	Bolt - Carriage	4
21	3272-16	Pin - Cotter	1
22	920215	Washer	1
23	3272-6	Pin - Cotter	2
24	3256-23	Washer	2
25	3231-25	Bolt - Carriage	1
26	3296-39	Nut - Lock	3
27	3231-29	Bolt - Carriage	2
28	3256-4	Washer	2
29	3256-24	Washer - Flat	2

ENGINE PULLEY & PTO CLUTCH ASSEMBLY




ENGINE PULLEY & PTO CLUTCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	115629	Electric Clutch Assembly (Incl. Ref. #2-5)	1
2	113820	Rotor Assembly	1
3	113821	Field Assembly (Incl. Ref. #9)	1
4	113822	Armature & Pulley Assy. (Incl. Ref. #9)	1

Ref. No.	Part No.	Description	No. Used
5	113823	Spring & Nut Assembly	3
6	112843	Washer	1
7	112853	Bolt	1
8	112858	Pulley - Engine	1
9	114064	Bearing - Ball	2

*Not Illustrated

ENGINE FUEL & EXHAUST ASSEMBLY




ENGINE FUEL & EXHAUST ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
2	78-8550	Engine - 12HP TORO Power Plus Model No. E125V Type N/10964B	1	28	915740	Nut - Lock	2
4	116702	Muffler	1	29	3230-1	Bolt - Carriage	2
5	79-3320	Control - Throttle	1	31	3296-29	Nut - Lock	2
6	116454	Knob	1	32	114764	Fitting - 90°	1
7	112153	Fuel Tank Assembly (Incl. Ref. #8 & 9)	1	33	NN10653	Plug - Pipe	1
8	104047	Bushing	1	34	115356	Arrester - Spark	1
9	104048	Valve	1	35	113113	Screw - Hex. Hd.	3
10	111474	Cap - Gas	1	37	3253-4	Washer - Lock	2
11	117225	Line - Fuel	1	39	911652	Screw	1
12	2412-98	Clamp - Hose	2	40	114636	Extension - Oil Drain	1
22	3256-23	Washer	2	41	926696	Screw	4
27	111499	Screw - Pan Hd.	2	42	48-7630	Bolt	2
				43	111392	Clip - J	2
				44	117184	Gasket	1
				45	3253-3	Washer - Lock	2

*Not Illustrated

12HP ENGINE CYLINDER BLOCK ASSEMBLY




12HP ENGINE CYLINDER BLOCK ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	NN10852	Block – Cylinder	1	14	NN10587	Kit – Connecting Rod (Standard)	1
2	NN10626	Pin – Dowel	2			(Incl. Ref. #15 & 16)	
3	NN10678	Bearing – Ball	2	*	NN10588	Kit – Connecting Rod (.25mm Undersize)	
4	NN10569	Seal – Oil	1			(Incl. Ref. 15 & 16)	
5	NN10570	Bearing – Crankshaft	1	*	NN10589	Kit – Connecting Rod (.50mm Undersize)	1
6	NN10571	Bearing – Camshaft	1			(Incl. Ref. #15 & 16)	
7	NN10646	Seal – Governor Shaft	1	15	NN10590	Bolt	
8	79-5840	Pin – Alignment	2	16	NN10591	Washer	2
9	NN10653	Plug – Pipe	1	17	NN10688	Indicator	2
10	NN10579	Kit – Piston (Standard)	1			(Incl. Ref. #18)	1
		(Incl. Ref. #11 & 12)		18	57-9610	Seal – O-Ring	1
*	NN10580	Kit – Piston (.25mm Oversize)		19	NN10689	Tube	1
		(Incl. Ref. #11 & 12)	1	20	NN10690	Seal	1
*	NN10581	Kit – Piston (.50mm Oversize)	1	21	82-1560	Screw	1
		(Incl. Ref. #11 & 12)		22	NN10691	Bracket – Support	1
11	NN10582	Pin – Piston		23	82-1700	Nut – Speed	1
12	NN10583	Ring – Retaining	2	24	NN10740	Washer – Lock	1
13	NN10584	Set – Piston Ring (Standard)	1	25	NN10768	Nut	1
*	NN10585	Set – Piston Ring (.25mm Oversize)	1				
*	NN10586	Set – Piston Ring (.50mm Oversize)	1				

*Not Illustrated

12HP ENGINE CRANKSHAFT & CAMSHAFT ASSEMBLY




12HP ENGINE CRANKSHAFT & CAMSHAFT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10627	Camshaft Assembly (Incl. Ref. #2-5)	1
2	NN10642	Camgear Assembly	1
3	NN10643	Key - Camgear	1
4	NN10644	Pin	1
5	NN10645	Spring	1
6	NN10640	Lever	1
7	NN10641	Clip - Retaining	2
8	82-1350	Washer	1
9	NN10630	Shim - Camshaft (.50mm)	1
*	NN10631	Shim - (.60mm)	1
*	NN10632	Shim - (.80mm)	1
*	NN10633	Shim - (.90mm)	1
*	NN10634	Shim - (1.00mm)	1
*	NN10635	Shim - (1.20mm)	1
10	NN10742	Gear - Crankshaft	1
11	NN10743	Gear - Balancer	1
12	NN10744	Crankshaft	1
13	NN10745	Key - Gear	1

Ref. No.	Part No.	Description	No. Used
14	NN10746	Shim - Crankshaft (.20mm)	1
*	NN10747	Shim - (.30mm)	1
*	NN10748	Shim - (.40mm)	1
*	NN10749	Shim - (.50mm)	1
*	79-5850	Shim - (.70mm)	1
*	79-5860	Shim - (.80mm)	1
15	NN10750	Plug	1
16	NN10751	Gear	1
17	NN10752	Gear	1
18	NN10753	Shaft	1
19	NN10754	Shaft	1
20	NN10755	Key - Gear	2
21	NN10756	Shim - Balancer Shaft (.50mm)	1
*	NN10757	Shim - (.60mm)	1
*	NN10758	Shim - (.70mm)	1
*	NN10759	Shim - (.80mm)	1
*	NN10760	Shim - (.90mm)	1
*	NN10761	Shim - (1.00mm)	1
*	NN10762	Shim - (1.20mm)	1

*Not Illustrated


12HP ENGINE OIL BASE & PUMP ASSEMBLY



12HP ENGINE OIL BASE & PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	NN10680	Bolt	9	16	82-1130	Plug - Pipe	1
2	NN10681	Gasket - Oil Base	1	17	NN10686	Plug - Pipe	2
3	NN10684	Filter - Oil	1	18	NN10575	Seal - O-Ring	1
4	NN10685	Adapter - Oil Filter	1	19	NN10569	Seal - Oil	1
5	NN10675	Base - Oil	1	20	NN10534	Ball - Steel	1
6	59-0280	Spring - Relief Valve	1	21	NN10677	Bearing - Ball	1
7	NN10572	Pump - Oil	1	22	NN10678	Bearing - Ball	2
8	NN10573	Cover - Oil Pump	1	23	59-0760	Plug	2
9	NN10577	Screen - Oil Pickup	1	24	NN10539	Ring - Retaining	1
10	NN10578	Cover - Screen	1	25	NN10628	Washer - Flat	1
11	NN10636	Gear - Governor	1	26	NN10629	Washer - Flat	1
12	NN10637	Shaft - Governor	1	27	NN10868	Screw - Torx Pan Hd.	4
13	NN10638	Sleeve - Governor	1	28	NN10813	Switch - Oil Pressure	1
14	NN10639	Stop - Governor	1	29	NN10798	Plug - Pipe	1
15	NN10687	Plug - Pipe	2				

12HP ENGINE CYLINDER HEAD & VALVES ASSEMBLY




12HP ENGINE CYLINDER HEAD & VALVES ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10592	Gasket – Cylinder Head	1
2	NN10593	Cylinder Head Assembly (Incl. Ref. #3–16)	1
*	NN10594	Cylinder Head Assembly (Incl. Ref. #3–6)	1
3	79–5880	Guide – Intake Valve	1
4	79–5870	Guide – Exhaust Valve	1
5		Seat – Intake Valve	1
6		Seat – Exhaust Valve	1
7	NN10597	Spring – Valve	2
8	NN10598	Valve – Intake	1
9	NN10599	Valve – Exhaust	1
10	NN10600	Retainer – Intake	1
11	NN10611	Retainer – Exhaust	1
12	NN10602	Lock – Intake	1
13	NN10603	Lock – Exhaust	1
14	NN10604	Ring	2
15	NN10605	Seal – Intake	1
16	NN10606	Washer	2
17	NN10607	Bolt	1
18	NN10608	Bolt	1

Ref. No.	Part No.	Description	No. Used
19	NN10609	Gasket	1
20	92–0930	Cover – Valve	1
21	NN10611	Fitting – 45°	1
22	NN10612	Breather	1
23	NN10613	Screw – Hex. Socket Hd.	7
24	NN10614	Washer	2
25	NN10615	Bolt	2
26	NN10616	Bolt	2
27	NN10617	Tappet	2
28	NN10618	Rod – Push	2
29	NN10619	Rocker Arm Assembly (Incl. Ref. #30 & 31)	1
30	NN10620	Screw	2
31	NN10621	Nut	2
32	NN10622	Shaft – Rocker Arm	1
33	NN10623	Washer – Rocker Arm	2
34	NN10624	Clip – Retainer	2
35	NN10625	Pin – Dowel	1
36	NN10626	Pin – Dowel (Hollow)	1
37	82–1340	Washer – Flat	7

*Not Illustrated

12HP ENGINE IGNITION ASSEMBLY




12HP ENGINE IGNITION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10735	Screw – Torx Pan Hd.	2
2	57-9440	Stator	1
3	NN10733	Bolt – Hex. Hd.	1
4	79-5890	Clamp – Cord	1
5	79-5900	Pin – Alignment	2

Ref. No.	Part No.	Description	No. Used
6	NN10820	Plug – Spark	1
7	NN10729	Lead	1
8	NN10730	Coil – Ignition	1
9	NN10731	Bolt – Hex. Hd.	2
10	NN10673	Harness – Regulator	1

12HP ENGINE AIR CLEANER ASSEMBLY




12HP ENGINE AIR CLEANER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10693	Hose - Breather	1
2	NN10694	Gasket	1
3	NN10899	Adapter	1
4	NN10872	Element	1
5	NN10697	Cover - Element	1
6	NN10698	Wrapper - Element	1
7	NN10704	Grommet	1
8	NN10703	Knob	1
9	92-0931	Clamp - Hose	1

Ref. No.	Part No.	Description	No. Used
10	NN10812	Clamp - Hose	1
11	82-1350	Washer - Flat	2
12	NN10702	Screw - Cap Hex. Hd.	2
13	NN10795	Clamp - Hose	1
14	NN10796	Hose - Breather	1
15	NN10700	Knob	2
16	NN10799	Cover - Air Cleaner	1
18	79-5910	Kit - Air Cleaner (Incl. Ref. #2-8 & 13-15)	1

*Not Illustrated

12HP ENGINE GOVERNOR LINKAGE & COVER ASSEMBLY




12HP ENGINE GOVERNOR LINKAGE & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10657	Spring – Governor	1
2	NN10647	Lever – Governor	1
3	NN10816	Washer – Governor Lever	2
4	NN10648	Screw – Cap Hex. Hd.	1
5	NN10740	Washer – Lock	1
6	NN10768	Nut – Hex.	1
7	NN10674	Clip – Link	1
8	NN10651	Throttle Plate Assembly	1
9	NN10652	Screw – Machine	1
10	NN10653	Clamp – Cable	1
11	59-0720	Pin – Cotter	1
12	NN10395	Screw – Thread Forming	1
13	NN10656	Swivel – Choke Lever	1
14	59-0850	Washer – Flat	1
15	NN10658	Link – Throttle	1
16	NN10654	Spring – Choke Linkage	1
17	NN10659	Link – Choke	1

Ref. No.	Part No.	Description	No. Used
18	NN10660	Spacer	1
19	NN10661	Stud	1
20	NN10817	Screw – Thread Forming	1
21	82-1340	Washer – Flat	2
22	82-1350	Washer – Flat	2
23	NN10663	Nut – Hex.	1
24	NN10344	Ring – Retaining	1
25	NN10785	Screw – Thread Forming	1
26	NN10770	Plug – Pipe	1
27	NN10800	Housing – Cylinder Air	1
28	NN10723	Deflector – Air	1
29	NN10725	Screw – Cap Hex. Hd.	1
30	82-1340	Washer – Flat	1
31	NN10726	Screw – Cap Hex. Hd.	5
32	82-1350	Washer – Flat	6
33	NN10727	Screw – Cap Hex. Hd.	1

*Not Illustrated

12HP ENGINE FLYWHEEL & COVER ASSEMBLY




12HP ENGINE FLYWHEEL & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10804	Screen	1
2	NN10712	Blower Wheel Assembly	1
3	NN10715	Nut	1
4	NN10713	Key	1


Ref. No.	Part No.	Description	No. Used
5	NN10805	Screw – Hex. Hd.	3
6	NN10803	Housing – Blower	1
7	NN10721	Bolt	4

12HP ENGINE STARTER ASSEMBLY



Ref. No.	Part No.	Description	No. Used
1	NN10739	Starter	1
2	NN10738	Screw – Cap Hex. Hd.	2

Ref. No.	Part No.	Description	No. Used




12HP ENGINE CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10666	Gasket	1
2	NN10667	Elbow – Intake	1
3	NN10668	Carburetor Assembly	1
4	NN10669	Insulator	1
5	NN10670	Gasket	2
9	79-5820	Screw – Cap Hex. Hd.	2
10	79-5830	Washer – Flat	2

Ref. No.	Part No.	Description	No. Used
12	NN10674	Clip – Link	2
14	NN10371	Screw – Hex. Washer Hd.	1
15	57-9120	Bushing	1
16	57-9430	Regulator – Voltage	1
17	NN10906	Kit – Float	1
19	NN10907	Kit – Carburetor Repair	1
20	NN10701	Stud	1

WIRING DIAGRAM (212-5 & 212-H)





DECAL & MISCELLANEOUS PARTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	79-4560	Decal - Hood R.H. (212-5)	1
*	79-4580	Decal - Hood R.H. (212-H)	1
*	79-4570	Decal - Hood L.H. (212-5)	1
*	79-4590	Decal - Hood L.H. (212-H)	1
3	116590	Decal - Hood Rear	1
4	111327	Decal - Parking Brake	1
5	78-8440	Decal - PTO Clutch	1
6	118600	Decal - Power Plus	1
7	117512	Decal - 5-Speed (212-5)	2
8	117511	Decal - Hydro (212-H)	2
9	117760	Decal - Fender	1
10	116874	Decal - Hood Front	1
*	807356	Loose Parts Package (212-5)	1
*	807363	Loose Parts Package (212-H)	1

Ref. No.	Part No.	Description	No. Used
11	111632	Decal - Clutch & Brake	1
12	114442	Decal - Hydro Push (212-H)	1
13	79-5400	Decal - Throttle	1
14	115196	Decal - Attach-a-Matic	1
15	114621	Decal - Noise	1
16	115398	Decal - Maintenance	1
17	111926	Decal - Electrical System	1
19	112403	Decal - VIN Overlay	1
20	79-0370	Decal - Danger (212-H)	1
		Decal - Danger (212-5)	2
21	112670	Decal - Danger	1
22	120040	Decal - TORO	1
23	114944	Decal - Shift 5-Speed (212-5)	1
24	114051	Decal - Motion Control (212-H)	1
25	78-8490	Decal - Lights	1
26	113370	Decal - PTO Adjustment	1
27	78-8480	Decal - Ignition	1
28	118610	Decal - Power Plus	1

*Not Illustrated

TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
1120	Key - Square	11 20 2	109262	Washer - Hubcap	11 11 2
1278	Washer - .050	11 9 A/R	109355	Fuse - 15 Amp.	7 28 1
1278	Washer - .050	11 21 A/R	109444	Pulley - Idler	27 14 1
1278	Washer - Shim (.050)	5 22 A/R	109447	Gear - Spacer	25 18 1
1336	Washer	23 31 2	109500	Fitting - Grease	11 6 2
1336	Washer	17 35 2	109547	Hook	7 4 2
2534	Clip - Spring	23 7 2	109553	Cover - Battery Terminal	7 21 1
2844	Washer	17 10 1	109779	Nut	5 41 2
2844	Washer - Special	9 39 2	109779	Nut - Jam	25 13 2
3023	Clip	7 31 4	109989	Spacer - Nylon	3 27 4
3765	Washer - Shim	13 24 A/R	110015	Spacer	19 4 1
3765	Washer - Shim	25 79 1	110015	Spacer	27 4 1
3765	Washer - Shim (.050)	9 29 A/R	110180	Mat - Footrest	5 7 2
5108	Valve - Stem	11 5 4	110189	Rod - End	25 6 1
5210	Washer - .015	11 10 A/R	110370	Pulley - Idler	5 44 1
5210	Washer - Shim (.015)	5 * A/R	110391	Bushing	9 18 1
5666	Bushing Nylon	25 80 1	110769	Spring - Brake Return	13 36 1
5666	Bushing - Nylon	13 7 1	111070	Knob	27 7 1
5977	Bushing - Nylon	1 38 2	111076	Cable - Battery	7 6 1
6366	Key - Square	17 7 1	111076	Wire - Solenoid/Battery	7 7 1
7228	Bulb - Light	1 26 2	111327	Decal - Parking Brake	53 4 1
8830	Clip	21 27 2	111392	Clip	1 10 1
8830	Clip	5 37 1	111392	Clip - J	31 43 2
100079	Tube - Inner	11 2 2	111397	Plate - Front Axle Support	5 4 1
100305	Washer - Friction	25 11 1	111406	Spindle - R.H.	9 7 1
100309	Spacer - Cam	25 12 2	111409	Spindle - L.H.	9 8 1
100365	Washer - Spring Disc	25 10 2	111417	Gear - Sector	9 13 1
100571	Tie - Cable	7 20 1	111418	Bushing - Eccentric	19 9 1
100656	Bearing - Cam Return	25 3 1	111418	Bushing - Eccentric	27 9 1
101884	Nut - Switch	7 23 1	111418	Bushing - Eccentric	9 14 1
102138	Switch - Light	7 17 1	111419	Washer	19 10 1
102533	Cup - Bearing	17 13 1	111419	Washer	27 10 1
102534	Bearing - Ball	17 16 1	111419	Washer	9 15 1
102536	Bearing Cup & Nuts	17 17 1	111422	Retainer	9 19 1
102572	Spring - Idler	27 17 1	111423	Rod - Drag Link	9 20 1
102950	Washer - Tab	7 34 1	111430	Arm	13 5 1
103995	Washer - Special	1 12 1	111430	Arm	25 76 1
104047	Bushing	31 8 1	111432	Spring	13 8 1
104048	Valve	31 9 1	111432	Spring	25 78 1
104524	Trunnion	25 35 1	111436	Pedal - Brake/Idler	19 1 1
104525	Spacer	19 15 1	111437	Shaft - Pedal	19 2 1
104859	Spacer - Lift Link	25 23 1	111437	Shaft - Pedal	27 2 1
104869	Washer - Special	13 13 1	111439	Grip	19 7 1
104926	Body - Connector	7 30 2	111439	Grip	5 48 1
104962	Battery	7 1 1	111442	Pulley - Idler	19 13 1
105302	Connector - 5 Terminal	7 26 1	111442	Pulley - Idler	27 13 1
105450	Tube - Inner	11 16 2	111443	Guide - Belt	19 14 1
105490	Clamp	7 38 1	111445	Spring - Brake	19 17 1
105503	Bushing	3 7 2	111446	Spring - Idler	19 18 1
105842	Battery	7 * 1	111467	Panel - Console	5 9 1
106288	Clamp - Shaft	19 3 2	111474	Cap - Gas	31 10 1
106288	Clamp - Shaft	27 3 2	111498	Body - Connector	7 29 2
106634	Pin - Tool	23 27 2	111499	Screw - Pan Hd.	5 10 4
106634	Pin - Tool	17 31 2	111499	Screw - Pan Hd.	31 27 2
106634	Pin - Tool	5 64 1	111524	Link	5 30 2
106661	Cam	25 17 1	111527	Spring	5 31 2
106948	Tray - Battery	7 3 1	111531	Spring	9 6 1
107677	Spring - Brake	25 36 1	111536	Spring	1 39 2
107831	Socket - Connector	7 39 1	111632	Decal - Clutch & Brake	53 11 1
108547	Reflector	1 14 2	111684	Bucket - Light	1 23 2
108881	Nut - Lock	9 31 1	111685	Retainer	1 24 4
108889	Bumper	3 13 2	111688	Clamp	25 29 1
108917	Knob	21 18 1	111712	Washer - Wave	19 5 1
109102	Fuse - 25 Amp.	7 * 1	111712	Washer - Wave	27 5 1
109154	Hubcap	11 1 2	111926	Decal - Electrical System	53 17 1
109193	Rivet - Pop	1 15 4	112153	Fuel Tank Assembly	31 7 1
109230	Retainer - Belt	5 47 1	112403	Decal - VIN Overlay	53 19 1
109261	Hubcap	11 13 2	112670	Decal - Danger	53 21 1
109262	Washer - .050	11 15 6	112744	Bracket - Pivot R.H.	3 * 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3315-189A

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
112745	Bracket - Pivot L.H.	3 4 1	114724	Bracket - R.H.	17 * 1
112757	Wire - Solenoid/Starter	7 8 1	114724	Bracket - R.H.	23 * 1
112837	Spring - Seat	3 22 2	114740	Pulley	17 11 1
112843	Washer	29 6 1	114741	Spacer - Shaft	17 12 1
112847	Bracket - Support	9 3 1	114756	Block - Rubber	23 18 2
112850	Plate - Frame Support	5 3 1	114756	Block - Rubber	17 23 2
112853	Bolt	29 7 1	114757	Spacer	23 22 2
112858	Pulley - Engine	29 8 1	114757	Spacer	17 27 2
112925	Washer - Backing	1 30 1	114762	Spacer - Rubber	23 17 2
112961	Plate	3 16 2	114762	Spacer - Rubber	17 22 2
112977	Support - Rear Axle	5 6 1	114764	Fitting - 90°	31 32 1
112981	Rod - Tie	9 11 1	114812	Spacer	23 5 1
112982	Strap - Torque	13 3 2	114818	Spring	25 25 1
112983	Knob	13 9 1	114821	Washer - Friction	25 72 2
112983	Knob	25 83 1	114851	Plate - Frame Support	5 63 1
112984	Rod - Lock	19 6 1	114859	Arm - Idler	19 8 1
113025	Pointer	13 22 1	114860	Belt - Transmission Drive	13 33 1
113025	Pointer	25 82 1	114944	Decal - Shift 5-Speed	53 23 1
113030	Pin	9 5 2	114989	Bracket - L.H.	5 49 1
113044	Tube	9 4 1	114990	Bracket - R.H.	5 * 1
113113	Screw - Hex. Hd.	31 35 3	115042	Rod	13 11 1
113116	Retainer	5 38 4	115043	End - Rod	13 12 1
113129	Rod - Brake/Idler	19 12 1	115196	Decal - Attach-a-Matic	53 14 1
113179	Nut - Hex.	7 33 1	115198	Arm - Transmission	13 10 1
113370	Decal - PTO Adjustment	53 26 1	115204	Harness - Headlight	7 22 1
113589	Tie - Plastic	23 6 2	115230	Switch - Clutch	7 37 1
113820	Rotor Assembly	29 2 1	115356	Arrester - Spark	31 34 1
113821	Field Assembly	29 3 1	115398	Decal - Maintenance	53 16 1
113822	Armature & Pulley Assy.	29 4 1	115413	Clevis	1 32 2
113823	Spring & Nut Assembly	29 5 3	115414	Cable - Hood Lanyard	1 27 1
113852	Plate - Seat Pivot	3 3 1	115629	Electric Clutch Assembly	29 1 1
114034	Arm - Idler	27 8 1	115677	Bracket	25 74 1
114051	Decal - Motion Control	53 24 1	115678	Plate - Mounting	25 28 1
114064	Bearing - Ball	29 9 2	115686	Pulley - Drive	23 1 1
114385	Axle - Front	9 1 1	115687	Fan	21 15 1
114389	Fender	1 1 1	115858	Clip - Snap-In	5 59 2
114400	Bracket - Reservoir	21 23 1	115860	Clip - Snap-In	5 58 1
114401	Plate - Cam	25 2 1	115968	Belt - V	23 12 1
114402	Spacer	25 15 1	115990	Guide - Belt	23 9 1
114403	Support - Cam Plate	25 8 1	115991	Guide - Belt	23 2 1
114404	Plate - Neutral Pivot	25 20 1	116005	Shoe - Belt	23 14 1
114409	Hose	21 7 1	116119	Shaft - Drive	17 18 1
114410	Bracket - Torque	25 27 1	116120	Pulley - Transmission	13 32 1
114416	Plate - Neutral Return	25 1 1	116126	Cable - Push Valve	21 19 1
114417	Plate - Rear Drawbar	5 2 1	116150	Spring - Extension	19 29 1
114418	Pedal - Brake	27 1 1	116180	Clamp - Hose	21 6 4
114433	Belt	21 2 1	116262	Socket - Light	1 25 2
114442	Decal - Hydro Push	53 12 1	116287	Bolt - Adjusting	25 38 1
114563	Gasket - Cover	21 11 1	116338	Switch - Ignition	7 15 1
114564	Reservoir	21 12 1	116339	Rod - Speed Control	25 5 1
114610	Roller - Cam	5 5 2	116340	Arm - Motion Control	25 16 1
114621	Decal - Noise	53 15 1	116397	Relay	7 40 3
114636	Extension - Oil Drain	31 40 1	116398	Plate - Arm	25 46 1
114656	Support - Angle	25 19 1	116454	Knob	31 6 1
114663	Plate	25 34 1	116590	Decal - Hood Rear	53 3 1
114665	Clevis	25 37 1	116591	Headlight Bar Assembly	1 9 1
114666	Bracket	25 32 1	116601	Bar - Light	1 22 1
114668	Bracket - Spring	25 26 1	116702	Muffler	31 4 1
114670	Pivot - Brake	25 33 1	116738	Key - Ignition	7 16 2
114686	Plate - Mounting	17 15 1	116784	Bar - Pivot	23 21 2
114693	Hose	21 8 1	116784	Bar - Pivot	17 26 2
114695	Nut - Special	25 9 1	116874	Decal - Hood Front	53 10 1
114697	Spacer	25 21 1	116879	Rear Wheel & Tire Assy.	11 17 2
114698	Spring - Brake	25 31 1	116880	Tire - Rear	11 18 2
114705	Rod - Lock	27 6 1	116883	Front Wheel & Tire Assy.	11 3 2
114707	Rod - Brake	27 12 1	116884	Tire - Front	11 4 2
114721	Tube - Drain	7 13 1	116885	Front Wheel Assembly	11 7 2
114723	Bracket - L.H.	23 25 1	116887	Bushing - Flange	11 8 4
114723	Bracket - L.H.	17 30 1	117142	Bracket - Fuse	5 55 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
117184	Gasket	31 44 1	788040	Ring - Retainer	15 28 1
117225	Line - Fuel	31 11 1	788051	Seal - Square Cut	15 33 1
117316	Hold-Down - Battery	7 5 1	788061	Ring - Seal	15 23 2
117325	Bracket - Spring	25 85 1	788067B	Grease (32 oz. bottle)	15 78 1
117326	Spring	25 84 1	788069	Seal - Square Cut	15 71 1
117343	Keeper - Latch	5 11 2	788075	Ring - Retaining	15 77 1
117344	Handle Assembly	1 6 2	790003	Disk - Brake	15 36 1
117389	Brace - L.H.	23 29 1	790006	Pad - Brake	15 38 2
117389	Brace - L.H.	17 34 1	790007	Plate - Brake Pad	15 37 1
117390	Brace - R.H.	17 * 1	790025	Holder - Brake Pad	15 44 1
117390	Brace - R.H.	23 * 1	790039	Lever - Brake	15 41 1
117431	Rivet - Pop	5 12 4	792001	Seal - O-Ring	15 32 1
117432	Rivet - Pop	1 7 4	792035	Ring - Retainer	15 27 1
117511	Decal - Hydro	53 8 2	792073	Screw - Flanged Hex Hd.	15 42 2
117512	Decal - 5-Speed	53 7 2	792073	Screw - Flanged Hex. Hd.	15 25 17
117760	Decal - Fender	53 9 1	792074	Plug - Hex. Hd.	15 64 1
118600	Decal - Power Plus	53 6 1	792075	Nut - Lock	15 43 1
118610	Decal - Power Plus	53 28 1	792076	Washer - Flat	15 40 1
119350	Guide - Belt	17 1 1	792077	Ball - Steel	15 20 1
120040	Decal - TORO	53 22 1	792078	Set Screw	15 21 1
120860	Washer - .075	11 26 6	792079	Spring	15 22 1
120930	Holder - Fuse	7 12 1	792125	Ring - Retainer (Pkg. of 2)	15 26 4
770102	Case - Transaxle	15 3 1	792136	Key - Shifter	15 8 2
772108	Cover - Transaxle	15 1 1	807356	Loose Parts Package	53 * 1
774688	Axle (11-5/8 long)	15 47 1	807363	Loose Parts Package	53 * 1
774747	Axle (16-1/4 long)	15 48 1	900036	Bolt - Carriage	13 17 2
776135	Shaft - Input	15 46 1	900036	Bolt - Carriage	5 60 2
776219	Output Shaft & Pinion Assy.	15 5 1	908011	Screw - Cap Hex. Hd.	23 11 1
776260	Shaft - Counter	15 4 1	908016	Bolt	25 65 2
776315A	Shaft - Brake (4-keyed)	15 45 1	910792	Screw	21 20 2
778068	Gear - Bevel Pinion	15 14 2	910796	Screw	5 52 2
778113A	Bevel Pinion - Input	15 12 1	910808	Screw	1 18 4
778121A	Gear - Spur (20 teeth)	15 53 1	910837	Screw	5 26 1
778123A	Gear - Spur (25 teeth)	15 52 1	910842	Screw - Pan Hd.	23 19 4
778124A	Gear - Spur (30 teeth)	15 51 1	910842	Screw - Pan Hd.	17 24 4
778125	Gear - Spur (35 teeth)	15 50 1	910948	Screw	7 35 2
778126A	Gear - Spur (20 teeth)	15 56 1	911459	Bolt	25 14 1
778127A	Gear - Spur (25 teeth)	15 57 1	911652	Screw	31 39 1
778129A	Gear - Spur (30 teeth)	15 58 1	911910	Screw - Flat H.D.	21 28 2
778136	Gear - Spur (15 teeth)	15 7 1	913111	Screw - Machine	1 29 1
778139	Gear - Output	15 6 1	915001	Nut - Lock	9 28 2
778151	Gear - Spur (15 teeth)	15 55 1	915002	Nut - Lock	9 36 2
778191	Gear - Spur (37 teeth)	15 49 1	915112	Nut - Hex.	23 24 2
778221	Gear - Bevel	15 13 2	915112	Nut - Hex.	17 29 2
778229	Gear - Bevel (42 teeth)	15 11 1	915112	Nut - Hex.	5 62 2
778230	Gear - Spur (12 teeth)	15 54 1	915112	Nut - Lock	13 21 2
778260	Gear - Ring	15 15 1	915112	Nut - Lock	13 38 1
780001	Washer	15 31 4	915732	Nut - Lock	7 36 2
780051	Washer - Thrust	15 69 2	915740	Nut - Hex.	5 25 2
780072	Washer - Thrust	15 29 5	915740	Nut - Lock	21 21 2
780086	Bearing - Needle	15 2 2	915740	Nut - Lock	1 28 1
780090	Washer - Thrust	15 76 1	915740	Nut - Lock	31 28 2
780105A	Bushing - Flanged	15 34 4	915740	Nut - Lock	5 53 2
780108	Washer - Thrust	15 30 4	920160	Washer - Lock	7 24 1
780109	Washer - Thrust	15 65 1	920215	Washer	19 22 1
780118A	Bushing - Flanged	15 35 2	920215	Washer	27 22 1
784352	Collar - Shifter	15 9 1	920242	Washer - Special	5 35 2
784354	Shift Rod & Fork Assy.	15 10 1	920251	Washer - .050	11 22 4
786026	Pin - Dowel	15 39 2	920259	Washer	25 75 1
786061	Sprocket (10 teeth)	15 61 1	920259	Washer - Special	7 19 1
786062A	Chain - Roller	15 60 1	920262	Washer - Special	7 18 1
786071	Spacer	15 74 1	920267	Washer - Special	17 19 2
786072	Spacer	15 75 1	920267	Washer - Special	23 32 2
786086	Bracket - Brake Lever	15 68 1	920268	Washer	13 28 1
786102	Spacer	15 18 1	920271	Washer - Special	25 22 1
786116	Disk	15 72 1	926640	Screw - Machine	5 57 2
786118	Spacer	15 70 1	926641	Screw	25 30 1
786124	Sprocket (14 teeth)	15 62 1	926696	Bolt	25 58 1
786139	Pin - Drive	15 16 1	926696	Screw	31 41 4

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3315-189A

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
926697	Bolt - Carriage	5 61 4	NN10616	Bolt	39 26 2
926698	Screw	25 64 1	NN10617	Tappet	39 27 2
926720	Screw	13 18 2	NN10618	Rod - Push	39 28 2
932000	Pin - Cotter	25 43 1	NN10619	Rocker Arm Assembly	39 29 1
932948	Pin - Clevis	25 53 1	NN10620	Screw	39 30 2
932948	Pin - Clevis	25 70 1	NN10621	Nut	39 31 2
933273	Pin - Spirol	13 23 1	NN10622	Shaft - Rocker Arm	39 32 1
933273	Pin - Spirol	25 77 1	NN10623	Washer - Rocker Arm	39 33 2
933505	Pin - Cotter Hair	23 28 2	NN10624	Clip - Retainer	39 34 2
933505	Pin - Cotter Hair	17 32 2	NN10625	Pin - Dowel	39 35 1
933505	Pin - Hair	5 65 1	NN10626	Pin - Dowel	33 2 2
937082	Key - Woodruff	25 71 1	NN10626	Pin - Dowel	39 36 1
937222	Key - Hi-Pro	21 13 1	NN10627	Camshaft Assembly	35 1 1
937222	Key - Hi-Pro	23 34 1	NN10628	Washer - Flat	37 25 1
937225	Key	13 34 1	NN10629	Washer - Flat	37 26 1
938031	Bushing	1 17 1	NN10630	Shim - Camshaft	35 9 1
938031	Bushing	5 36 1	NN10631	Shim - (.60mm)	35 * 1
938050	Plug - Nylon	5 54 2	NN10632	Shim - (.80mm)	35 * 1
960151	Screw	5 50 2	NN10633	Shim - (.90mm)	35 * 1
5-1336	Key - Square	11 23 2	NN10634	Shim - (1.00mm)	35 * 1
NN10277	Fuse - 30 Amp.	7 * 1	NN10635	Shim - (1.20mm)	35 * 1
NN10344	Ring - Retaining	45 24 1	NN10636	Gear - Governor	37 11 1
NN10371	Screw - Hex. Washer Hd.	50 14 1	NN10637	Shaft - Governor	37 12 1
NN10395	Screw - Thread Forming	45 12 1	NN10638	Sleeve - Governor	37 13 1
NN10534	Ball - Steel	37 20 1	NN10639	Stop - Governor	37 14 1
NN10539	Ring - Retaining	37 24 1	NN10640	Lever	35 6 1
NN10569	Seal - Oil	33 4 1	NN10641	Clip - Retaining	35 7 2
NN10569	Seal - Oil	37 19 1	NN10642	Camgear Assembly	35 2 1
NN10570	Bearing - Crankshaft	33 5 1	NN10643	Key - Camgear	35 3 1
NN10571	Bearing - Camshaft	33 6 1	NN10644	Pin	35 4 1
NN10572	Pump - Oil	37 7 1	NN10645	Spring	35 5 1
NN10573	Cover - Oil Pump	37 8 1	NN10646	Seal - Governor Shaft	33 7 1
NN10575	Seal - O-Ring	37 18 1	NN10647	Lever - Governor	45 2 1
NN10577	Screen - Oil Pickup	37 9 1	NN10648	Screw - Cap Hex. Hd.	45 4 1
NN10578	Cover - Screen	37 10 1	NN10651	Throttle Plate Assembly	45 8 1
NN10579	Kit - Piston	33 10 1	NN10652	Screw - Machine	45 9 1
NN10580	Kit - Piston	33 * 1	NN10653	Clamp - Cable	45 10 1
NN10581	Kit - Piston	33 * 1	NN10653	Plug - Pipe	33 9 1
NN10582	Pin - Piston	33 11 1	NN10653	Plug - Pipe	31 33 1
NN10583	Ring - Retaining	33 12 2	NN10654	Spring - Choke Linkage	45 16 1
NN10584	Set - Piston Ring	33 13 1	NN10656	Swivel - Choke Lever	45 13 1
NN10585	Set - Piston Ring	33 * 1	NN10657	Spring - Governor	45 1 1
NN10586	Set - Piston Ring	33 * 1	NN10658	Link - Throttle	45 15 1
NN10587	Kit - Connecting Rod	33 14 1	NN10659	Link - Choke	45 17 1
NN10588	Kit - Connecting Rod	33 * 1	NN10660	Spacer	45 18 1
NN10589	Kit - Connecting Rod	33 * 1	NN10661	Stud	45 19 1
NN10590	Bolt	33 15 2	NN10663	Nut - Hex.	45 23 1
NN10591	Washer	33 16 2	NN10666	Gasket	50 1 1
NN10592	Gasket - Cylinder Head	39 1 1	NN10667	Elbow - Intake	50 2 1
NN10593	Cylinder Head Assembly	39 2 1	NN10668	Carburetor Assembly	50 3 1
NN10594	Cylinder Head Assembly	39 * 1	NN10669	Insulator	50 4 1
NN10597	Spring - Valve	39 7 2	NN10670	Gasket	50 5 2
NN10598	Valve - Intake	39 8 1	NN10673	Harness - Regulator	41 10 1
NN10599	Valve - Exhaust	39 9 1	NN10674	Clip - Link	45 7 1
NN10600	Retainer - Intake	39 10 1	NN10674	Clip - Link	50 12 2
NN10602	Lock - Intake	39 12 1	NN10675	Base - Oil	37 5 1
NN10603	Lock - Exhaust	39 13 1	NN10677	Bearing - Ball	37 21 1
NN10604	Ring	39 14 2	NN10678	Bearing - Ball	33 3 2
NN10605	Seal - Intake	39 15 1	NN10678	Bearing - Ball	37 22 2
NN10606	Washer	39 16 2	NN10680	Bolt	37 1 9
NN10607	Bolt	39 17 1	NN10681	Gasket - Oil Base	37 2 1
NN10608	Bolt	39 18 1	NN10684	Filter - Oil	37 3 1
NN10609	Gasket	39 19 1	NN10685	Adapter - Oil Filter	37 4 1
NN10611	Fitting - 45°	39 21 1	NN10686	Plug - Pipe	37 17 2
NN10611	Retainer - Exhaust	39 11 1	NN10687	Plug - Pipe	37 15 2
NN10612	Breather	39 22 1	NN10688	Indicator	33 17 1
NN10613	Screw - Hex. Socket Hd.	39 23 7	NN10689	Tube	33 19 1
NN10614	Washer	39 24 2	NN10690	Seal	33 20 1
NN10615	Bolt	39 25 2	NN10691	Bracket - Support	33 22 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
NN10693	Hose - Breather	43 1 1	NN10907	Kit - Carburetor Repair	50 19 1
NN10694	Gasket	43 2 1	38-1420	Switch - Seat	7 14 1
NN10697	Cover - Element	43 5 1	48-7630	Bolt	31 42 2
NN10698	Wrapper - Element	43 6 1	57-9120	Bushing	50 15 1
NN10700	Knob	43 15 2	57-9430	Regulator - Voltage	50 16 1
NN10701	Stud	50 20 1	57-9440	Stator	41 2 1
NN10702	Screw - Cap Hex. Hd.	43 12 2	57-9610	Seal - O-Ring	33 18 1
NN10703	Knob	43 8 1	59-0280	Spring - Relief Valve	37 6 1
NN10704	Grommet	43 7 1	59-0720	Pin - Cotter	45 11 1
NN10712	Blower Wheel Assembly	47 2 1	59-0760	Plug	37 23 2
NN10713	Key	47 4 1	59-0850	Washer - Flat	45 14 1
NN10715	Nut	47 3 1	78-0370	Insert - Steering Wheel	9 40 1
NN10721	Bolt	47 7 4	78-1640	Frame	5 1 1
NN10723	Deflector - Air	45 28 1	78-1670	Cam - Adjustment	5 32 2
NN10725	Screw - Cap Hex. Hd.	45 29 1	78-1991	Bracket - Steering Gear	9 17 1
NN10726	Screw - Cap Hex. Hd.	45 31 5	78-2020	Shaft	13 6 1
NN10727	Screw - Cap Hex. Hd.	45 33 1	78-2030	Collar	13 40 1
NN10729	Lead	41 7 1	78-2030	Collar	25 87 1
NN10730	Coil - Ignition	41 8 1	78-2050	Bracket - Switch	5 56 1
NN10731	Bolt - Hex. Hd.	41 9 2	78-2710	Transmission Assembly	21 1 1
NN10733	Bolt - Hex. Hd.	41 3 1	78-2870	Pulley - Input Shaft	21 14 1
NN10735	Screw - Torx Pan Hd.	41 1 2	78-3030	Switch - PTO	7 32 1
NN10738	Screw - Cap Hex. Hd.	49 2 2	78-3100	Wheel - Steering	9 22 1
NN10739	Starter	49 1 1	78-3221	Bracket - Steering Gear	9 * 1
NN10740	Washer - Lock	45 5 1	78-3230	Shaft	25 81 1
NN10740	Washer - Lock	33 24 1	78-3340	Transmission Assembly	13 2 1
NN10742	Gear - Crankshaft	35 10 1	78-3390	Hoodstand	5 8 1
NN10743	Gear - Balancer	35 11 1	78-8440	Decal - PTO Clutch	53 5 1
NN10744	Crankshaft	35 12 1	78-8480	Decal - Ignition	53 27 1
NN10745	Key - Gear	35 13 1	78-8490	Decal - Lights	53 25 1
NN10746	Shim - Crankshaft	35 14 1	78-8550	Engine - 12HP	31 2 1
NN10747	Shim - (.30mm)	35 * 1	79-0370	Decal - Danger (212-H)	53 20 1
NN10748	Shim - (.40mm)	35 * 1	79-0670	Seat	3 1 1
NN10749	Shim - (.50mm)	35 * 1	79-1080	Cover	21 10 1
NN10750	Plug	35 15 1	79-1100	Reservoir Assembly	21 9 1
NN10751	Gear	35 16 1	79-2590	Push Nut	1 40 2
NN10752	Gear	35 17 1	79-3320	Control - Throttle	31 5 1
NN10753	Shaft	35 18 1	79-3840	Hood & Grill	1 2 1
NN10754	Shaft	35 19 1	79-3920	Harness Wire	7 2 1
NN10755	Key - Gear	35 20 2	79-4560	Decal - Hood R.H.	53 1 1
NN10756	Shim - Balancer Shaft	35 21 1	79-4570	Decal - Hood L.H.	53 * 1
NN10757	Shim - (.60mm)	35 * 1	79-4580	Decal - Hood R.H.	53 * 1
NN10758	Shim - (.70mm)	35 * 1	79-4590	Decal - Hood L.H.	53 * 1
NN10759	Shim - (.80mm)	35 * 1	79-5400	Decal - Throttle	53 13 1
NN10760	Shim - (.90mm)	35 * 1	79-5560	Rear Wheel & Tire Assy.	11 24 2
NN10761	Shim - (1.00mm)	35 * 1	79-5570	Rear Wheel Assembly	11 25 2
NN10762	Shim - (1.20mm)	35 * 1	79-5590	Rear Wheel Assembly	11 19 2
NN10768	Nut	33 25 1	79-5660	Shaft - Pinion	9 12 1
NN10768	Nut - Hex.	45 6 1	79-5820	Screw - Cap Hex. Hd.	50 9 2
NN10770	Plug - Pipe	45 26 1	79-5830	Washer - Flat	50 10 2
NN10785	Screw - Thread Forming	45 25 1	79-5840	Pin - Alignment	33 8 2
NN10795	Clamp - Hose	43 13 1	79-5850	Shim - (.70mm)	35 * 1
NN10796	Hose - Breather	43 14 1	79-5860	Shim - (.80mm)	35 * 1
NN10798	Plug - Pipe	37 29 1	79-5870	Guide - Exhaust Valve	39 4 1
NN10799	Cover - Air Cleaner	43 16 1	79-5880	Guide - Intake Valve	39 3 1
NN10800	Housing - Cylinder Air	45 27 1	79-5890	Clamp - Cord	41 4 1
NN10803	Housing - Blower	47 6 1	79-5900	Pin - Alignment	41 5 2
NN10804	Screen	47 1 1	79-5910	Kit - Air Cleaner	43 18 1
NN10805	Screw - Hex. Hd.	47 5 3	82-1130	Plug - Pipe	37 16 1
NN10812	Clamp - Hose	43 10 1	82-1340	Washer - Flat	45 21 2
NN10813	Switch - Oil Pressure	37 28 1	82-1340	Washer - Flat	45 30 1
NN10816	Washer - Governor Lever	45 3 2	82-1340	Washer - Flat	39 37 7
NN10817	Screw - Thread Forming	45 20 1	82-1350	Washer	35 8 1
NN10820	Plug - Spark	41 6 1	82-1350	Washer - Flat	43 11 2
NN10852	Block - Cylinder	33 1 1	82-1350	Washer - Flat	45 22 2
NN10868	Screw - Torx Pan Hd.	37 27 4	82-1350	Washer - Flat	45 32 6
NN10872	Element	43 4 1	82-1560	Screw	33 21 1
NN10899	Adapter	43 3 1	82-1700	Nut - Speed	33 23 1
NN10906	Kit - Float	50 17 1	92-0930	Cover - Valve	39 20 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3315-189A

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
92-0931	Clamp - Hose	43 9 1	3253-17	Washer - Lock	1 20 4
2412-98	Clamp - Hose	31 12 2	3253-21	Washer - Lock	17 8 1
302-5	Fitting - Grease	9 2 3	3254-2	Washer - Lock	5 21 2
321-2	Screw - Cap Hex. Hd.	17 5 3	3256-4	Washer	27 28 2
321-4	Bolt	7 9 2	3256-4	Washer	25 73 1
321-4	Bolt	21 24 4	3256-22	Washer	7 10 4
321-4	Screw - Cap Hex. Hd.	23 13 2	3256-22	Washer	25 49 1
322-2	Bolt	25 59 1	3256-22	Washer - Flat	23 15 2
322-3	Bolt	25 60 2	3256-22	Washer - Flat	21 25 2
322-3	Screw - Cap Hex. Hd.	17 14 5	3256-23	Washer	13 16 8
322-3	Screw - Cap Hex. Hd.	23 33 2	3256-23	Washer	3 18 8
322-3	Screw - Hex. Hd.	5 24 4	3256-23	Washer	5 19 15
322-4	Bolt	3 6 4	3256-23	Washer	31 22 2
322-4	Screw - Cap Hex. Hd.	9 25 2	3256-23	Washer	19 24 3
322-5	Bolt	3 2 4	3256-23	Washer	27 24 2
322-5	Bolt	3 17 6	3256-23	Washer	9 34 1
322-5	Bolt - Brake Stop	13 37 1	3256-23	Washer	25 47 5
322-5	Screw - Cap Hex. Hd.	17 3 1	3256-23	Washer - Flat	17 2 4
322-5	Screw - Cap Hex. Hd.	23 8 3	3256-23	Washer - Flat	23 3 8
322-5	Screw - Cap Hex. Hd.	25 86 2	3256-23	Washer - Flat	21 4 8
322-6	Bolt	3 26 2	3256-23	Washer - Flat	13 39 1
322-6	Bolt	13 30 1	3256-24	Washer	19 28 2
322-6	Screw - Hex. Hd.	5 20 2	3256-24	Washer	5 46 2
322-12	Screw - Cap Hex. Hd.	13 15 4	3256-24	Washer	25 48 1
322-13	Bolt	21 5 4	3256-24	Washer - Flat	27 29 2
323-6	Screw - Cap Hex. Hd.	17 9 1	3272-2	Pin - Cotter	23 4 1
323-7	Bolt	5 42 1	3272-2	Pin - Cotter	25 52 1
323-7	Screw - Cap Hex. Hd.	23 23 4	3272-6	Pin - Cotter	19 23 3
323-7	Screw - Cap Hex. Hd.	17 28 4	3272-6	Pin - Cotter	27 23 2
323-10	Bolt	5 45 1	3272-6	Pin - Cotter	13 29 1
329-5	Screw - Cap Hex. Hd.	13 26 1	3272-6	Pin - Cotter	25 50 3
3217-5	Nut	7 11 4	3272-7	Pin - Cotter	25 51 1
3217-5	Nut - Lock	5 27 1	3272-16	Pin - Cotter	19 21 1
3217-6	Nut - Hex.	3 25 4	3272-16	Pin - Cotter	27 21 1
3217-6	Nut - Lock	1 21 8	3272-16	Pin - Cotter	5 34 2
3219-14	Nut	1 8 2	3272-17	Pin - Cotter	11 12 2
3220-1	Nut - Jam	25 7 1	3296-29	Nut - Lock	21 3 4
3220-2	Nut - Jam	13 25 1	3296-29	Nut - Lock	3 8 6
3229-2	Bolt - Carriage	25 63 1	3296-29	Nut - Lock	5 16 14
3229-29	Nut - Lock	9 33 3	3296-29	Nut - Lock	13 19 5
3230-1	Bolt - Carriage	27 20 4	3296-29	Nut - Lock	19 19 4
3230-1	Bolt - Carriage	31 29 2	3296-29	Nut - Lock	27 19 4
3230-2	Bolt	9 35 1	3296-29	Nut - Lock	17 20 7
3230-2	Bolt - Carriage	25 62 2	3296-29	Nut - Lock	23 26 3
3230-16	Bolt - Carriage	5 15 7	3296-29	Nut - Lock	31 31 2
3230-16	Bolt - Carriage	19 20 4	3296-29	Nut - Lock	25 55 3
3230-22	Bolt	9 32 2	3296-39	Nut - Lock	23 20 6
3230-23	Bolt - Carriage	1 16 8	3296-39	Nut - Lock	17 25 6
3231-4	Bolt - Carriage	25 61 1	3296-39	Nut - Lock	19 26 2
3231-25	Bolt - Carriage	19 25 1	3296-39	Nut - Lock	27 26 3
3231-25	Bolt - Carriage	27 25 1	3296-39	Nut - Lock	5 43 2
3231-25	Bolt - Carriage	23 30 2	3296-42	Nut - Lock	23 16 6
3231-25	Bolt - Carriage	17 33 2	3296-42	Nut - Lock	17 21 4
3231-28	Bolt	9 30 1	3296-42	Nut - Lock	21 26 4
3231-29	Bolt - Carriage	27 27 2	3296-42	Nut - Lock	5 51 2
3231-33	Bolt - Carriage	19 27 1	3296-42	Nut - Lock	25 57 2
3242-2	Screw - Set	17 6 1	32103-19	Nut - Wing	1 11 1
3242-2	Screw - Sq. Hd. Set	13 35 2	32103-22	Nut - Wing	7 27 2
3253-3	Washer - Lock	17 4 3	32120-47	E-Ring	25 4 1
3253-3	Washer - Lock	23 10 1	32120-50	Pin - Spirol	25 69 1
3253-3	Washer - Lock	7 25 1	32120-93	Ring - Retaining	9 9 2
3253-3	Washer - Lock	13 27 1	32120-93	Ring - Retaining	5 23 1
3253-3	Washer - Lock	5 28 1	32121-103	Pin - Spirol	9 27 2
3253-3	Washer - Lock	31 45 2	32121-111	Pin	9 37 1
3253-4	Washer - Lock	13 20 2	32146-2	Nut - Lock	25 54 1
3253-4	Washer - Lock	3 24 8	32151-36	Ring - Snap	11 27 2
3253-4	Washer - Lock	9 26 2	32151-48	Ring - Snap	11 14 2
3253-4	Washer - Lock	31 37 2	32151-57	Ring - Snap	25 68 2
3253-4	Washer - Lock	25 67 4	32151-73	Ring - Retaining	25 39 1

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The 200 Series Garden Tractors have two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the 200 Series Garden Tractor, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the 200 Series Garden Tractor.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Body Assembly	1	Engine Fuel & Exhaust Assembly	30
Seat Assembly	2	12hp Engine Cylinder Block Assembly	32
Frame Assembly	4	12hp Engine Crankshaft & Camshaft Assembly	34
Electrical System Assembly	6	12hp Engine Oil Base & Pump Assembly	36
Front Axle & Steering Assembly	8	12hp Engine Cylinder Head & Valves Assembly	38
Wheel & Tire Assembly	10	12hp Engine Ignition Assembly	40
Transmission Assembly (212-5)	12	12hp Engine Air Cleaner Assembly	42
Peerless Transmission		12hp Governor Linkage & Cover Assembly	44
Model No. 930-020 (212-5)	14	12hp Engine Flywheel & Cover Assembly	46
Sweeper P.T.O. Assembly (212-5)	16	12hp Engine Starter Assembly	48
Brake & Idler Assembly (212-5)	18	12hp Engine Carburetor Assembly	50
Transmission Assembly (212-H)	20	Wiring Diagram	51
12-Sweeper P.T.O. Assembly (212-H)	22	Decal & Miscellaneous Parts Assembly	52
Transmission Linkage Assembly (212-H)	24	Part Number Index	54-59
Brake & Idler Assembly (212-H)	26		
Engine Pulley & PTO Clutch Assembly	28		