
FORM NO. 3315–300

TORO®

MODEL NO. 074XVC01–2000001 & UP

PARTS CATALOG

WHEEL HORSE®
Vacuum Bagger



C–1203


BAG TOP & FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	116130	Clip	2
2	3296–42	Nut – Lock	4
3	114963	Top – Bagger	1
4	920270	Washer	4
5	114439	Rivet – Pop	16
6	115481	Latch – Bagger Top	2
7	115880	Grip	2
8	116355	Rivet – Pop	8
9	114967	Screen – Bagger	1
10	115879	Screen – Support	1
11	88–9570	Stiffener Assembly (Incl. Ref. #27)	1
12	114961	Hinge – Bagger	1
13	323–6	Screw – Hex Hd. Cap	2

Ref. No.	Part No.	Description	No. Used
14	114955	Frame	1
15	3296–39	Nut – Lock	2
16	979094	Spacer	2
17	321–4	Screw – Hex Hd. Cap	2
18	114962	Spring – Extension	2
19	114960	Pin – Spring	1
20	910837	Screw	2
21	3218–1	Nut – Hex Jam	1
22	118320	Handle	1
23	114969	Feeler – Full Bag	1
24	117239	Seal – Chute	1
25	114966	Seal – Clamp	1
26	116347	Decal	1
27	79–7410	Decal	1

TPS


© The TORO Company – 1992



C–1201

CHUTE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	79–7240	Chute – Discharge	1
2	3290–479	Fastener – Panel	1
3	82–5690	Retainer	1
4	22–9741	Spacer	1




C–1202

HOUSING & IMPELLER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144–8	Screw – Phillips Pan Hd.	1
2	3256–49	Washer – Flat	1
3	233–68	Knob	1
4	3296–42	Nut – Lock	1
5	79–7230	Latch (48" Deck)	1
6	79–7220	Latch (42" Deck)	1
7	79–7390	Spring – Extension	1
8	32105–13	Screw – Hex Hd. Ind.	1
9	3217–26	Nut – Hex	2
10	3256–14	Washer – Flat	2
11	3257–40	Key – Woodruff	1
12	3253–4	Washer – Lock	6
13	3217–6	Nut – Hex	6
14	3220–6	Nut – Hex Jam	2

Ref. No.	Part No.	Description	No. Used
15	3253–8	Washer – Lock	2
16	79–1460	Pulley – Blower	1
17	251–341	Flangette – Bearing	4
18	251–288	Bearing – Ball	2
19	7038	Flange – Bearing	1
20	79–1470	Shaft – Blower	1
21	3256–22	Washer – Flat	7
22	321–4	Screw – Hex Hd. Cap	1
23	79–7170	Cover – Blower Bottom	1
24	3296–56	Nut – Lock	6
25	79–4300	Impeller	1
26	3229–22	Bolt – Carriage	6
27	79–6890	Housing – Fan	1
28	3230–1	Bolt – Carriage	6




PULLEY & BELT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296–39	Nut – Lock	2
2	79–1970	Arm – Idler	1
3	79–2020	Rod – Compression	1
4	79–7110	Spring – Compression	1
5	32128–20	Nut – Hex Flange	4
6	79–1380	Plate – Blower Mounting	1
7	3272–10	Pin – Cotter	1
8	3256–23	Washer – Flat	1
9	3230–1	Bolt – Carriage	3
10	3256–3	Washer – Flat	1
11	79–7440	Bracket – Housing Support	1
12	3272–7	Pin – Cotter	1
13	3256–26	Washer – Flat	1

Ref. No.	Part No.	Description	No. Used
14	100284	Bushing	2
15	79–7280	Support – Belt Shield	1
16	79–7480	Belt – 71" (42" Deck)	1
*	79–7490	Belt – 73.8" (48" Deck)	1
17	112895	Pulley – Flat Idler	1
18	323–9	Screw – Hex Hd. Cap	1
19	323–10	Screw – Hex Hd. Cap	1
20	3256–24	Washer – Flat	1
21	107213	Spacer – Pivot Link	1
22	3256–4	Washer – Flat	2
23	115118	Pulley – V–Idler	1
24	322–5	Screw – Hex Hd. Cap	1

*Not Illustrated




C–1211

SHIELD ASSEMBLY (42" CUTTING UNIT)

Ref. No.	Part No.	Description	No. Used
1	321–3	Screw – Hex Hd. Cap	2
2	92–1161	Inner Shield Assembly (Incl. Ref. #17)	1
3	926671	Screw – Hex Hd. Flange Thread Forming	6
4	79–7120	Adapter – Shield	1
5	79–7310	Pulley	1
6	3296–39	Nut – Lock	1
7	322–3	Screw – Hex Hd. Cap	1
8	79–7000	Support – Pivot	1

Ref. No.	Part No.	Description	No. Used
9	32128–20	Nut – Hex Flange Lock	1
10	79–7300	Deflector	1
11	323–6	Screw – Hex Hd. Cap	1
12	3256–24	Washer – Flat	1
13	88–1870	Bracket – Shield Support	2
14	3296–42	Nut – Lock	2
15	79–0470	Rivet – Pop	4
16	86–9300	Shield – Belt	1
17	66–1340	Decal – Danger	1
18	79–7620	Decal	1




C–1212

SHIELD ASSEMBLY (48" CUTTING UNIT)

Ref. No.	Part No.	Description	No. Used
1	66–1340	Decal – Danger	1
2	92–1160	Inner Shield Assembly (Incl. Ref. #1)	1
3	3234–26	Screw – Hex Flange Hd.	3
4	79–7200	Adapter – Shield	1
5	79–7130	Pulley	1
6	3296–29	Nut – Lock	2
7	322–3	Screw – Hex Hd. Cap	1
8	79–7000	Support – Pivot	1
9	32128–20	Nut – Hex Flange Lock	1

Ref. No.	Part No.	Description	No. Used
10	926671	Screw – Hex Hd. Flange Thread Forming	2
11	321–3	Screw – Hex Hd Cap	2
12	3296–42	Nut – Lock	2
13	88–1870	Bracket – Shield Support	2
14	79–7290	Deflector	1
15	3230–22	Bolt – Carriage	2
16	79–0470	Rivet – Pop	4
17	86–9300	Shield – Belt	1
18	79–7620	Decal	1



C–1213

BAG & FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	114972	Frame – Bag	2
2	3296–29	Nut – Lock	8
3	114974	Clamp	2
4	114973	Hanger – Bag	2
5	3230–1	Bolt – Carriage	4
6	114971	Bag	2

Ref. No.	Part No.	Description	No. Used
7	115131	Support – Bagger L.H.	1
8	322–4	Screw – Hex Hd. Cap	4
9	115124	Bracket – Quick Attach	1
10	933506	Pin – Hair Cotter	2
11	115130	Support – Bagger R.H.	1

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.