



Z550 Z Master[®]

With 60in TURBO FORCE[®] Side Discharge Mower

Model No. 74272CP - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front Frame Assembly	 3	Electrical Assembly	 29
Caster Wheel and Fork Assembly	 5	Cylinder and Crankcase Assembly Kawasaki FH770D-AS05	 31
Main Frame and Rear Wheel Assembly	 6	Piston and Crankshaft Assembly Kawasaki FH770D-AS05	 32
Brake and Wheel Hub Assembly	 7	Valve and Camshaft Assembly Kawasaki FH770D-AS05	 33
Steering Control Assembly	 8	Lubrication Equipment Assembly Kawasaki FH770D-AS05	 34
LH Motion Control Assembly No. 109-3906	 9	Cooling Equipment Assembly Kawasaki FH770D-AS05	 35
RH Motion Control Assembly No. 109-3707	 10	Electric Equipment Assembly Kawasaki FH770D-AS05	 36
Hydraulic Assembly	 11	Control Equipment Assembly Kawasaki FH770D-AS05	 37
Pump Idler Assembly No. 103-5679	 13	Carburetor Assembly Kawasaki FH770D-AS05	 38
Seat and Roll-Over Protection System Assembly	 14	Air Filter and Muffler Assembly Kawasaki FH770D-AS05	 39
Deluxe Seat Assembly No. 110-0838	 15	Fuel Tank and Valve Assembly Kawasaki FH770D-AS05	 40
Roll-Over Protection System Assembly No. 108-1097	 16	Starter Assembly Kawasaki FH770D-AS05	 41
Deck Connection Assembly	 17	Power-Take-Off Assembly Kawasaki FH770D-AS05	 42
Deck Assembly	 18	Label Assembly Kawasaki FH770D-AS05	 43
Deck Decal Assembly No. 107-1624	 20	Attachments and Accessories List	 44
Spindle Assembly No. 112-8698	 21		
Rubber Deflector Assembly No. 108-2792	 22		
Lever Assembly No. 107-1664	 23		
Drive Idler Assembly	 24		
Z-Stand Assembly	 25		
Engine and Clutch Assembly	 26		
Guard Assembly	 27		
Fuel Tank Assembly	 28		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes

- ❶ Not illustrated
- ❷ Obtain from your local Kawasaki dealer


- ❸ Not serviced separately



Front Frame Assembly


Ref	Part No.	Qty.	Description
1	106-8998	1	Frame ASM
1:2	107-1857	1	Decal-Brake, Parking
1:3	1-811010	2	Plug
1:4	302-19	5	Fitting-Grease
1:5	94-1291	2	Bushing
1:6	104-7759	1	Decal-Warning
1:7	103-1918	1	Bushing
3	106-9981	1	Footrest
3:2	106-7451	1	Decal
3:3	107-2112	1	Decal-Warning
4	103-1918	1	Bushing
5	110-5860	1	Deck Lift Handle ASM
5:1	1-633295	1	Grip-Lever, Lift
5:2	103-2083	1	Lever-Lift
5:3	103-2064	1	Arm-Lift, Deck
5:4	1-633325	1	Spring-Compression
5:5	3296-39	1	Nut-Lock, NI
5:6	3256-24	1	Washer-Flat
10	3296-39	8	Nut-Lock, NI
11	32151-103	5	Ring-Retaining, EXT
12	1-633068	2	Arm-Lift, Deck
14	323-29	2	Screw-HH
15	110-0833	1	Plate-Deck Lift, Outer
15:2	107-1860	1	Decal-Height, Deck

Ref	Part No.	Qty.	Description
16	110-0834	1	Plate-Deck Lift, Inner
16:2	107-1861	1	Decal-Height, Deck
17	1-633082	1	Bushing-Lever, Lift
18	1-633080	1	Bushing-Lever, Lift
19	323-13	1	Screw-HH
20	106-9951	1	Hitch Pin ASM
22	323-9	2	Screw-HH
23	98-5975	12	Washer-Belleville
24	3290-357	15	Nut-HHF, Whiz
25	323-6	1	Screw-HH
26	323-7	12	Screw-HH
27	3256-29	4	Washer-Flat
35		2	Front Frame Spring ASM
35:1	1-633096	1	Rod-Lift, Deck
35:2	1-633441	2	Swivel-Deck Mount, Rear
35:3	3217-11	4	Nut-Hex
35:4	3218-6	2	Nut-Jam
35:5	3256-7	2	Washer-Flat
35:6	1-633064	1	Spring-Support, Deck
38	3274-94	4	Screw-HSBH
40	108-7786-01	1	RH Front Deck Lift ASM
41	106-8984-01	1	LH Deck Lift ASM
42	1-523157	2	Washer-Spacer
43	32151-29	2	Ring-Retaining




Front Frame Assembly (continued)

Ref	Part No.	Qty.	Description
44	3274-18	2	Screw-HSH
45	3218-2	2	Nut-Jam
46	1-513658	2	Bumper



Caster Wheel and Fork Assembly


Ref	Part No.	Qty.	Description				
1	103-4882	2	Cap-Grease				
2	3296-51	2	Nut-Lock, NI				
3	1-633508	6	Washer-Bellville				
4	254-94	4	Bearing-Cone, Tapered				
5	254-72	4	Bearing-Cup, Tapered				
6	110-8837	1	Caster Wheel Bearing Kit				
6:1	1-633581	2	Spacer-Bearing				
6:2	1-633580	2	Seal-Bearing				
6:3	1-633584	2	Bearing-Cup				
6:4	1-633585	2	Bearing-Cone, Taper				
7	1-543511	2	Seal-Grease				
8	103-1474-01	2	Fork-Caster				
11	110-5746	2	Castor Wheel ASM				
11:1	1-633580	2	Seal-Bearing				
11:2	1-633581	2	Spacer-Bearing				
11:3	1-633585	2	Bearing-Cone, Taper				
11:4	1-633959	1	Spacer-Caster, Front				
11:5	110-5744	1	Wheel And Tire ASM (Semi-Pneumatic)				
11:5:3	1-633584	1	Bearing-Cup				
11:21	325-24	1	Screw-HH				
11:22	3296-45	1	Nut-Lock, NI				



Main Frame and Rear Wheel Assembly

Ref	Part No.	Qty.	Description
1	1-633964-03	1	Stop-Brake, Park
4	322-43	6	Screw-HH
5	323-6	2	Screw-HH
11	114-1509	1	Frame ASM
11:1	107-8076	1	Decal-Console, Top
12	1-633970	2	Wheel And Tire ASM
12:1	1-633993	1	Tire
12:2	109-3156	1	Wheel
12:3	5108	1	Valve
13	107-1858	1	Floorpan
13:2	98-4387	1	Decal-Protection, Ear
13:3	107-1864	1	Decal-Location, Manual
15	242-50	8	Nut-Lug
21	3296-39	2	Nut-Lock, NI
24	1-513762	1	Clip-Loom
25	1-303335	2	Tie-Plastic
27	321-4	3	Screw-HH
28	32128-33	1	Nut-HF
44	3256-70	6	Washer-Flat
47	106-7498	1	Pocket
48	106-7488-03	1	Hinge-Floorpan, LH
49	106-7489-03	1	Hinge-Floorpan, RH
50	323-20	2	Screw-HH
51	3296-59	2	Nut-Lock, NI


Ref	Part No.	Qty.	Description
52	3296-42	4	Nut-Lock, NI
53	3256-63	2	Washer-Flat
54	3258-166	2	Screw-PRH
55	106-9989	1	Decal-Warning
56	106-7492	1	Decal-Danger
57	107-1865	2	R-Clamp
58	104-7050	1	Housing-Manual
59	104-7048	1	Cap-Housing
61	109-7949	2	Decal-Wheel Hub, Slotted Nut



Brake and Wheel Hub Assembly

Ref	Part No.	Qty.	Description
1	1-513140	2	Bearing-Control
2	1-633454	2	Spring-Brake
3	103-4332	1	Brake Rod And Yoke ASM
3:1	1-633131	2	Yoke-Linkage, Brake
3:2	1-633477	1	Rod-Brake
3:3	3219-3	2	Nut-Hex
4	1-634500	1	Brake Lever ASM
4:2	1-633268	1	Grip-Lever, Brake
5	1-632217-03	1	Shaft-Brake
6	103-0352-03	2	Bracket-Brake
7	1-523157	2	Washer-Spacer
9	103-0355	2	Band-Brake
10	1-633380	4	Spacer-Wheel, Short
11	1-633382	4	Spacer-Wheel, Long
12	1-633102	2	Bearing-Flange, Side
13	103-4333	2	Brake Rod And Yoke ASM
13:1	1-633131	1	Yoke-Linkage, Brake
13:2	1-633477	1	Rod-Brake
13:3	3219-3	1	Nut-Hex
14	1-633144	2	Pin-Trunion
15	103-0590	2	Hub And Wheel ASM
15:1	103-0589	1	Wheel Hub ASM
15:2	1-633926	4	Stud-Wheel
18	323-4	4	Screw-HH


Ref	Part No.	Qty.	Description
19	103-2399	3	Pin-Spring, Clevis
20	325-17	8	Screw-HH
21	302-11	2	Fitting-Lube, 45 DEG
22	109-5618	8	Nut,Square Special
23	3219-3	4	Nut-Hex
24	3290-357	4	Nut-HHF, Whiz
26	3256-4	4	Washer-Flat
27	3272-10	2	Pin-Cotter
28	1-806800	2	Pin-Cotter
29	322-9	6	Screw-HH
30	103-0384	6	Spacer
31	103-0374	2	Retainer-Band, Brake
32	1-808285	1	Pin-Clevis



Steering Control Assembly


Ref	Part No.	Qty.	Description
2	98-5975	4	Washer-Belleville
3	109-2339	2	Damper-Control, Motion
4	109-6058-03	1	Bracket-Mount, Damper
5	3230-16	2	Screw-CARR
8	1-403180	4	Screw-HH
9	103-4331	2	Tracking Rod ASM
9:1	1-543017	1	Balljoint-RH
9:2	3219-2	3	Nut-Hex
9:4	1-804524	1	Nut
9:5	1-633152	1	Balljoint-LH
10	103-0384	1	Spacer
11	108-7238	1	LH Lever ASM
11:1	106-9987	1	Grip-Control, Motion
12	1-632208	2	Arm-Control, Pump
16	1-633102	4	Bearing-Flange, Side
20	322-6	3	Screw-HH
21	323-4	8	Screw-HH
22	323-6	4	Screw-HH
24	1-803022	2	Screw-Set
30	3256-3	4	Washer-Flat
34	32128-20	6	Nut-HF
35	3290-357	8	Nut-HHF, Whiz
37	108-7237	1	RH Lever ASM
37:1	106-9987	1	Grip-Control, Motion

Ref	Part No.	Qty.	Description
38	3296-29	10	Nut-Lock, NI
39	3217-6	4	Nut-Hex
40	109-3906	1	LH Motion Control ASM
41	109-3907	1	RH Motion Control ASM
42	322-12	1	Screw-HH
43	105-7699	1	Strip-Seal




LH Motion Control Assembly No. 109-3906

Ref	Part No.	Qty.	Description				
1	1-808280	1	Pin-Clevis				
2	103-0407	1	Arm-Shaft, Control				
3	109-3902	1	Control-Motion, LH				
4	109-3903	1	Neutral Return ASM				
4:1	1-303105	1	Yoke-Adjustable				
4:2	1-603737	1	Bolt-Return, Neutral				
4:3	1-603807	1	Spring-Return, Neutral				
4:4	109-3769	1	Bushing-Nylon, Flanged				
4:5	3219-2	3	Nut-Hex				
4:6	3230-23	1	Screw-CARR				
4:7	3256-2	1	Washer-Flat				
4:8	109-3908	1	Tab-Adjustment				
5	323-9	3	Screw-HH				
6	3272-5	1	Pin-Cotter				
7	3296-39	3	Nut-Lock, NI				



RH Motion Control Assembly No. 109-3707


Ref	Part No.	Qty.	Description				
1	1-808280	1	Pin-Clevis				
2	103-0407	1	Arm-Shaft, Control				
3	109-3901	1	Control-Motion, RH				
4	109-3903	1	Neutral Return ASM				
4:1	1-303105	1	Yoke-Adjustable				
4:2	1-603737	1	Bolt-Return, Neutral				
4:3	1-603807	1	Spring-Return, Neutral				
4:4	109-3769	1	Bushing-Nylon, Flanged				
4:5	3219-2	3	Nut-Hex				
4:6	3230-23	1	Screw-CARR				
4:7	3256-2	1	Washer-Flat				
4:8	109-3908	1	Tab-Adjustment				
5	323-9	3	Screw-HH				
6	3272-5	1	Pin-Cotter				
7	3296-39	3	Nut-Lock, NI				



Hydraulic Assembly


Ref	Part No.	Qty.	Description
1	103-3736	1	HYD Hose ASM
2	103-1947	1	HYD Reservoir ASM
2:2:1		1	Reservoir-HYD
2:1:1	103-1948	1	Cap-Reservoir, HYD
2:1:2	103-1949	1	Gasket-Cap
2:2	1-523552	1	Decal-Tank, HYD
3	104-7836	1	Head-Filter
4	103-3733	1	HYD Hose ASM
6	1-633752	1	Filter-HYD, Winter
6	1-633750	1	Filter-Oil, HYD
7	103-1799	2	Elbow-90 DEG
7:1	237-42	1	O-Ring
10	1-603991	4	Fitting-Straight
10:1	237-80	1	O-Ring
10:2	1-603992	1	O-Ring
11	1-523328	2	Motor-Wheel
11:1	1-809036	1	Nut-HH
11:2	3257-42	1	Key-Woodruff
11:99	103-6994	1	Seal Kit
11:99	1-000139	1	Bearing Kit
11:99	103-2748	1	Drive Link Kit
13	103-3330	1	Spring-Extension
14	109-6273	1	HYD Hose ASM
14:1		1	Adapter-Run, Tee

Ref	Part No.	Qty.	Description
14:1:1	237-42	1	O-Ring
16	103-1716	3	Clamp-Hose
17	103-1988	1	Clamp-Hose
18	103-1801	1	Adapter-Straight
18:1	237-42	1	O-Ring
20	103-2156	2	Fitting-Straight
20:1	1-603921	1	O-Ring
20:2	103-1020	1	O-Ring
21	1-603990	4	Fitting-Straight
21:1	1-603920	1	O-Ring
21:2	1-603992	1	O-Ring
22	103-3737	1	HYD Hose ASM
23	103-3735	1	HYD Hose ASM
25	109-7689	1	HYD Hose ASM
25:3		1	Fitting-Barb
25:3:1	237-42	1	O-Ring
26	103-1807	1	Elbow-45 DEG
26:1	237-42	1	O-Ring
27	103-1806	1	HYD Hose ASM
28	109-6046	2	Sheave
29	109-7738	1	Sheave
30	114-1512	1	Belt
31	109-4076	1	Pulley-Flat Idler
32	1-603050	1	Spacer




Hydraulic Assembly (continued)

Ref	Part No.	Qty.	Description				
33	103-5679	1	Pump Idler ASM				
34	321-6	2	Screw-HH				
35	323-8	1	Screw-HH				
36	323-11	1	Screw-HH				
37	1-800805	1	Screw-HH				
38	323-7	4	Screw-HH				
39	1-803050	2	Screw-Set				
40	30-1710	4	Screw				
41	103-2916	2	Guard-Top				
42	3256-22	2	Washer-Flat				
43	3256-4	1	Washer-Flat				
45	13-2840	1	Key-Square				
46	5-1077	2	Key-Square				
47	3290-357	8	Nut-HHF, Whiz				
48	32128-33	2	Nut-HF				
49	1-805004	2	Washer-Lock				
50	321-3	2	Screw-HH				
51	109-6130	2	Pump-HYD, 12Cc W/Fan				




Pump Idler Assembly No. 103-5679

Ref	Part No.	Qty.	Description				
1	103-3504	2	Bearing-Spherical				
2	103-3506	2	Seal-Single Lip				
23		1	Pump Idler				
3:1	302-40	1	Fitting-Grease				
4	103-5677	1	Spacer				
5	106-7159	2	O-Ring				
6	32120-10	2	Ring-Snap				




Seat and Roll-Over Protection System Assembly

Ref	Part No.	Qty.	Description				
2	110-0838	1	Deluxe Seat ASM				
14	110-5850	1	Seat Frame And Latch ASM				
14:2	103-4434	1	Grip-Lever				
16	1-633293	1	Rod-Holdup, Seat				
17	322-5	1	Screw-HH				
18	323-39	2	Screw-HH				
20	3296-29	3	Nut-Lock, NI				
21	3296-39	2	Nut-Lock, NI				
23	32128-20	4	Nut-HF				
34	99-4693	1	Decal				
78	108-1097	1	ROPS ASM				




Deluxe Seat Assembly No. 110-0838

Ref	Part No.	Qty.	Description				
1	112-8355	1	Seat-Suspension				
1:1	107-1880	1	Seat Track Kit				
1:2	107-1885	1	Weight Indicator Kit				
1:3	107-1881	1	Knob Kit				
1:4	107-1883	1	Bottom Cushion Kit				
1:5	82-2190	1	Switch-Bail				
1:6	107-1887	1	Armrest Kit				
1:7	107-1884	1	Shock Absorber Kit				
1:8	112-8356	1	Cushion-Back				
4	110-0883	1	Retractable Seatbelt Kit				
4:1		1	Seatbelt-Retractable				
4:2	3212-4	2	Screw-HH				
4:3	3296-7	2	Nut-Lock				
4:99	109-6226	1	Seat Belt Extension Kit				




Roll-Over Protection System Assembly No. 108-1097

Ref	Part No.	Qty.	Description				
1		1	Upper Tube ASM				
1:2	107-2101	1	Decal-ROPS				
1:3	107-2102	1	Decal-Warning, Folding ROPS				
2	3296-73	2	Nut-Lock, NI				
4	103-4553	2	ROPS Fold Pin ASM				
5	325-13	2	Screw-HH				
6	32128-23	2	Nut-HF				
7		1	Tube-Support, RH				
12		1	Tube-Support, LH				
13	109-2365	2	Bumper-Rubber (W/Stud)				
16	110-5850	1	Seat Frame And Latch ASM				
16:2	103-4434	1	Grip-Lever				
17	107-3058	1	Catch-Latch, Seat				
18	322-3	2	Screw-HH				
19	3296-29	2	Nut-Lock, NI				
34	110-0883	1	Retractable Seatbelt Kit				
34:2	3212-4	2	Screw-HH				
34:3	3296-7	2	Nut-Lock				
34:99	109-6226	1	Seat Belt Extension Kit				
54		1	Bag-Bolt, ROPS				
54:3	323-6	8	Screw-HH				
54:4	98-5975	8	Washer-Belleville				
54:5	3290-357	8	Nut-HHF, Whiz				




Deck Connection Assembly

Ref	Part No.	Qty.	Description				
1	32128-37	8	Nut-HF				
3	103-9792	4	Deck Chain ASM				
3:1	1-633447	1	Chain-Lift, Deck				
3:2	103-1898	2	Screw-HH				
3:3	32128-37	2	Nut-HF				
5	3217-11	2	Nut-Hex				
6	3253-8	2	Washer-Lock				
7	327-11	2	Screw-HH				
8	1-633029	2	Balljoint-Spherical				
9	3219-6	2	Nut-Hex				
10	109-1181	2	Strut-Deck				
10:2		1	Tube And Zerk ASM				
10:2:2	109-1380	2	Fitting-Grease				
11	1-632199-01	2	Pin-Strut				
12	322-3	2	Screw-HH				
13	3296-29	2	Nut-Lock, NI				
14		1	Deck ASM				




Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	107-1624	1	Deck Decal ASM	26	98-7912	4	Tube-Spanner
2	105-8783	1	Belt	27	108-4052	1	Spring-Torsion
3	112-8664	2	Cover-Belt	28	105-4622	1	Spacer
4	106-3220	1	Guide-Belt	29	108-2792	1	Rubber Deflector ASM
5	105-8792-01	1	Plate-Skid	30	108-4122-01	1	Bracket-Cover
6	32144-70	4	Screw-HWHTF	31	107-1664	2	Lever ASM
7	108-4121-01	2	Bracket-Cover	32	323-12	2	Screw-HH
8	108-2177-01	1	Bracket-Cover, Tall	33	106-3214	2	Mount-Pulley
9	106-7354-01	1	Mount-Wheel, LH	34	3256-24	4	Washer-Flat
11	3290-357	43	Nut-HHF, Whiz	35	1-633109	3	Idler-Flat
12	323-28	1	Screw-HH	36	3231-1	10	Screw-CARR
13	95-1726	24	Screw-Taptite	37	99-3058	2	Washer
14	105-7734	3	Pulley	38	323-9	1	Screw-HH
15	112-8698	3	Spindle ASM	39	1-603496	1	Bushing-Idler
16	105-7718-03	3	Blade-Hi Flow	40	105-7787-01	1	Plate-Idler
17	323-23	4	Screw-HH	41	105-7788	2	Spacer
18	98-7913	4	Tube-Spacer	42	3231-4	2	Screw-CARR
19	322-50	1	Screw-HH	43	3296-39	6	Nut-Lock, NI
20	98-5967	1	Spacer-Wheel	44	98-5975	1	Washer-Belleville
21	1-603299	6	Roller-Scalp, Anti	45	51-4060	3	Screw-Blade
22	3296-29	1	Nut-Lock, NI	46	103-0865	3	Washer-Blade Bolt, Heavy
23	112-8663-01	4	Spacer-Cover, Belt	47	106-3216-01	1	Baffle-Discharge
24	105-7657-01	1	Baffle ASM	48	112843	1	Washer
25	105-7669-01	1	Baffle ASM	50	108-7220-01	1	Guide-Belt




Deck Assembly (continued)

Ref	Part No.	Qty.	Description
51	106-6777	2	Handle-Latch, Swell
52	106-6778	2	Bushing-Latch, Swell
53	1-804254	2	Nut
54	323-4	9	Screw-HH
55	3256-24	9	Washer-Flat
56	3290-455	9	Washer-Belleville



Deck Decal Assembly No. 107-1624

Ref	Part No.	Qty.	Description				
2	54-9220	1	Decal-Danger				
3	66-1340	1	Decal-Danger				
4	98-5954	3	Decal-Cover, Missing				
5	1-403005	1	Decal-Danger				
6	68-8340	1	Decal-Torque				
7	105-7797	1	Decal-Routing, Belt				
8	105-7798	1	Decal-Scalp, Anti				
9	58-6520	3	Decal-Grease				
10	110-2067	1	Decal-Setting, Baffle				
11	107-1613	2	Decal-Grease				
12	107-1619	1	Decal				
13	107-1621	1	Decal-Service, Check				
14	110-2068	1	Decal-Adjustment, Baffle				
15	107-3137	1	Plate-Turbo				
16	3274-104	2	Screw-HSBH				
17	1-303334	4	Washer-Spring				
18	3296-29	2	Nut-Lock, NI				




Spindle Assembly No. 112-8698

Ref	Part No.	Qty.	Description				
1		1	Spindle Bearing ASM				
1:1		1	Housing-Spindle				
1:2	253-154	2	Seal-Oil				
1:3	71-2530	1	Bearing/Spacer Kit				
2	110-3285	1	Spindle Shaft ASM				
3	114-1161	1	Hub-Spline				
4	69-6950	1	Spacer-Shaft, Spindle				
5	3296-49	1	Nut-Lock, NI				
6	3-8514	1	Washer-Thrust				
7	302-2	1	Fitting-Grease				


Lever Assembly No. 107-1664

Ref	Part No.	Qty.	Description
1	106-3239	1	Screw-Lock
2	107-1644	1	Cap-Lock
3	106-3241	1	Lever-Lock
4	3296-29	1	Nut-Lock, NI




Drive Idler Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	98-5975	1	Washer-Belleville	26:3	3269-24	2	Rivet
6	103-2627	1	Bushing-Idler	27	108-7204-03	1	Guide-Belt, LH
7	1-603384	1	Bushing-Pivot, Idler	28	108-7229-03	1	Guide-Belt, RH
9	1-603496	1	Bushing-Idler	29	3231-2	2	Screw-CARR
10	1-603805	1	Pulley-Idler				
11	1-603402	1	Spring-Extension				
12	1-633166	1	Pulley-Idler				
14	103-3147	1	Arm ASM				
14:1	1-513034	2	Sleeve-Bearing				
14:2		1	Arm-Idler				
10	1-603805	1	Pulley-Idler				
14:2:1	302-40	1	Fitting-Grease				
15	323-12	2	Screw-HH				
16	323-9	1	Screw-HH				
17	323-13	1	Screw-HH				
18	1-800805	1	Screw-HH				
19	3296-39	3	Nut-Lock, NI				
20	3256-24	3	Washer-Flat				
21	3290-357	6	Nut-HHF, Whiz				
22	1-603401	1	Spacer-Fender				
24	3256-4	3	Washer-Flat				
26	106-3271	1	Travel Limiter ASM				
26:1	106-3228-03	1	Plate-Limiter, Pulley				
26:2	106-3229	1	Pad-Bumper				




Z-Stand Assembly

Ref	Part No.	Qty.	Description				
1	323-20	1	Screw-HH				
2	100-6542-01	1	Bracket-Cradle				
3	3296-39	2	Nut-Lock, NI				
4	107-1874	1	Leg ASM				
4:2	106-7464	1	Decal-Z Stand				
5	283-55	1	Pin-Clevis				
6	100-9692-01	1	Pivot Pin ASM				
7	323-8	1	Screw-HH				
8	100-9686-01	1	Bracket-Latch				
9	3-6781	2	Washer-Thrust				
10	283-71	1	Pin-Lynch				
11	3290-355	1	Pin-Hair				
12	100-6547	2	Cushion-Rubber				
14	105-1647	1	Pin-Hitch, Cotterless				
15	100-9385	1	Lanyard-Nylon				
16	321-4	1	Screw-HH				
17	3296-42	1	Nut-Lock, NI				




Engine and Clutch Assembly

Ref	Part No.	Qty.	Description				
2	323-9	4	Screw-HH				
3	98-5975	4	Washer-Belleville				
4	106-7022	1	Tube-Drain, Oil				
5	109-7083-03	1	Anchor-Clutch				
6	1-603610	2	Washer-Spring				
7	1-633615-03	1	Guard-Clutch				
9	109-7666	1	Spot Brake Clutch Kit				
10	1-633179	1	Spacer-Clutch				
19	103-3270	1	Decal				
20	103-7454-03	2	Strap-Guard				
24	323-6	6	Screw-HH				
25	3212-6	1	Screw-HH				
32	3290-357	8	Nut-HHF, Whiz				
42		1	Engine-Kawasaki, FH770D-As05				
43	92-6877	1	Valve-Drain, Oil				
44	103-1966	1	Adapter				
47	322-5	1	Screw-HH				
48	1-303334	1	Washer-Spring				
53	103-0152	1	Keeper-Clutch				
54	1-303335	1	Tie-Plastic				
55	3296-29	1	Nut-Lock, NI				



Guard Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	112-8346-03	1	Guard-Muffler	34	1-633396	1	Clip-Loom
2	112-8347-03	1	Bracket-Mount, Muffler	43	1-633794-03	1	Shield-RH
3	112-8348-03	1	Bracket-Support, Muffler	44	1-643339	1	Decal-Routing, Belt
4	324-2	2	Screw-HH				
5	3253-6	2	Washer-Lock				
6	322-2	4	Screw-HH				
7	3256-23	4	Washer-Flat				
8	32128-20	4	Nut-HF				
9	33104-025	2	Screw-HHF				
10	33004-00	2	Nut-HF				
11	105-6196	1	Shield ASM				
11:1	1-633462	1	Decal-Important				
11:2	103-1301	1	Drive Cover ASM				
11:2:1	103-1308	1	Shield-Engine				
11:2:2	103-1304-03	1	Plate-Cover, Drive				
11:2:3	1-803035	5	Rivet-Pop				
11:3	103-5881	1	Decal-Devices, Rotating				
12	109-2365	2	Bumper-Rubber (W/Stud)				
14	1-633795-03	1	Baffle-Engine Shield, LH				
15	3253-4	2	Washer-Lock				
22	321-4	10	Screw-HH				
27	3296-42	4	Nut-Lock, NI				
29	3256-2	4	Washer-Flat				
33	32128-33	5	Nut-HF				



Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	107-9285	1	Fuel Line ASM
1:1	1-303077	12	Clamp
1:2	109-0678	2	Hose-Fuel
1:3	99-5000	2	Valve-Check, Fuel
1:4	109-0305	1	Hose-Fuel
1:5	99-5005	1	Fitting-Tee, Barbed
1:7	109-0302	1	Hose-Fuel
1:8	109-0299	1	Hose-Fuel
1:9	1-603770	1	Valve-Fuel
1:10	110-5701	1	Hose-Fuel
2	110-5732	1	Control Panel ASM
2:2	110-5731	1	Decal-Panel, Control
4	1-303335	4	Tie-Plastic
9	1-633023	6	Stud
10	105-3644	1	LH Fuel Tank Kit ASM
10:1		1	LH Fuel Tank ASM
10:1:2	103-2605	1	Fitting-Fuel, Bulkhead
10:2	109-0346	1	Cap-Fuel, Gas
11	105-3643	1	RH Fuel Tank Kit ASM
11:1		1	RH Fuel Tank ASM
11:1:2	103-2605	1	Fitting-Fuel, Bulkhead
11:2	109-0346	1	Cap-Fuel, Gas
14	1-633349	6	Spring-Tank, Fuel
16	322-3	2	Screw-HH


Ref	Part No.	Qty.	Description
17	3296-47	6	Nut-Lock, NI
19	1-805005	2	Washer-Lock
20	3256-23	8	Washer-Flat
23	109-2661	4	Screw-PPH
26	110-5720	1	Control-Choke, Push / Pull
27	1-807513	2	Bolt-CARR
28	1-603175	1	Knob-Ball
29	110-5727	1	Throttle Cable Control ASM
29:1	112-2334	1	Lever-Throttle
30	3296-2	2	Nut-Lock



Electrical Assembly


Ref	Part No.	Qty.	Description
1	107-9277-03	1	Strap-Holddown, Battery
2	105-1692	1	Battery
2:1	104-4163	1	Decal-Battery
2:2	104-4164	1	Decal-Battery
3	1-543792	2	Wingnut
4	1-633307	1	Wire-Ground
6	1-800282	1	Screw-HH
7	3256-2	2	Washer-Flat
8	3296-29	1	Nut-Lock, NI
9	1-523415	1	Spring-Switch, Seat
10	1-522424-03	1	Mount-Spring, Seat
11	321-4	8	Screw-HH
12	32128-33	7	Nut-HF
13	63-8360	2	Key-Ignition
14	1-513152	1	Switch-Closed, Normally
15	1-513180	1	Plate-Switch, Seat
16	3290-500	12	Screw-PPH
17	1-633181	4	Plate-Tapped
18	1-816001	2	Fuse-Blade Type, 20 Amp
19	1-633111	1	Switch
20	1-513051	2	Switch-Open, Normally
21	1-303287	5	Tie-Plastic
22	100-6186	1	Module-Delay, Seat
23	104-2541	1	Switch ASM

Ref	Part No.	Qty.	Description
23:1	218-461	1	Nut-HH
23:2	3254-5	1	Washer-Tooth
24	1-513374	1	Meter-Hour
25	103-5221	1	Switch-PTO
26	1-633396	3	Clip-Loom
27	106-7494	1	Harness-Wire
28	1-303335	2	Tie-Plastic
29	109-7630	1	Positive Battery Cable ASM
29:1	109-2407	1	Insulator-Battery
29:2	1-543393	1	Insulator-Solenoid
31	1-633651	2	Bolt-Holddown
33	3296-2	4	Nut-Lock
34	1-643275	2	Relay
37	3256-22	1	Washer-Flat
38	1-513075	1	Switch-Solenoid
38:1	3253-17	2	Washer-Lock
38:2	3253-4	2	Washer-Lock
38:3	3219-14	2	Nut-Hex
38:4	3220-2	2	Nut-Jam
39	109-7620	1	Positive Starter Cable ASM
39:1	1-543393	2	Insulator-Solenoid
40	321-2	1	Screw-HH
49	1-805004	1	Washer-Lock
50	3217-5	1	Nut-Hex




Electrical Assembly (continued)

Ref	Part No.	Qty.	Description
51	3217-6	1	Nut-Hex
53	107-9309	1	Decal-Instructions, Charging




Cylinder and Crankcase Assembly Kawasaki FH770D-AS05

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
①11004	11004-7021	2	Gasket-Head	⑨92153	92153-7043	4	Bolt (6X12)
①11008	11008-7030	1	Head-Cylinder, No.1	⑨92153A	92153-7073	10	Bolt (8X50)
①11008A	11008-7031	1	Head-Cylinder, No.2	⑨92153B	92153-7074	2	Bolt (8X75)
①11022	11022-7002	1	Case-Rocker	⑨92153C	92153-7083	8	Bolt (8X55)
①11022A	11022-7004	1	Case-Rocker	①130	130B0640	4	Bolt-Flanged (6X40)
①11060	11060-7013	2	Gasket-Case, Rocker	①172	172G0818	4	Bolt-Stud (8X18)
①11060A	11060-7014	1	Gasket-Breather	①214	214B0408	2	Screw-Pan (4X8)
①11061	11061-7047	1	Gasket-Crankcase				
①12021	12021-7002	1	Reed Valve ASM				
①14091	14091-7004	1	Cover				
①18088	18088-7003	2	Pipe-Exhaust				
①32153	32153-7003	1	Pipe				
①32154	32154-7021	1	Pipe				
①49015	49015-6269	1	Cover-Crankcase				
①49120	49120-6151	1	Crankcase				
①92033	92033-7004	1	Ring-Snap				
①92043	92043-7001	6	Pin				
①92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)				
①92049A	92049-7005	1	Seal-Oil, S O (8X14X5 H S)				
①92049B	92049-7010	1	Seal-Oil, Sd (35X48X8 R Hs)				
①92049C	92049-7022	1	Seal-Oil, Sd-40-55-8-L-Hs				
①92055	92055-7022	1	O-Ring (25X30.2X2.62)				
①92066	92066-7002	1	Plug				
①92139	92139-7009	2	Bushing				



Valve and Camshaft Assembly
Kawasaki FH770D-AS05


Ref	Part No.	Qty.	Description				
❶12004	12004-7002	2	Valve-Intake				
❶12005	12005-7004	2	Valve-Exhaust				
❶12009	12009-7001	4	Retainer-Spring, Valve				
❶12011	12011-2056	8	Collet				
❶12016	12016-7009	4	Arm-Rocker				
❶12032	12032-7001	4	Tappet				
❶13070	13070-7007	2	Guide				
❶13070A	13070-7008	1	Guide				
❶13116	13116-7002	4	Rod-Push				
❶13271	13271-7007	1	Plate				
❶13271A	13271-7021	1	Plate-Governor				
❶42036	42036-7010	1	Sleeve				
❶49078	49078-7002	4	Spring-Valve, Engine (In)				
❶49118	49118-7013	1	Camshaft				
❶92009	92009-2341	4	Screw				
❶92033	92033-7001	2	Ring-Snap				
❶92140	92140-7005	6	Ball				
❶92145	92145-7001	1	Spring				
❶92153	92153-7019	4	Bolt				
❶92200	92200-7001	1	Washer				
❶92200A	92200-7009	1	Washer (16X42X0.91)				
❶92210	92210-7032	4	Nut (M6)				



Lubrication Equipment Assembly Kawasaki FH770D-AS05


Ref	Part No.	Qty.	Description
③11054	11054-7001	1	Bracket
③13107	13107-7009	1	Shaft
③13271	13271-7014	1	Plate
③16115	16115-7001	1	Cap-Filter, Oil
③16154	16154-2053	1	Rotor-Pump (In)
③16154A	16154-2054	1	Rotor-Pump (Out)
③32153	32153-7002	1	Pipe
③39067	39067-7006	1	Cooler-Oil
③41077	41077-7003	1	Adapter
③49065	49065-2078	1	Filter-Oil
③49065A	49065-7005	1	Filter-Oil
③52005	52005-7003	1	Guage
③59051	59051-7011	1	Gear-Spur
③59071	59071-7009	1	Joint
③92005	92005-7003	2	Fitting
③92015	92015-1193	2	Nut
③92043	92043-7003	2	Pin
③92055	92055-7004	1	O-Ring
③92055A	92055-7006	1	O-Ring (58)
③92066	92066-7003	3	Plug
③92140	92140-7003	1	Ball
③92145	92145-7046	1	Spring
③92153	92153-7007	2	Bolt
③92153A	92153-7043	3	Bolt (6X12)

Ref	Part No.	Qty.	Description
③92171	92171-7020	4	Clamp
③92192	92192-7026	1	Tube
③92192A	92192-7027	1	Tube
③130	130B0612	5	Bolt-Flanged (6X12)
③551	551A0408	1	Pin-Dowel
③670	670D2016	3	O-Ring (16Mm)



Cooling Equipment Assembly
Kawasaki FH770D-AS05


Ref	Part No.	Qty.	Description				
❶11053	11053-7030	1	Bracket, Choke				
❶13271	13271-7015	1	Plate				
❶14037	14037-7014	1	Screen				
❶14091	14091-7002	1	Cover				
❶14091A	14091-7047	1	Cover				
❶49089	49089-7050	1	Shroud-Engine				
❶49089A	49089-7056	1	Shroud-Engine				
❶49089B	49089-7058	1	Shroud-Engine				
❶49089C	49089-7059	1	Shroud-Engine				
❶59041	59041-7004	1	Fan				
❶59066	59066-7034	1	Housing-Fan				
❶92009	92009-7009	4	Screw				
❶92151	92151-7018	4	Bolt				
❶92153	92153-7007	2	Bolt				
❶92153A	92153-7043	10	Bolt (6X12)				
❶92153B	92153-7071	2	Bolt				
❶92200	92200-7011	1	Washer				
❶92210	92210-7011	4	Nut				
❶92210A	92210-7022	1	Nut				
❶130	130B0816	2	Bolt-Flanged (8X16)				



Electric Equipment Assembly


Kawasaki FH770D-AS05

Ref	Part No.	Qty.	Description				
③21066	21066-7011	1	Regulator-Voltage				
③21171A	21171-7037	2	Ignition Coil ASM				
③21193	21193-7030	1	Flywheel ASM				
③26030	26030-7002	1	Harness				
③26031	26031-7012	1	Harness				
③27010	27010-7001	1	Switch				
③59031	59031-7009	1	Coil-Charging				
③92009	92009-2308	1	Screw				
③92070	92070-7004	2	Sparkplug, B P R 4 E S (N G K) Solid				
③92072	92072-7003	3	Band				
③92151	92151-2097	1	Bolt (12X30)				
③92172	92172-7018	4	Screw (5X20)				
③92200	92200-7002	1	Washer				
③130	130B0620	4	Bolt-Flanged (6X20)				
③510	510A5100	1	Key-Woodruff				




Control Equipment Assembly
Kawasaki FH770D-AS05

Ref	Part No.	Qty.	Description				
❶13107	13107-7011	1	Shaft				
❶13271	13271-7032	1	Plate				
❶16169	16169-7008	1	Link-Choke				
❶16171	16171-7005	1	Link				
❶39129	39129-7012	1	Spring-Governor				
❶49103	49103-7004	1	Arm-Governor				
❶49113	49113-7040	1	Panel Control				
❶92145	92145-7004	1	Spring				
❶92145A	92145-7005	1	Spring				
❶92145B	92145-7014	1	Spring				
❶92150	92150-2182	2	Bolt (5X18)				
❶92151	92151-7014	1	Bolt (5X30)				
❶92153	92153-7033	1	Bolt (6X35)				
❶92153A	92153-7043	2	Bolt (6X12)				
❶92170	92170-7001	2	Clamp				
❶214	214B0408	2	Screw-Pan (4X8)				
❶311	311B0600	1	Nut-Hex (6Mm)				
❶411	411B0600	1	Washer-Plain (6Mm)				



Carburetor Assembly Kawasaki FH770D-AS05


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
⑤11009	11009-2056	1	Gasket	⑤92055	92055-7012	1	O-Ring
⑤11060	11060-7010	2	Gasket-Carburetor	⑤92055A	92055-7013	2	O-Ring
⑤11060A	11060-7011	2	Gasket-Manifold	⑤92055B	92055-7016	1	O-Ring
⑤11061	11061-7037	1	Gasket	⑤92063	92063-7086	1	Jet-Main, No.124
⑤11061A	11061-7038	1	Gasket	⑤92063A	92063-7087	1	Jet-Main, No.122
⑤11061B	11061-7039	1	Gasket	⑤92063B	92063-7092	1	Jet-Main, No.119
⑤11061C	11061-7042	1	Gasket-Filter, Air	⑤92063C	92063-7093	1	Jet-Main, No.121
⑤14091	14091-7031	1	Cover	⑤92063D	92063-7094	1	Jet-Main, No.116
⑤15003	15003-7125	1	Carburetor ASM	⑤92063E	92063-7095	1	Jet-Main, No.118
⑤16025	16025-7010	2	Valve-Throttle	⑤92066	92066-7009	2	Plug, Extension
⑤16030	16030-7004	1	Valve-Float	⑤92093	92093-7001	1	Seal (I D 5.9)
⑤16031	16031-7003	1	Float	⑤92093A	92093-7002	1	Seal (I D 6.9)
⑤16041	16041-7028	1	Shaft-Carburetor	⑤92145	92145-7005	1	Spring
⑤16041A	16041-7032	1	Shaft-Carburetor	⑤92145A	92145-7011	1	Spring
⑤16073	16073-7002	1	Insulator	⑤92152	92152-7005	1	Collar
⑤16126	16126-7015	1	Valve	⑤92172	92172-7005	2	Screw
⑤16184	16184-7017	1	Chamber Float ASM	⑤92172A	92172-7006	3	Screw
⑤16187	16187-7002	2	Needle-Jet	⑤130	130B0620	4	Bolt-Flanged (6X20)
⑤21188	21188-7003	1	Solenoid	⑤220	220B0520	1	Screw-Pan (5X20)
⑤59076	59076-7006	1	Manifold-Intake				
⑤92009	92009-7003	6	Screw				
⑤92009A	92009-7006	1	Screw-Drain				
⑤92026	92026-7011	1	Spacer				
⑤92043	92043-7014	1	Pin				



Air Filter and Muffler Assembly Kawasaki FH770D-AS05


Ref	Part No.	Qty.	Description
①11010	11010-7011	1	Air Filter ASM
①11011	11011-7013	1	Case-Filter, Air
①11011A	11011-7014	1	Case-Filter, Air
①11013	11013-7019	1	Element-Filter, Air
①11013A	11013-7020	1	Element-Filter, Air
①11052	11052-7001	1	Bracket
①11053	11053-7002	1	Bracket
①11060	11060-7016	2	Gasket-Muffler
①11065	11065-7006	1	Cap
①11065A	11065-7008	1	Cap
①11065B	11065-7009	1	Cap
①16060	16060-7022	1	Pipe-Intake
①23062	23062-7009	1	Bracket
①49070	49070-7023	1	Muffler
①92015	92015-1193	2	Nut
①92153	92153-7043	2	Bolt (6X12)
①92171	92171-7007	3	Clamp
①92171A	92171-7009	2	Clamp
①92171B	92171-7013	1	Clamp
①92191	92191-7032	1	Tube, Breather
①92192	92192-7049	1	Tube
①92210	92210-7027	6	Nut (M8)
①130	130B06105	2	Bolt-Flanged (6X10.5)
①130A	130B0814	2	Bolt-Flanged (8X14)

Ref	Part No.	Qty.	Description
①130B	130B0816	4	Bolt-Flanged (8X16)
①411	411B0600	1	Washer-Plain (6Mm)
①461	461F0800	6	Washer-Spring (8Mm)




Fuel Tank and Valve Assembly Kawasaki FH770D-AS05

Ref	Part No.	Qty.	Description				
③23062	23062-7004-9H	1	Bracket				
③42036	42036-7016	1	Sleeve				
③49019	49019-7001	1	Filter-Fuel				
③49040	49040-7001	1	Pump-Fuel				
③92170	92170-2088	4	Clamp				
③92170A	92170-7003	1	Clamp				
③92191	92191-7027	1	Tube				
③92192	92192-7037	1	Tube (6.35X12.7X160)				
③92192A	92192-7073	1	Tube (6.35X12.7X195)				
③130	130B0616	2	Bolt-Flanged (6X16)				
③130A	130B0620	2	Bolt-Flanged (6X20)				



Starter Assembly Kawasaki FH770D-AS05

Ref	Part No.	Qty.	Description				
③13101	13101-7003	1	Gear ASM				
③21039	21039-7004	1	Brush				
③21080	21080-7001	1	Armature				
③21163	21163-7010	1	Starter-Electric				
③39184	39184-7004	1	Bracket ASM				
③92151	92151-7013	1	Bolt				
③130	130B0816	2	Bolt-Flanged (8X16)				



Power-Take-Off Assembly Kawasaki FH770D-AS05

Ref	Part No.	Qty.	Description
③13107	13107-7030	1	Shaft
③130	130G0825	4	Bolt-Flanged (8X25)

Attachments and Accessories

For 74272CP - Z550 Z Master, With 60in TURBO FORCE Side Discharge Mower

Product Name	Model/Part
1.25 Inch Spark Arrester Kit	105-1672
Blade-Mid Flow, 20.5 Inch	105-7715-03
Blade-Lo Flow, 20.5 Inch	105-7716-03
Blade-Hi Flow, 20.5 Inch	105-7718-03
Blade-Recycler, 20.5 Inch	105-7777-03
Blade-Atomic, 20.5 Inch	105-8777-03
60 Inch Recycler Kit	107-1611
Striping Kit	107-1630
Turbo Baffle Kit	107-1634
Light Kit	107-9880
6 Pack Blade, 20.5 Inch Hi-Flow	108-1114
6 Pack-Blade, 20.5 Inch Atomic	108-1115
6 Pack Blade, 20.5 Inch Mid-Flow	108-1123
6 Pack-Blade, 20.5 Inch Lo Flow	108-1128
Roller Striping Kit	108-2162
6 Pack-Blade, 20.5 Inch Recycler	110-0405
Cool Top ROPS Mounted Fan	110-1996
Bimini Sunshade	110-5726
Channel Reinforcement Kit	112-8674
DFS Vac Collection System	78513
Triple Bag Assembly	78534
Blower and Drive Kit	78538
Filter Minder Gauge	99-4664
Hitch Kit	99-8925

NOTES

NOTES

NOTES

