





MODEL NO. R116O804-2000001 & UP

PARTS
CATALOG

WHEEL HORSE®
416-8E Garden Tractor






FRAME

Ref. No.	Part No.	Description	No. Used
1	78-2680	Frame	1
2	3231-25	Bolt - Carriage 3/8-16 x 1-1/4	3
3	3296-39	Nut 3/8-16	3

Ref. No.	Part No.	Description	No. Used
4	323-5	Bolt 3/8-16 x 7/8	4
5	3253-21	Washer - Lock 3/8	4




DRIVE BELT AND PULLEYS

Ref. No.	Part No.	Description	No. Used
1	7466	Pulley – Engine Drive	1
2	3246-2	Screw – Set 5/16-18 x 5/16	2
3	105453	Key 1/4 x 1/4 x 3/4	1
4	937221	Key – Hi-Pro 5/32 x 5/8	1
5	3242-2	Screw – Set 5/16-18 x 1/2 Nylok	2
6	107939	Belt – Drive	1

Ref. No.	Part No.	Description	No. Used
7	106165	Pulley – Transmission Drive	1
11	323-6	Bolt 3/8-16 x 1	2
12	3253-21	Washer – Lock 3/8	2
17	120320	Guide – Belt	1
18	322-6	Bolt 5/16-18 x 1-1/4	1
19	3256-3	Washer 5/16 US	2
20	3296-29	Nut 5/16-18	16

MECHANICAL TRANSMISSION 8-SPEED




MECHANICAL TRANSMISSION 8-SPEED

Ref. No.	Part No.	Description	No. Used
	110995	Transmission Assy - 8-Speed	1
1	111200	Case-Trans, RH	1
2	111198	Case-Trans, LH	1
3	323-16	Bolt 3/8-16 x 4	1
4	323-11	Bolt 3/8-16 x 2-1/4	5
5	3296-39	Nut 3/8-16	6
6	281-10	Plug - Pipe, Allen Hd 1/4	1
7	281-2	Plug - Pipe, Sq Hd 3/8	1
8	111199	Bearing - Ball 40mm I.D.	2
9	1532	Bearing - Needle 1 I.D.	2
10	1542	Bearing - Needle 5/8 I.D.	1
11	9416	Bearing - Needle 1-1/8 I.D.	2
12	1529	Bearing - Needle 3/4 I.D.	1
13	100442	Seal - Input Shaft 5/8 I.D.	1
14	100443	Seal - Axle 1 1/8 I.D. x 1-3/8 O.D.	2
15	3915	Pin - Locating	2
16	1523	Bearing - Needle 3/4 I.D.	1
17	1531	Bearing - Needle 5/8 I.D.	1

Ref. No.	Part No.	Description	No. Used
18	100441	Seal - Brake Shaft 3/4 I.D.	1
19	7201	Shaft - Input	1
20	7418	Washer - Thrust	1
21	7204	Gear	1
22	1518	Bearing - Needle 5/8 I.D.	4
23	5175	Gear	1
24	7205	Gear - Sliding	1
25	7206	Gear - Reduction	1
26	7207	Bearing - Needle 3/8 I.D.	2
27	7208	Shaft - Reduction Gear	1
28	1243	Cup - Plug	1
29	5173	Gear - 2nd & 3rd	1
30	5174	Gear - 1st & Reverse	1
31	5615	Rail - Shift, Front	1
32	5616	Rail - Shift, Rear	1
33	3503	Fork - Shift	2
34	933156	Pin - Spirol 1/8 x 1	2
35	5614	Pin - Shift	1

MECHANICAL TRANSMISSION 8-SPEED




MECHANICAL TRANSMISSION 8-SPEED

Ref. No.	Part No.	Description	No. Used
36	7269	Cluster Gear With Bushing	1
37	1504	Bushing – Bronze	2
38	3527	Gear – Reduction	1
39	9840	Shaft – Cluster	1
40	3257-5	Key – Woodruff 3/16 x 3/4	1
41	4204	Gear – Reverse Idler	1
42	3909	Pin – Reverse Idler	1
43	1516	Bushing – Reverse Idler	1
44	101847	Dipstick Assembly	1
45	102703	Nipple – Transmission Fill	1
46	3912	Gasket – Transmission Case	1
47	1239	Screw – Set – Special	1
48	3217-5	Nut 1/4-20	1
49	3577	Cover – Dust	1
50	9547	Washer – Thrust	1
51	102974	Gear Assembly	1
52	101625	Gear 11 Tooth	1
53	101626	Gear 44 Tooth	1
54	108758	Knob – Gear Shift	2
55	3517	Ball – Detent 1/4 Dia.	2
56	106030	Spring – Detent	1

Ref. No.	Part No.	Description	No. Used
57	7213	Bolt – Detent	1
58	7214	Shaft – Shift Hi-Low Range	1
59	116636	Fork – Shift Hi-Low Range	1
60	3517	Ball – Detent 1/4 Dia.	1
61	106030	Stop – Shift	1
62	110727	Lever – Shift Hi-Low Range	1
63	933184	Pin – Spirol 3/16 x 3/4	1
64	111196	Cap – Diff End	2
65	911423	Bolt 3/8-16 x 3-1/2 (Grade 8)	4
66	107374	Washer – Special, Case Hardened	4
67	108881	Nut 3/8-16 High-Tensile	4
68	105061	Gear – Differential Ring 43 Tooth	1
70	101623	Gear – Differential Pinion 11 Tooth	8
71	101889	Gear – Differential Axle	2
72	105875	Axle – Rear (1-1/8" dia)	2
73	105876	Ring – Special, Snap	2
74	110725	Lever – Gear Shift	1
75	1001	Knob – Hi-Lo Range Shift	1

FRONT AXLE AND STEERING




FRONT AXLE AND STEERING

Ref. No.	Part No.	Description	No. Used
1	5638	Axle - Front	1
2	1030	Fitting - Grease, Straight	2
3	1481	Fitting - Grease, 45°	1
4	6216	Pin & Plate	1
5	322-1	Bolt 5/16-18 x 1/2	1
6	3253-4	Washer - Lock 5/16	1
7	113381	Spindle - Front, LH	1
*	113382	Spindle - Front, RH	1
8	5618	Ring - Retaining	1
10	78-2900	Tie Rod (Includes Item 38)	2
11	915693	Nut 3/8-24	4
12	6472	Bearing - Flanged	1
13	323-7	Bolt 3/8-16 x 1-1/4	2
14	3296-39	Nut 3/8-16	2
15	78-2880	Shaft - Lower Steering	1
16	5210	Washer - Shim 3/4 x .015	1
17	1278	Washer - Shim 3/4 x .050	1
18	3272-19	Pin - Cotter 5/32 x 1-3/4	1
19	88-2710	Support - Steering	1
20	323-9	Bolt 3/8-16 x 1-3/4	2

Ref. No.	Part No.	Description	No. Used
21	32146-2	Nut 3/8-16	2
22	1481	Fitting - Grease, 45°	1
23	6397	Bearing - Lower Steering Shaft	1
24	109189	Bearing - Upper Steering Shaft	1
25	106177	Shaft - Upper Steering	1
26	1085	Collar	1
27	3245-32	Screw - Set 1/4-20 x 1/4	1
28	113443	Tube - Steering	1
29	7896	Washer - Bowed	1
30	117337	Steering Wheel	1
31	32121-111	Pin - Spirol 1/4 x 2	1
32	109262	Washer - Special	1
33	1278	Washer	2
34	104822	Ring - Retaining	2
36	111646	Ring - Grip	1
37	915035	Nut - Slotted 3/4-16	1
38	78-2920	Joint - Ball	1
39	915002	Nut 3/8-24	1
*	78-0370	Insert - Steering Wheel	1

*Not Illustrated

CLUTCH, BRAKE AND SPEED CONTROL LINKAGE




CLUTCH, BRAKE AND SPEED CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
1	106719	Drum - Brake	1
2	110234	Bolt 3/8-16 x 3/4 Nylok	1
3	2844	Washer - Special	1
4	9593	Band - Brake	1
5	321-3	Bolt 1/4-20 x 5/8	2
6	3253-3	Washer - Lock 1/4	2
7	9598	Plate - Back-Up	1
8	114814	Pedal - Clutch	1
9	114813	Pedal - Brake	1
10	1085	Collar	2
11	3245-32	Screw - Set 1/4-20 x 1/4	2
12	7896	Washer - Bowd	1
13	1278	Washer - Shim 3/4 x .050	1
14	103347	Rod - Clutch	1
15	3272-6	Pin - Cotter 3/32 x 3/4	1
16	78-2970	Arm - Clutch Idler	1
17	933190	Pin - Spirol 3/16 x 1-1/4	1
18	105896	Arm - Clutch Rod	1
19	920248	Washer - Nylon 3/8	3
20	3272-10	Pin - Cotter 1/8 x 3/4	2
21	3765	Washer - Shim 1/2 x .0301	1
22	101161	Trunnion - Clutch Rod	1
23	103543	Bell Crank - Brake Linkage	1
24	7879	Bushing	2
25	3256-26	Washer 1/2 SAE	1
26	106417	Rod - Bell Crank Pivot	1
27	926694	Bolt 5/16-18 x 5/8 ST	1
28	105900	Rod - Brake, Rear	1
29	105886	Rod - Brake, Front	1

Ref. No.	Part No.	Description	No. Used
30	920248	Washer - Nylon 3/8	2
31	3272-10	Pin - Cotter	3
32	3296-39	Nut 3/8-16	1
34	106451	Lever - Parking Brake	1
35	6820	Grip	1
36	102025	Spacer	1
37	323-9	Bolt 3/8-16 x 1-3/4	1
38	3256-24	Washer 3/8 SAE	1
39	102809	Nut - Special	1
40	107677	Spring - Brake Return	1
41	103628	Spring - Parking Brake Return	1
42	7451	Pulley - Idler	1
43	106193	Bolt - Special 3/8-16 x 1-1/2	1
44	3296-39	Nut 3/8-16	1
48	108035	Spring - Clutch Return	1
49	920225	Washer - Special	1
50	933267	Pin - Spirol 5/32 x 1-1/4	1
51	3256-24	Washer 3/8 SAE	1
52	114131	Bracket - Damper	1
53	78-3240	Spring - Gas	1
54	321-6	Bolt 1/4-20 x 1	1
55	78-3260	Spacer	1
56	3256-22	Washer	2
57	3253-3	Washer - Lock	1
58	3296-42	Nut 1/4-20	2
59	321-9	Bolt 1/4-20 x 1-1/2	1
60	78-3250	Spacer	1
61	302-5	Fitting - Grease	2

HITCHES




HITCHES

Ref. No.	Part No.	Description	No. Used
1	101711	Housing – Front Hitch	1
2	105859	Latch – Front Hitch	1
3	101750	Rod	1
4	101751	Rod – Front Hitch Lock	1
5	105797	Ring – Retaining	8
6	101707	Lock	1
7	8616	Spring	2
8	105316	Cap – Lock Rod	2
9	1644	Hitch – Drawbar	1
10	105269	Shaft – Drawbar Hitch	1
11	979120	Spacer	2

Ref. No.	Part No.	Description	No. Used
12	5618	Ring – Retaining	2
13	106634	Pin – Hitch	1
14	933505	Pin – Cotter	1
15	102644	Plate – Mid Hitch	2
16	117940	Rod – Mid Hitch Lock	1
17	117930	Latch – Mid Hitch	1
18	83-6520	Rod – Lock	1
19	323-6	Bolt 3/8-16 x 1	3
20	3296-39	Nut 3/8-16	5
21	323-7	Bolt 3/8-16 x 1-1/4	2
22	9038	Grip	1

MANUAL LIFT LINKAGE




MANUAL LIFT LINKAGE

Ref. No.	Part No.	Description	No. Used
1	108563	Lever – Lift (Includes Items 46, 47, & 48)	1
2	106257	Rod – Latch	1
3	8130	Retainer – Spring	1
4	3624	Spring	1
5	933148	Pin – Spirol 1/8 x 1/2	1
6	6542	Grip – Lift Lever	1
7	105316	Cap – Rod	2
8	4944	Button – Plug	1
14	933507	Pin – Cotter	2
15	3256-30	Washer 1 in. SAE	3
16	106269	Bushing	2
17	106414	Retainer	1
18	1121	Key 1/4 Sq x 1-3/16	1
19	78-1550	Bellcrank	1
20	6739	Trunnion	1
21	933504	Pin – Cotter	1
22	106522	Chain – Lift	1
24	322-6	Bolt 5/16-18 x 1-1/4	1
25	3256-23	Washer 5/16	1
26	3296-29	Nut 5/16-18	1
27	113445	Bar – Lift	1
28	6229	Bearing	1
29	5701	Ring – Retaining	1

Ref. No.	Part No.	Description	No. Used
30	105845	Tube – Rear Lift Cable	1
31	108903	Clamp – Tube	1
33	3235-22	Bolt 3/8-16 x 1	2
34	110653	Rod – Height Control	1
35	3272-10	Pin – Cotter 1/8 x 3/4	1
36	3256-5	Washer 7/16 U.S.	1
37	106345	Casting – Height Control	1
38	322-5	Bolt 5/16-18 x 1	3
39	106258	Sleeve	1
40	5280	Knob – Height Control	1
41	106411	Latch Bracket	1
42	926694	Bolt 5/16-18 x 5/8 ST	1
43	3256-23	Washer 5/16 SAE	2
44	3296-29	Nut 5/16-18	3
45	926696	Bolt 5/16-18 x 7/8 ST	2
46	108565	Shaft	1
47	32121-103	Pin – Spirol	1
48	32121-35	Pin – Roll	1
52	8830	Clamp	1
53	111154	Wire – Lock	1
54	933505	Pin – Cotter	1
55	3256-26	Washer 1/2 SAE	1
56	3296-39	Nut 3/8-16	1

SHEET METAL AND COVERS




SHEET METAL AND COVERS

Ref. No.	Part No.	Description	No. Used
1	112358	Hood	1
2	117341	Latch - Hood	2
3	117432	Rivet - Pop 1/8 x .294	4
4	111271	Console	1
5	926694	Bolt - Washer Hd ST 5/16-18 x 5/8	3
6	105797	Ring - Retaining	2
7	116745	Rod - Pivot	1
8	101850	Rod - Hood Stop	1
9	932000	Pin - Cotter 1/16 x 1/2	2
10	116746	Bracket - RH	1
11	116747	Bracket - LH	1
12	3229-25	Bolt - Carriage 1/4-20 x 3/4	4

Ref. No.	Part No.	Description	No. Used
13	3256-22	Washer 1/4 SAE	4
14	32146-17	Nut 1/4-20	4
16	117431	Rivet - Pop 1/8 x .232	2
17	120590	Stop - Throttle	1
18	112506	Bracket	1
19	920150	Washer - Lock Internal Tooth	4
20	910762	Screw - Black #6-32 x 3/8	4
21	112415	Stop - PTO	1
22	111757	Edging - Console	1
23	111392	J-Clip	1
24	3217-29	Nut #6-32	4
*	5983	Bushing - Hood Pivot & Bracket	2

*Not Illustrated

SHEET METAL AND COVERS




SHEET METAL AND COVERS

Ref. No.	Part No.	Description	No. Used
1	79-4900	Hoodstand	1
3	106261	Bracket - Belt	1
4	926694	Bolt 5/16-18 x 5/8 ST	1
5	78-3010	Bracket - Battery Support	1
6	117371	Bolt - Carriage 5/16-18 x 1/2	4
7	3217-6	Nut 5/16-18	4
9	78-3020	Plate - Front	1
10	926694	Bolt 5/16-18 x 5/8 ST	1
11	106772	Trim - Edge 4"	1
12	926694	Bolt 5/16-18 x 5/8 ST	4
*	926696	Bolt 5/16-18 x 7/8 ST	2
13	113935	Cover - Side, LH	1

Ref. No.	Part No.	Description	No. Used
14	910837	Screw - Black 1/4-20 x 5/8	6
15	107069	Nut - Speed	6
16	106250	Cover - Dust	1
17	926694	Bolt 5/16-18 x 5/8 ST	4
18	104248	Grommet	1
19	111386	Plate - Shift Cover	1
20	111034	Plate - Hood Stand	1
23	110142	Trim - Edge	1
24	910837	Screw 1/4-20 x 5/8	1
25	106454	Trim - Edge	1
26	3023	Clip	1

SHEET METAL AND COVERS




SHEET METAL AND COVERS

Ref. No.	Part No.	Description	No. Used
1	114877	Guard - Belt	1
2	910837	Screw 1/4-20 x 5/8	2
3	116000	Bolt - Carriage 5/16-18 x 3/4	1
4	926694	Bolt 5/16-18 x 5/8 ST	1
5	106352	Guard - Lower Belt	1
6	106222	Footrest - RH	1
7	106223	Footrest - LH	1
8	107069	Clip	3
9	116000	Bolt - Carriage 5/16-18 x 3/4	6
10	3296-29	Nut 5/16-18	7
11	7456	Clamp	4
13	110636	Pad - Footrest	2
14	107951	Bracket - Fender Front	1
15	322-3	Bolt 5/16-18 x 3/4	2
16	3256-23	Washer 5/16 SAE	2

Ref. No.	Part No.	Description	No. Used
17	109554	Bracket - Support Belt Guard	1
18	108897	Bracket - Fender Support	1
19	108464	Support - Fuel Tank, LH	1
20	106236	Support - Fuel Tank, RH	1
21	322-3	Bolt 5/16-18 x 3/4	4
22	3256-23	Fender	1
23	926694	Bolt 5/16-18 x 5/8 ST	4
24	920008	Washer 5/16 SAE	4
30	3296-29	Nut 5/16-18	6
31	111071	Bumper	2
32	108457	Nut - Push	1
33	118620	Bolt - Carriage 5/16-18 x 3/4	2
36	118280	Holder - Fuse	1
37	321-4	Bolt 1/2-20 x 3/4	2
38	3296-42	Nut 1/4-20	1

ENGINE AND EXHAUST




ENGINE

Ref. No.	Part No.	Description	No. Used
1	79-5210	Engine - 16HP TORO Power Plus P216G-I/10976D	1
2	116609	Plate - Engine	1
3	908035	Bolt 3/8-16 x 1-1/4	4
4	915553	Nut 3/8-16	4
5	908035	Bolt 3/8-16 x 1-1/4	4
7	3256-24	Washer 3/8 SAE	4
8	3253-24	Washer - Lock 3/8	4
13	32146-2	Nut 3/8-16	4
17	322-3	Bolt 5/16-18 x 3/4	4
18	3253-4	Washer - Lock 5/16	4
19	321-2	Bolt 1/4-20 x 1/2	3

Ref. No.	Part No.	Description	No. Used
20	910331	Screw #10-24 x 3/8	4
21	114217	Deflector - Air	1
22	114215	Cover - Exhaust, LH	1
23	114216	Cover - Exhaust, RH	1
24	116470	Muffler 416	1
25	114636	Pipe 3/8 x 3	1
26	114764	Elbow - 90°	1
27	114763	Pipe 3/8 x 4	1
28	5224	Cap	1
30	114214	Gasket - Exhaust	2
31	111357	Clip	1

ENGINE POWER PLUS CYLINDER BLOCK




ENGINE POWER PLUS CYLINDER BLOCK

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-0900	Block - Short	1	25	NN10821	Cover - Valve	2
2	57-9690	Plug	1	26	57-8280	Gasket	2
3	59-0880	Bolt 3/8-16 x 1-1/4	5	27	NN10129	Tappet - Standard	4
4	57-8170	Shim 0.005"	X		NN10130	Tappet .002" Oversize	4
5	57-8050	Bearing - Crankshaft, Rear, Standard	1		NN10131	Tappet .004" Oversize	4
	NN10010	Bearing - Crankshaft, Rear .002" Under	1	28	NN10075	Valve - Intake	2
	57-8060	Bearing - Crankshaft, Rear .010" Under	1	29	NN10075	Valve - Exhaust	2
	NN10012	Bearing - Crankshaft, Rear .020" Under	1	30	NN10370	Bolt 1/4-20 x 1-3/4	2
	NN10013	Bearing - Crankshaft, Rear .030" Under	1	31	NN10077	Spring	4
6	57-8160	Washer - Thrust	2	32	NN10082	Lock - Spring	8
7	NN10554	Gasket	1	33	NN10326	Seal	2
8	82-0020	Plate - Bearing	1	34	NN10385	Screw 3/8-16 x 5/8	2
9	57-8160	Bearing - Camshaft	2	36	NN10070	Gasket	2
10	57-8000	Seal - Oil	1	37	NN10080	Head - Right Cylinder	1
11	NN10334	Pin - Stop	4		NN10079	Head - Left Cylinder	1
12	59-0290	Tube - Oil	1	38	NN10078	Washer	4
13	NN10054	Insert - Exhaust Seat, Standard	2	39	82-1480	Screw #8 x 3/4	1
	NN10055	Insert - Exhaust Seat .002" Oversize	2	40	57-9770	Washer - Flat 1/4	18
	NN10056	Insert - Exhaust Seat .005" Oversize	2	41	NN10381	Bolt - Special 2" Long	10
	NN10057	Insert - Exhaust Seat .010" Oversize	2	42	NN10359	Washer 1/4	2
	NN10058	Insert - Exhaust Seat .025" Oversize	2	44	71-5830	Cap - Valve	4
14	NN10035	Insert - Intake Seat, Standard	2	45	71-6290	Kit - Engine Gasket	
	NN10036	Insert - Intake Seat .002" Oversize	2			Valve Grind/Carbon Removal	1
	NN10037	Insert - Intake Seat .005" Oversize	2	46	NN10136	Pump - Oil, Complete	1
	NN10038	Insert - Intake Seat .010" Oversize	2	47	NN10134	Pump - Oil, Gasket Kit	1
	NN10039	Insert - Intake Seat .025" Oversize	2	48	82-1340	Washer - Flat	2
15	NN10003	Bearing - Crankshaft, Front, Standard	1	49	87-1370	Bolt 1/4-20 x 1	2
	NN10004	Bearing - Crankshaft, Front .002" Under	1	50	59-0910	Bolt 3/8-24 x 7/8	1
	NN10005	Bearing - Crankshaft, Front .010" Under	1	51	NN10361	Washer 3/8	1
	NN10006	Bearing - Crankshaft, Front .020" Under	1	52	NN10133	Spring	1
	NN10007	Bearing - Crankshaft, Front .030" Under	1	53	NN10135	Plunger	1
16	NN10479	Guide - Exhaust Valve	2	54	92-0901	Piston Pin & Retaining Rings STD	2
	NN10478	Guide - Intake Valve	2	*	92-0902	Piston Pin & Retaining Rings .010"	2
19	82-1640	Washer - Spring 3/8	5	*	92-0903	Piston Pin & Retaining Rings .020"	2
20	NN10336	Pin	2	*	92-0904	Piston Pin & Retaining Rings .030"	2
21	82-0530	Clamp	1	55	NN10100	Piston Pin	2
22	57-8580	Breather - Baffle	1	56	NN10345	Retaining Ring	4
23	82-0570	Seal	1	57	92-0905	Set - Piston Ring, Standard	2
					92-0906	Set - Piston Ring .005" Oversize	2
					92-0907	Set - Piston Ring .010" Oversize	2
					92-0908	Set - Piston Ring .020" Oversize	2
					92-0909	Set - Piston Ring .030" Oversize	2
				58	NN10125	Rod w/Bolts & Nuts - STD	2
					NN10126	Rod w/Bolts & Nuts - .010"	2
					NN10127	Rod w/Bolts & Nuts - .020"	2
					NN10128	Rod w/Bolts & Nuts - .030"	2
				59	NN10120	Bolt - Special Rod	4
				60	NN10428	Nut	4
				64	82-0550	Breather Cap & Valve	1
				65	82-0540	Tube - Baffle Breather	1
				66	82-0560	Screen	2

*Not Illustrated

CRANKSHAFT, CAMSHAFT, FLYWHEEL POWER PLUS




CRANKSHAFT, CAMSHAFT, FLYWHEEL POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10853	Crankshaft	1
2	57-9710	Ring - Retaining	1
3	NN10439	Washer	1
4	NN10438	Gear	1
5	NN10330	Key	1
6	NN10215	Ring - Retaining	1
7	NN10221	Hub - Governor Cup	1
8	NN10222	Cup - Governor	1
9	57-9640	Ball	1
10	57-9660	Key	1
11	NN10032	Camshaft (Includes Item 13)	1
12	57-8210	Camshaft Gear (Includes Gear, Spacer, & Plate)	1

Ref. No.	Part No.	Description	No. Used
13	NN10030	Washer	1
14	NN10214	Pin	1
15	NN10171	Flywheel (Includes Ring Gear)	1
16	NN10021	Screw	1
17	82-1320	Washer 7/16	1
18	NN10355	Washer 7/16	1
19	NN10409	Screw #10-24 x 3/8	6
20	82-1400	Screw 5/16-18 x 1/2	4
21	79-6440	Screen	1
22	57-8180	Gear - Ring	1
23	82-1150	Key	1

OIL BASE FILL TUBE AND BRACKET POWER PLUS




OIL BASE FILL TUBE AND BRACKET POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10018	Base - Oil (Includes All Plugs & Plug Gasket)	1
2	57-8090	Gasket	1
3	82-1310	Washer - Lock 3/8	4
4	NN10379	Screw 3/8-16 x 3-3/4	4
5	82-1130	Plug - Sq Hd 3/8	2
8	NN10138	Cup - Oil Pump Intake	1
9	NN10159	Cap - Oil Fill & Indicator (Includes O-Ring)	1

Ref. No.	Part No.	Description	No. Used
10	NN10323	Ring - Oil	1
11	79-6460	Bracket	1
12	NN10854	Tube - Oil Fill, Chrome 15-3/4" Lg	1
13	NN10690	Seal	1
14	82-1560	Screw #10 x 1-1/4	1
15	82-1700	Nut - Speed	1

OIL FILTER POWER PLUS




OIL FILTER POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	82-0500	Adapter - Oil Filter	1
2	57-9750	Washer 5/16	2
3	NN10373	Screw 5/16-18 x 1	2
4	NN10894	Drain - Oil Filter	1
5	82-1510	Screw #10-32 x 3/8	2
6	79-6470	Gasket	1

Ref. No.	Part No.	Description	No. Used
7	NN10143	Filter - Oil	1
8	NN10465	Wrench	1
9	82-0680	Gasket	1
10	NN10824	Switch - Oil Pressure	1
11	92-0912	Elbow 45°	1

GEARCASE AND IGNITION CONTROLS POWER PLUS




GEARCASE AND IGNITION CONTROLS POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10825	Kit – Gearcase (Incl. Ref.# 2-9, 13, 19, & 20)	1
2	57-9650	Bearing	1
3	NN10826	Governor Shaft & Arm – Chromed	1
4	59-0420	Yoke	1
5	59-0950	Screw #8-32 x 3/8	1
6	NN10335	Pin – Dowel	1
7	57-9570	Seal – Oil	1
8	NN10327	Bearing	1
9	57-9580	Seal – Oil	1
10	NN10895	Gasket	1
11	82-1410	Screw 5/16-18 1-3/4	4
12	57-9750	Washer 5/16	5
13	59-0360	Tube – Vacuum Port	1
14	NN10352	Stud – Gear Cover	1
15	3253-2	Washer – Lock #10	3
16	NN10426	Nut 5/6-18	1
17	NN10518	Stator w/Terminals	1
18	NN10290	Terminal – Stator Leads	3
19	57-9550	Clamp	1
20	59-0370	Cap	1
21	82-1000	Kit – Terminal Connector Body	1

Ref. No.	Part No.	Description	No. Used
22	NN10444	Control – Ignition	1
23	82-1500	Screw – Hex. Hd. #10-32 x 1	3
24	NN10394	Screw – Hex. Hd. #10-32 x 3/8	2
25	82-1660	Washer – Lock IT #10	2
26	57-9730	Clip – Retaining	1
27	NN10414	Screw – Hex. Hd. 1/4-20 x 5/16	1
28	NN10261	Regulator – Voltage 20 amp	1
29	79-6490	Gasket – Plate	1
30	NN10515	Cover – Ignition Plunger	1
31	NN10245	Battery Ignition Coil – w/Nuts	1
32	NN10247	Rotor – Ignition	1
33	57-9340	Plug – Spark	2
34	82-1340	Cable – Spark Plug 18" Long	1
35	82-1340	Washer – Flat (M6)	2
36	NN10248	Nut	1
37	NN10348	Clip – Wire	1
38	82-1360	Screw – Hex. Hd. 1/4-20 x 5/8	1
39	NN10249	Nut	1
40	82-1410	Screw – Hex. Hd. 5/16-18 x 1.75	1
41	NN10408	Screw – Hex. Hd. 1/4-20 x 1	2
42	NN10516	Indicator – Ignition Module	1

AIR CLEANER POWER PLUS




AIR CLEANER POWER PLUS

Ref. No.	Part No.	Description	No. Used
2	79-6320	Cover - Air Cleaner	1
3	NN10176	Element - Foam	1
4	NN10174	Element - Air Cleaner	1
5	82-1690	Nut - Flange 5/16-18	1
6	79-6330	Housing - Air Cleaner	1
7	82-1550	Screw - Hex. Hd. 1/4-20 x 3/8	2
11	NN10187	Tube - Air Intake	1
14	79-6340	Support - Air Cleaner	1
16	NN10309	Grommet - 3/4" Hole	1

Ref. No.	Part No.	Description	No. Used
20	NN0980	Capacitor (300 VD)	1
22	NN10390	Screw - Hex. Hd. #10-32 x 5/8	1
23	79-6520	Spacer	1
25	92-0917	Tube	1
29	79-6350	Knob - Toolless	1
31	92-0915	Screw - 10-32 x 3/8	1
32	92-0914	Cover - Element	1
33	92-0913	Nut - Wing - 1/4-20	1

INTAKE MANIFOLD POWER PLUS




INTAKE MANIFOLD POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10504	Carburetor (Includes Mounting Gasket, Elbow, & O-Ring)	1
2	72-0850	Gasket	1
4	82-1350	Washer - Flat	4
5	92-0918	Manifold - Intake	1
6	82-1410	Washer - Flat	2
7	82-1410	Screw - Hex. Hd. 1/4-20 x 1-3/8	2
8	NN10375	Screw - Hex. Hd. 5/16 x 2	4
9	NN10348	Clip - Fuel Line	1
10	71-5980	Gasket	2

Ref. No.	Part No.	Description	No. Used
11	82-1450	Screw 1/4-14 x 1/2	2
12	57-9700	Clip - Retaining, Rod to Carburetor	1
13	92-0919	Rod - Governor Control	1
14	57-9620	O-Ring	1
15	NN10362	Washer - Flat 5/16	1
16	NN10858	Hose - Fuel	1
17	82-1120	Hose - Breather	1
18		Fitting	1
19	82-1090	Clamp - Hose	1
20	NN10877	Spring - Governor Rod	1

CARBURETOR COMPONENTS POWER PLUS




CARBURETOR COMPONENTS POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10209	Kit - Float (Includes Float, Pin, & Valve)	1
2	82-0780	Kit - Repair (Includes Screw & Plug Package, Gasket Package, Float Valve, Idle Adjustment Needle & Spring, Mounting Gaskets, & Idle Limit Cap)	1
3	82-0850	Gasket - Carburetor Mounting Jet (Power-Fixed Optional High Altitude)	1
4	NN10810	Kit - Fixed Jet	1

Ref. No.	Part No.	Description	No. Used
5	NN10201	Jet - Idle	1
6	NN10199	Jet - Power	1
7	NN10207	Kit - Choke Shaft (Includes Choke Valve, Valve Screw - Set, & Air Filter)	1
8	NN10809	Kit - Choke Lever (Include Choke Lever Ring, Choke Spring, & Choke Collar)	1
9	NN10811	Kit - Throttle Shaft (Includes Valve Screw - Set, Air Filter, & Throttle Valve)	1

BLOWER HOUSING AND GOVERNOR POWER PLUS




BLOWER HOUSING AND GOVERNOR POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10862	Housing – Blower	1
2	59-0970	Screw 1/4-20 x 7/16	1
3	92-0920	Housing – Cylinder Air, LH	1
4	92-0921	Housing – Cylinder Air, RH	1
5	59-0980	Screw 1/4-20 x 5/8	1
6	NN10289	Clamp	1
7	82-1600	Screw 5/16-18 x 3/4	2
8	NN10393	Screw 1/4-20 x 5/8	4
9	NN10289	Clamp	1
10	NN10356	Washer – Flat 1/4	1
11	NN10217	Spring – Governor, 5 Ball	1
12	57-9190	Clamp – Cable	1
13	79-6360	Bracket	1
14	NN10395	Screw #10-32 x 1/2	1
15	59-1030	Screw #6-32 x 5/8	1
16	NN10219	Spring	1
17	92-0922	Arm – Governor Control, w/o Swivel	1
18	59-1100	Screw 1/4-20 x 1/2	2
19	NN10357	Washer – Flat 1/4	1
20	NN10218	Bushing	1
22	59-1000	Screw 10-32 x 1/2	1

Ref. No.	Part No.	Description	No. Used
23	57-9190	Clamp – Throttle Cable	1
24	79-6390	Bracket – Governor Control	1
25	59-0830	Washer – Flat 1/4	1
26	82-1620	Washer – Lock	1
27	82-1370	Screw 1/4-20 x 1	1
28	201327	Screw	3
29	79-6400	Bushing – Governor Control	1
30	NN10320	Swivel – Throttle Control	1
31	59-0720	Pin – Cotter	1
32	NN10410	Screw – Machine	1
33	79-6410	Link – Governor Control	1
34	79-6420	Adapter – Governor Arm	1
35	59-1050	Screw 10-32 x 1/2	2
37	59-1080	Bushing – Black Nylon	1
38	NN10414	Screw 1/4-20 x 5/16	4
39	82-0620	Guard – Stationary	1
41	NN10832	Bracket	1
42	82-0930	Screw 1/4-20 x 1/2	2
49	82-1590	Screw 1/4-20 x 3/8	4
55	NN10348	Clip – Wire	1
56	NN10296	Bracket – Lifting	2

STARTER POWER PLUS




STARTER POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	NN10885	Starter Hdwr Kit (Includes Solenoid Screws [2], Brush Holder Screws [2], Thru Bolts [2], Armature Shims [2], Pinion Stop Collar, & Pinion Retaining Ring)	1
2	71-6040	Starter, Complete - See Components Below	1
3	57-9770	Washer - Flat 5/16	2
4	79-6580	Screw - Cap 5/16-18 x 3-1/2	2
5	NN10886	Seal - Dust	1
6	NN10884	Clutch - Starter (Includes Pinion Gear w/Clutch)	1
7	NN10266	Kit - Starter Shift Lever (Includes Shift Lever, Wear Plate & Rubber Plug)	1

Ref. No.	Part No.	Description	No. Used
8	NN10887	Kit - Starter Solenoid (Includes Solenoid, Spring, & Plunger)	1
9	NN10930	Cap - Starter Solenoid	1
10	NN10768	Nut	1
11	NN10883	Kit - Starter Brush (Includes Positive Brush [2] & Negative Brush w/Pigtail)	1
12	62-2730	Kit - Bushing (Includes Front Bushing & Rear Cap w/Bushing)	1
13	NN10929	Holder - Starter Brush (Includes Brush Holder w/Negative Brush)	1

CHOKE LINKAGE POWER PLUS




CHOKE LINKAGE POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	59-0850	Washer #10	2
2	59-0460	Lever - Choke	1
3	57-9180	Link - Choke	1
4	59-0470	Bracket	1
5	NN10412	Screw #10-32 x 1-1/4	1
6	92-0916	Screw #10-32 x .38	1

Ref. No.	Part No.	Description	No. Used
7	NN10830	Plug	1
8	57-9170	Swivel - Choke Lever	1
9	NN10410	Screw #8-32 x .375	1
10	59-0720	Pin - Cotter	1
11	NN10784	Screw #10-32 x 7/8	1
12	57-9190	Clip	1

THROTTLE CHOKE AND FUEL CONTROLS POWER PLUS




THROTTLE CHOKE AND FUEL CONTROLS POWER PLUS

Ref. No.	Part No.	Description	No. Used
1	115392	Control - Throttle	1
2	116454	Knob - Throttle Control	1
3	114951	Control - Choke	1
4	116454	Knob - Choke Control	1
5	910792	Screw #10-24 x 1/2	4
6	915740	Nut - Lock #10-24	4
7	NN10506	Filter - Fuel	1
8	57-9550	Clamp - Hose 7/16	1
9	59-0370	Cap - Fuel Fitting	1
10	82-1080	Clamp - Hose 1/2	7
13	106234	Tank - Fuel (Includes Items 20 & 21)	1
14	55-3570	Cap - Fuel	1
16	926697	Bolt 5/16-18 x 1 ST	2

Ref. No.	Part No.	Description	No. Used
17	3256-4	Washer 3/8	2
18	322-2	Bolt 5/16-18 x 5/8	3
19	3252-4	Washer - Lock 5/16	2
20	104047	Bushing	1
21	104048	Valve - Fuel Shut-Off	1
22	2739	Line - Fuel 53"	1
23	108898	Clamp	2
24	950154	Clamp 1/2" (13 cm) Dia.	2
*	105490	Clamp 1" (2.5 cm) Dia.	1
25	NN10302	Line - Fuel 12"	3
26	57-9080	Pump - Fuel	1
27	59-1050	Screw #10-24 x 5/8	2
28	NN10348	Clip - Wire	1
29	92-0923	Hose - Fuel	1

*Not Illustrated

ELECTRICAL SYSTEM




ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	111216	Switch – Ignition	1
2	920160	Washer – Internal Tooth Lock 5/8	1
3	101884	Nut – Special	1
4	62-7770	Key – Ignition, Padded	1
5	79-3600	Harness Assy – Wiring	1
6	104926	Switch – Connector Body Ignition, Part of 5	1
7	518105	Terminal – Part of 5	1
8	103480	Switch – Clutch Interlock, w/Item 16	1
9	120930	Body – Fuse, Part of 5	1
12	109355	Fuse 15 Amp ATO or ATC	1
*	109102	Fuse 25 Amp ATO or ATC	1
*	NN10277	Fuse 30 Amp ATO or ATC	1
13	111642	Barrier – Switch Insulator	2
14	38-1420	Switch – Seat	1
16	110502	Shield – Dirt	1
17	112185	Body – Connector, Part of 5	1
18	115411	Support – Switch	1
19	926671	Bolt 1/4-20 x 1/2 ST	1
20	111332	Switch – PTO Interlock	2
21	79-0060	Voltmeter	1
22	78-0080	Clamp – Voltmeter, Back	1
23	5924	Nut #10-32	2
28	109553	Cover – Terminal	1
30	321-4	Bolt 1/4-20 x 3/4	2
31	3256-22	Washer 1/4 SAE	4
32	116497	Nut 1/4-20	4

Ref. No.	Part No.	Description	No. Used
33	105842	Battery	1
34	106948	Tray – Battery	1
35	910794	Screw #10-24 x 3/4	1
36	32146-7	Nut 1/4-20	2
37	113969	Hook – Battery Hold Down	2
38	113010	Hold Down – Battery	1
39	114720	Tube – Drain	1
41	100571	Tie – Cable	1
44	102651	Terminal – Female 1/4 Part of 5	8
45	3253-3	Washer – Lock 1/4	4
48	920262	Washer – Special	1
51	78-0020	Meter – Hour, Complete (Includes Items 52-54)	1
52	114017	Clamp – Steel	1
53	920120	Washer – Lock	1
54	915962	Nut – Hex	1
55	8830	Clip	1
59	910478	Screw #4-40 x 1-1/4	2
60	915732	Nut #4-40	2
62	116397	Relay	1
63	519337	Clip – Cable	1
64	518105	Terminal – Part of 5	1
65	6921	Terminal – Shur Plug, Part of 5	1
68	518077	Terminal – Part of 5	2
69	111332	Switch – Parking Brake	1
70	915732	Nut – Hex #4-40	2
71	910948	Screw #4-40 x 3/4	2

*Not Illustrated

ELECTRICAL SYSTEM




ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	114210	Cable – Battery Ground (24")	1
2	113825	Cable – Battery (+) to Solenoid (40")	1
3	NN10824	Switch – Low Oil Pressure	1
4	109553	Cover – Terminal	2
5	3023	Clip – Small	1
6	321-4	Bolt 1/4-20 x 3/4	2
7	3256-22	Washer 1/4 SAE	4
8	116497	Nut 1/4-20	6
11	113969	Hook – Battery Hold Down	2
12	113010	Rod – Battery Hold Down	1
13	100571	Tie – Cable	1

Ref. No.	Part No.	Description	No. Used
16	NN10294	Harness – Engine Wiring	1
19	NN10278	Connector – Terminal, Male 2	1
20	114052	Harness – Headlight	1
21	109357	Connector – Terminal, Female 2	1
26	NN10348	Clip	1
27	NN10399	Screw 1/4-10 x 1/2	1
28	NN10425	Washer – Internal Tooth 1/4	1
29	NN10281	Connector – Terminal, Male 9	1
30	NN10279	Contact – Socket	1
32	109459	Clamp	2
33	926671	Hex – Bolt 1/4-20 x 1/2 ST	2
34	8830	Clip	1

ELECTRICAL SYSTEM




ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	117377	Harness – Wiring	1
2	114825	PC Board w/Lights	1
3	116796	Test Switch	1
4	111359	Nut – Hex	2
5	111767	Washer	1

Ref. No.	Part No.	Description	No. Used
6	111343	Bushing Assy & Indicator Lens	5
12	117217	Switch – Button	1
13	112506	Bracket	1
14	910756	Screw #4–40 x 1/2	2
15	915732	Nut #4–40	2

ELECTRICAL SYSTEM




ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	3023	Clip - Small	1
2	3253-17	Washer - Lock #10 (Optional)	4
3	105202	Base - Taillight, w/Bulb	2
4	910808	Screw #10-32 x 5/8 (Optional)	4
5	112564	Lens - Taillight	2
6	8043	Bulb - Light, Metal Base (Auto #1895)	2
*	109045	Bulb - Light, All Glass (Auto #194)	2
9	109495	Retainer - Headlight LH	1
10	518104	Terminal	1
11	8830	Clip	1
12	926671	Bolt 1/4-20 x 1/2 ST	2
13	102138	Switch - Light	1
14	920259	Washer - Special	1

Ref. No.	Part No.	Description	No. Used
15	113179	Nut	1
16	102950	Ring - Retaining	1
17	109459	Clamp	2
18	109494	Retainer - Headlight RH	1
19	3269-3	Rivet - Pop 3/16 x 402 Aluminum (Production)	4
20	8519	Clip - Large	1
21	100571	Tie - Cable	1
22	3296-29	Nut 5/16-18	1
23	3254-2	Washer - Lock 5/16	1
25	102881	Headlight	2
26	3256-23	Washer 5/16 SAE	1
27	915551	Nut #10-32 (Optional)	4
29	3256-21	Washer #8 (Used with Pop Rivet)	4

*Not Illustrated

WHEELS AND TIRES




WHEELS AND TIRES

Ref. No.	Part No.	Description	No. Used
1	109500	Fitting - Grease	2
2	78-1660	Wheel - Front	2
3	117127	Tire - Front 16 x 650-8	2
7	116744	Tire - Turf Trac, Rear 23 x 950-12,	2
8	7607	Tire - Cleat, Rear 23 x 850-12	2
9	111516	Wheel - Rear 12 x 7	2
10	5108	Stem - Valve	2
11	110513	Bearing - Ball	4
12	7007	Tube - Rear	2
*	100291	Tube - Cleat Tires	2
13	111951	Hubcap	2
14	3272-17	Pin - Cotter 5/32 x 1/4	2
15	111952	Washer - Special Hub Cap	2
16	1278	Washer - Shim .050	A/R

Ref. No.	Part No.	Description	No. Used
17	5210	Washer - Shim .015	A/R
18	105763	Hub - Rear Wheel 1-1/8" I.D.	
19	3218-3	Nut - Jam 3/8-16	4
20	3243-5	Screw - Set 3/8-16x1	4
21	937108	Key - Woodruff 1/4 x 1-3/8	2
22	1004	Bolt - Lug	10
23	116743	Tire Assy - Rear Wheel	2
24	110934	Tire Assy - RH Cleat Wheel	1
	110933	Tire Assy - LH Cleat Wheel	1
25	78-1650	Tire Assy - Front Wheel	2
26	114426	Logo - Hub Cap 6" (Optional)	2
*	114427	Logo - Hub Cap 8" (Optional)	2
27	114428	Logo - Hub Cap 12" (Optional)	2
28	106826	Washer - Thrust	2

*Not Illustrated

PTO CLUTCH AND CONTROL




PTO CLUTCH AND CONTROL

Ref. No.	Part No.	Description	No. Used
1	111234	Lever – PTO Clutch	1
2	9038	Grip	1
3	106649	Ring – Grip	1
4	3765	Washer – Shim	2
5	5666	Bushing – Nyliner	1
6	5983	Bushing	1
7	3272-10	Pin – Cotter 1/8 x 3/4	1
11	111052	Rod – PTO Clutch	1
12	3272-10	Pin – Cotter 1/8 x 3/4	2
13	103125	Spring	1
14	110656	Trunnion	1
16	323-7	Bolt 3/8-16 x 1-1/4	1
17	110669	Plate – PTO	1
18	104859	Spacer	1
19	3296-39	Nut 3/8-16	1
20	933505	Pin – Cotter	1
21	3218-1	Nut – Jam 1/4-20	2
22	3256-22	Washer 1/4 SAE	2
23	110665	Brake Assembly – PTO	1
24	3229-25	Bolt – Carriage 1/4-20 x 3/4	2

Ref. No.	Part No.	Description	No. Used
25	113853	Bracket – Engine	1
28	111314	Pin – Locking	1
29	113107	Clevis	1
30	933274	Pin – Spirol 5/32 x 1-3/8	1
31	113108	Rod – PTO Housing	1
32	933506	Pin – Cotter	1
33	102872	Shaft – Stub	1
34	32120-72	Ring – Snap 3/4 External	2
35	936032	Ring – Snap 1-3/4 Internal	1
36	109842	Bearing – Ball	1
37	103478	Housing – Pulley	1
38	106769	Bearing – Needle	1
39	6662	Seal	1
40	6658	Race – Bearing	1
41	321-3	Bolt – Nylok 1/4-20 x 5/8	4
42	6659	Retainer	2
43	114881	Facing – Clutch Plate	1
45	106695	Push-On Ring	1
47	3253-3	Washer – Lock 1/4	1
48		Washer – Flat	1

SEAT



SEAT

Ref. No.	Part No.	Description	No. Used
1	79-0670	Seat	1
2	114263	Spring - Seat	2
3	322-3	Bolt 5/8-18 x 3/4	4
4	3253-4	Washer - Lock 5/16	8
5	3296-29	Nut 5/16-18	4
6	3256-23	Washer 5/16 SAE	4
7	322-4	Bolt 5/16-18 x 7/8	4
8	78-2990	Plate - Seat Pivot	1
9	111071	Bumper	2
13	322-4	Bolt 5/16-18 x 7/8	2
14	105503	Bushing	2
15	3296-29	Nut 5/16-18	2
16	112744	Bracket - Pivot RH	1
*	112745	Bracket - Pivot LH	1
17	913464	Bolt 5/16-18 x 7/8	4
18	3256-23	Washer 5/16 SAE	4
22	3253-4	Washer - Lock 5/16	4

Ref. No.	Part No.	Description	No. Used
23	114264	Adjuster - RH (With Latch)	1
24	114265	Adjuster - LH	1
25	109989	Spacer	4
26	910865	Screw 5/16-18 x 3/4	4
27	3256-3	Washer 5/16 SAE	4
28	3217-6	Nut 5/16-18	4
29	110932	Spacer	4
34	3296-29	Nut 5/16-18	2
36	78-3240	Spring	1
37	3296-42	Nut 1/4-20	2
38	3256-22	Washer 1/4 SAE	2
39	321-8	Bolt 1/4-20 x 1-1/4	2
40	78-3250	Spacer	1
41	114345	Bracket	1
*	79-3670	Seat Assy - Deluxe (Includes Items 1,23,24,25,26 & 29)	1

*Not Illustrated

DECALS

Ref. No.	Part No.	Description	No. Used
1	79-4640	Decal - Hood RH	1
2	79-4650	Decal - Hood LH	1
4	111510	Decal - Parking Brake	1
5	111960	Decal - PTO Clutch	1
9	117760	Decal - Rear Fender	1
10	118540	Decal - Power Plus	1
11	117509	Decal - Front Hood	1
14	119220	Decal - Switch Plate	1
15	119200	Decal - Lower Dash	1

Ref. No.	Part No.	Description	No. Used
17	111534	Decal - Hi-Low Shift	1
18	117513	Decal - 8-Speed	2
20	115197	Decal - Attach-A-Matic	1
21	112168	Decal - Lift	1
22	110831	Plastic Tractor Cover	1
23	115398	Decal - Maintenance	1
24	111926	Decal - Electrical System	1
25	104955	Decal - Unidrive	1
*	807298	Loose Parts	1

*Not Illustrated

TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
5638	Axle - Front	9 11	6542	Grip - Lift Lever	15 6 1
7466	Pulley - Engine Drive	3 1 1	6658	Race - Bearing	59 40 1
1001	Knob - Hi-Lo Range Shift	7 75 1	6659	Retainer	59 42 2
1004	Bolt - Lug	57 22 10	6662	Seal	59 39 1
1030	Fitting - Grease, Straight	9 2 2	6739	Trunnion	15 20 1
1085	Collar	11 10 2	6820	Grip	11 35 1
1085	Collar	9 26 1	6921	Terminal - Shur Plug, Part of	54965 1
1121	Key 1/4 Sq x 1-3/16	15 18 1	7007	Tube - Rear	57 12 2
1239	Screw - Set - Special	7 47 1	7201	Shaft - Input	5 19 1
1243	Cup - Plug	5 28 1	7204	Gear	5 21 1
1278	Washer	9 33 2	7205	Gear - Sliding	5 24 1
1278	Washer - Shim .050	57 16A/R	7206	Gear - Reduction	5 25 1
1278	Washer - Shim 3/4 x .050	11 13 1	7207	Bearing - Needle 3/8 I.D.	5 26 2
1278	Washer - Shim 3/4 x .050	9 17 1	7208	Shaft - Reduction Gear	5 27 1
1481	Fitting - Grease, 45°	9 3 1	7213	Bolt - Detent	7 57 1
1481	Fitting - Grease, 45°	9 22 1	7214	Shaft - Shift Hi-Low Range	7 58 1
1504	Bushing - Bronze	7 37 2	7269	Cluster Gear With Bushing	7 36 1
1516	Bushing - Reverse Idler	7 43 1	7418	Washer - Thrust	5 20 1
1518	Bearing - Needle 5/8 I.D.	5 22 4	7451	Pulley - Idler	11 42 1
1523	Bearing - Needle 3/4 I.D.	5 16 1	7456	Clamp	21 11 4
1529	Bearing - Needle 3/4 I.D.	5 12 1	7607	Tire - Cleat, Rear 23 x 850-1257	8 2
1531	Bearing - Needle 5/8 I.D.	5 17 1	7879	Bushing	11 24 2
1532	Bearing - Needle 1 I.D.	5 9 2	7896	Washer - Bowed	11 12 1
1542	Bearing - Needle 5/8 I.D.	5 10 1	7896	Washer - Bowed	9 29 1
1644	Hitch - Drawbar	13 9 1	8043	Bulb - Light, Metal Base	55 6 2
2739	Line - Fuel 53	47 22 1	8130	Retainer - Spring	15 3 1
2844	Washer - Special	11 3 1	8519	Clip - Large	55 20 1
3023	Clip	19 26 1	8616	Spring	13 7 2
3023	Clip - Small	55 1 1	8830	Clamp	15 52 1
3023	Clip - Small	51 5 1	8830	Clip	55 11 1
3503	Fork - Shift	5 33 2	8830	Clip	51 34 1
3517	Ball - Detent 1/4 Dia.	7 55 2	8830	Clip	49 55 1
3517	Ball - Detent 1/4 Dia.	7 60 1	9038	Grip	59 2 1
3527	Gear - Reduction	7 38 1	9038	Grip	13 22 1
3577	Cover - Dust	7 49 1	9416	Bearing - Needle 1-1/8 I.D.	5 11 2
3624	Spring	15 4 1	9547	Washer - Thrust	7 50 1
3765	Washer - Shim	59 4 2	9593	Band - Brake	11 4 1
3765	Washer - Shim 1/2 x .0301	11 21 1	9598	Plate - Back-Up	11 7 1
3909	Pin - Reverse Idler	7 42 1	9840	Shaft - Cluster	7 39 1
3912	Gasket - Transmission Case	7 46 1	100291	Tube - Cleat Tires	57 * 2
3915	Pin - Locating	5 15 2	100441	Seal - Brake Shaft 3/4 I.D.	5 18 1
4204	Gear - Reverse Idler	7 41 1	100442	Seal - Input Shaft 5/8 I.D.	5 13 1
4944	Button - Plug	15 8 1	100443	Seal - Axle 1 1/8 I.D. x 1-3/8	5 14 2
5108	Stem - Valve	57 10 2	100571	Tie - Cable	51 13 1
5173	Gear - 2nd & 3rd	5 29 1	100571	Tie - Cable	55 21 1
5174	Gear - 1st & Reverse	5 30 1	100571	Tie - Cable	49 41 1
5175	Gear	5 23 1	101161	Trunnion - Clutch Rod	11 22 1
5210	Washer - Shim .015	57 17A/R	101623	Gear - Differential Pinion 11	7 70 8
5210	Washer - Shim 3/4 x .015	9 16 1	101625	Gear 11 Tooth	7 52 1
5224	Cap	23 28 1	101626	Gear 44 Tooth	7 53 1
5280	Knob - Height Control	15 40 1	101707	Lock	13 6 1
5614	Pin - Shift	5 35 1	101711	Housing - Front Hitch	13 1 1
5615	Rail - Shift, Front	5 31 1	101750	Rod	13 3 1
5616	Rail - Shift, Rear	5 32 1	101751	Rod-Front Hitch Lock	13 4 1
5618	Ring - Retaining	9 8 1	101847	Dipstick Assembly	7 44 1
5618	Ring - Retaining	13 12 2	101850	Rod - Hood Stop	17 8 1
5666	Bushing - Nyliner	59 5 1	101884	Nut - Special	49 3 1
5701	Ring - Retaining	15 29 1	101889	Gear - Differential	7 71 2
5924	Nut 10-32	49 23 2	102025	Spacer	11 36 1
5983	Bushing	59 6 1	102138	Switch - Light	55 13 1
5983	Bushing - Hood	17 * 2	102644	Plate - Mid Hitch	13 15 2
6216	Pin & Plate	9 4 1	102651	Terminal - Female 1/4	49 44 8
6229	Bearing	15 28 1	102703	Nipple - Transmission Fill	7 45 1
6397	Bearing - Lower Steering Shaft	9 23 1	102809	Nut - Special	11 39 1
6472	Bearing - Flanged	9 12 1	102872	Shaft - Stub	59 33 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3315-325

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
102881	Headlight	55 25 2	107069	Clip	21 8 3
102950	Ring - Retaining	55 16 1	107069	Nut - Speed	19 15 6
102974	Gear Assembly	7 51 1	107374	Washer - Special, Case	7 66 4
103125	Spring	59 13 1	107677	Spring - Brake Return	11 40 1
103347	Rod - Clutch	11 14 1	107939	Belt - Drive	3 6 1
103478	Housing - Pulley	59 37 1	107951	Bracket - Fender Front	21 14 1
103480	Switch - Clutch Interlock,	49 8 1	108035	Spring - Clutch Return	11 48 1
103543	Bell Crank - Brake Linkage	11 23 1	108457	Nut - Push	21 32 1
103628	Spring - Parking Brake	11 41 1	108464	Support - Fuel Tank, LH	21 19 1
104047	Bushing	47 20 1	108563	Lever - Lift	15 1 1
104048	Valve - Fuel Shut-Off	47 21 1	108565	Shaft	15 46 1
104248	Grommet	19 18 1	108758	Knob - Gear Shift	7 54 2
104822	Ring - Retaining	9 34 2	108881	Nut 3/8-16 High-Tensile	7 67 4
104859	Spacer	59 18 1	108897	Bracket - Fender Support	21 18 1
104926	Switch - Connector Body	49 6 1	108898	Clamp	47 23 2
104955	Decal - Unidrive	63 25 1	108903	Clamp - Tube	15 31 1
105061	Gear - Differential Ring	7 68 1	109045	Bulb - Light, All Glass	55 * 2
105202	Base - Taillight, w/Bulb	55 3 2	109102	Fuse 25 Amp ATO or ATC	49 * 1
105269	Shaft-Drawbar Hitch	13 10 1	109189	Bearing - Upper Steering	9 24 1
105316	Cap - Rod	15 7 2	109262	Washer - Special	9 32 1
105316	Cap-Lock Rod	13 8 2	109355	Fuse 15 Amp ATO or ATC	49 12 1
105453	Key 1/4 x 1/4 x 3/4	3 3 1	109357	Connector - Terminal	51 21 1
105490	Clamp 1 (2.5 cm) Dia.	47 * 1	109459	Clamp	55 17 2
105503	Bushing	61 14 2	109459	Clamp	51 32 2
105763	Hub - Rear Wheel 1-1/8 I.D.	57 18	109494	Retainer - Headlight RH	55 18 1
105797	Ring - Retaining	13 5 8	109495	Retainer - Headlight LH	55 9 1
105797	Ring - Retaining	17 6 2	109500	Fitting - Grease	57 1 2
105842	Battery	49 33 1	109553	Cover - Terminal	51 4 2
105845	Tube - Rear Lift Cable	15 30 1	109553	Cover - Terminal	49 28 1
105859	Latch-Front Hitch	13 2 1	109554	Bracket	21 17 1
105875	Axle - Rear (1-1/8 dia)	7 72 2	109842	Bearing - Ball	59 36 1
105876	Ring - Special, Snap	7 73 2	109989	Spacer	61 25 4
105886	Rod - Brake, Front	11 29 1	110142	Trim - Edge	19 23 1
105896	Arm - Clutch Rod	11 18 1	110234	Bolt 3/8-16 x 3/4 Nylok	11 2 1
105900	Rod - Brake, Rear	11 28 1	110502	Shield - Dirt	49 16 1
106030	Spring - Detent	7 56 1	110513	Bearing - Ball	57 11 4
106030	Stop - Shift	7 61 1	110636	Pad - Footrest	21 13 2
106165	Pulley - Transmission Drive	3 7 1	110653	Rod - Height Control	15 34 1
106177	Shaft - Upper Steering	9 25 1	110656	Trunnion	59 14 1
106193	Bolt - Special 3/8-16 x 1-1/2	43 1	110665	Brake Assembly - PTO	59 23 1
106222	Footrest - RH	21 6 1	110669	Plate - PTO	59 17 1
106223	Footrest - LH	21 7 1	110725	Lever - Gear Shift	7 74 1
106234	Tank - Fuel	47 13 1	110727	Lever - Shift Hi-Low Range	7 62 1
106236	Support - Fuel Tank, RH	21 20 1	110831	Plastic Tractor Cover	63 22 1
106250	Cover - Dust	19 16 1	110932	Spacer	61 29 4
106257	Rod - Latch	15 2 1	110933	Tire Assy - LH Cleat Wheel	57 1
106258	Sleeve	15 39 1	110934	Tire Assy - RH Cleat Wheel	57 24 1
106261	Bracket - Belt	19 3 1	110995	Transmission Assy	5 1
106269	Bushing	15 16 2	111034	Plate - Hood Stand	19 20 1
106345	Casting - Height Control	15 37 1	111052	Rod - PTO Clutch	59 11 1
106352	Guard - Lower Belt	21 5 1	111071	Bumper	61 9 2
106411	Latch Bracket	15 41 1	111071	Bumper	21 31 2
106414	Retainer	15 17 1	111154	Wire - Lock	15 53 1
106417	Rod - Bell Crank Pivot	11 26 1	111196	Cap - Diff End	7 64 2
106451	Lever - Parking Brake	11 34 1	111198	Case-Trans, LH	5 2 1
106454	Trim - Edge	19 25 1	111199	Bearing - Ball 40mm I.D.	5 8 2
106522	Chain - Lift	15 22 1	111200	Case-Trans, RH	5 1 1
106634	Pin - Hitch	13 13 1	111216	Switch - Ignition	49 1 1
106649	Ring - Grip	59 3 1	111234	Lever - PTO Clutch	59 1 1
106695	Push-On Ring	59 45 1	111271	Console	17 4 1
106719	Drum - Brake	11 1 1	111314	Pin - Locking	59 28 1
106769	Bearing - Needle	59 38 1	111332	Switch - PTO Interlock	49 20 2
106772	Trim - Edge 4	19 11 1	111332	Switch - Parking Brake	49 69 1
106826	Washer - Thrust	57 28 2	111343	Bushing Assy	53 6 5
106948	Tray - Battery	49 34 1	111357	Clip	23 31 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
111359	Nut - Hex	53	4	2	116000	Bolt - Carriage 5/16-18 x 3/4	421	3	1
111386	Plate - Shift Cover	19	19	1	116000	Bolt - Carriage 5/16-18 x 3/4	421	9	6
111392	J-Clip	17	23	1	116397	Relay	49	62	1
111510	Decal - Parking Brake	63	4	1	116454	Knob - Choke Control	47	4	1
111516	Wheel - Rear 12 x 7	57	9	2	116454	Knob - Throttle Control	47	2	1
111534	Decal - Hi-Low Shift	63	17	1	116470	Muffler 416	23	24	1
111642	Barrier - Switch Insulator	49	13	2	116497	Nut 1/4-20	51	8	6
111646	Ring - Grip	9	36	1	116497	Nut 1/4-20	49	32	4
111757	Edging - Console	17	22	1	116609	Plate - Engine	23	2	1
111767	Washer	53	5	1	116636	Fork - Shift Hi-Low Range	7	59	1
111926	Decal - Electrical System	63	24	1	116743	Tire Assy - Rear Wheel	57	23	2
111951	Hubcap	57	13	2	116744	Tire - Turf Trac, Rear 23 x	57	7	2
111952	Washer - Special Hub Cap	57	15	2	116745	Rod - Pivot	17	7	1
112168	Decal - Lift	63	21	1	116746	Bracket - RH	17	10	1
112185	Body - Connector	49	17	1	116747	Bracket - LH	17	11	1
112358	Hood	17	1	1	116796	Test Switch	53	3	1
112415	Stop - PTO	17	21	1	117127	Tire - Front 16 x 650-8	57	3	2
112506	Bracket	53	13	1	117217	Switch - Button	53	12	1
112506	Bracket	17	18	1	117337	Steering Wheel	9	30	1
112564	Lens - Taillight	55	5	2	117341	Latch - Hood	17	2	2
112744	Bracket - Pivot RH	61	16	1	117371	Bolt - Carriage 5/16-18 x 1/2	219	6	4
112745	Bracket - Pivot LH	61	*	1	117377	Harness - Wiring	53	1	1
113010	Hold Down - Battery	49	38	1	117431	Rivet - Pop 1/8 x .232	17	16	2
113010	Rod - Battery Hold Down	51	12	1	117432	Rivet - Pop 1/8 x .294	17	3	4
113107	Clevis	59	29	1	117509	Decal - Front Hood	63	11	1
113108	Rod - PTO Housing	59	31	1	117513	Decal - 8-Speed	63	18	2
113179	Nut	55	15	1	117760	Decal - Rear Fender	63	9	1
113381	Spindle - Front, LH	9	7	1	117930	Latch-Mid Hitch	13	17	1
113382	Spindle - Front, RH	9	*	1	117940	Rod-Mid Hitch Lock	13	16	1
113443	Tube - Steering	9	28	1	118280	Holder - Fuse	21	36	1
113445	Bar - Lift	15	27	1	118540	Decal - Power Plus	63	10	1
113825	Cable - Battery (+) to	51	2	1	118620	Bolt - Carriage 5/16-18 x 3/4	421	33	2
113853	Bracket - Engine	59	25	1	119200	Decal - Lower Dash	63	15	1
113935	Cover - Side, LH	19	13	1	119220	Decal - Switch Plate	63	14	1
113969	Hook - Battery Hold Down	51	11	2	120320	Guide - Belt	3	17	1
113969	Hook - Battery Hold Down	49	37	2	120590	Stop - Throttle	17	17	1
114017	Clamp - Steel	49	52	1	201327	Screw	41	28	3
114052	Harness - Headlight	51	20	1	518077	Terminal - Part of 5	49	68	2
114131	Bracket - Damper	11	52	1	518104	Terminal	55	10	1
114210	Cable - Battery Ground (24)	51	1	1	518105	Terminal - Part of 5	49	7	1
114214	Gasket - Exhaust	23	30	2	518105	Terminal - Part of 5	49	64	1
114215	Cover - Exhaust, LH	23	22	1	519337	Clip - Cable	49	63	1
114216	Cover - Exhaust, RH	23	23	1	807298	Loose Parts	63	*	1
114217	Deflector - Air	23	21	1	908035	Bolt 3/8-16 x 1-1/4	23	3	4
114263	Spring - Seat	61	2	2	908035	Bolt 3/8-16 x 1-1/4	23	5	4
114264	Adjuster - RH (With Latch)	61	23	1	910331	Screw 10-24 x 3/8	23	20	4
114265	Adjuster - LH	61	24	1	910478	Screw #4-40 x 1-1/4	49	59	2
114345	Bracket	61	41	1	910756	Screw #4-40 x 1/2	53	14	2
114426	Logo - Hub Cap 6	57	26	2	910762	Screw - Black #6-32 x 3/8	17	20	4
114427	Logo - Hub Cap 8	57	*	2	910792	Screw 10-24 x 1/2	47	5	4
114428	Logo - Hub Cap 12	57	27	2	910794	Screw 10-24 x 3/4	49	35	1
114636	Pipe 3/8 x 3	23	25	1	910808	Screw 10-32 x 5/8	55	4	4
114720	Tube - Drain	49	39	1	910837	Screw - Black 1/4-20 x 5/8	19	14	6
114763	Pipe 3/8 x 4	23	27	1	910837	Screw 1/4-20 x 5/8	21	2	2
114764	Elbow - 90°	23	26	1	910837	Screw 1/4-20 x 5/8	19	24	1
114813	Pedal - Brake	11	9	1	910865	Screw 5/16-18 x 3/4	61	26	4
114814	Pedal - Clutch	11	8	1	910948	Screw #4-40 x 3/4	49	71	2
114825	PC Board w/Lights	53	2	1	911423	Bolt 3/8-16 x 3-1/2	7	65	4
114877	Guard - Belt	21	1	1	913464	Bolt 5/16-18 x 7/8	61	17	4
114881	Facing - Clutch Plate	59	43	1	915002	Nut 3/8-24	9	39	1
114951	Control - Choke	47	3	1	915035	Nut - Slotted 3/4-16	9	37	1
115197	Decal - Attach-A-Matic	63	20	1	915551	Nut 10-32	55	27	4
115392	Control - Throttle	47	1	1	915553	Nut 3/8-16	23	4	4
115398	Decal - Maintenance	63	23	1	915693	Nut 3/8-24	9	11	4
115411	Support - Switch	49	18	1	915732	Nut #4-40	53	15	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3315-325

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
915732	Nut #4-40	49 60 2	NN10037	Insert - Intake Seat .005	25 2
915732	Nut - Hex #4-40	49 70 2	NN10038	Insert - Intake Seat .010	25 2
915740	Nut - Lock 10-24	47 6 4	NN10039	Insert - Intake Seat .025	25 2
915962	Nut - Hex	49 54 1	NN10054	Insert - Exhaust Seat, Standard	25 13
920008	Washer 5/16 SAE	21 24 4			
920120	Washer - Lock	49 53 1	NN10055	Insert - Exhaust Seat .002	25 2
920150	Washer - Lock	17 19 4	NN10056	Insert - Exhaust Seat .005	25 2
920160	Washer - Lock 5/8	49 2 1	NN10057	Insert - Exhaust Seat .010	25 2
920225	Washer - Special	11 49 1	NN10058	Insert - Exhaust Seat .025	25 2
920248	Washer - Nylon 3/8	11 19 3	NN10070	Gasket	25 36 2
920248	Washer - Nylon 3/8	11 30 2	NN10075	Valve - Exhaust	25 29 2
920259	Washer - Special	55 14 1	NN10075	Valve - Intake	25 28 2
920262	Washer - Special	49 48 1	NN10077	Spring	25 31 4
926671	Bolt 1/4-20 x 1/2 ST	55 12 2	NN10078	Washer	25 38 4
926671	Bolt 1/4-20 x 1/2 ST	49 19 1	NN10079	Head - Left Cylinder	25 1
926671	Hex - Bolt 1/4-20 x 1/2 ST	51 33 2	NN10080	Head - Right Cylinder	25 37 1
926694	Bolt - Washer Hd ST	17 5 3	NN10082	Lock - Spring	25 32 8
926694	Bolt 5/16-18 x 5/8 ST	19 4 1	NN10100	Piston Pin	25 55 2
926694	Bolt 5/16-18 x 5/8 ST	21 4 1	NN10120	Bolt - Special Rod	25 59 4
926694	Bolt 5/16-18 x 5/8 ST	19 10 1	NN10125	Rod w/Bolts & Nuts - STD	25 58 2
926694	Bolt 5/16-18 x 5/8 ST	19 12 4	NN10126	Rod w/Bolts & Nuts - .010	25 2
926694	Bolt 5/16-18 x 5/8 ST	19 17 4	NN10127	Rod w/Bolts & Nuts - .020	25 2
926694	Bolt 5/16-18 x 5/8 ST	21 23 4	NN10128	Rod w/Bolts & Nuts - .030	25 2
926694	Bolt 5/16-18 x 5/8 ST	11 27 1	NN10129	Tappet - Standard	25 27 4
926694	Bolt 5/16-18 x 5/8 ST	15 42 1	NN10130	Tappet .002 O.S.	25 4
926696	Bolt 5/16-18 x 7/8 ST	19 * 2	NN10131	Tappet .004 O.S.	25 4
926696	Bolt 5/16-18 x 7/8 ST	15 45 2	NN10133	Spring	25 52 1
926697	Bolt 5/16-18 x 1 ST	47 16 2	NN10134	Pump - Oil, Gasket Kit	25 47 1
932000	Pin - Cotter 1/16 x 1/2	17 9 2	NN10135	Plunger	25 53 1
933148	Pin - Spirol 1/8 x 1/2	15 5 1	NN10136	Pump - Oil, Complete	25 46 1
933156	Pin - Spirol 1/8 x 1	5 34 2	NN10138	Cup - Oil Pump Intake	29 8 1
933184	Pin - Spirol 3/16 x 3/4	7 63 1	NN10143	Filter - Oil	31 7 1
933190	Pin - Spirol 3/16 x 1-1/4	11 17 1	NN10159	Cap - Oil Fill & Indicator	29 9 1
933267	Pin - Spirol 5/32 x 1-1/4	11 50 1	NN10171	Flywheel	27 15 1
933274	Pin - Spirol 5/32 x 1-3/8	59 30 1	NN10174	Element - Air Cleaner	35 4 1
933504	Pin - Cotter	15 21 1	NN10176	Element - Foam	35 3 1
933505	Pin - Cotter	59 20 1	NN10187	Tube - Air Intake	35 11 1
933505	Pin - Cotter	15 54 1	NN10199	Jet - Power	39 6 1
933505	Pin - Cotter	13 14 1	NN10201	Jet - Idle	39 5 1
933506	Pin - Cotter	59 32 1	NN10207	Kit - Choke Shaft	39 7 1
933507	Pin - Cotter	15 14 2	NN10209	Kit - Float	39 1 1
936032	Ring - Snap 1-3/4 Internal	59 35 1	NN10214	Pin	27 14 1
937108	Key - Woodruff 1/4 x 1-3/8	57 21 2	NN10215	Ring - Retaining	27 6 1
937221	Key - Hi-Pro 5/32 x 5/8	3 4 1	NN10217	Spring - Governor, 5 Ball	41 11 1
950154	Clamp 1/2 (13 cm) Dia.	47 24 2	NN10218	Bushing	41 20 1
979120	Spacer	13 11 2	NN10219	Spring	41 16 1
78-2680	Frame	2 1 1	NN10221	Hub - Governor Cup	27 7 1
79-6350	Knob - Toolless	35 29 1	NN10222	Cup - Governor	27 8 1
Carburetor (Includes Mounting)		371NN1	NN10245	Battery Ignition Coil - w/Nuts	33 31 1
0504	1		NN10247	Rotor - Ignition	33 32 1
NN0980	Capacitor (300 VD)	35 20 1	NN10248	Nut	33 36 1
NN10003	Bearing - Crankshaft, Front,	25 15 1	NN10249	Nut	33 39 1
NN10004	Bearing - Crankshaft, Front	25 1	NN10261	Regulator - Voltage 20 amp	33 28 1
NN10005	Bearing - Crankshaft, Front	25 1	NN10266	Kit - Starter Shift Lever	43 7 1
NN10006	Bearing - Crankshaft, Front	25 1	NN10277	Fuse 30 Amp ATO or ATC	49 * 1
NN10007	Bearing - Crankshaft, Front	25 1	NN10278	Connector - Terminal, Male	251 19 1
NN10010	Bearing - Crankshaft, Rear	25 1	NN10279	Contact - Socket	51 30 1
NN10012	Bearing - Crankshaft, Rear	25 1	NN10281	Connector - Terminal, Male	951 29 1
NN10013	Bearing - Crankshaft, Rear	25 1	NN10289	Clamp	41 6 1
NN10018	Base - Oil	291 1	NN10289	Clamp	41 9 1
NN10021	Screw	27 16 1	NN10290	Terminal - Stator Leads	33 18 3
NN10030	Washer	27 13 1	NN10294	Harness - Engine Wiring	51 16 1
NN10032	Camshaft	27 11 1	NN10296	Bracket - Lifting	41 56 2
NN10035	Insert - Intake Seat, Standard	25 14 2	NN10302	Line - Fuel 12	47 25 3
NN10036	Insert - Intake Seat .002	25 2	NN10309	Grommet - 3/4 Hole	35 16 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
NN10320	Swivel - Throttle Control	41 30 1	NN10854	Tube - Oil Fill, Chrome	29 12 1
NN10323	Ring - Oil	29 10 1	NN10858	Hose - Fuel	37 16 1
NN10326	Seal	25 33 2	NN10862	Housing - Blower	41 1 1
NN10327	Bearing	33 8 1	NN10877	Spring - Governor Rod	37 20 1
NN10330	Key	27 5 1	NN10825	Kit - Gearcase	33 1 1
NN10334	Pin - Stop	25 11 4	NN10853	Crankshaft	27 1 1
NN10335	Pin - Dowel	33 6 1	NN10883	Kit - Starter Brush	43 11 1
NN10336	Pin	25 20 2	NN10884	Clutch - Starter	43 6 1
NN10345	Retaining Ring	25 56 4	NN10885	Starter Hdw Kit	43 1 1
NN10348	Clip	51 26 1	NN10886	Seal - Dust	43 5 1
NN10348	Clip - Fuel Line	37 9 1	NN10887	Kit - Starter Solenoid	43 8 1
NN10348	Clip - Wire	47 28 1	NN10894	Drain - Oil Filter	31 4 1
NN10348	Clip - Wire	33 37 1	NN10895	Gasket	33 10 1
NN10348	Clip - Wire	41 55 1	NN10929	Holder - Starter Brush	43 13 1
NN10352	Stud - Gear Cover	33 14 1	NN10930	Cap - Starter Solenoid	43 9 1
NN10355	Washer 7/16	27 18 1	38-1420	Switch - Seat	49 14 1
NN10356	Washer - Flat 1/4	41 10 1	55-3570	Cap - Fuel	47 14 1
NN10357	Washer - Flat 1/4	41 19 1	57-8000	Seal - Oil	25 10 1
NN10359	Washer 1/4	25 42 2	57-8050	Bearing - Crankshaft, Rear,	25 5 1
NN10361	Washer 3/8	25 51 1	57-8060	Bearing - Crankshaft, Rear	25 1 1
NN10362	Washer - Flat 5/16	37 15 1	57-8090	Gasket	29 2 1
NN10370	Bolt 1/4-20 x 1-3/4	25 30 2	57-8160	Bearing - Camshaft	25 9 2
NN10373	Screw 5/16-18 x 1	31 3 2	57-8160	Washer - Thrust	25 6 2
NN10375	Screw - Hex. Hd. 5/16 x 2	37 8 4	57-8170	Shim 0.005	25 4 X
NN10379	Screw 3/8-16 x 3-3/4	29 4 4	57-8180	Gear - Ring	27 22 1
NN10381	Bolt - Special 2 Long	25 41 10	57-8210	Camshaft Gear	27 12 1
NN10385	Screw 3/8-16 x 5/8	25 34 2	57-8280	Gasket	25 26 2
NN10390	Screw - Hex. Hd. 10-32 x 5/8	35 22 1	57-8580	Breather - Baffle	25 22 1
NN10393	Screw 1/4-20 x 5/8	41 8 4	57-9080	Pump - Fuel	47 26 1
NN10394	Screw - Hex. Hd. 10-32 x 3/8	33 24 2	57-9170	Swivel - Choke Lever	45 8 1
NN10395	Screw 10-32 x 1/2	41 14 1	57-9180	Link - Choke	45 3 1
NN10399	Screw 1/4-10 x 1/2	51 27 1	57-9190	Clamp - Cable	41 12 1
NN10408	Screw - Hex. Hd. 1/4-20 x 1	33 41 2	57-9190	Clamp - Throttle Cable	41 23 1
NN10409	Screw 10-24 x 3/8	27 19 6	57-9190	Clip	45 12 1
NN10410	Screw #8-32 x .375	45 9 1	57-9340	Plug - Spark	33 33 2
NN10410	Screw - Machine	41 32 1	57-9550	Clamp	33 19 1
NN10412	Screw 10-32 x 1-1/4	45 5 1	57-9550	Clamp - Hose 7/16	47 8 1
NN10414	Screw - Hex. Hd.	33 27 1	57-9570	Seal - Oil	33 7 1
NN10414	Screw 1/4-20 x 5/16	41 38 4	57-9580	Seal - Oil	33 9 1
NN10425	Washer - Internal Tooth 1/4	51 28 1	57-9620	O-Ring	37 14 1
NN10426	Nut 5/6-18	33 16 1	57-9640	Ball	27 9 1
NN10428	Nut	25 60 4	57-9650	Bearing	33 2 1
NN10438	Gear	27 4 1	57-9660	Key	27 10 1
NN10439	Washer	27 3 1	57-9690	Plug	25 2 1
NN10444	Control - Ignition	33 22 1	57-9700	Clip - Retaining, Rod to	37 12 1
NN10465	Wrench	31 8 1	57-9710	Ring - Retaining	27 2 1
NN10478	Guide - Intake Valve	25 2 2	57-9730	Clip - Retaining	33 26 1
NN10479	Guide - Exhaust Valve	25 16 2	57-9750	Washer 5/16	31 2 2
NN10506	Filter - Fuel	47 7 1	57-9750	Washer 5/16	33 12 5
NN10515	Cover - Ignition Plunger	33 30 1	57-9770	Washer - Flat 1/4	25 40 18
NN10516	Indicator - Ignition Module	33 42 1	57-9770	Washer - Flat 5/16	43 3 2
NN10518	Stator w/Terminals	33 17 1	59-0290	Tube - Oil	25 12 1
NN10554	Gasket	25 7 1	59-0360	Tube - Vacuum Port	33 13 1
NN10690	Seal	29 13 1	59-0370	Cap	33 20 1
NN10768	Nut	43 10 1	59-0370	Cap - Fuel Fitting	47 9 1
NN10784	Screw 10-32 x 7/8	45 11 1	59-0420	Yoke	33 4 1
NN10809	Kit - Choke Lever	39 8 1	59-0460	Lever - Choke	45 2 1
NN10810	Kit - Fixed Jet	39 4 1	59-0470	Bracket	45 4 1
NN10811	Kit - Throttle Shaft	39 9 1	59-0720	Pin - Cotter	45 10 1
NN10821	Cover - Valve	25 25 2	59-0720	Pin - Cotter	41 31 1
NN10824	Switch - Low Oil Pressure	51 3 1	59-0830	Washer - Flat 1/4	41 25 1
NN10824	Switch - Oil Pressure	31 10 1	59-0850	Washer 10	45 1 2
NN10826	Governor Shaft &	33 3 1	59-0880	Bolt 3/8-16 x 1-1/4	25 3 5
NN10830	Plug	45 7 1	59-0910	Bolt 3/8-24 x 7/8	25 50 1
NN10832	Bracket	41 41 1	59-0950	Screw #8-32 x 3/8	33 5 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3315-325

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
59-0970	Screw 1/4-20 x 7/16	41 2 1	82-0850	Gasket - Carburetor Mounting	39 3 1
59-0980	Screw 1/4-20 x 5/8	41 5 1	82-0930	Screw 1/4-20 x 1/2	41 42 2
59-1000	Screw 10-32 x 1/2	41 22 1	82-1000	Kit - Terminal Connector Body	3321 1
59-1030	Screw #6-32 x 5/8	41 15 1	82-1080	Clamp - Hose 1/2	47 10 7
59-1050	Screw 10-24 x 5/8	47 27 2	82-1090	Clamp - Hose	37 19 1
59-1050	Screw 10-32 x 1/2	41 35 2	82-1120	Hose - Breather	37 17 1
59-1080	Bushing - Black Nylon	41 37 1	82-1130	Plug - Sq Hd 3/8	29 5 2
59-1100	Screw 1/4-20 x 1/2	41 18 2	82-1150	Key	27 23 1
62-2730	Kit - Bushing	43 12 1	82-1310	Washer - Lock 3/8	29 3 4
62-7770	Key - Ignition, Padded	49 4 1	82-1320	Washer 7/16	27 17 1
71-5830	Cap - Valve	25 44 4	82-1340	Cable - Spark Plug 18 Long	33 34 1
71-5980	Gasket	37 10 2	82-1340	Washer - Flat	25 48 2
71-6040	Starter, Complete - See	43 2 1	82-1340	Washer - Flat (M6)	33 35 2
71-6290	Kit - Engine Gasket	25 45 1	82-1350	Washer - Flat	37 4 4
72-0850	Gasket	37 2 1	82-1360	Screw - Hex. Hd. 1/4-20 x 5/8	3338 1
78-0020	Meter - Hour, Complete	49 51 1	82-1370	Screw 1/4-20 x 1	41 27 1
78-0080	Clamp - Voltmeter, Back	49 22 1	82-1400	Screw 5/16-18 x 1/2	27 20 4
78-0370	Insert - Steering Wheel	9 * 1	82-1410	Washer - Flat	37 6 2
78-1550	Bellcrank	15 19 1	82-1410	Screw - Hex. Hd.	37 7 2
78-1650	Tire Assy - Front Wheel	57 25 2	82-1410	Screw - Hex. Hd.	33 40 1
78-1660	Wheel - Front	57 2 2	82-1410	Screw 5/16-18 1-3/4	33 11 4
78-2880	Shaft - Lower Steering	9 15 1	82-1450	Screw 1/4-14 x 1/2	37 11 2
78-2900	Tie Rod	9 10 2	82-1480	Screw #8 x 3/4	25 39 1
78-2920	Joint - Ball	9 38 1	82-1500	Screw - Hex. Hd. 10-32 x 1	33 23 3
78-2970	Arm - Clutch Idler	11 16 1	82-1510	Screw 10-32 x 3/8	31 5 2
78-2990	Plate - Seat Pivot	61 8 1	82-1550	Screw - Hex. Hd. 1/4-20 x 3/8	3357 2
78-3010	Bracket - Battery Support	19 5 1	82-1560	Screw 10 x 1-1/4	29 14 1
78-3020	Plate - Front	19 9 1	82-1590	Screw 1/4-20 x 3/8	41 49 4
78-3240	Spring	61 36 1	82-1600	Screw 5/16-18 x 3/4	41 7 2
78-3240	Spring - Gas	11 53 1	82-1620	Washer - Lock	41 26 1
78-3250	Spacer	11 60 1	82-1640	Washer - Spring 3/8	25 19 5
78-3250	Spacer	61 40 1	82-1660	Washer - Lock IT 10	33 25 2
78-3260	Spacer	11 55 1	82-1690	Nut - Flange 5/16-18	35 5 1
79-0060	Voltmeter	49 21 1	82-1700	Nut - Speed	29 15 1
79-0670	Seat	61 1 1	83-6520	Rod - Lock	13 18 1
79-3600	Harness Assy - Wiring	49 5 1	87-1370	Bolt 1/4-20 x 1	25 49 2
79-3670	Seat Assy - Deluxe	61 * 1	88-2710	Support - Steering	9 19 1
79-4640	Decal - Hood RH	63 1 1	92-0900	Block - Short	25 1 1
79-4650	Decal - Hood LH	63 2 1	92-0901	Piston Pin & Retaining	25 54 2
79-4900	Hoodstand	19 1 1	92-0902	Piston Pin & Retaining	25 * 2
79-5210	Engine - 16HP TORO Power	23 1 1	92-0903	Piston Pin & Retaining	25 * 2
79-6320	Cover - Air Cleaner	35 2 1	92-0904	Piston Pin & Retaining	25 * 2
79-6330	Housing - Air Cleaner	35 6 1	92-0905	Set - Piston Ring, Standard	25 57 2
79-6340	Support - Air Cleaner	35 14 1	92-0906	Set - Piston Ring .005 O.S.	25 2
79-6360	Bracket	41 13 1	92-0907	Set - Piston Ring .010 O.S.	25 2
79-6390	Bracket - Governor Control	41 24 1	92-0908	Set - Piston Ring .020 O.S.	25 2
79-6400	Bushing - Governor Control	41 29 1	92-0909	Set - Piston Ring .030 O.S.	25 2
79-6410	Link - Governor Control	41 33 1	92-0912	Elbow 45°	31 11 1
79-6420	Adapter - Governor Arm	41 34 1	92-0913	Nut - Wing - 1/4-20	35 33 1
79-6440	Screen	27 21 1	92-0914	Cover - Element	35 32 1
79-6460	Bracket	29 11 1	92-0915	Screw - 10-32 x 3/8	35 31 1
79-6470	Gasket	31 6 1	92-0916	Screw 10-32 x .38	45 6 1
79-6490	Gasket - Plate	33 29 1	92-0917	Tube	35 25 1
79-6520	Spacer	35 23 1	92-0918	Manifold - Intake	37 5 1
79-6580	Screw - Cap 5/16-18 x 3-1/4	243 4 2	92-0919	Rod - Governor Control	37 13 1
82-0020	Plate - Bearing	25 8 1	92-0920	Housing - Cylinder Air, LH	41 3 1
82-0500	Adapter - Oil Filter	31 1 1	92-0921	Housing - Cylinder Air, RH	41 4 1
82-0530	Clamp	25 21 1	92-0922	Arm - Governor Control,	41 17 1
82-0540	Tube - Baffle Breather	25 65 1	92-0923	Hose - Fuel	47 29 1
82-0550	Breather Cap & Valve	25 64 1	281-2	Plug - Pipe, Sq Hd 3/8	5 7 1
82-0560	Screen	25 66 2	281-10	Plug - Pipe, Allen Hd 1/4	5 6 1
82-0570	Seal	25 23 1	302-5	Fitting - Grease	11 61 2
82-0620	Guard - Stationary	41 39 1	321-2	Bolt 1/4-20 x 1/2	23 19 3
82-0680	Gasket	31 9 1	321-3	Bolt - Nylok 1/4-20 x 5/8	59 41 4
82-0780	Kit - Repair	39 2 1	321-3	Bolt 1/4-20 x 5/8	11 5 2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
321-4	Bolt 1/2-20 x 3/4	21 37 2	3256-5	Washer 7/16 U.S.	15 36 1
321-4	Bolt 1/4-20 x 3/4	51 6 2	3256-21	Washer #8 55	29 4
321-4	Bolt 1/4-20 x 3/4	49 30 2	3256-22	Washer	11 56 2
321-6	Bolt 1/4-20 x 1	11 54 1	3256-22	Washer 1/4 SAE	51 7 4
321-8	Bolt 1/4-20 x 1-1/4	61 39 2	3256-22	Washer 1/4 SAE	17 13 4
321-9	Bolt 1/4-20 x 1-1/2	11 59 1	3256-22	Washer 1/4 SAE	59 22 2
322-1	Bolt 5/16-18 x 1/2	9 5 1	3256-22	Washer 1/4 SAE	49 31 4
322-2	Bolt 5/16-18 x 5/8	47 18 3	3256-22	Washer 1/4 SAE	61 38 2
322-3	Bolt 5/16-18 x 3/4	21 15 2	3256-23	Fender	21 22 1
322-3	Bolt 5/16-18 x 3/4	23 17 4	3256-23	Washer 5/16	15 25 1
322-3	Bolt 5/16-18 x 3/4	21 21 4	3256-23	Washer 5/16 SAE	61 6 4
322-3	Bolt 5/8-18 x 3/4	61 3 4	3256-23	Washer 5/16 SAE	21 16 2
322-4	Bolt 5/16-18 x 7/8	61 7 4	3256-23	Washer 5/16 SAE	61 18 4
322-4	Bolt 5/16-18 x 7/8	61 13 2	3256-23	Washer 5/16 SAE	55 26 1
322-5	Bolt 5/16-18 x 1	15 38 3	3256-23	Washer 5/16 SAE	15 43 2
322-6	Bolt 5/16-18 x 1-1/4	15 24 1	3256-24	Washer 3/8 SAE	23 7 4
322-6	Bolt 5/16-18 x 1-1/4	3 18 1	3256-24	Washer 3/8 SAE	11 38 1
323-5	Bolt 3/8-16 x 7/8	2 4 4	3256-24	Washer 3/8 SAE	11 51 1
323-6	Bolt 3/8-16 x 1	13 19 3	3256-26	Washer 1/2 SAE	11 25 1
323-7	Bolt 3/8-16 x 1-1/4	9 13 2	3256-26	Washer 1/2 SAE	15 55 1
323-7	Bolt 3/8-16 x 1-1/4	59 16 1	3256-30	Washer 1 in. SAE	15 15 3
323-7	Bolt 3/8-16 x 1-1/4	13 21 2	3257-5	Key - Woodruff 3/16 x 3/4	7 40 1
323-9	Bolt 3/8-16 x 1-3/4	9 20 2	3269-3	Rivet - Pop 3/16 x 402	55 19 4
323-9	Bolt 3/8-16 x 1-3/4	11 37 1	3272-6	Pin - Cotter 3/32 x 3/4	11 15 1
323-11	Bolt 3/8-16 x 2-1/4	5 4 5	3272-10	Pin - Cotter	11 31 3
323-16	Bolt 3/8-16 x 4	5 3 1	3272-10	Pin - Cotter 1/8 x 3/4	59 7 1
3217-5	Nut 1/4-20	7 48 1	3272-10	Pin - Cotter 1/8 x 3/4	59 12 2
3217-6	Nut 5/16-18	19 7 4	3272-10	Pin - Cotter 1/8 x 3/4	11 20 2
3217-6	Nut 5/16-18	61 28 4	3272-10	Pin - Cotter 1/8 x 3/4	15 35 1
3217-29	Nut #6-32	17 24 4	3272-17	Pin - Cotter 5/32 x 1/4	57 14 2
3218-1	Nut - Jam 1/4-20	59 21 2	3272-19	Pin - Cotter 5/32 x 1-3/4	9 18 1
3218-3	Nut - Jam 3/8-16	57 19 4	3296-29	Nut 5/16-18	61 5 4
3229-25	Bolt - Carriage 1/4-20 x 3/4	17 12 4	3296-29	Nut 5/16-18	21 10 7
3229-25	Bolt - Carriage 1/4-20 x 3/4	59 24 2	3296-29	Nut 5/16-18	61 15 2
3231-25	Bolt - Carriage 3/8-16 x 1-1/4	2 2 3	3296-29	Nut 5/16-18	55 22 1
3235-22	Bolt 3/8-16 x 1	15 33 2	3296-29	Nut 5/16-18	15 26 1
3242-2	Screw - Set	3 5 2	3296-29	Nut 5/16-18	21 30 6
3243-5	Screw - Set 3/8-16x1	57 20 4	3296-29	Nut 5/16-18	61 34 2
3245-32	Screw - Set 1/4-20 x 1/4	11 11 2	3296-29	Nut 5/16-18	15 44 3
3245-32	Screw - Set 1/4-20 x 1/4	9 27 1	3296-29	Nut 5/16-18	3 20 16
3246-2	Screw - Set 5/16-18 x 5/16	3 2 2	3296-39	Nut 3/8-16	2 3 3
3252-4	Washer - Lock 5/16	47 19 2	3296-39	Nut 3/8-16	5 5 6
3253-2	Washer - Lock 10	33 15 3	3296-39	Nut 3/8-16	9 14 2
3253-3	Washer - Lock	11 57 1	3296-39	Nut 3/8-16	59 19 1
3253-3	Washer - Lock 1/4	11 6 2	3296-39	Nut 3/8-16	13 20 5
3253-3	Washer - Lock 1/4	49 45 4	3296-39	Nut 3/8-16	11 32 1
3253-3	Washer - Lock 1/4	59 47 1	3296-39	Nut 3/8-16	11 44 1
3253-4	Washer - Lock 5/16	61 4 8	3296-39	Nut 3/8-16	15 56 1
3253-4	Washer - Lock 5/16	9 6 1	3296-42	Nut 1/4-20	61 37 2
3253-4	Washer - Lock 5/16	23 18 4	3296-42	Nut 1/4-20	21 38 1
3253-4	Washer - Lock 5/16	61 22 4	3296-42	Nut 1/4-20	11 58 2
3253-17	Washer - Lock 10	55 2 4	32120-72	Ring - Snap 3/4 External	59 34 2
3253-21	Washer - Lock 3/8	2 5 4	32121-35	Pin - Roll	15 48 1
3253-21	Washer - Lock 3/8	3 12 2	32121-103	Pin - Spirol	15 47 1
3253-24	Washer - Lock 3/8	23 8 4	32121-111	Pin - Spirol 1/4 x 2	9 31 1
3254-2	Washer - Lock 5/16	55 23 1	32146-2	Nut 3/8-16	23 13 4
3256-3	Washer 5/16 SAE	61 27 4	32146-2	Nut 3/8-16	9 21 2
3256-3	Washer 5/16 US	3 19 2	32146-7	Nut 1/4-20	49 36 2
3256-4	Washer 3/8	47 17 2	32146-17	Nut 1/4-20	17 14 4

*Not Illustrated

[illegible]

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Frame	2	Air Cleaner Power Plus	34
Drive Belt And Pulleys	3	Intake Manifold Power Plus	36
Mechanical Transmission 8-Speed	4	Carburetor Components Power Plus	38
Front Axle and Steering	8	Blower Housing and Governor Power Plus	40
Clutch, Brake and Speed Control Linkage	10	Starter Power Plus	42
Hitches	12	Choke Linkage Power Plus	44
Manual Lift Linkage	14	Throttle Choke & Fuel Controls Power Plus	46
Sheet Metal and Covers	16-20	Electrical System	48-54
Engine	22	Wheel And Tires	56
Engine Power Plus Cylinder Block	24	P.T.O. Clutch And Control	58
Crankshaft, Camshaft, Flywheel, Power Plus	26	Seat	60
Oil , Base Fill Tube and Bracket Power Plus	28	Decals	62
Oil Filter Power Plus	30	Numerical Parts List	63-70
Gear Case & Ignition Controls Power Plus	32		