


TORO®

MODEL NO. 07404

**PARTS
CATALOG****ELECTRIC CLUTCH KIT**
For Workman Series Auxiliary Power Units


T-1673

CONTROL PANEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-2642	Bracket-Switch Mount	1
2	92-2662	Plug-Snap-In	4
3	92-2658	Decal-Electric Clutch (US)	1
*	93-9865	Decal-Electric Clutch (CE)	1
4	321-3	Screw-HH	4
5	85-4980	Asm-Switch (Incl. Ref. #13 & 14)	1
6	92-2646	Asm-Wire Harness (Incl. Ref. #13-15)	1
7	3296-2	Nut-Lock	2

* Not Illustrated

Ref. No.	Part No.	Description	No. Used
8	92-2666	Decal-20 Amp (US)	1
*	93-9086	Decal-20 Amp (CE)	1
9	92-2641	Block-Fuse	1
10	218-594	Fuse-20 Amp	1
11	3250-13	Screw-PH	2
12	3296-56	Nut-Lock	4
13	3218-19	Nut-Hex.	4
14	3254-20	Washer	2
15	92-2679	Lens-Red	1
*	92-2680	Bulb	1



T-1674

CLUTCH DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290-379	Tie-Cable	7
2	32128-20	Nut-Flange Lock	2
3	92-2646	Asm-Wire Harness	1
4	3272-33	Pin-Cotter	2
5	92-2634	Shaft-Pivot	1
6	3296-39	Nut-Lock	1
7	92-2645	Spacer-Clutch Bracket	1
8	92-2644	Bracket-Adjustment	1
9	92-2652	Bolt-Tap	1
10	3256-24	Washer-Flat	1
11	322-6	Screw-HH	2
12	3217-7	Nut-Hex.	1
13	92-2643	Guide	1
14	92-2651	Washer	1
15	3296-45	Nut-Lock	1
16	92-2639	Pulley (Incl. Ref. #35)	1
17	92-2650	Spacer	1
18	251-82	Bearing-Ball	2

Ref. No.	Part No.	Description	No. Used
19	92-2630	Bracket-Tightener	1
20	87-2750	Spacer-Bearing	1
21	92-2640	Shaft-Clutch	1
22	92-2637	Spacer-Clutch	1
23	92-2636	Belt-V (Matched Set)	1
24	92-2638	Spacer	1
25	32151-36	Ring-Snap	1
26	321-3	Screw-HH	2
27	92-2627	Asm-Electric Clutch	1
28	3296-9	Nut-Lock	1
29	92-2635	Bracket-Clutch	1
30	66-2910	Bumper-Rubber	1
31	3250-39	Screw-PH	1
32	3296-56	Nut-Lock	2
33	7-0238	Key-Square (Long)	1
34	92-2649	Key-Square (Short)	1
35	3246-14	Screw-Set	1
36	3255-8	Washer-Lock ETLW	1