



Tri-Roller Greensmaster® 3000 Series

Model No. 04495 - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



Tri-Roller Mounting Assembly

Ref	Part No.	Qty.	Description				
2	94-2958	6	Stud-Ball				
3	3254-6	6	Washer-Lock, Internal				
4	94-4548	6	Bumper-Recessed				
5	32144-44	6	Screw-HWH				
6	61-2370	1	Spacer				
7	32144-102	1	Screw-HWH				
17	54-7460	6	Joint-Ball				
18	94-2958	6	Stud-Ball				
19	3220-5	6	Nut-Jam				
20	18-3049	6	Pull Link ASM				
20:1	95-0532	1	Rubber Bushing ASM				
21	256-292	6	Bushing-Flange, NI				
22	75-5270	6	Spacer-Knob, Seat				
23	3256-4	6	Washer-Flat				
24	3211-6	6	Screw-HH				



Tri-Roller Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	100-6443-01	1	Frame ASM	19	33114-025	2	Screw-HH
2	94-3405	2	Bearing-Ball	20	67-1300	1	Decal
2:1	3245-35	1	Screw-Set	21	48-9590	4	Washer-Lock
2:2	251-77	1	Collar-Lock, Bearing	22	33115-025	4	Screw-HH
3	95-7148	2	Housing-Bearing	23	99-1614	1	Roller ASM
4	95-1642-01	1	Weight-Counter	24	33126-040	2	Screw-CARR
5	93-2569	4	Screw-HHF	25	99-1637-01	1	Plate-Scraper
6	3256-24	2	Washer-Flat	26	99-1620-01	9	Plate-Weight, Long
7	302-5	2	Fitting-Grease	27	33116-070	2	Screw-HH
10	3296-39	1	Nut-Lock, NI	30	3256-74	4	Washer-Flat
11	33026-00	6	Nut-Lock	31	100-6446-01	2	Plate-Pivot
12	323-5	2	Screw-HH	32	100-6449	1	Roller-Lift
13	99-4210	2	Roller-Anti Scalp	33	100-6448	1	Spacer-Roller
14	99-1615	1	Rear Roller ASM	34	323-12	1	Screw-HH
14:1	93-2466	1	Shaft-Roller	35	88-6330	1	Spring-Extension
14:2	99-1616	1	Rear Roller Tube ASM	36	100-9818-01	1	Plate-Mount, Spring
14:3	93-2559	2	Bearing-Ball	37	52-2480	2	Spacer-Wheel
14:4	93-2525	2	Ring-Retaining	38	3234-1	2	Screw-HHF
14:5	302-5	2	Fitting-Grease	39	3256-45	2	Washer-Flat
14:6	98-2194	2	Sleeve-Grease	40	33126-045	2	Screw-CARR
15	99-4209	2	Shaft-Roller	41	115-3269	1	Decal-Regulatory
16	33024-00	2	Nut-Lock				
17	99-8168	2	Collar-HOC				
18	2410-30	1	Cap-Plastic				

