



TORO®**MODEL NO. 30185-20001 THRU
49001 AND UP****PARTS
CATALOG****PROLINE 185 MID SIZE
HYDRO TRACTION UNIT**

C-0733

FRAME, ENGINE, FUEL TANK, CLUTCH & COOLER ASS'Y

Ref. No.	Part No.	Description	No. Used
1	82-3900	Frame	1
2	47-2982	Hose - Fuel	1
3	56-6360	Filter - Fuel	1
4	2412-98	Clamp - Fuel Line	4
5	47-2964	Hose - Fuel	1
6		Engine - 14 H.P. Kohler	1
7	288-4	Cap - Pipe	1
8	74-0950	Elbow - Pipe	2
9	289-51	Nipple - Pipe	1
10	63-8440	Decal - Hot	1
11	3296-42	Nut - Lock	2
12	82-4220	Cooler - Oil	1
13	2412-134	"R"Clamp	1
14	82-4500	Mount - Cooler	1
15	74-0490	Decal - Fuel Line Shut Off	1

Ref. No.	Part No.	Description	No. Used
16	321-39	Screw - Hex. Hd.	6
17	3256-1	Washer - Flat	6
18	29-0642	Trim	1
19	240-9	Grommet	2
20	2412-136	Clamp - Hose	2
21	82-4193	Hose - Hyd.	1
22	82-4192	Hose - Hyd.	1
23	3296-6	Nut - Lock	1
24	322-3	Screw - Hex. Hd.	4
25	3253-4	Washer - Lock	8
26	74-0510	Valve - Fuel Shut Off	1
27	237-7	"O"Ring	1
28	82-8440	Tank - Fuel	1
30	55-3570	Cap - Fuel Tank	1
33	32149-2	Nut - Keps	2




C-0733

FRAME, ENGINE, FUEL TANK, CLUTCH & COOLER ASS'Y

Ref. No.	Part No.	Description	No. Used
34	32149-8	Nut - Keps	1
35	32144-4	Screw	2
36	47-1910	Solenoid	1
37	3296-39	Nut	1
38	62-4540	Pulley - Idler	1
39	256-156	Bushing	2
40	86-4770	Idler Assembly (Incl. Ref.#39)	1
41	68-2190	Spring	1
42	27-6230	Bolt - Wheel	1
43	57-6380	Screw	4
44	51-4540	Retainer - Clutch	1


Ref. No.	Part No.	Description	No. Used
45	3256-23	Washer - Flat	4
47	112843	Washer - Clutch	1
49	57-6360	Screw - Hex. Hd.	1
50	54-3200	Clutch Assembly	1
51	44-5940	Pulley - Clutch	1
52	608006	Key	1
53	74-0930	Guard - Pulley	1
54	323-9	Screw - Hex. Hd.	1
55	28-3891	Wire Assembly - Starter	1
56	2412-106	R-Clamp	1
57	2410-71	Cap - Plug	2
58	88-1880	Spring - Compression	1



T-0080

CLUTCH ASSEMBLY NO. 54-3200

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	54-0230	Field Ass'y (Incl. Ref. # 2 & 3)	1	6	44-8330	Spacer - Pulley Bearing	1
2	251-292	Bearing - Field	1	7	44-8340	Collar - Bearing	1
3	44-8310	Ring - Retaining	2	8	251-291	Bearing - Pulley	1
4	44-8360	Field Coil, Rotor & Bearing Assembly (Incl. Ref. # 1)	1	9	3296-5	Nut - Lock	3
5	55-7410	Armature & Pulley Assembly (Incl. Ref. # 3, 6, 7, & 8)	1	10	44-8320	Spring	3




c-0734

HYDRAULIC PUMP & LINKAGE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	82-4580	Bracket - Neutral	2
2	3290-378	Tie - Cable	3
3	65-7410	Switch Assembly	2
4	82-4570	Plate - Switch	2
5	32144-1	Screw - Hex.Hd.	4
6	82-4130	Bearing Assembly	4
7	322-5	Screw - Hex. Hd.	2
8	82-4210	Bracket - Bushing	1
9	82-4290	Lever Assembly R.H.	1
10	3296-13	Nut - Lock	4
11	82-8220	Pump Assembly - Hydraulic	2
12	32128-42	Nut - Lock	4
13	322-7	Screw - Hex. Hd.	4
14	82-3790	Arm - Pump Control	2
15	3256-1	Washer	4
16	82-4230	Arm - Follower	2
17	3256-23	Washer - Flat	4
18	322-5	Screw - Hex. Hd.	4
19	2411-34	Joint - Ball	4
20	82-4270	Lever Assembly - L.H.	1
21	3296-47	Nut - Lock	2
22	82-4330	Detent Arm Assembly L.H.	1
*	82-4340	Detent Arm Assembly R.H.	1
23	82-4370	Bushing	2
24	3296-39	Nut	6
25	82-4240	Spacer	2
26	251-259	Bearing - Ball	2
27	3274-32	Screw - Hex. Hd.	2

Ref. No.	Part No.	Description	No. Used
28	82-3920	Stop - Reverse	2
29	82-4090	Bracket Assembly L.H.	1
*	82-4070	Bracket Assembly R.H.	1
30	322-14	Screw - Hex. Hd.	2
31	321-3	Screw - Hex. Hd.	8
32	82-4600	Decal - Hydro Drive	2
33	323-6	Screw - Hex. Hd.	6
34	321-8	Screw - Hex. Hd.	2
35	32112-11	Nut - Push On	8
36	80-0650	Spacer	2
37	32128-10	Nut - Lock	2
38	82-4160	Spring	2
39	86-4760	Spring	4
40	82-4030	Pivot Assembly L.H.	1
*	82-4040	Pivot Assembly R.H.	1
41	257-5	Washer - Thrust	2
42	3296-29	Nut - Lock	12
43	237-124	Grommet	1
44	324-5	Screw - Hex. Hd.	4
45	32144-3	Screw - Hex. Hd.	4
46	3296-42	Nut - Lock	8
47	32121-4	Pin - Roll	2
48	82-4120	Rod	2
49	32144-4	Screw	1
50	2412-106	"R" Clamp	1
51	3290-418	Pushnut	4
52	86-4750	Bracket - Stop	2

* Not Illustrated




T-1236

HYDRAULIC PUMP ASSEMBLY NO. 82-8220

Ref. No.	Part No.	Description	No. Used
1	80-6120	Check Valve Kit (Incl. Ref. #2-4)	1
2		Seal - O-Ring	2
3		Spring	2
4		Ball	2
5		Journal - Bearing	1
6		Gasket - End Cap	1
7		Cylinder Block Kit (Incl. Ref. #8-10 & 27-29)	1
8		Spring	1
9		Washer	1
10		Ring - Retaining	1
11		Plate - Thrust	1
12		Arm - Trunion	1
13		Guide - Slot	1
14		Cradle - Bearing	2
15		Pin	2
16		Seal - Lip	1
17		Journal - Bearing	1
18		Housing - Assembly (Incl. Ref. #16 & 17)	1
19		Shaft	1
20		Ring - Retaining	2
21		Bearing - Ball	1
22		Spacer	1

Ref. No.	Part No.	Description	No. Used
23		Seal - Lip	1
24		Ring - Retaining	1
25		Swashplate Assembly	1
26		Roller - Thrust	1
27		Piston	5
28		Washer - Thrust	5
29		Spring - Piston	5
30		Screw	4
31		End Cap Assembly (Incl. Ref. #5)	1
32		Ball	1
33		Spring	1
34		Screw	2
35		Housing - Charge Pump	1
36		Gerotor Assembly	1
37		Seal - O-Ring	1
38		Seal - O-Ring	1
39		Ring - Back-Up	1
40		Valve - Bypass	1
*	80-6110	Charge Relief Valve Kit (Incl. Ref. #32-33)	1
*	80-6130	Overhaul Seal Kit (Incl. Ref. #6, 10, 16, 20, 23 & 37-39)	1

*Not Illustrated




C-0735

WHEEL ASSEMBLY & HYDRAULIC COMPONENTS

Ref. No.	Part No.	Description	No. Used
1	3296-23	Nut	8
2	237-80	"O"Ring	A/R
3	340-6	Fitting - Hyd.	4
4	237-30	"O"Ring	A/R
5	82-4540	Hose - Hyd.	2
6	82-4550	Hose - Hyd.	1
7	82-4201	Hose - Hyd.	1
8	2815-15	Fitting - Hyd.	1
9	82-4192	Hose - Hyd.	1
10	3253-4	Washer - Lock	3
11	322-3	Screw	3
12	82-4560	Hose - Hyd.	1
13	354-115	Fitting - Hyd.	2
14	237-42	"O"Ring	A/R
15	354-116	Fitting - Hyd.	2
16	82-4180	Hose - Hyd.	1
17	82-4170	Hose - Hyd.	1
18	2815-16	Fitting - Hyd.	1
19	340-4	Fitting Hyd.	4
20	82-4200	Hose - Hyd.	1
21	76-0200	Cap Assembly - Oil	1
22	29-0590	Screen - Filler	1
23	82-3910	Reservoir - Oil	1
24	237-79	"O"Ring	A/R
25	3296-29	Nut	2
26	354-118	Fitting - Hyd.	2
27	82-4193	Hose - Hyd.	1

Ref. No.	Part No.	Description	No. Used
28	321-3	Screw	2
29	3253-3	Washer - Lock	2
30	82-4140	Bracket - Filter	1
31	322-3	Screw	2
32	54-0100	Head Assembly - Filter	1
34	354-117	Fitting - Hyd.	2
35	237-78	"O" Ring	A/R
36	67-8110	Filter - Oil	1
37	82-8230	Motor - Wheel	2
38	3257-8	Key - Woodruff	2
39	85-7310	Nut (Incl. w/Motor)	2
40	231-111	Tire	2
41	242-87	Wheel	2
42	242-50	Nut - Lug	8
43	32112-17	Nut - Push On	8
44	82-3830	Hub - Wheel	2
45	3213-8	Screw - Hex. Hd.	8
46	325-11	Screw	8
48	3245-3	Screw - Set	4
49	82-4110	"V" Belt	1
50	82-4380	Pulley - Pump	2
51	80-6090	Key	2
52	3256-23	Washer	1
*	232-27	Valve stem	2
53	86-4740	Spacer	2
54	86-4730	Plate - Frame	2

*Not Illustrated




C-0737

TRACTION DRIVE MOTOR (Torqumotor)

Ref. No.	Part No.	Description	No. Used
1		Seal	1
2		Bearing	1
3		Housing	1
4		Washer - Back Up	1
5		Washer - Back Up	1
6		Seal	1
7		Washer - Thrust	1
8		Bearing - Thrust	1
9		Washer - Thrust	1
10		Bearing - Inner	1
11		Coupling - Shaft	1
12		Bearing - Thrust	1
13		"O"Ring	5
14		Link - Drive	1

Ref. No.	Part No.	Description	No. Used
15		Plate Wear	1
16		Rotor	1
17		Vane	7
18		Stator	
19		Manifold	1
20		Commutator	1
21		Seal - Commutator	1
22		Commutator - Ring	1
23		Cover - End	1
24		Bolt - Special	A/R
25		Stator Half	
26	85-7310	Nut	1
*	85-7320	Kit - Seal (Incl. Ref. #1,4,6,13 & 20)	1

*Not Illustrated




C-0769

HANDLE / CONTROL PANEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75-6820	Meter - Hour	1
2	32144-18	Screw - Hex. Hd.	2
5	71-1280	Decal - Danger	1
6	82-3820	Boot - Switch	1
7	82-2300	Switch - Clutch	1
8	74-0630	Control - Throttle	1
9	65-3090	Decal - Instructions	1
10	3296-2	Nut - Lock	4
11	32144-19	Screw	4
12	2412-120	"R" Clamp	2
13	74-0720	Tube - Manual	1
14	86-7910	Module	1
15	3296-42	Nut - Lock	2
16	63-7590	Relay	1
17	57-5811	Panel - Bottom	1
18	3296-2	Nut	1
19	82-2190	Switch - Bail	1
20	82-7680	Bail Assembly	1
21	82-2610	Decal - Control Bar	1
22	237-141	Grommet	2
23	82-7690	Control Bar Assembly	1
24	82-7631	Rod - Control	2
25	32105-1	Screw - Hex. Hd.	1
26	3290-307	Pin - Cotter	4
28	82-3940	Pivot Control Assembly	1
29	82-4300	Handle Assembly	1


Ref. No.	Part No.	Description	No. Used
30	82-4590	Decal - Caution	1
31	3256-23	Washer - Flat	2
32	74-0521	Fitting - Rod	2
33	283-6	Pin - Clevis	2
34	32151-80	Ring - Push On	2
35	74-0470	Rod - Pivot	1
36	32105-14	Screw - Hex. Hd.	4
37	3290-378	Tie - Cable	2
38	67-6451	Handle - Upper	1
39	82-4511	Wire Harness (Ref.)	1
40	3234-11	Screw - Hex. hd.	4
41	32128-21	Nut - Lock	4
42	3230-26	Bolt Carriage	1
43	82-3840	Spacer - Latch	1
44	19-4050	Knob - Handle	1
45	32112-18	Retainer - Bolt	1
46	321-3	Screw - Hex. hd.	2
47	23-0660	Switch - Ignition	1
48	3234-5	Washer - Lock	1
49	218-461	Nut	1
50	63-8360	Key	1
51	82-2181	Panel - Control	1
52	82-7721	Decal - Control Panel	1
53	218-595	Body	1
54	3255-7	Washer - Lock, Ext.	1



T-0875

BATTERY ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
2	323-9	Screw - Hex. Hd.	2	10	77-0981	Boot - Terminal	1
3	51-4210	Pad - Battery Mount	2	11	3296-42	Nut - Lock	2
4	92-2350	Holder - Battery	2	12	82-4620	Strap - Battery	1
5	82-4640	Battery	1	13	28-3893	Cable - Battery	1
6	68-3810	Tube -Vent	1	14	322-3	Screw - Cap Hex. Hd.	2
7	54-3093	Cable - Battery	1	15	3296-39	Nut - Lock	2
8	32149-1	Nut	2	16	12-5950	Rod - Battery Support	2
9	77-0980	Boot - Terminal	1	17	84-1830	Cap	1




C-0738

ELECTRIC SCHEMATIC

Ref. No.	Part No.	Description	No. Used
1	82-4511	Wire Harness	1
2	63-7590	Relay	1
3	86-7910	Module - Interlock	1
4	28-3891	Wire Assembly	1

Ref. No.	Part No.	Description	No. Used
5	54-3093	Wire Assembly	1
6	54-3091	Wire Assembly	1
7	28-3893	Wire Assembly	1
8	92-2361	Wire Assembly	1





C-0708

HYDRAULIC SCHEMATIC

Ref. No.	Part No.	Description	No. Used
1	82-4550	Hose Assembly	2
2	82-4170	Hose Assembly	1
3	82-4180	Hose Assembly	1
4	82-4200	Hose Assembly	1
5	82-4193	Hose Assembly	1

Ref. No.	Part No.	Description	No. Used
6	82-4192	Hose Assembly	1
7	82-4201	Hose Assembly	1
8	82-4560	Hose Assembly	1
9	82-4540	Hose Assembly	1

Group 1**Group 3**


C-0770

ENGINE KOHLER MODEL NO. CV14 S-1429

Ref. No.	Part No.	Description	No. Used
Crankshaft Group 1			
1	12 014 02	Crankshaft Assembly	1
2	12 139 0	Plug	1
Oil Pan / Lubrication Group 3			
1	12 038 01	Dipstick Assembly	1
2	12 153 01	"O"Ring - Dipstick	1
3	12 153 02	"O"Ring - Upper Tube	1
4	12 123 04	Tube - Oil Fill	1
5	SM-0545020	Screw - Oil Fill Tube	1
6	12 153 01	"O"Ring - Lower Tube	2
7	12 162 02	Screen - Oil Pick Up	1
8	12 096 03	Cover - Oil Screen	1
9	SM-0545016	Screw	1
10	SM-1039025	Screw	1
11	12 126 02	Bracket - Oil Pump Relief Valve	1

Ref. No.	Part No.	Description	No. Used
12	12 089 03	Spring - Oil Pump Relief Valve	1
13	12 462 01	Piston - Oil Pump Relief Valve	1
14	12 208 01	Body - Oil Pump Relief Valve	1
15	52 050 02	Filter - Oil	1
16	12 136 01	Adapter - Oil Filter	1
17	X-75-1	Plug - 1/8 N.P.T.F.	2
18	X-75-10	Plug - 3/8 N.P.T.F.	2
19	12 393 01	Pump - Oil Assembly	1
20	12 032 04	"O"Ring - Pump Cover	1
21	12 096 02	Cover - Oil Pump	1
22	SM-0545016	Screw	3
23	12 032 03	Seal - Oil (P.T.O.End)	1
24	SM-0839045	Screw - Oil Pan	11
25	12 199 09	Pan - Oil	1

Group 2




C-0771

ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
		Crankcase	
		Group 2	
1	12 032 03	Seal – Crankshaft	1
2	12 030 01	Bearing – Crankshaft Flywheel End (Std.)	1
*	12 030 02	Bearing – Crankshaft (.25)	1
*	12 030 03	Bearing – Crankshaft (.50)	1
3	12 445 02	Strap – Lifting	1
4	SM-0839025	Screw – Lifting Strap	1
5	12 380 03	Dowel – Locating	4
6	12 010 01	Camshaft Assembly	1
7	12 089 18	Spring – Actuating	1
8	12 422 08	Shim – Camshaft	1
*	12 422 02	Shim – Camshaft	A/R
*	12 422 10	Shim – Camshaft	A/R
*	12 422 11	Shim – Camshaft	A/R
*	12 422 12	Shim – Camshaft	A/R
*	12 422 06	Shim – Camshaft	A/R
*	12 422 07	Shim – Camshaft	A/R
9	12 422 04	Shaft – Balance	1

Ref. No.	Part No.	Description	No. Used
10	12 847 01	Piston W/Ring Set (Std.)	1
*	12 847 02	Piston W/Ring Set (.25)	1
*	12 847 03	Piston W/Ring Set (.50)	1
11	12 018 02	Retainer – Piston Pin	2
12	12 108 01	Ring Set (Std.)	1
*	12 108 02	Ring Set (.25)	1
*	12 108 03	Ring Set (.50)	1
13	12 067 01	Connecting Rod (Std.)	1
*	12 067 02	Connecting Rod (.25)	1
14	12 380 01	Pin – Governor Regulating	1
15	12 043 05	Gear – Governor Assembly	1
16	SM-0631005	Washer – Governor Gear	1
17	12 144 02	Shaft – Governor Gear	1
18	52 139 09	Plug – Cap	1
19	12 144 01	Shaft – Governor Cross	1
20	SM-0631015	Washer – Governor Shaft	1
21	12 032 01	Seal – Cross Shaft	1
22	12 380 04	Pin – Governor Hitch	1
*	12 522 01	Short Block	1

*Not Illustrated

Group 4


C-0772

ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
		Cylinder Head / Valve / Breather - Group 4	
1	12 318 01	Cylinder Head	1
*	12 755 02	Kit Cylinder Head	1
2	12 351 01	Lifter - Valve	2
3	12 441 01	Rod - Push	2
4	12 041 04	Gasket - Cylinder Head	1
5	12 017 01	Valve - Intake (Std.)	1
	12 017 02	Valve - Intake (.25)	1
6	12 016 01	Valve - Exhaust (Std)	1
	12 016 02	Valve - Exhaust (.25)	1
7	12 112 04	Spacer - Head Bolt	1
8	SM-1040080	Screw - Cylinder Head	5
9	52 018 01	Retainer - Spring	2
10	12 089 15	Spring - Valve, Exhaust	1
11	12 173 01	Cap - Valve Spring	2

Ref. No.	Part No.	Description	No. Used
12	12 755 03	Kit - Retainer	2
13	12 089 13	Spring - Valve, Intake	1
14	12 032 02	Seal - Valve Stem	1
15	X-426-9	Clamp - Hose	2
16	12 326 03	Hose - Breather	1
17	SM-0645020	Screw - Valve Cover	3
18	12 096 07	Cover - Valve W/Nipple	1
19	SM-0545010	Screw - Breather Reed	1
20	12 018 01	Retainer - Breather Reed	1
21	12 402 01	Reed - Breather	1
22	SM-0642025	Screw - Rocker Bridge	2
23	12 189 01	Arm - Rocker	2
24	12 126 05	Bridge - Rocker Arm	1
25	12 144 03	Shaft - Rocker Arm	1
26	X-426-3	Clamp - Hose	1

Group 5




C-0773

ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
		Ignition / Electrical Group 5					
1	M-1040045	Screw - Flywheel	1	12	12 025 08	Flywheel Assembly	1
2	12 468 03	Washer - Flywheel	1	13	M-0548025	Screw - Stator	4
3	12 162 01	Screen - Grass	1	14	SM-0545010	Screw - Stator Harness	1
4	SM-0651016	Screw - Fan	4	15	12 154 02	Clip - Stator Harness	1
5	12 112 01	Spacer - Fan	4	16	41 085 07	Stator - 15 Amp.	1
6	12 157 02	Fan	1	17	12 132 02	Spark Plug	1
7	X-42-15	Key	1	18	X-728-1	Clip - Kill Lead	1
8	12 403 09	Rectifier - Unregulator	1	19	SM-0545010	Screw - Lead Clip	1
9	M-0651016	Screw - Regulator	2	20	12 584 01	Module - Ignition	1
10	236602	Connector - Regulator	1	21	SM-0545020	Screw - Ignition Module	2
11	41 155 03	Connector	1	*	25 518 05	Lead - Black, Rectifier to	
				*		Connector (5"-14 Gauge)	1
				*	12 518 01	Lead - White, Ground to Kill	1

* Not Illustrated.

Group 6

C-0774


ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
		Blower Housing & Baffle Group 6	
1	SM-0545010	Screw	14
2	12 146 07	Plate - Blower Housing	1
3	12 063 01	Baffle - Cylinder Barrel	1
4	12 096 01	Cover - Starter	1

Ref. No.	Part No.	Description	No. Used
5	12 027 09	Cover - Housing	1
6	12 063 05	Baffle - Carburetor	1
7	12 313 03	Grommet	1
8	12 063 03	Baffle - Cylinder Head	1
*	133 14	Decal - H.P.	1

* Not Illustrated.

Group 7




C-0776

ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
		Starting System Group 7	
1	SM-0839065	Screw	5
2	12 468 01	Washer	2
3	12 098 06	Starter (Incl. Ref.#4-10)	1
4	12 755 12	Kit - Drive (Incl. Ref.#5)	1
5	12 755 06	Kit	1
6	12 277 01	Cap - Drive End	1
7	12 170 02	Armature	1
8	12 086 02	Screw - Flange	1
9	12 243 -03	Cap - Commutator End	1
10	52 755 15	Kit - Brush	1
*	52 357 01	Lubricant	1

* Not Illustrated.

Group 8

C-0781


ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
		Fuel System Group 8	
1	12 853 01	Kit - Carburetor	1
2	12 313 01	Grommet	1
3	12 041 01	Gasket - Air Cleaner	1
4	12 265 01	Deflector - Heat	1
5	12 053 01	Carburetor Assembly(Ref.)	1
6	12 041 01	Gasket - Carburetor	1
7	12 041 02	Gasket - Air Cleaner	1
8	M-0629122	Stud - Carburetor	2
9	48 154 01	Clip - Cable	1
10	SM-0641060	Nut - Carburetor	2
11	12 368 01	Needle - Idle	1
12	12 089 09	Spring - Idle	1
13	12 086 04	Screw - Idle	1


Ref. No.	Part No.	Description	No. Used
14	12 089 09	Spring - Idle	1
15	12 146 03	Plate - Throttle	1
16	25 086 27	Screw - Throttle Plate	2
17	12 144 09	Shaft Assembly-Throttle	1
18	12 144 08	Shaft - Choke	1
19	12 089 10	Spring - Choke Return	1
20	12 146 02	Plate - Choke	1
21	12 337 01	Jet - Main	1
22	12 757 02	Kit - Float	1
23	12 041 05	Gasket - Bowl	1
24	12 104 01	Bowl - Fuel	1
25	12 041 06	Gasket - Bowl	1
26	12 086 05	Screw - Bowl	1
*	12 757 01	Kit - Carburetor Repair	1
*	12 755 09	Kit - Kit High Altitude Jet	1

* Not Illustrated.

Group 9



Group 10




C-0775

ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
Engine Control Group 9			
1	12 079 03	Linkage - Choke	1
2	12 237 01	Clamp - Cable	1
3	SM-0645020	Screw - Hex. Hd.	2
4	SM-0545016	Screw - Cable Clamp	1
5	12 536 01	Control - Speed (Incl. Ref.#6-8)	1
6	SM-0443025	Screw	1
7	12 089 11	Spring	1
8	12 089 04	Spring - Choke	1
9	12 089 20	Spring - Governor	1
10	SM-0641060	Nut - Governor	1
11	SM-0642025	Screw - Governor	1
12	12 090 05	Lever - Governor	1
13	25 158 09	Bushing - Black Retainer	1

Ref. No.	Part No.	Description	No. Used
14	12 079 01	Linkage - Throttle	1
15	25 158 08	Bushing - Natural, Linkage	1
AIR Intake / Filtration Group 10			
1	12 341 01	Knob - Air Cleaner Cover	1
2	12 096 06	Cover - Air Cleaner	1
3	12 100 01	Nut - Wing	1
4	X-25-63	Washer - Flat	1
5	12 083 08	Precleaner - Element	1
6	12 083 05	Element - Air Cleaner	1
7	12 072 03	Stud - Mounting Plate	1
8	12 086 01	Screw - Mounting Plate	1
9	12 041 02	Gasket - Air Cleaner	1
10	12 094 01	Base - Air Cleaner	1
*	12 113 04	Decal - Air Cleaner	1

* Not Illustrated.

Group 11

C-0782

ENGINE KOHLER MODEL NO. CV14 S-1429(Continued)

Ref. No.	Part No.	Description	No. Used
Exhaust Group 11			
1	12 068 03	Muffler	1
2	M-0829036	Stud - Exhaust Manifold	2
3	12 041 03	Gasket - Exhaust	1
4	SM-0645025	Screw - Lifting Strap	1
5	12 445 01	Strap - Lifting	1

Ref. No.	Part No.	Description	No. Used
6	SM-0645020	Screw - Valve Cover	1
7	X-25-52	Washer - Flat	1
8	12 126 39	Bracket - Muffler	1
9	12 468 01	Washer - Flat	1
10	M-0840050	Screw	1
11	SM-0841080	Nut - Muffler	2
12	M-0650012	Screw	2
*	12 755 01	Gasket Set	1

* Not Illustrated.

TORO PART NUMBER INDEX

3315-548

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
112843	Washer - Clutch	2 47 1	82-2190	Switch - Bail	8 19 1
608006	Key	2 52 1	82-2300	Switch - Clutch	8 7 1
12-5950	Rod - Battery Support	9 16 2	82-2610	Decal - Control Bar	8 21 1
19-4050	Knob - Handle	8 44 1	82-3790	Arm - Pump Control	4 14 2
23-0660	Switch - Ignition	8 47 1	82-3820	Boot - Switch	8 6 1
27-6230	Bolt - Wheel	2 42 1	82-3830	Hub - Wheel	6 44 2
28-3891	Wire Assembly	10 4 1	82-3840	Spacer - Latch	8 43 1
28-3891	Wire Assembly - Starter	2 55 1	82-3900	Frame	1 1 1
28-3893	Cable - Battery	9 13 1	82-3910	Reservoir - Oil	6 23 1
28-3893	Wire Assembly	10 7 1	82-3920	Stop - Reverse	4 28 2
29-0590	Screen - Filler	6 22 1	82-3940	Pivot Control Assembly	8 28 1
29-0642	Trim	1 18 1	82-4030	Pivot Assembly L.H.	4 40 1
44-5940	Pulley - Clutch	2 51 1	82-4040	Pivot Assembly R.H.	4 * 1
44-8310	Ring - Retaining	3 3 2	82-4070	Bracket Assembly R.H.	4 * 1
44-8320	Spring	3 10 3	82-4090	Bracket Assembly L.H.	4 29 1
44-8330	Spacer - Pulley Bearing	3 6 1	82-4110	VBelt	6 49 1
44-8340	Collar - Bearing	3 7 1	82-4120	Rod	4 48 2
44-8360	Field Coil, Rotor & Bearing	3 4 1	82-4130	Bearing Assembly	4 6 4
47-1910	Solenoid	2 36 1	82-4140	Bracket - Filter	6 30 1
47-2964	Hose - Fuel	1 5 1	82-4160	Spring	4 38 2
47-2982	Hose - Fuel	1 2 1	82-4170	Hose - Hyd.	6 17 1
51-4210	Pad - Battery Mount	9 3 2	82-4170	Hose Assembly	11 2 1
51-4540	Retainer - Clutch	2 44 1	82-4180	Hose - Hyd.	6 16 1
54-0100	Head Assembly - Filter	6 32 1	82-4180	Hose Assembly	11 3 1
54-0230	Field Ass'y	3 1 1	82-4192	Hose - Hyd.	6 9 1
54-3091	Wire Assembly	10 6 1	82-4192	Hose - Hyd.	1 22 1
54-3093	Cable - Battery	9 7 1	82-4192	Hose Assembly	11 6 1
54-3093	Wire Assembly	10 5 1	82-4193	Hose - Hyd.	1 21 1
54-3200	Clutch Assembly	2 50 1	82-4193	Hose - Hyd.	6 27 1
55-3570	Cap - Fuel Tank	1 30 1	82-4193	Hose Assembly	11 5 1
55-7410	Armature & Pulley Assembly	3 5 1	82-4200	Hose - Hyd.	6 20 1
56-6360	Filter - Fuel	1 3 1	82-4200	Hose Assembly	11 4 1
57-5811	Panel - Bottom	8 17 1	82-4201	Hose - Hyd.	6 7 1
57-6360	Screw - Hex. Hd.	2 49 1	82-4201	Hose Assembly	11 7 1
57-6380	Screw	2 43 4	82-4210	Bracket - Bushing	4 8 1
62-4540	Pulley - Idler	2 38 1	82-4220	Cooler - Oil	1 12 1
63-7590	Relay	10 2 1	82-4230	Arm - Follower	4 16 2
63-7590	Relay	8 16 1	82-4240	Spacer	4 25 2
63-8360	Key	8 50 1	82-4270	Lever Assembly - L.H.	4 20 1
63-8440	Decal - Hot	1 10 1	82-4290	Lever Assembly R.H.	4 9 1
65-3090	Decal - Instructions	8 9 1	82-4300	Handle Assembly	8 29 1
65-7410	Switch Assembly	4 3 2	82-4330	Detent Arm Assembly L.H.	4 22 1
67-6451	Handle - Upper	8 38 1	82-4340	Detent Arm Assembly R.H.	4 * 1
67-8110	Filter - Oil	6 36 1	82-4370	Bushing	4 23 2
68-2190	Spring	2 41 1	82-4380	Pulley - Pump	6 50 2
68-3810	Tube - Vent	9 6 1	82-4500	Mount - Cooler	1 14 1
71-1280	Decal - Danger	8 5 1	82-4511	Wire Harness	10 1 1
74-0470	Rod - Pivot	8 35 1	82-4511	Wire Harness (Ref.)	8 39 1
74-0490	Decal - Fuel Line Shut Off	1 15 1	82-4540	Hose - Hyd.	6 5 2
74-0510	Valve - Fuel Shut Off	1 26 1	82-4540	Hose Assembly	11 9 1
74-0521	Fitting - Rod	8 32 2	82-4550	Hose - Hyd.	6 6 1
74-0630	Control - Throttle	8 8 1	82-4550	Hose Assembly	11 1 2
74-0720	Tube - Manual	8 13 1	82-4560	Hose - Hyd.	6 12 1
74-0930	Guard - Pulley	2 53 1	82-4560	Hose Assembly	11 8 1
74-0950	Elbow - Pipe	1 8 2	82-4570	Plate - Switch	4 4 2
75-6820	Meter - Hour	8 1 1	82-4580	Bracket - Neutral	4 1 2
76-0200	Cap Assembly - Oil	6 21 1	82-4590	Decal - Caution	8 30 1
77-0980	Boot - Terminal	9 9 1	82-4600	Decal - Hydro Drive	4 32 2
77-0981	Boot - Terminal	9 10 1	82-4620	Strap - Battery	9 12 1
80-0650	Spacer	4 36 2	82-4640	Battery	9 5 1
80-6090	Key	6 51 2	82-7631	Rod - Control	8 24 2
80-6110	Charge Relief Valve Kit	5 * 1	82-7680	Bail Assembly	8 20 1
80-6120	Check Valve Kit	5 1 1	82-7690	Control Bar Assembly	8 23 1
80-6130	Overhaul Seal Kit	5 * 1	82-7721	Decal - Control Panel	8 52 1
82-2181	Panel - Control	8 51 1	82-8220	Pump Assembly - Hydraulic	4 11 2

*Not Illustrated

TORO PART NUMBER INDEX (Continued)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
82-8230	Motor - Wheel	6 37 2	324-5	Screw - Hex. Hd.	4 44 4
82-8440	Tank - Fuel	1 28 1	325-11	Screw	6 46 8
84-1830	Cap	9 17 1	3213-8	Screw - Hex. Hd.	6 45 8
85-7310	Nut	7 26 1	3230-26	Bolt Carriage	8 42 1
85-7310	Nut	6 39 2	3234-5	Washer - Lock	8 48 1
85-7320	Kit - Seal	7 * 1	3234-11	Screw - Hex. hd.	8 40 4
86-4730	Plate - Frame	6 54 2	3245-3	Screw - Set	6 48 4
86-4740	Spacer	6 53 2	3253-3	Washer - Lock	6 29 2
86-4750	Bracket - Stop	4 52 2	3253-4	Washer - Lock	6 10 3
86-4760	Spring	4 39 4	3253-4	Washer - Lock	1 25 8
86-4770	Idler Assembly	2 40 1	3255-7	Washer - Lock, Ext.	8 54 1
86-7910	Module	8 14 1	3256-1	Washer	4 15 4
86-7910	Module - Interlock	10 3 1	3256-1	Washer - Flat	1 17 6
88-1880	Spring - Compression	2 58 1	3256-23	Washer	6 52 1
92-2350	Holder - Battery	9 4 2	3256-23	Washer - Flat	4 17 4
92-2361	Wire Assembly	10 8 1	3256-23	Washer - Flat	8 31 2
218-461	Nut	8 49 1	3256-23	Washer - Flat	2 45 4
218-595	Body	8 53 1	3257-8	Key - Woodruff	6 38 2
231-111	Tire	6 40 2	3274-32	Screw - Hex. Hd.	4 27 2
232-27	Valve stem	6 * 2	3290-307	Pin - Cotter	8 26 4
237-7	ORing	1 27 1	3290-378	Tie - Cable	4 2 3
237-30	ORing	6 4 A/R	3290-378	Tie - Cable	8 37 2
237-42	ORing	6 14 A/R	3290-418	Pushnut	4 51 4
237-78	ORing	6 35 A/R	3296-2	Nut	8 18 1
237-79	ORing	6 24 A/R	3296-2	Nut - Lock	8 10 4
237-80	ORing	6 2 A/R	3296-5	Nut - Lock	3 9 3
237-124	Grommet	4 43 1	3296-6	Nut - Lock	1 23 1
237-141	Grommet	8 22 2	3296-13	Nut - Lock	4 10 4
240-9	Grommet	1 19 2	3296-23	Nut	6 1 8
242-50	Nut - Lug	6 42 8	3296-29	Nut	6 25 2
242-87	Wheel	6 41 2	3296-29	Nut - Lock	4 42 12
2410-71	Cap - Plug	2 57 2	3296-39	Nut	4 24 6
2411-34	Joint - Ball	4 19 4	3296-39	Nut	2 37 1
2412-98	Clamp - Fuel Line	1 4 4	3296-39	Nut - Lock	9 15 2
2412-106	R-Clamp	4 50 1	3296-42	Nut - Lock	1 11 2
2412-106	R-Clamp	2 56 1	3296-42	Nut - Lock	9 11 2
2412-120	RClamp	8 12 2	3296-42	Nut - Lock	8 15 2
2412-134	RClamp	1 13 1	3296-42	Nut - Lock	4 46 8
2412-136	Clamp - Hose	1 20 2	3296-47	Nut - Lock	4 21 2
251-259	Bearing - Ball	4 26 2	32105-1	Screw - Hex. Hd.	8 25 1
251-291	Bearing - Pulley	3 8 1	32105-14	Screw - Hex. Hd.	8 36 4
251-292	Bearing - Field	3 2 1	32112-11	Nut - Push On	4 35 8
256-156	Bushing	2 39 2	32112-17	Nut - Push On	6 43 8
257-5	Washer - Thrust	4 41 2	32112-18	Retainer - Bolt	8 45 1
283-6	Pin - Clevis	8 33 2	32121-4	Pin - Roll	4 47 2
288-4	Cap - Pipe	1 7 1	32128-10	Nut - Lock	4 37 2
289-51	Nipple - Pipe	1 9 1	32128-21	Nut - Lock	8 41 4
2815-15	Fitting - Hyd.	6 8 1	32128-42	Nut - Lock	4 12 4
2815-16	Fitting - Hyd.	6 18 1	32144-1	Screw - Hex.Hd.	4 5 4
321-3	Screw	6 28 2	32144-3	Screw - Hex. Hd.	4 45 4
321-3	Screw - Hex. Hd.	4 31 8	32144-4	Screw	2 35 2
321-3	Screw - Hex. hd.	8 46 2	32144-4	Screw	4 49 1
321-8	Screw - Hex. Hd.	4 34 2	32144-18	Screw - Hex. Hd.	8 2 2
321-39	Screw - Hex. Hd.	1 16 6	32144-19	Screw	8 11 4
322-3	Screw	6 11 3	32149-1	Nut	9 8 2
322-3	Screw	6 31 2	32149-2	Nut - Keps	1 33 2
322-3	Screw - Cap Hex. Hd.	9 14 2	32149-8	Nut - Keps	2 34 1
322-3	Screw - Hex. Hd.	1 24 4	32151-80	Ring - Push On	8 34 2
322-5	Screw - Hex. Hd.	4 7 2	340-4	Fitting Hyd.	6 19 4
322-5	Screw - Hex. Hd.	4 18 4	340-6	Fitting - Hyd.	6 3 4
322-7	Screw - Hex. Hd.	4 13 4	354-115	Fitting - Hyd.	6 13 2
322-14	Screw - Hex. Hd.	4 30 2	354-116	Fitting - Hyd.	6 15 2
323-6	Screw - Hex. Hd.	4 33 6	354-117	Fitting - Hyd.	6 34 2
323-9	Screw - Hex. Hd.	9 2 2	354-118	Fitting - Hyd.	6 26 2
323-9	Screw - Hex. Hd.	2 54 1			

*Not Illustrated

[illegible]

TABLE OF CONTENTS

Description	Page	Description	Page
Frame, Engine, Fuel Tank, Clutch & Cooler Assembly	1-2	Handle/Control Panel Assembly	8
Clutch Assembly No. 54-3200	3	Battery Assembly	9
Hydraulic Pump & Linkage Assembly	4	Electrical Schematic	10
Hydraulic Pump Assembly	5	Hydraulic Schematic	11
Wheel Assembly & Hydraulic Components	6	Engine Kohler Model No. CV14 S-1429	12-20
Traction Drive Motor (Torquemotor)	7	Numerical Parts Index	21-22

Optional Equipment

36" Cutting Unit	Model No. 30136
37" Recycler Deck	Model No. 30137
44" Cutting Unit	Model No. 30144
48" Recycler Deck	Model No. 30148
52" Cutting Unit	Model No. 30152
62" Cutting Unit	Model No. 30162
36" Deck Bag Kit	Model No. 30125
37" Deck (Cloth Bag) Bag Kit	Model No. 30129
37" Deck (Steel Hopper) Bag Kit ...	Model No. 30130
44"/52" Deck Bag Kit	Model No. 30128
2"-5" HOC Kitd	Part No. 84-5010
Front Weight Kit-36"/37" Deck ...	Part No. 80-3350
Standard Sulky	Model No. 30122
Steerable Sulky	Model No. 30123

Compliance with Radio Interference Regulations Certified.
 Certifié Conforme au Règlement sur le Brouillage Radioélectrique.