



Groomer Kit Greensmaster® Flex™ 21

Model No. 107-8100

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Groomer Assembly 3	Right Hand Groomer Arm Assembly 5
Left Hand Groomer Arm Assembly 4	Right Hand Drive Sideplate Assembly 6


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	LH.	left hand
BBC.	blade brake clutch	NI.	nylon insert
CARR.	carriage	NPTF.	national pipe thread fine
DEG.	degrees	PFH.	phillips flat head
EXT.	external	PPH.	phillips pan head
FH.	flat head	PPHTF.	phillips pan head thread forming
GA.	gauge	PRH.	phillips round head
HD.	heavy-duty	PTH.	phillips truss head
HF.	hex flange	PTO.	power-take-off
HH.	hex head	RH.	right hand
HHF.	hex head flange	ROPS.	roll-over protection system
HHFTF.	hex head flange thread forming	SFH.	slotted fillister head
HJ.	hex jam	SHH.	slotted hex head
HLH.	hex lag head	SHWH.	slotted hex washer head
HOC.	height-of-cut	SPH.	slotted pan head
HSBH.	hex socket button head	SQH.	square head
HSFH.	hex socket flat head	SRH.	slotted round head
HSH.	hex socket head	STD.	standard
HWH.	hex washer head	TAP.	self tapping
HWHTF.	hex washer head thread forming	TTH.	torx truss head

Footnotes


- ❶ Not serviced separately



Groomer Assembly

Ref	Part No.	Qty.	Description
❶		1	LH Groomer Arm ASM
❷		1	RH Groomer Arm ASM
❸		1	RH Non-Drive Sideplate ASM
❸:1		1	RH Non-Drive Sideplate And Bushing ASM
3:1:2	106-8527	1	Bushing
3:2	106-8530	1	Seal-Grease
❹		1	RH Drive Sideplate ASM
5	256-2	2	Bushing
6	3290-301	2	Washer-Spring
7	3296-5	2	Nut-Lock
8	112-9452	1	Helix Blade Grooming Reel ASM
8:1	110-2338	1	Groomer Shaft ASM
8:2	110-2333	42	Blade-Groomer, Helix
8:3	70-1350	86	Spacer-Plastic
8:4	3296-60	2	Nut-Lock, NI
9	107-8105	2	Bearing-Ball, Extended Race
11	107-8126	2	Bolt-Plow
12	107-8127	2	Adapter-Sideplate
13	107-8116	2	Nut-Jam, Adhesive
15	110-2471	1	Pulley-Groomer, Splined
16	104-2612	2	Nut-HF
17	106-8539	1	Pulley ASM
17:2	106-8521	1	Decal-Warning


Ref	Part No.	Qty.	Description
18	104-4705	1	Belt-Groomer
20	33024-00	2	Nut-Lock
21	106-8529	1	Plug-Cap
22	302-5	1	Fitting-Grease
23	33113-012	2	Screw-HH
24	107-8122	1	Shim-Groomer
25	66-4460	1	Spring-Lever, Shift
26	107-3233	1	Seal-Oil
27	106-8464	1	Cover-Groomer



Left Hand Groomer Arm Assembly

Ref	Part No.	Qty.	Description
1	107-8119	1	Arm-Groomer, HOC (LH)
2	106-8536	1	LH Lift Arm ASM
2:3	256-42	1	Bushing
2:4	106-8489	2	Bushing-Sleeve
3	104-2611	1	Nut-HF
4	107-8107	1	Washer-Wave
5	106-8482	1	Adjuster-Groomer
6	32120-19	1	E-Ring
7	104-4754	1	Spring-Detent
8	43-5930	1	Washer-Spring
9	33113-008	1	Screw-HH
10	106-8528	1	Screw-Lock
11	104-9312	1	Pin-Grooved
12	106-8491	1	Rod-Lift, Groomer

--	--	--	--



Right Hand Groomer Arm Assembly

Ref	Part No.	Qty.	Description
1	107-8118	1	Arm-Groomer, HOC (RH)
2	106-8535	1	RH Lift Arm ASM
2:3	256-42	1	Bushing
2:4	106-8489	2	Bushing-Sleeve
3	104-2611	1	Nut-HF
4	107-8107	1	Washer-Wave
5	106-8482	1	Adjuster-Groomer
6	32120-19	1	E-Ring
7	104-4754	1	Spring-Detent
8	43-5930	1	Washer-Spring
9	33113-008	1	Screw-HH
10	106-8528	1	Screw-Lock
11	104-9312	1	Pin-Grooved
12	106-8491	1	Rod-Lift, Groomer

--	--	--	--

NOTES

