



Insight[®] Lawn Mower

Model No. 10671 - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front End and Tunnel Assembly	 3	Engine Assembly No. 2 Tecumseh LV195EA-362044D	 12
Housing Assembly No. 114-2803	 4	Carburetor Assembly No. 640350 Tecumseh LV195EA-362044D	 14
Rear End Assembly	 5	Recoil Starter Assembly No. 590739 Tecumseh LV195EA-362044D	 15
Upper Handle Assembly	 6	Recoil Starter Assembly No. 590702 (optional) Tecumseh LV195EA-362044D	 16
Lower Handle Assembly	 7	Attachments and Accessories List	 17
Blade and Engine Assembly	 8		
Rear Bag Assembly	 9		
Engine Assembly No. 1 Tecumseh LV195EA-362044D	 10		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head


Footnotes

- | | |
|--|---------------------------|
| ❶ Not illustrated | ❷ Not serviced separately |
| ❸ Obtain from your local Tecumseh dealer | |




Front End and Tunnel Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	114-2803	1	Housing ASM	28	80-6990	2	Washer-Hardened
3	614650	2	Bolt-Shoulder	29	108-1044	1	Arm-Pivot, LH
4	112-1548	2	7 Inch Front Wheel ASM	30	108-7453	1	Decal
5	614672	2	Bolt-Shoulder	33	110-9457	1	Decal-Mulch Plug
6	40-1940	2	Washer	35	110-9468	1	Mulch Plug ASM
7	107-3877	1	Arm-Pivot, RH	36	108-7502	1	Insert-Housing
8	92-4890	2	Washer				
9	107-3878	2	Arm-Spring				
10	110-0549	2	Knob-HOC				
11	107-3926	1	Cover-Front				
12	108-7476	8	Screw-Plastite				
13	3296-39	2	Nut-Lock, NI				
14	115-3177	1	Cover-Rear				
14:2	114-2820	1	Decal-Warning				
15	110-9455	1	Tunnel				
16	110-9446	1	Plug-Mulch, LH				
17	110-9448	1	Latch-Mulch Plug				
18	110-9447	1	Plug-Mulch, RH				
19	108-7475	2	Screw-Plastite				
20	108-0967	1	Module-Switch				
21	94-1610	2	Nut-Clip				
22	110-9458	1	Spring-Extension				
23	108-0965	2	Screw-PTH				
24	105-6849	2	Screw-Thread Forming				




Housing Assembly No. 114-2803

Ref	Part No.	Qty.	Description
2	94-8072	1	Decal-Danger
3	108-7450	1	Decal-HOC, RH
4	108-7451	1	Decal-HOC, LH
5	107-3889	1	Decal-Safety




Rear End Assembly

Ref	Part No.	Qty.	Description				
1	614650	2	Bolt-Shoulder				
2	107-3898	2	8 Inch Wheel ASM				
3	40-1940	2	Washer				
4	322-6	2	Screw-HH				
5	105-3048	2	Washer-Flat				
6	108-9344	1	Arm-Rear Pivot, LH				
7	110-9445	2	Arm-Spring, Rear				
8	110-0549	2	Knob-HOC				
9	112-8768	1	Shield-Trailing				
10	105-1818	2	Bushing-Mount, HOC				
11	3296-29	2	Nut-Lock, NI				
14	99-8445	2	Screw-HWH				
15	99-5293	1	Spring-Torsion				
16	112-6416	1	Bracket-Cover				
17	99-5291	1	Rod-Cover				
18	105-3028	1	Chute-Discharge, Side				
19	106-8376	1	Discharge Door ASM				
19:2	107-0795	1	Latch-Door				
19:3	107-7456	1	Cap-Door				
19:4	107-7461	1	Screw-Plastite				
20	108-9343	1	Arm-Rear Pivot, RH				




Upper Handle Assembly

Ref	Part No.	Qty.	Description				
1	112-1538-03	1	Bail-Brake				
2	110-1752	1	Handle ASM				
3	110-1769	1	Mount-Handle, LH				
4	108-0963	1	Cable-Brake				
6	108-0988	2	Screw-CARR				
7	3296-73	2	Nut-Lock, NI				
8	110-1770	1	Mount-Handle, RH				
13	107-3865	2	Mount-Handle, Lower				
14	107-3871	1	Rod-Threaded				
15	107-3867-03	1	Tube-Cross				
16	107-3937	1	Knob				
18	112-8801	1	Clamp-Cable				
19	112-8764	1	Stop-Pivot				




Lower Handle Assembly

Ref	Part No.	Qty.	Description
1	108-0988	3	Screw-CARR
2	3296-73	4	Nut-Lock, NI
3	107-3887-03	2	Tube-Lower
5	115-3157	2	Handle Mount ASM
8	108-0994	1	Guide-Rope, Lower
9	107-3908	1	Guide-Rope, Upper
10	106-6805	1	Guide-Cable
19	106-4161	2	Knob-Handle
20	49-2040	4	Screw-HWHTF



Blade and Engine Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	108-3766-03	1	Support-Blade				
3	108-0954-03	1	Blade-21 Inch				
4	106-3987	1	Blade Driver ASM				
5	106-3999	1	Spacer-Driver				
6	92-1624	3	Screw				
9	46-8091	3	Screw-HWH				
10	92-1701	1	Stop-Rope				
2011		1	Engine-Tecumseh, Lv195Ea-362044D				
11:3	108-7452	1	Decal-Recoil				
12	106-8387	1	Muffler Guard ASM				
12:1	106-5517	1	Decal-Surface, Hot				
13	32144-85	1	Screw-HWH				
17	98-1394	1	Screw-HWH				
19	105-6832	1	Decal-Primer				
20	110-1778	1	Handle-Recoil				




Rear Bag Assembly

Ref	Part No.	Qty.	Description
1	107-3911	1	Bag-Grass
2	112-8750-03	1	Frame-Bag

Engine Assembly No. 1

Tecumseh LV195EA-362044D




Engine Assembly No. 1

Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
③1	37465	1	Cylinder (Includes 2, 20, 150)	③130	6021A	8	Screw (5/16-18X1-1/2)
③2	26727	2	Pin-Dowel	③135	35395	1	Spark Plug-Resistor (R J19 L M)
③6	33734	1	Element-Breather	③150	31672	2	Spring-Valve
③7	36557	1	Breather ASM (Includes 6, 12A)	③151	31673	2	Cap-Valve, Spring
③12	37944	1	Tube-Breather	③151A	40017	1	Seal-Valve, Intake
③12A	36558	1	Breather Cover And Tube ASM (Includes 12B)	③166	37813A	1	Shroud-Engine (Green)
③12B	36694	1	Elbow-Tube, Breather	③169	36783	1	Gasket-Cover, Valve
③14	28277	1	Washer-Flat	③172	36784	1	Cover-Valve
③15	30589	1	Rod-Governor (Includes 14)	③174	30200	2	Screw (10-24 X 9/16)
③16	34839A	1	Lever-Governor	③178	29752	2	Nut And Lock Washer (1/4-28)
③17	31335	1	Clamp-Lever, Governor	③179	30593	1	Retainer Clip
③18	651018	1	Screw (T-15, 8-32 X 19/64)	③182	6201	2	Screw (1/4-28 X 7/8)
③19	36281	1	Spring-Extension	③184	26756	1	Gasket
③20	32600	1	Seal-Oil	③185	37466	1	Pipe-Intake
③30	37692	1	Crankshaft	③186	32653	1	Link-Governor
③40	40027	1	Piston, Pin And Ring Set (STD.)	③189	650839	2	Screw (1/4-20 X 3/8)
③42	40006	1	Ring Set (STD)	③191	36559A	1	Bracket-Brake (Includes 195)
③43	20381	2	Ring-Retaining, Piston Pin	③195	610973	1	Terminal
③45	36777	1	Connecting Rod ASM (Includes 46)	③207	34336A	1	Link-Throttle
③46	32610A	2	Bolt-Rod, Connecting	③216	33086	1	Lever-Adjusting, R P M
③48	27241	2	Lifter-Valve	③223	650451	1	Screw (1/4-20 X 1)
③50	37460	1	Camshaft (Includes 104)	③223A	651074	1	Stud-Pipe, Intake
③52	29914	1	Oil Pump ASM	③224	36786	1	Gasket-Pipe, Intake
③69	37609	1	Gasket-Flange, Mounting	③238	650932	2	Screw (10-32 X 49/64)
③70	37608A	1	Flange-Mounting (Includes 72-83, 306, 309A, 311A)	③239	34338	1	Gasket-Cleaner, Air
③72	37614	1	Plug-Drain, Oil	③241	36919	1	Collar-Cleaner, Air
③75	27897	1	Seal-Oil	③245	36905	1	Filter-Cleaner, Air (Paper)
③80	30574A	1	Shaft-Governor	③250	37122	1	Cover-Cleaner, Air
③81	30590A	1	Washer-Flat	③260	37696A	1	Housing-Blower
③82	30591	1	Governor Gear ASM (Includes 81)	③261	30200	2	Screw (10-24 X 9/16)
③83	30588A	1	Spool-Governor	③262	650831	2	Screw (1/4-20 X 1/2)
③86	650488	6	Screw (1/4-20 X 1-1/4)	③275	37498	1	Muffler
③89	611298	1	Key-Flywheel	③277	650988	2	Screw (1/4-20 X 2-9/32)
③90	611299	1	Flywheel	③285	35000A	1	Cup-Starter
③92	650815	1	Washer-Belleville	③287	650926	2	Screw (8-32 X 21/64)
③93	650816	1	Nut-Flywheel	③290	37962	1	Line-Fuel, Low Permeation (8.62)
③100	34443C	1	Ignition-State, Solid	③292	26460	2	Clamp-Line, Fuel
③101	610118	1	Cover-Spark Plug	③298	28763	2	Screw (10-32 X 35/64)
③103	651007	2	Screw (T-15, 10-24 X 15/16)	③300	37947	1	Fuel Tank ASM
③104	37480	1	Bushing-Cam	③301	37844	1	Cap-Fuel (Black) (1-1/2 I D)
③110	37047	1	Wire-Ground	③305	35647A	1	Tube-Fill, Oil
③110A	611227	1	Wire-Ground	③306	37610	1	O-Ring
③119	37796	1	Gasket-Head, Cylinder	③307	35499	1	O-Ring
③120	3771	1	Head-Cylinder	③309	650562	1	Screw (10-32 X 1/2)
③125	36780	1	Valve-Exhaust (1/32In Os) (Includes 151)	③309A	650783	1	Screw (10-24 X 3/4)
③125	37288	1	Valve-Exhaust (STD) (Includes 151)	③310	35648	1	Dipstick
③126	37289	1	Valve-Intake (STD) (Includes 151, 151A)	③311A	37611	1	Bracket-Holddown
				③313	34080	1	Spacer
				③324	33177	1	Terminal
				③347	650898A	4	Screw (10-32 X 27/32)
				③370A	36261	2	Decal-Lubrication

Engine Assembly No. 2


Tecumseh LV195EA-362044D



Engine Assembly No. 2

Tecumseh LV195EA-362044D


Ref	Part No.	Qty.	Description
④370C	37695	1	Decal-Primer
④370D	35977	1	Decal-Warning
④380	640350	1	Carburetor ASM (Includes 184)
④390	590739	1	Starter-Rewind (Note: This Engine Could Have Been Built With Starter 590702)
④400	37613A	1	Gasket Set (Includes 69, 119, 169, 184, 224, 239, 306)
④416	37530	1	Spark Arrestor Kit
④420	730225A	1	Oil-Engine (4-Cycle Sae 30)



Carburetor Assembly No. 640350 Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description
❶1	631615	1	Throttle Shaft And Lever ASM
❷2	631767	1	Spring-Return, Throttle
❹4	631184	1	Washer-Seal, Dust
❺5	631183	1	Seal-Dust
❻6	640070	1	Shutter-Throttle
❼7	650506	1	Screw-Shutter
❶16	631807	1	Fitting-Fuel
❶17	651025	1	Screw-Throttle Crack And Idle Speed
❶18	630766	1	Spring-Tension
❶20	640016	1	Screw-Restrictor, Idle
❶20A	640200	1	Cap-Screw, Restrictor Idle
❶25	631867	1	Bowl-Float (No Drain)
❶27	631024	1	Shaft-Float
❶28	632802	1	Float (Plastic)
❶29	631028	1	O Ring-Bowl, Float
❶30	631021A	1	Inlet Needle, Seat, And Clip ASM (Includes 31)
❶31	631022	1	Clip-Spring
❶35	640351	1	Primer Bulb And Valve Repair Kit
❶36	640080	1	Tube-Nozzle, Main
❶36A	632766	1	Tube-Carburetor
❶37	632547	2	O-Ring
❶40	640030	1	Nut-Bowl, High Speed


Ref	Part No.	Qty.	Description
❶44	27110A	1	Washer-Nut, Bowl
❶47	630748	1	Plug-Welch, Idle Mixture Well
❶48	631027	2	Plug-Welch, Atmospheric Vent
❶60	632760B	1	Repair Kit (Includes 4, 5, 7, 27, 29, 30, 37, 44, 47, 48)
❶184	26756	1	Gasket



Recoil Starter Assembly No. 590739

Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description
③3	590740	1	Retainer
③6	590616	2	Dog-Starter
③7	590617	2	Spring-Dog
③8	590618A	1	Pulley And Rewind Spring ASM
③11	590638A	1	Starter Housing ASM (40 Degree Grommet)
③12	590535	1	Rope-Starter (98 Cut To Length)
③13	590701	1	Handle-Starter (STD)
③14	590760	1	Clip-Spring



Recoil Starter Assembly No. 590702 (optional)
Tecumseh LV195EA-362044D

Ref	Part No.	Qty.	Description				
❶1	590599A	1	Spring Pin ASM (Includes 4)				
❷2	590600	1	Washer				
❸3	590696	1	Retainer				
❹4	590601	1	Washer				
❺5	590697	1	Spring-Brake				
❻6	590698	2	Dog-Starter				
❼7	590699	2	Spring-Dog				
❽8	590700	1	Pulley And Rewind Spring ASM				
❾11	590703A	1	Starter Housing ASM (40 Degree Grommet)				
❿12	590535	1	Rope-Starter (98 Cut To Length)				
⓫13	590701	1	Handle-Starter (STD)				

Attachments and Accessories

For 10671 - Insight Lawn Mower

Product Name	Model/Part
Lawn Boy Paint	110-8800
Height-of-Cut Kit	110-8801
Loose Parts Kit	112-8770
Replacement Bag	89815
Rear Bag Kit	89913
21 Inch Blade	89914
Air Filter	89945
Spark Plug	89946
Cup Holder	89951

NOTES

NOTES

