



TORO®**MODEL NO. 30576-690001 & Up****PARTS
CATALOG****GRASS COLLECTION SYSTEM**

T-0098A

BLOWER ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	59-5230	Chute Assembly (Incl. Ref. #2 & 3)	1	21	3218-3	Nut - Jam	2
2	3290-409	Rivet	6	22	59-5090	Bracket - RH	1
3	56-4630	Deflector - Chute	1	23	322-3	Screw - Hex. Hd	2
4	82-5510	Decal - Warning	1	24	44-5460	Plate - Bracket LH	2
5	56-4780	Impeller	1	25	3230-1	Bolt - Carriage	4
6	3234-14	Screw - Hex. Flange Hd.	4	26	3234-11	Screw - Hex. Flange Hd.	2
7	59-5070	Plate - Mounting	1	27	3296-44	Nut - Lock	2
8	74-0910	Bracket - Pivot	2	28	3296-42	Nut - Lock	9
9	59-5050	Bracket - LH	1	29	63-9710	Spacer - Bearing	1
10	59-5140	Mount - Blower	1	30	321-3	Screw - Hex. Hd.	13
11	3296-29	Nut - Lock	8	31	13-0269	Housing - Blower	1
12	62-6520	Knob	2	32	37-6730	Cup - Bearing	1
13	3257-40	Key - Hi-Pro	1	33	38-7820	Bearing - Ball	1
14	53-4530	Gear Box Assembly	1	34	63-9700	Plate - Cover	1
15	59-5150	Cover - Gear Box	1	35	43-0940	Spacer - Blower Hub	1
16	3255-17	Washer - Lock	2	36	3235-22	Screw - Hex. Hd.	1
17	3290-134	Screw - Hex. Hd.	2	37	3253-3	Washer - Lock	4
18	323-7	Screw - Hex. Hd.	2	38	43-0960	Bracket - Chute	1
20	32152-1	Nut - Lock	6	39	54-9220	Decal - Danger	1




T-0064

HOPPER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	56-4650	Hopper - Bagger	1
2	59-5210	Snout - Bagger	1
3	3256-14	Washer - Flat	6
4	3296-4	Rivet	13
5	14-4119	Hood - Bagger	1
6	56-4581	Screen - Bagger	1
7	56-4610	Pivot	1
8	321-3	Screw - Hex. Hd.	6
9	62-6510	Plate - Hood	1
10	3296-16	Nut - Lock	6
11	62-6500	Plate - Hinge	1
12	3296-2	Nut - Lock	7
13	56-4670	Link	1
14	3296-29	Nut - Lock	16
15	322-3	Screw - Hex. Hd.	5


Ref. No.	Part No.	Description	No. Used
16	3290-134	Screw - Hex. Hd.	7
17	56-4680	Link - Bag	1
18	56-4660	Latch - Hopper	2
19	322-4	Screw - Hex. Hd.	6
20	322-10	Screw - Hex. Hd.	5
21	56-4500	Bracket - Rear	1
22	56-5350	Plate - Reinforcing	1
23	56-4530	Bracket - Front	1
24	56-4400	Frame - Hopper	1
25	3290-211	Washer - Spring	2
26	3256-55	Washer - Flat	2
27	3-3468	Handle - Basket	1
28	62-6520	Knob	2
29	3296-2	Rivet	2



T-1728

GEAR BOX ASSEMBLY NO. 53-4530

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	794402	Head Assembly (Incl. Ref. #2-15)	1	10	788019	Ring - Snap	1
2	770026A	Housing	1	11	788018	Ring - Snap	1
3	778046	Gear - Miter	2	12	788029	Seal - Oil	1
4	776250	Shaft - Input	1	13	788030	Gasket - Cap	1
5	776249	Shaft - Output	1	14	792025	Screw - Round Hd.	4
6	772035	Cover	1	15	786029	Retainer Cap & Seal Assy. (Incl. Ref. #16 & 17)	1
7	788028	Gasket - Cover	1	16	788031	Seal - Oil	1
8	780034	Bearing - Ball	3	17	792026	Screw - Hex. Hd.	4
9	780024	Bearing - Ball	1				



T-0065

DEFLECTOR AND PULLEY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	59-5350	Deflector - Rear	1
2	322-9	Screw - Hex. Hd.	3
3	32152-1	Nut - Lock	9
4	322-3	Screw - Hex. Hd.	3
5	3256-56	Washer - Flat	3
6	3296-29	Nut - Hex	2
7	59-4920	Bracket - Idler	1
8	32152-4	Nut - Lock	4
9	59-4930	Slide - Idler	1
10	59-4940	Rod - Idler	1
11	3290-211	Washer - Spring	1
12	19-1470	Bolt - Shoulder	3
13	3256-23	Washer - Flat	4
14	3272-6	Pin - Cotter	2
15	56-4900	Lever - Idler	1
16	23-1120	Washer - Flat	2
17	3296-44	Nut - Hex.	1
18	67-7460	Pulley	1
19	59-5260	Cover - Right	1
20	59-5270	Belt - V	1

Ref. No.	Part No.	Description	No. Used
21	3290-321	Screw - Machine	2
22	249-21	Latch	1
23	32128-17	Nut - Flange	2
24	56-4810	Pulley - Gear Box	1
25	32121-8	Pin - Roll	1
26	43-1120	Decal - Warning	1
27	56-4920	Pulley - Idler	1
28	323-6	Screw - Hex. Hd.	4
29	3253-21	Washer - Lock	4
30	323-7	Screw - Hex. Hd.	1
31	44-7770	Shelf - Rear	1
32	92-6297	Deflector - Front	1
33	3230-1	Bolt - Carriage	2
34	44-7780	Shelf - RH	1
35	321-4	Screw - Hex. Hd.	7
*	232-45	Extension - Tire Valve	1
*	56-5310	Weight - Wheel	1
*	322-19	Screw - Hex. Hd.	2
*	44-5480	Blade - High Sail (Optional)	3