


TORO®

MODEL NO. 30751-390001 & UP

**PARTS
CATALOG****GRASS COLLECTION SYSTEM**


T-0068

BLOWER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	56-4630	Deflector	1
2	3290-409	Rivet - Pop	6
3	56-5220	Chute Assembly (Incl. Ref. #1 & 2)	1
4	43-1110	Decal - Warning	1
5	63-9710	Spacer - Bearing	1
6	56-4780	Impeller	1
7	3234-14	Screw - Hex. Flange Hd.	4
8	56-4760	Plate - Mounting	1
9	62-4360	Mount - Blower LH	1
10	62-4430	Mount - Blower Ctr.	1

Ref. No.	Part No.	Description	No. Used
11	3296-29	Nut - Hex.	8
12	62-6520	Knob	2
13	3257-40	Key	1
14	53-4530	Gear Box Assembly	1
15	56-5260	Cover - Gear Box	1
16	323-6	Screw - Hex. Hd.	2
17	32149-1	Nut - Hex.	5
18	3218-3	Nut - Jam	4
19	3230-18	Bolt - Carriage	2
20	56-5040	Mount - Blower RH	1
21	3234-11	Screw - Hex. Flange Hd.	4

TPS




T-0068

BLOWER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
22	3296-44	Nut - Hex.	2
23	3296-42	Nut - Hex.	9
24	321-3	Screw - Hex. Hd.	13
25	13-0269	Housing - Blower	1
26	37-6730	Cup - Bearing	1
27	63-9700	Plate - Cover	1

Ref. No.	Part No.	Description	No. Used
28	43-0940	Spacer	1
29	3235-22	Screw - Hex. Hd.	1
30	3253-3	Washer - Lock	4
31	38-7820	Bearing - Ball	1
32	43-0960	Bracket	2
33	43-8480	Decal - Danger	1




T-0067

HOPPER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	56-4650	Hopper - Bagger	1
2	56-4560	Hood - Bagger	1
3	56-4570	Snout - Bagger	1
4	3296-4	Rivet - Pop	18
5	62-6820	Screen - Bagger	1
6	56-4610	Pivot - Bagger	2
7	321-3	Screw - Hex. Hd.	6
8	3256-55	Washer - Flat	2
9	3296-16	Nut - Hex.	6
10	3296-2	Nut - Hex.	7
11	3256-14	Washer - Flat	10
12	56-4670	Link - Bag	1
13	3296-29	Nut - Hex.	16
14	322-10	Screw - Hex. Hd.	5

Ref. No.	Part No.	Description	No. Used
15	322-5	Screw - Hex. Hd.	6
16	56-4500	Bracket - Rear	1
17	3290-134	Screw - Hex. Hd.	7
18	56-4680	Link - Bag	1
19	322-3	Screw - Hex. Hd.	5
20	56-4400	Frame - Hopper	1
21	56-4660	Latch - Hopper	2
22	56-5350	Plate - Reinforcing	1
23	56-4530	Bracket - Front	1
24	3290-211	Washer - Spring	2
25	3-3468	Handle - Basket	1
26	62-6510	Plate - Hood	1
27	62-6500	Plate - Hinge	1




T-0096

BAFFLE & DEFLECTOR ASSY.

Ref. No.	Part No.	Description	No. Used
1	3296-5	Nut - Hex.	2
2	56-4960	Deflector - Grass	1
3	3211-5	Screw - Hex. Hd.	1
4	3211-15	Screw - Hex. Hd.	1
5	40-6230	Spring - Torsion	1
6	56-4980	Bracket - Pivot RH	1
7	56-5010	Bracket - Pivot LH	1
8	62-6520	Knob	2
9	3296-42	Nut - Hex.	6
10	321-4	Screw - Hex. Hd.	9
11	32149-1	Nut - Hex.	5
12	11-9760	Screw - Hex. Flange Hd.	2

Ref. No.	Part No.	Description	No. Used
13	3256-22	Washer - Flat	2
14	56-5190	Baffle - Bagging	1
15	56-5180	Ring - Bagging LH	1
16	56-5170	Baffle - Rear	1
17	3230-18	Bolt - Carriage	5
18	56-5140	Ring - Bagging RH	1
19	56-5110	Baffle - Front	1
20	32149-2	Nut - Hex.	4
21	3230-10	Bolt - Carriage	3
22	3229-22	Bolt - Carriage	1
*	55-4940	Blade - High Sail (Optional)	3




T-0097

DECK COVER AND PULLEY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	62-6800	Slide - Idler	1
2	3296-44	Nut - Hex.	2
3	19-1470	Bolt - Shoulder	3
4	36-4791	Washer - Flat	2
5	53-4650	Belt - V	1
6	3256-23	Washer - Flat	4
7	3272-6	Pin - Cotter	2
8	56-4920	Pulley - Idler	1
9	249-36	Stud - Wing Hd.	2
10	56-5280	Cover - Deck	1
11	249-35	Ring - Retaining	2
12	71-3120	Pulley	1
13	323-7	Screw - Hex. Hd.	1

Ref. No.	Part No.	Description	No. Used
14	3296-29	Nut - Hex.	2
15	3230-18	Bolt - Carriage	2
16	62-6550	Bracket - Idler	1
17	62-6850	Lever - Idler	1
18	3290-211	Washer - Spring	1
19	32149-1	Nut - Keps	2
20	32121-8	Pin - Roll	1
21	56-4810	Pulley - Gear Box	1
22	62-4450	Rod - Idler	1
23	3256-24	Washer	4
24	32121-73	Pin - Roll	2
25	62-5930	Spring - Compression	1
26	62-4440	Trunnion	1




T-0109

WHEEL WEIGHT

Ref. No.	Part No.	Description	No. Used
1	56-5310	Weight - Wheel	2
2	232-45	Extension - Valve	2

Ref. No.	Part No.	Description	No. Used
3	3253-4	Washer - Lock	4
4	322-19	Screw - Hex. Hd.	4



GEAR BOX ASSEMBLY NO. 4398-P91

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	794402	Head Assembly (Incl. Ref. #2-15)	1	10	788019	Ring - Snap	1
2	770026A	Housing	1	11	788018	Ring - Snap	1
3	778046	Gear - Miter	2	12	788029	Seal - Oil	1
4	776250	Shaft - Input	1	13	788030	Gasket - Cap	1
5	776249	Shaft - Output	1	14	792025	Screw - Round Hd.	4
6	772035	Cover	1	15	786029	Retainer Cap & Seal Assembly (Incl. Ref. #16 & 17)	1
7	788028	Gasket - Cover	1	16	788031	Seal - Oil	1
8	780034	Bearing - Ball	3	17	792026	Screw - Hex. Hd.	4
9	780024	Bearing - Ball	1				

TORO PART NUMBER INDEX

3315-662

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
770026A	Housing	"6" 2 1	62-4450	Rod - Idler	"5" 22 1
772035	Cover	"6" 6 1	62-5930	Spring - Compression	"5" 25 1
776249	Shaft - Output	"6" 5 1	62-6500	Plate - Hinge	"3" 27 1
776250	Shaft - Input	"6" 4 1	62-6510	Plate - Hood	"3" 26 1
778046	Gear - Miter	"6" 3 2	62-6520	Knob	"4" 8 2
780024	Bearing - Ball	"6" 9 1	62-6520	Knob	"1" 12 2
780034	Bearing - Ball	"6" 8 3	62-6550	Bracket - Idler	"5" 16 1
786029	Retainer Cap &	"6" 15 1	62-6800	Slide - Idler	"5" 1 1
788018	Ring - Snap	"6" 11 1	62-6820	Screen - Bagger	"3" 5 1
788019	Ring - Snap	"6" 10 1	62-6850	Lever - Idler	"5" 17 1
788028	Gasket - Cover	"6" 7 1	63-9700	Plate - Cover	"2" 27 1
788029	Seal - Oil	"6" 12 1	63-9710	Spacer - Bearing	"1" 5 1
788030	Gasket - Cap	"6" 13 1	71-3120	Pulley	"5" 12 1
788031	Seal - Oil	"6" 16 1	249-35	Ring - Retaining	"5" 11 2
792025	Screw - Round Hd.	"6" 14 4	249-36	Stud - Wing Hd.	"5" 9 2
792026	Screw - Hex. Hd.	"6" 17 4	321-3	Screw - Hex. Hd.	"3" 7 6
794402	Head Assembly	"6" 1 1	321-3	Screw - Hex. Hd.	"2" 24 13
3-3468	Handle - Basket	"3" 25 1	321-4	Screw - Hex. Hd.	"4" 10 9
11-9760	Screw - Hex. Flange Hd.	"4" 12 2	322-3	Screw - Hex. Hd.	"3" 19 5
13-0269	Housing - Blower	"2" 25 1	322-5	Screw - Hex. Hd.	"3" 15 6
19-1470	Bolt - Shoulder	"5" 3 3	322-10	Screw - Hex. Hd.	"3" 14 5
36-4791	Washer - Flat	"5" 4 2	323-6	Screw - Hex. Hd.	"1" 16 2
37-6730	Cup - Bearing	"2" 26 1	323-7	Screw - Hex. Hd.	"5" 13 1
38-7820	Bearing - Ball	"2" 31 1	3211-5	Screw - Hex. Hd.	"4" 3 1
40-6230	Spring - Torsion	"4" 5 1	3211-15	Screw - Hex. Hd.	"4" 4 1
43-0940	Spacer	"2" 28 1	3218-3	Nut - Jam	"1" 18 4
43-0960	Bracket	"2" 32 2	3229-22	Bolt - Carriage	"4" 22 1
43-1110	Decal - Warning	"1" 4 1	3230-10	Bolt - Carriage	"4" 21 3
43-8480	Decal - Danger	"2" 33 1	3230-18	Bolt - Carriage	"5" 15 2
53-4530	Gear Box Assembly	"1" 14 1	3230-18	Bolt - Carriage	"4" 17 5
53-4650	Belt - V	"5" 5 1	3230-18	Bolt - Carriage	"1" 19 2
55-4940	Blade - High Sail	"4" * 3	3234-11	Screw - Hex. Flange Hd.	"1" 21 4
56-4400	Frame - Hopper	"3" 20 1	3234-14	Screw - Hex. Flange Hd.	"1" 7 4
56-4500	Bracket - Rear	"3" 16 1	3235-22	Screw - Hex. Hd.	"2" 29 1
56-4530	Bracket - Front	"3" 23 1	3253-3	Washer - Lock	"2" 30 4
56-4560	Hood - Bagger	"3" 2 1	3256-14	Washer - Flat	"3" 11 10
56-4570	Snout - Bagger	"3" 3 1	3256-22	Washer - Flat	"4" 13 2
56-4610	Pivot - Bagger	"3" 6 2	3256-23	Washer - Flat	"5" 6 4
56-4630	Deflector	"1" 1 1	3256-24	Washer	"5" 23 4
56-4650	Hopper - Bagger	"3" 1 1	3256-55	Washer - Flat	"3" 8 2
56-4660	Latch - Hopper	"3" 21 2	3257-40	Key	"1" 13 1
56-4670	Link - Bag	"3" 12 1	3272-6	Pin - Cotter	"5" 7 2
56-4680	Link - Bag	"3" 18 1	3290-134	Screw - Hex. Hd.	"3" 17 7
56-4760	Plate - Mounting	"1" 8 1	3290-211	Washer - Spring	"5" 18 1
56-4780	Impeller	"1" 6 1	3290-211	Washer - Spring	"3" 24 2
56-4810	Pulley - Gear Box	"5" 21 1	3290-409	Rivet - Pop	"1" 2 6
56-4920	Pulley - Idler	"5" 8 1	3296-2	Nut - Hex.	"3" 10 7
56-4960	Deflector - Grass	"4" 2 1	3296-4	Rivet - Pop	"3" 4 18
56-4980	Bracket - Pivot RH	"4" 6 1	3296-5	Nut - Hex.	"4" 1 2
56-5010	Bracket - Pivot LH	"4" 7 1	3296-16	Nut - Hex.	"3" 9 6
56-5040	Mount - Blower RH	"1" 20 1	3296-29	Nut - Hex.	"1" 11 8
56-5110	Baffle - Front	"4" 19 1	3296-29	Nut - Hex.	"3" 13 16
56-5140	Ring - Bagging RH	"4" 18 1	3296-29	Nut - Hex.	"5" 14 2
56-5170	Baffle - Rear	"4" 16 1	3296-42	Nut - Hex.	"4" 9 6
56-5180	Ring - Bagging LH	"4" 15 1	3296-42	Nut - Hex.	"2" 23 9
56-5190	Baffle - Bagging	"4" 14 1	3296-44	Nut - Hex.	"5" 2 2
56-5220	Chute Assembly	"1" 3 1	3296-44	Nut - Hex.	"2" 22 2
56-5260	Cover - Gear Box	"1" 15 1	32121-8	Pin - Roll	"5" 20 1
56-5280	Cover - Deck	"5" 10 1	32121-73	Pin - Roll	"5" 24 2
56-5350	Plate - Reinforcing	"3" 22 1	32149-1	Nut - Hex.	"4" 11 5
62-4360	Mount - Blower LH	"1" 9 1	32149-1	Nut - Hex.	"1" 17 5
62-4430	Mount - Blower Ctr.	"1" 10 1	32149-1	Nut - Keps	"5" 19 2
62-4440	Trunnion	"5" 26 1	32149-2	Nut - Hex.	"4" 20 4

*Not Illustrated